

## Dear Reader ...

We would like to congratulate you on the purchase of your new motorhome. You have selected a top-quality vehicle which will afford you many years of enjoyment.

To enable you to always use and operate your motorhome properly and easily, your Bürstner dealer will first provide you detailed instructions for all important functions when you take delivery.

This manual, the instruction manuals from the base vehicle manufacturer as well as the instruction manuals from the appliance manufacturer will always be at hand to answer any questions you may have regarding your motorhome.

## Before your first journey

Please familiarise yourself with this manual rather than relying on it strictly for reference.

Fill in the warranty cards for the appliances and special equipment in the individual instructions and send these cards to the respective manufacturers. This ensures your warranty claim for each appliance.



|          |  |           |          |  |           |
|----------|--|-----------|----------|--|-----------|
| <b>1</b> | <b>Introduction</b> . . . . .  | <b>7</b>  | 4.7      | Child restraint systems . . . . .  | 43        |
| 1.1      | General . . . . .  | 7         | 4.8      | Pilot seats for the driver's<br>and front passenger's seats . . . . .                      | 44        |
| 1.2      | Environmental tips . . . . .   | 8         | 4.9      | Seat heater (special equipment) . . . . .  | 45        |
| <b>2</b> | <b>Safety</b> . . . . .  | <b>9</b>  | 4.10     | Headrests . . . . .  | 45        |
| 2.1      | Fire prevention . . . . .  | 9         | 4.11     | Seating arrangement . . . . .  | 46        |
| 2.1.1    | Avoidance of fire risks . . . . .  | 9         | 4.12     | Roman shade in the driver's cabin . . . . .  | 46        |
| 2.1.2    | Fire-fighting . . . . .  | 9         | 4.12.1   | Pleated Roman shades . . . . .   | 46        |
| 2.1.3    | In case of fire . . . . .  | 9         | 4.12.2   | Roman shades, Remis<br>(partially special equipment) . . . . .                             | 47        |
| 2.2      | General . . . . .  | 10        | 4.13     | Filling up with diesel . . . . .   | 47        |
| 2.3      | Road safety . . . . .  | 11        | <b>5</b> | <b>Pitching the motorhome</b> . . . . .  | <b>49</b> |
| 2.4      | Towing . . . . .   | 12        | 5.1      | Handbrake . . . . .  | 49        |
| 2.5      | Gas system . . . . .   | 12        | 5.2      | Entrance step . . . . .  | 49        |
| 2.5.1    | General instructions . . . . .   | 12        | 5.3      | Ramps . . . . .  | 49        |
| 2.5.2    | Gas bottles . . . . .  | 14        | 5.4      | Wheel chocks . . . . .   | 49        |
| 2.6      | Electrical system . . . . .  | 14        | 5.5      | Supports . . . . .   | 50        |
| 2.7      | Water system . . . . .   | 15        | 5.5.1    | General instructions . . . . .   | 50        |
| <b>3</b> | <b>Before the journey</b> . . . . .  | <b>17</b> | 5.5.2    | Steady legs (SAWIKO)<br>(special equipment) . . . . .                                      | 50        |
| 3.1      | Keys . . . . .   | 17        | 5.5.3    | Steady legs (AL-KO)<br>(special equipment) . . . . .                                       | 51        |
| 3.2      | Registration . . . . .   | 17        | 5.5.4    | Electrical steady legs (AL-KO)<br>(special equipment) . . . . .                            | 52        |
| 3.3      | Payload . . . . .  | 18        | 5.6      | 230 V connection . . . . .   | 54        |
| 3.3.1    | Terms . . . . .  | 18        | 5.7      | Refrigerator . . . . .   | 54        |
| 3.3.2    | Calculating the payload . . . . .  | 20        | 5.8      | Satellite unit (special equipment) . . . . .   | 54        |
| 3.3.3    | Loading the vehicle correctly . . . . .  | 22        | 5.8.1    | Equipment with automatic<br>antenna alignment (Alden) . . . . .                            | 54        |
| 3.3.4    | Roof rail and ladder<br>(partially special equipment) . . . . .                | 23        | 5.8.2    | Equipment with semi-automatic<br>antenna alignment (Alden) . . . . .                       | 55        |
| 3.3.5    | Rear garage/rear storage space . . . . .                                       | 24        | 5.8.3    | Equipment with automatic<br>antenna alignment (Oyster) . . . . .                           | 56        |
| 3.3.6    | Bike rack (special equipment) . . . . .  | 25        | 5.9      | Awning (special equipment) . . . . .   | 56        |
| 3.3.7    | Bike/e-bike bike rack<br>(special equipment) . . . . .                         | 27        | <b>6</b> | <b>Living</b> . . . . .  | <b>59</b> |
| 3.3.8    | Removable load rack AL-KO<br>(special equipment) . . . . .                     | 29        | 6.1      | Central locking system<br>(special equipment) . . . . .                                    | 59        |
| 3.3.9    | Load rack SAWIKO<br>(special equipment) . . . . .                              | 30        | 6.2      | Conversion door . . . . .  | 59        |
| 3.4      | Towing . . . . .   | 31        | 6.2.1    | Conversion door, outside<br>(Hartal M1) . . . . .  | 60        |
| 3.5      | Caravan coupling<br>(special equipment) . . . . .                              | 31        | 6.2.2    | Conversion door, inside<br>(Hartal M1) . . . . .   | 60        |
| 3.6      | Electrically operated entrance step<br>(partially special equipment) . . . . . | 32        | 6.2.3    | Conversion door, outside<br>(Hartal Premium) (partially<br>special equipment) . . . . .    | 61        |
| 3.7      | TV unit (special equipment) . . . . .  | 33        | 6.2.4    | Conversion door, inside<br>(Hartal Premium) (partially<br>special equipment) . . . . .     | 61        |
| 3.8      | Sink and drain basin covers . . . . .  | 34        | 6.2.5    | Window of conversion door<br>(Hartal Premium) (partially<br>special equipment) . . . . .   | 61        |
| 3.9      | Securing add-on parts . . . . .  | 34        | 6.2.6    | Folding insect screen on<br>the conversion door (partially<br>special equipment) . . . . . | 62        |
| 3.10     | Snow chains (special equipment) . . . . .                                      | 35        |          |  |           |
| 3.11     | Road safety . . . . .  | 35        |          |  |           |
| <b>4</b> | <b>During the journey</b> . . . . .  | <b>39</b> |          |  |           |
| 4.1      | Driving the motorhome . . . . .  | 39        |          |  |           |
| 4.2      | Parking distance control<br>Park Boy V (special equipment) . . . . .           | 40        |          |  |           |
| 4.3      | Reversing camera<br>(special equipment) . . . . .                              | 41        |          |  |           |
| 4.4      | Driving speed . . . . .  | 42        |          |  |           |
| 4.5      | Brakes . . . . .   | 42        |          |  |           |
| 4.6      | Seat belts . . . . .   | 43        |          |  |           |
| 4.6.1    | Fastening the seat belt correctly . . . . .                                    | 43        |          |  |           |

## Contents

|        |   |    |          |   |            |
|--------|---|----|----------|---|------------|
| 6.3    | External flaps . . . . .  | 62 | 6.12.6   | Pull-down bed, electrically operated (special equipment, Ixeo series) . . . . . | 94         |
| 6.3.1  | Flap lock with recessed handle . . . . .  | 63 | 6.12.7   | Bed widening (short) for single beds (special equipment) . . . . .              | 97         |
| 6.3.2  | Flap lock with push button . . . . .  | 63 | 6.13     | Converting seating groups for sleeping . . . . .                                | 97         |
| 6.3.3  | Flap for the 230 V connection, square . . . . .                                     | 64 | 6.13.1   | Small central seating group . . . . .   | 100        |
| 6.3.4  | Cap for the drinking water filler neck . . . . .                                    | 64 | 6.13.2   | Central seating group with bed widening . . . . .                               | 101        |
| 6.4    | Furniture flaps . . . . .   | 65 | 6.13.3   | Central bench with divan (with bed widening) . . . . .                          | 102        |
| 6.4.1  | Furniture flaps with push button . . . . .  | 65 | 6.13.4   | Central bench with divan . . . . .  | 103        |
| 6.4.2  | Furniture flaps with unlocking bar . . . . .  | 65 | 6.13.5   | Central bench with divan (with bed widening) . . . . .                          | 104        |
| 6.4.3  | Furniture flaps with handle and push button . . . . .                               | 66 | 6.13.6   | Central bench with divan (Van) . . . . .  | 105        |
| 6.5    | Light switch . . . . .  | 66 | 6.13.7   | Centre bench with divan on the left . . . . .                                   | 106        |
| 6.5.1  | Entrance area . . . . .   | 66 | 6.13.8   | L-shaped bench with divan . . . . .   | 107        |
| 6.5.2  | Interior . . . . .  | 66 | 6.13.9   | L-shaped bench with divan (with bed widening) . . . . .                         | 108        |
| 6.5.3  | Wardrobe light . . . . .  | 67 | 6.13.10  | L-shaped bench (long) with divan . . . . .                                      | 109        |
| 6.6    | Spotlight . . . . .   | 68 | 6.13.11  | L-shaped bench with divan (without extra cushions) . . . . .                    | 110        |
| 6.7    | Holder for flat screen . . . . .  | 68 | 6.13.12  | L-shaped bench with divan . . . . .   | 111        |
| 6.7.1  | Holder on the column . . . . .  | 69 | 6.13.13  | L-shaped bench on the right with a divan on the left . . . . .                  | 112        |
| 6.7.2  | Holder with jointed arm . . . . .   | 69 | 6.13.14  | L-shaped bench with divan (with angled bed widening) . . . . .                  | 113        |
| 6.7.3  | Holder in the TV cabinet . . . . .  | 70 | 6.14     | Shower connection point for external shower (special equipment) . . . . .       | 114        |
| 6.7.4  | Holder in the TV compartment . . . . .  | 70 |          |   |            |
| 6.8    | Ventilation . . . . .   | 71 | <b>7</b> | <b>Gas system . . . . .</b>   | <b>115</b> |
| 6.9    | Windows . . . . .   | 71 | 7.1      | General . . . . .   | 115        |
| 6.9.1  | Hinged window with rotary hinges . . . . .  | 72 | 7.2      | Gas bottles . . . . .   | 116        |
| 6.9.2  | Hinged window with automatic hinges . . . . .                                       | 74 | 7.3      | Changing gas bottles . . . . .  | 117        |
| 6.9.3  | Blind and insect screen . . . . .   | 76 | 7.4      | Gas isolator taps . . . . .   | 118        |
| 6.9.4  | Roman shade and insect screen . . . . .   | 76 | 7.5      | External gas connection (special equipment) . . . . .                           | 118        |
| 6.9.5  | Roman shades for windscreen, driver's window and front passenger's window . . . . . | 77 | 7.6      | Crash protection unit switching facility (special equipment) . . . . .          | 119        |
| 6.10   | Skylights . . . . .   | 79 | <b>8</b> | <b>Electrical system . . . . .</b>  | <b>123</b> |
| 6.10.1 | Heki skylight (mini and midi) (partially special equipment) . . . . .               | 80 | 8.1      | General safety instructions . . . . .   | 123        |
| 6.10.2 | Wind-up skylight (special equipment) . . . . .                                      | 81 | 8.2      | Terms . . . . .   | 123        |
| 6.10.3 | Omni-Vent skylight with fan (special equipment) . . . . .                           | 82 | 8.3      | 12 V power supply . . . . .   | 124        |
| 6.10.4 | Skyroof skylight (partially special equipment) . . . . .                            | 83 | 8.3.1    | Selector switch for radio (special equipment) . . . . .                         | 125        |
| 6.11   | Tables . . . . .  | 85 | 8.3.2    | Starter battery . . . . .   | 125        |
| 6.11.1 | Fixed table . . . . .   | 85 | 8.3.3    | Living area battery . . . . .   | 127        |
| 6.11.2 | Suspension table . . . . .  | 87 | 8.4      | Transformer/rectifier (EBL 99) . . . . .  | 128        |
| 6.11.3 | Lift-off table . . . . .  | 89 | 8.4.1    | Battery cut-off switch . . . . .  | 129        |
| 6.12   | Beds . . . . .  | 90 | 8.4.2    | Battery selector switch . . . . .   | 129        |
| 6.12.1 | Fixed bed (gas-pressure springs) . . . . .  | 90 | 8.4.3    | Battery monitor . . . . .   | 129        |
| 6.12.2 | Fixed bed (adjustable head section) . . . . .                                       | 91 | 8.4.4    | Charging the battery . . . . .  | 130        |
| 6.12.3 | Fixed bed, electrically adjustable (partially special equipment) . . . . .          | 91 |          |   |            |
| 6.12.4 | Bunk bed . . . . .  | 92 |          |   |            |
| 6.12.5 | Pull-down bed, manually operated (Ixeo series) . . . . .                            | 93 |          |   |            |

|          |  |            |           |   |            |
|----------|--|------------|-----------|---|------------|
| 8.5      | Panel IT 96-2 . . . . .  | 130        | 9.3       | Air conditioning unit<br>(special equipment) . . . . .                        | 168        |
| 8.5.1    | 12 V main switch . . . . .   | 130        | 9.3.1     | Dometic . . . . .   | 168        |
| 8.5.2    | V/tank gauge for battery voltage<br>and water or waste water levels . . . .      | 131        | 9.3.2     | Telair . . . . .  | 170        |
| 8.5.3    | Switch for water pump . . . . .  | 133        | 9.4       | Boiler . . . . .  | 171        |
| 8.5.4    | Battery alarm for the<br>living area battery . . . . .                           | 133        | 9.4.1     | Models with waste gas vent on the<br>right-hand side of the vehicle . . . . . | 171        |
| 8.5.5    | 12 V indicator lamp . . . . .  | 133        | 9.4.2     | Truma Combi boiler . . . . .  | 171        |
| 8.5.6    | 230 V indicator lamp . . . . .   | 133        | 9.4.3     | Truma Combi boiler D . . . . .  | 174        |
| 8.6      | Panel IT 994 . . . . .   | 134        | 9.4.4     | Alde boiler (special equipment) . . . .                                       | 176        |
| 8.6.1    | V/tank gauge for battery voltage<br>and water or waste water levels . . . .      | 134        | 9.5       | Cooker . . . . .  | 177        |
| 8.6.2    | Battery alarm for the<br>living area battery . . . . .                           | 136        | 9.5.1     | Gas cooker . . . . .  | 177        |
| 8.6.3    | Digital clock/temperature gauge . . . .  | 136        | 9.5.2     | Gas oven (Dometic)<br>(special equipment) . . . . .                           | 179        |
| 8.6.4    | Current gauge for charging/discharging<br>the living area battery . . . . .      | 137        | 9.5.3     | Microwave oven<br>(special equipment) . . . . .                               | 180        |
| 8.6.5    | 12 V main switch . . . . .   | 138        | 9.5.4     | Extractor hood<br>(special equipment) . . . . .                               | 181        |
| 8.6.6    | 12 V indicator lamp . . . . .  | 138        | 9.6       | Refrigerator . . . . .  | 182        |
| 8.6.7    | 230 V indicator lamp . . . . .   | 138        | 9.6.1     | Refrigerator ventilation grill . . . . .                                      | 182        |
| 8.6.8    | Switch for water pump . . . . .  | 138        | 9.6.2     | Operation (Dometic 8 series with<br>manual power selection MES) . . . . .     | 183        |
| 8.7      | Fuel cell (EFOY)<br>(special equipment) . . . . .                                | 138        | 9.6.3     | Operation (Dometic 8 series with<br>automatic power selection AES) . . . .    | 185        |
| 8.8      | Solar installation<br>(special equipment) . . . . .                              | 141        | 9.6.4     | Operation (Thetford with SES) . . . .   | 187        |
| 8.9      | 230 V power supply . . . . .   | 143        | 9.6.5     | Refrigerator door<br>locking mechanism . . . . .                              | 189        |
| 8.9.1    | 230 V connection . . . . .   | 143        |           |   |            |
| 8.9.2    | Connecting 230 V power supply . . . .  | 143        | <b>10</b> | <b>Sanitary fittings . . . . .</b>  | <b>191</b> |
| 8.10     | Fuses . . . . .  | 144        | 10.1      | Water supply, general . . . . .   | 191        |
| 8.10.1   | 12 V fuses . . . . .   | 144        | 10.2      | Water tank . . . . .  | 192        |
| 8.10.2   | 230 V fuse . . . . .   | 148        | 10.2.1    | Volumes . . . . .   | 192        |
| 8.11     | External socket<br>(special equipment) . . . . .                                 | 149        | 10.2.2    | Drinking water filler neck with cap . . .                                     | 192        |
| 8.12     | Circuit diagrams . . . . .   | 150        | 10.2.3    | Closing/opening the overflow . . . . .  | 193        |
| 8.12.1   | Circuit diagrams, interior . . . . .   | 150        | 10.2.4    | Filling with water . . . . .  | 193        |
| 8.12.2   | Circuit diagram, exterior . . . . .  | 153        | 10.2.5    | Draining water<br>(handle with overflow) . . . . .                            | 193        |
| <b>9</b> | <b>Appliances . . . . .</b>  | <b>155</b> | 10.3      | Waste water tank . . . . .  | 194        |
| 9.1      | General . . . . .  | 155        | 10.3.1    | Draining waste water . . . . .  | 194        |
| 9.2      | Heater . . . . .   | 156        | 10.3.2    | Waste water tank heater<br>(special equipment) . . . . .                      | 195        |
| 9.2.1    | Models with waste gas vent<br>on the right-hand side<br>of the vehicle . . . . . | 156        | 10.4      | Filling the water system . . . . .  | 195        |
| 9.2.2    | To heat properly . . . . .   | 156        | 10.5      | Emptying the water system . . . . .   | 196        |
| 9.2.3    | Truma Combi hot-air heater . . . . .   | 157        | 10.6      | Toilet compartment . . . . .  | 197        |
| 9.2.4    | Truma Combi hot-air heater D . . . . .   | 159        | 10.7      | Toilet . . . . .  | 198        |
| 9.2.5    | Alde hot-water heater<br>(special equipment) . . . . .                           | 160        | 10.7.1    | Swivel toilet (Thetford C-200) . . . . .                                      | 198        |
| 9.2.6    | Auxiliary heat exchanger<br>(partially special equipment) . . . . .              | 165        | 10.7.2    | Toilet with fixed seat<br>(Thetford C-402) . . . . .                          | 204        |
| 9.2.7    | Electrical floor warming unit<br>(special equipment) . . . . .                   | 166        | 10.7.3    | Toilet (Dometic) . . . . .  | 208        |
| 9.2.8    | Independent vehicle heater<br>(special equipment) . . . . .                      | 167        | <b>11</b> | <b>Care . . . . .</b>   | <b>211</b> |
|          |  |            | 11.1      | External care . . . . .   | 211        |
|          |  |            | 11.1.1    | General . . . . .   | 211        |
|          |  |            | 11.1.2    | Washing with<br>a high-pressure cleaner . . . . .                             | 211        |

|           |  |            |           |  |            |
|-----------|--|------------|-----------|--|------------|
| 11.1.3    | Washing the vehicle . . . . .  | 212        | 13.3      | Tyre specifications . . . . .                                | 237        |
| 11.1.4    | Windows of acrylic glass . . . . .   | 212        | 13.4      | Handling of tyres . . . . .                                  | 237        |
| 11.1.5    | Underbody . . . . .  | 212        | 13.5      | Changing wheels . . . . .                                    | 237        |
| 11.1.6    | Waste water tank . . . . .   | 213        | 13.5.1    | General instructions . . . . .                               | 237        |
| 11.1.7    | Entrance step . . . . .  | 213        | 13.5.2    | Tightening torque . . . . .                                  | 238        |
| 11.2      | Interior care . . . . .  | 213        | 13.5.3    | Changing a wheel . . . . .                                   | 240        |
| 11.3      | Water system . . . . .   | 214        | 13.6      | Spare wheel support<br>(special equipment) . . . . .         | 241        |
| 11.3.1    | Cleaning the water tank . . . . .  | 214        | 13.7      | Tyre pressure . . . . .                                      | 241        |
| 11.3.2    | Cleaning the water pipes . . . . .   | 214        |           |  |            |
| 11.3.3    | Disinfecting the water system . . . . .  | 215        | <b>14</b> | <b>Troubleshooting . . . . .</b>                             | <b>243</b> |
| 11.4      | Extractor hood . . . . .   | 216        | 14.1      | Braking system . . . . .                                     | 243        |
| 11.5      | Air conditioning unit . . . . .  | 216        | 14.2      | Electrical system . . . . .                                  | 243        |
| 11.5.1    | Dometic . . . . .  | 216        | 14.3      | Fuel cell . . . . .  | 245        |
| 11.5.2    | Telair . . . . .   | 216        | 14.4      | Gas system . . . . .   | 246        |
| 11.6      | Winter care . . . . .  | 217        | 14.5      | Heater/boiler . . . . .                                      | 246        |
| 11.6.1    | Preparations . . . . .   | 217        | 14.5.1    | Truma heater/boiler (gas heater) . . . . .                   | 246        |
| 11.6.2    | Winter operation . . . . .   | 217        | 14.5.2    | Truma heater/boiler<br>(diesel heater) . . . . .             | 247        |
| 11.6.3    | At the end of the winter season . . . . .  | 218        | 14.5.3    | Alde heater/boiler . . . . .                                 | 248        |
| 11.7      | Lay-up . . . . .   | 218        | 14.6      | Air conditioning unit . . . . .                              | 249        |
| 11.7.1    | Temporary lay-up . . . . .   | 218        | 14.6.1    | Dometic . . . . .  | 249        |
| 11.7.2    | Winter lay-up . . . . .  | 219        | 14.6.2    | Telair . . . . .   | 249        |
| 11.7.3    | Starting up the vehicle after<br>a temporary lay-up or after<br>lay-up over winter . . . . . | 220        | 14.7      | Cooker . . . . .   | 250        |
|           |  |            | 14.7.1    | Gas cooker/gas oven . . . . .                                | 250        |
|           |  |            | 14.7.2    | Microwave oven . . . . .                                     | 250        |
| <b>12</b> | <b>Maintenance . . . . .</b>   | <b>223</b> | 14.8      | Refrigerator . . . . .                                       | 250        |
| 12.1      | Inspection work . . . . .  | 223        | 14.8.1    | Dometic 8 series with MES . . . . .                          | 251        |
| 12.2      | Maintenance work . . . . .   | 223        | 14.8.2    | Dometic 8 series with AES . . . . .                          | 252        |
| 12.3      | Doors . . . . .  | 224        | 14.9      | Thetford refrigerator . . . . .                              | 253        |
| 12.4      | Living area battery . . . . .  | 224        | 14.10     | Water supply . . . . .                                       | 254        |
| 12.5      | Fuel cell . . . . .  | 224        | 14.11     | Body . . . . .   | 255        |
| 12.5.1    | Replacing the tank cartridge . . . . .   | 224        |           |  |            |
| 12.5.2    | Refilling service fluid . . . . .  | 225        | <b>15</b> | <b>Special equipment . . . . .</b>                           | <b>257</b> |
| 12.6      | Alde hot-water heater . . . . .  | 225        | 15.1      | Weight details for<br>special equipment . . . . .            | 257        |
| 12.6.1    | Checking the fluid level . . . . .   | 226        |           |  |            |
| 12.6.2    | Topping up heating fluid . . . . .   | 226        | <b>16</b> | <b>Technical data . . . . .</b>                              | <b>261</b> |
| 12.6.3    | Bleeding the heating system . . . . .  | 226        | 16.1      | View of ground plans . . . . .                               | 261        |
| 12.7      | Independent vehicle heater . . . . .   | 227        | 16.2      | Table of linear measures . . . . .                           | 268        |
| 12.8      | Replacing bulbs, external . . . . .  | 227        | 16.3      | Power supply . . . . .                                       | 269        |
| 12.8.1    | Front lights . . . . .   | 228        |           |  |            |
| 12.8.2    | Rear lights . . . . .  | 228        | <b>17</b> | <b>Helpful notes . . . . .</b>                               | <b>271</b> |
| 12.8.3    | Side lights . . . . .  | 228        | 17.1      | Traffic rules in foreign countries . . . . .                 | 271        |
| 12.8.4    | Types of bulbs for exterior lighting . . . . .   | 229        | 17.2      | Help on Europe's roads . . . . .                             | 271        |
| 12.9      | Replacing bulbs, internal . . . . .  | 229        | 17.3      | Traffic rules for motorhomes . . . . .                       | 273        |
| 12.9.1    | Recessed halogen light . . . . .   | 230        | 17.4      | Sleeping in the vehicle away<br>from camping areas . . . . . | 276        |
| 12.9.2    | Recessed halogen light (flat) . . . . .  | 230        | 17.5      | Gas supply in European countries . . . . .                   | 277        |
| 12.9.3    | Recessed light with LED . . . . .  | 231        | 17.6      | Toll regulations in<br>European countries . . . . .          | 278        |
| 12.9.4    | Halogen spotlight (movable) . . . . .  | 231        | 17.7      | Tips on staying overnight<br>safely during travel . . . . .  | 278        |
| 12.9.5    | Halogen spotlight (movable) . . . . .  | 232        | 17.8      | Tips for winter campers . . . . .                            | 278        |
| 12.9.6    | Garage light . . . . .   | 232        | 17.9      | Travel checklists . . . . .                                  | 279        |
| 12.10     | Spare parts . . . . .  | 233        |           |  |            |
| 12.11     | Vehicle identification plate . . . . .   | 234        | <b>18</b> | <b>Inspection plan . . . . .</b>                             | <b>283</b> |
| 12.12     | Warning and information stickers . . . . .   | 234        |           |  |            |
| <b>13</b> | <b>Wheels and tyres . . . . .</b>  | <b>235</b> |           |  |            |
| 13.1      | General . . . . .  | 235        |           |  |            |
| 13.2      | Tyre selection . . . . .   | 236        |           |  |            |

## Please read this instruction manual completely before using the vehicle for the first time!

Always keep this instruction manual in the vehicle. Also inform all other users of the safety regulations.



- ▶ The non-observance of this symbol can lead to personal injury.



- ▷ The non-observance of this symbol can lead to damage being caused to, or inside the vehicle.



- ▷ This symbol indicates recommendations or special aspects.



- ▷ This symbol indicates actions which lead to environmental awareness.

**This instruction manual contains sections which describe model-specific equipment or special equipment. These sections are specially marked. It may be that your vehicle has not been fitted with this special equipment. In some cases, the actual equipment of your vehicle may therefore be different from that shown in some illustrations and descriptions.**

However, your vehicle may be fitted with other special equipment not described in this instruction manual.

Special equipment is described when an explanation is required.

Adhere to the instruction manuals which are separately enclosed.



- ▷ The details "right", "left", "front" and "rear" always refer to the vehicle in direction of travel.
- ▷ All dimensions and weight details are "approximate".

Should the vehicle be subjected to damage due to a failure to follow the instructions in this instruction manual, then the guarantee claim is deemed invalid.

Our vehicles are subjected to continuous development. Please understand that we reserve the right to alter the form, equipment and technology. Therefore, no claims can be made against the manufacturer as a result of the contents of this instruction manual. The equipment which was known and included at the time of going to press is described.

The reprinting, translation and copying, including extracts is not permitted without prior written authorisation from the manufacturer.

### 1.1 General

The vehicle is constructed in accordance with the latest technology and the recognised safety regulations. Nevertheless, personal injury may result and the vehicle may be damaged if the safety instructions in this instruction manual are not followed.

Only use the vehicle in a technically impeccable condition. Follow the instructions in the instruction manual.

Malfunctions which impair the safety of persons or the vehicle should be immediately remedied by qualified personnel. To avoid further damages, observe the duty to avert, minimize or mitigate loss for the user during faults.

Have the vehicle's braking and gas systems inspected and repaired by an authorised specialist workshop only.

Alterations to the body are only to be carried out with the authorisation of the manufacturer.

The vehicle is designed for the exclusive transport of persons. Luggage and accessories may only be transported up to the maximum permissible gross weight.

Observe the test and inspection periods stipulated by the manufacturer.

## 1.2 Environmental tips



- ▷ Be considerate of the environment.
- ▷ Remember that: All kinds of waste water and household waste are not to be disposed of in drains or in the open countryside.
- ▷ On board, collect waste water only in the waste water tank or – if necessary – in other containers designed for that purpose.
- ▷ Only empty the waste water tank and toilet cassette or sewage tank at disposal stations at the camping or caravan sites, which are especially provided for this purpose. When stopping in towns and communities, observe the instructions at caravan sites or ask where there are disposal stations.
- ▷ Empty waste water tank as often as possible, even when it is not completely full (hygiene).  
If possible, flush out waste water tank and, if necessary, drainage pipe with fresh water every time it is emptied.
- ▷ Never allow the toilet cassette or sewage tank to become too full. Empty the toilet cassette or sewage tank frequently, at the latest as soon as the level indicator lights up.
- ▷ Separate household waste according to glass, tin cans, plastic and wet waste also when on a journey. Enquire at the town or community authority about disposal points. Household waste is not to be disposed of in waste paper baskets which are situated at car parks.
- ▷ Empty waste bins as often as possible into the containers provided for this purpose. This helps to avoid unpleasant smells and an accumulation of rubbish on board.
- ▷ When parked, do not allow the engine to run more than necessary. When running idle, a cold engine releases more contaminants than usual. The running temperature of the engine is achieved more quickly whilst the vehicle is in motion.
- ▷ Use an environmentally-friendly WC chemical agent for the WC which can also be biologically degraded and only use small doses.
- ▷ When staying in towns and communities for long periods, search for parking areas which are specially reserved for motorhomes. Enquire at the town or community authority about parking spaces.
- ▷ Always leave the parking places in a clean condition.

## Chapter overview

This chapter contains important safety instructions. The safety instructions are for the protection of persons and property.

The instructions address the following topics:

- fire prevention and what to do in case of fire
- general care of the vehicle
- road safety of the vehicle
- towing
- gas system of the vehicle
- electrical system of the vehicle
- water system of the vehicle

## 2.1 Fire prevention

### 2.1.1 Avoidance of fire risks



- ▶ Never leave children in the vehicle unattended.
- ▶ Keep flammable materials clear of heating and cooking appliances.
- ▶ Lights can get very hot. When the light is switched on, there must always be a safety distance of 30 cm between light and flammable objects. Fire hazard!
- ▶ Never use portable heating or cooking appliances.
- ▶ Only authorised qualified personnel may make changes to the electrical system, gas system or appliances.

### 2.1.2 Fire-fighting



- ▶ Always carry a dry powder fire extinguisher in the vehicle. The fire extinguisher must be approved, tested and close at hand.
- ▶ Have the fire extinguisher tested at regular intervals by authorised qualified personnel. Observe the date of testing.
- ▶ Depending on the equipment, the fire extinguisher is included in the scope of delivery.
- ▶ Always keep a fire blanket near the cooker.

### 2.1.3 In case of fire



- ▶ Evacuate all passengers.
- ▶ Cut off the electrical power supply and disconnect from the mains.
- ▶ Close regulator tap on the gas bottle.
- ▶ Sound the alarm and call the fire brigade.
- ▶ Fight the fire if this is possible without risk.



- ▷ Acquaint yourself with the position and operation of the emergency exits.
- ▷ Keep escape routes clear.
- ▷ Observe the fire extinguisher instructions for use.

All windows and doors which meet the following requirements are considered as emergency exits:

- Open to the outside or can be shifted in horizontal direction
- Opening angle at least 70°
- Minimum diameter of clearance = 450 mm
- Maximum distance from the vehicle floor = 950 mm

## 2.2 General



- ▶ The oxygen in the vehicle interior is used up by breathing and the use of gas operated appliances. That is why the oxygen needs to be replaced on a constant basis. For this purpose, forced ventilation options (e.g. skylights with forced ventilation, mushroom-shaped vents or floor vents) are fitted to the vehicle. Never cover or block forced ventilations from the inside or outside with objects such as e.g. a winter mat. Keep forced ventilations clear of snow and leaves. There is a danger of suffocation due to increased CO<sub>2</sub> levels.
- ▶ Do not use storage compartments or rear garages as places for people or animals to stay or sleep in. These spaces are not forced-air ventilated. There is a danger of suffocation due to oxygen deprivation or exhaust from the heater.
- ▶ Observe the headroom of the doors.



- ▷ As far as the fitted appliances (heater, cooker, refrigerator, etc.) and the base vehicle (engine, brakes, etc.) are concerned, the instruction manuals are authoritative. It is imperative that they be observed.
- ▷ Fitting accessories or special equipment can alter the dimensions, weight and road behaviour of the vehicle. Some of the parts must be entered in the vehicle papers.
- ▷ Only use wheel rims and tyres which are approved for the vehicle. Information concerning the size of the approved wheel rims and tyres is included in the vehicle documents or can be obtained from authorised dealers and service centres.
- ▷ Firmly apply the handbrake when parking the vehicle.
- ▷ If the maximum permissible gross weight of the vehicle exceeds 4 tonnes, wheel chocks must be used when parking on gradients. The wheel chocks are provided as standard for vehicles with a maximum permissible gross weight exceeding 4 tonnes.



- ▷ When leaving the vehicle, it is imperative that all doors, external flaps and windows are closed.
- ▷ Carry a hazard warning triangle and a first-aid kit and/or flashing hazard warning light when this is required by law.
- ▷ The vehicle may only be driven by drivers who hold a driving licence which is valid for the respective vehicle class.
- ▷ When selling the vehicle, hand over all instruction manuals for the vehicle and the fitted appliances.

## 2.3 Road safety



- ▶ Before commencing the journey, carry out a functional check of indicating and lighting equipment, the steering and the brakes.
- ▶ If the vehicle has been stationary for a long period (approx. 10 months) have the braking and gas systems checked by an authorised specialist workshop.
- ▶ Before commencing the journey and after short interruptions of the journey, ensure that the entrance step is completely retracted.
- ▶ Before commencing the journey, secure the hinged pull-down bed.
- ▶ Before commencing the journey, open and secure the shades on the windscreen and on the driver's and front passenger's windows.
- ▶ Before commencing the journey, remove the television from the support and store it securely.
- ▶ Before commencing the journey, place and secure the flat screen and screen support in the initial position. If the screen holder is installed in a TV cabinet: Close TV cabinet.
- ▶ Before commencing the journey, take off the loose sink and drain basin covers and store them securely in the kitchen unit or the wardrobe.
- ▶ Before commencing the journey, fix adjustable tables.
- ▶ Before commencing the journey, rotate all swivel seats in the direction of travel and lock in position. During the journey, the swivel seats must remain locked in place in the direction of travel.
- ▶ During the journey, persons are only to sit on the permitted seats (see chapter 4). The authorised number of seats is stipulated in the vehicle documents.
- ▶ Seat belts must be worn by all passengers.
- ▶ Fasten your seat belts before the beginning of the journey and keep them fastened during the journey.
- ▶ Always secure children with the children safety equipment prescribed for the respective height and weight.
- ▶ Factory-set three-point safety belts must be used when attaching child restraint systems.
- ▶ The base vehicle is a commercial vehicle (small truck). Adjust your driving technique accordingly.
- ▶ In case of underpasses, tunnels or similar obstacles, note the total height of the vehicle (including the roof load).
- ▶ In winter, the roof must be free of snow and ice before commencing the journey.
- ▶ Check tyre pressure before a journey or every 2 weeks. Wrong tyre pressure causes excessive wear and can lead to damage or even to tyre burst. You can lose control of the vehicle.
- ▶ Do not operate the heater at petrol stations. Danger of explosion!
- ▶ Do not operate the heater in closed spaces. Danger of suffocation!



- ▷ Before commencing the journey, distribute the payload evenly within the vehicle (see chapter 3).
- ▷ When loading the vehicle and when taking a rest from driving, in order to load luggage or food, for example, observe the maximum permissible gross weight and axle loads (refer to vehicle documents).
- ▷ Before commencing the journey, ensure that all cupboard doors, the toilet compartment door and all drawers and flaps are secure. Engage the refrigerator door securing device.
- ▷ Before commencing the journey, close windows and skylights.
- ▷ Before commencing the journey, close all external flaps and lock them.
- ▷ Before commencing the journey, remove the external supports and retract the corner steadies or steady legs, which are fitted to the vehicle.
- ▷ Before commencing the journey, put the antenna in park position.
- ▷ During the initial journey and each time after changing a wheel, re-tighten the wheel bolts/wheel nuts after 50 km (30 miles). Subsequently inspect them at regular intervals in order to ensure that they are firmly seated. See chapter 13 for tightening torque.
- ▷ Tyres may not be older than 6 years as the material becomes brittle over time (see chapter 13).
- ▷ When using snow chains, the tyres, wheel suspension and steering are subjected to an additional load. When using snow chains, drive slowly (maximum speed 50 km/h) and only on streets which are completely covered with snow. Otherwise the vehicle could be damaged.

## 2.4 Towing



- ▶ Care is to be taken when connecting and detaching a trailer. Risk of accident and injury!
- ▶ No persons are to be between the towing vehicle and the trailer during positioning for connecting and detaching.

## 2.5 Gas system

### 2.5.1 General instructions



- ▶ Before commencing the journey, when leaving the vehicle or when gas equipment is not in use, close all gas isolator taps and the main isolator tap on the gas bottle.
- ▶ No appliance operated by a naked flame (e.g. heater or refrigerator) may be in operation when filling the tank, on ferries or in the garage. Danger of explosion!
- ▶ Do not use appliances operated with a naked flame in closed spaces (e.g. garages). Danger of poisoning and suffocation!
- ▶ Only have the gas system maintained, repaired or altered by an authorised specialist workshop.
- ▶ Have the gas system checked by an authorised specialist workshop according to the national regulations before commissioning. This also applies for not registered vehicles. For modifications to the gas system have the gas system immediately checked by an authorised specialist workshop.



- ▶ The gas pressure regulator and exhaust gas pipes must also be inspected. The gas pressure regulator has to be replaced after 10 years at the latest. The vehicle owner is responsible for seeing that this is carried out.
- ▶ In case of a defect of the gas system (gas odour, high gas consumption) there is danger of explosion! Close regulator tap on the gas bottle immediately. Open doors and windows and ventilate well.
- ▶ If the gas system is defective: Do not smoke; do not ignite any open flames, and do not operate electric switches (light switches etc.).
- ▶ Before using the cooker make sure that there is sufficient ventilation. Open windows or the skylight.
- ▶ Do not use the gas cooker or gas oven for heating purposes.
- ▶ If there are several gas devices, each gas device must have its own gas isolator tap. If individual gas devices are not in use, close the respective gas isolator tap.
- ▶ Ignition safety valves must close within 1 minute after the gas flame has extinguished. A clicking sound is audible. Check function from time to time.
- ▶ The built-in gas devices are exclusively meant for use with propane or butane gas or a mixture of both. The gas pressure regulator as well as all built-in gas devices are designed for a gas pressure of 30 mbar.
- ▶ Propane gas is capable of gasification up to -42 °C, whereas butane gas gasifies at 0 °C. Below these temperatures no gas pressure is available. Butane gas is unsuitable for use in winter.
- ▶ Regularly inspect the gas tube fitted to the gas bottle connection for tightness. The gas tube must not have any tears and must not be porous. Have the gas tube replaced by an authorised specialist workshop no later than ten years after the manufacturing date. The operator of the gas system must see to it that the parts are replaced.
- ▶ Due to its function and construction, the gas bottle compartment is a space which is open to the exterior. Never cover or block up the standard forced ventilations. Otherwise gas that is emitted can not be diverted to the outside.
- ▶ Do not use the gas bottle compartment as storage space as it is not moisture-proof.
- ▶ Secure the gas bottle compartment against unauthorised access. To do this, lock the compartment.
- ▶ The regulator tap on the gas bottle must be accessible.
- ▶ Only connect gas-operated devices (e.g. gas grill) which have been designed for a gas pressure of 30 mbar.
- ▶ The exhaust gas pipe must be fitted tightly to the heating system and to the vent and must be sealed. The exhaust gas pipe must not show any evidence of damage.
- ▶ Exhaust fumes must be able to escape into the atmosphere unhindered and fresh air must be able to enter unhindered. For this reason, keep the exhaust pipe and intake openings clean and unobstructed (e.g. free from snow and ice). For this reason, no snow walls or aprons may lie against the vehicle.

### 2.5.2 Gas bottles



- ▶ Gas bottles are only to be transported within the designated gas bottle compartment.
- ▶ Place the gas bottles in vertical position in the gas bottle compartment.
- ▶ Fasten the gas bottles so that they are unable to turn or tilt.
- ▶ If the gas bottles are not connected to the gas tube, always place the protective cap on top.
- ▶ Close the regulator tap on the gas bottle before the gas pressure regulator or gas tube are removed from the gas bottle.
- ▶ Use your hands only to connect the gas pressure regulator or the gas tube to the gas bottles. Do not use any tools.
- ▶ Only use special gas pressure regulators with a safety valve designed for vehicle use. Other gas pressure regulators are not permitted and cannot meet the demanding requirements.
- ▶ Use the gas pressure regulator defroster if the temperature falls below 5 °C.
- ▶ Use only 11 kg or 5 kg gas bottles. Camping gas bottles with built-in check valve (blue bottle with max. 2.5 or 3 kg content) are can be used in exceptional cases with a safety valve.
- ▶ Use the shortest possible tube lengths (150 cm max.) for external gas bottles.
- ▶ Never block the floor ventilation openings below the gas bottles.

### 2.6 Electrical system



- ▶ Only allow qualified personnel to work on the electrical system.
- ▶ Prior to carrying out work on the electrical system, switch off all devices and lights, disconnect the battery and disconnect the vehicle from the mains.
- ▶ Only use original fuses with the stipulated values.
- ▶ Only replace defective fuses when the cause of the defect is known and has been remedied.
- ▶ Never bridge or repair fuses.

## 2.7 Water system



- ▶ Water left standing in the water tank or in the water pipes becomes undrinkable after a short period. Therefore, before each use of the vehicle, thoroughly clean the water pipes and the water tank. After each use of the vehicle completely empty the water tank and the water pipes.
- ▶ In the case of lay-ups lasting more than a week disinfect the water system before using the vehicle (see chapter 11).



- ▷ If the vehicle is not used for several days or if it is not heated when there is a risk of frost, empty the entire water system. Make certain that the water pump is switched off on the panel. Otherwise, the water pump will overheat and may get damaged. Leave the water taps on in central position. Leave the safety/drainage valve (if there is one) and all drain cocks open. Frost damage to appliances, frost damage to the vehicle and deposits in water-carrying components can be avoided in this way.



## Chapter overview

This chapter contains important information which has to be noted before commencing your journey or carrying out any tasks before the journey.

The instructions address the following topics:

- keys
- registration
- calculating the payload
- correct loading of the vehicle and bike rack
- load rack
- towing
- retracting and extending the entrance step
- storing the television
- storing the sink cover
- securing add-on parts
- using snow chains

At the end of the chapter there is a checklist which once again summarises the most important points.

### 3.1 Keys

The following keys are included with your vehicle:

Two keys for

- ignition lock
- driver's and passenger's doors
- fuel tank

Two keys for

- conversion door of the body
- drinking water filler neck
- external flaps

Always deposit a replacement key outside the vehicle. Make a note of the key number. Our authorised dealers and workshops can offer assistance in case of loss.

### 3.2 Registration

Your motorhome is a vehicle which must be registered. Observe national regulations on registration.

Please remember that certain countries require a separate national code sticker in addition to the EU plate.

### 3.3 Payload



- ▶ Overloading the vehicle and wrong tyre pressure can cause tyres to burst. You can lose control of the vehicle.
- ▶ Only the maximum permissible gross weight and the mass in a ready-to-drive condition, not the actual weight of the vehicle, is stated in the vehicle documents. For your own safety, we recommend that you have your loaded vehicle (with all passengers, luggage and personal objects) weighed on a public weighbridge before you set out on your journey.
- ▶ Adapt the speed to the payload. The stopping distance is increased if the payload is high.



- ▷ Do not exceed the maximum permissible gross weight stated in the vehicle documents by the payload.
- ▷ Built-in accessories and special equipment reduce the payload.
- ▷ Adhere to the axle load stated in the vehicle documents.

On loading, make sure that the payload's centre of gravity is as low as possible (directly above the floor of the vehicle). Otherwise this may affect the driving characteristics of the vehicle.

#### Maximum permitted payloads

| Description                        | Load (kg) |
|------------------------------------|-----------|
| Pull-down bed                      | 200       |
| Bunk bed                           | 100       |
| Roof load                          | 200       |
| Rear garage and rear storage space | 200       |
| Bike rack Double                   | 60        |
| Bike rack Triple                   | 60        |
| E-bike bike rack Double            | 100       |
| Load rack (AL-KO)                  | 150       |
| Load rack (SAWIKO)                 | 130       |

#### 3.3.1 Terms



- ▷ Technically speaking, the term "mass" has now replaced the term "weight". However, "weight" is still the term more frequent in common use. For better understanding, "mass" is therefore only used in the following sections for fixed formulations.
- ▷ All specifications according to EU norm DIN EN 1646-2.

#### Maximum permissible gross weight in a laden condition

The maximum permissible gross weight in a laden condition is the weight that a vehicle may never exceed.

The maximum permissible overall weight in laden condition consists of the **mass in ready-to-drive condition** and of the **payload**.

In the vehicle documents, the manufacturer has specified the maximum permissible gross weight in a laden condition.

#### Permitted mass

The permitted mass is the weight specified by the manufacturer for issuing the type approval. The permitted mass must never exceed the maximum permissible gross weight of the loaded vehicle.

## Mass in ready-to-drive condition

The mass in ready-to-drive condition is the weight of the ready-to-drive standard vehicle.

The mass in ready-to-drive condition is made up as follows:

- Unladen weight (mass of the empty vehicle) with factory-installed standard equipment
- Driver's weight
- Basic equipment weight

Unladen weight includes lubricants such as oils and coolants which have been filled, the on-board tool set, the spare wheel and a fuel tank which has been filled up to 90 %.

75 kg are calculated for the weight of the driver, regardless of how much the driver really weighs.

Basic equipment includes all equipment and fluids required for safe and proper vehicle use. The weight of the basic equipment includes:

- Water system filled up to 90 % (water tank and pipes)
- Gas bottles filled up to 90 %
- A full heating system
- The power cables for the 230 V power supply
- A full toilet flushing system
- The installation kit for an auxiliary battery if an auxiliary battery can be used

The waste water and sewage tanks are empty.

## Example for calculating the basic equipment

|   |                   |
|---|-------------------|
| Water tank with 60 l (overflow open)                          | 60 kg             |
| Gas bottle (11 kg <sub>gas</sub> + 5.5 kg <sub>bottle</sub> ) | + 16.5 kg         |
| Boiler with 12 l  | + 12 kg           |
| 230 V power cable   | + 4 kg            |
| Installation kit for auxiliary battery                        | + 20 kg           |
| <b>Total</b>  | <b>= 112.5 kg</b> |

In the vehicle documents, the manufacturer specifies the mass in ready-to-drive conditions.

## Payload

The payload is made up as follows:

- Conventional load
- Additional equipment
- Personal equipment



- ▷ The vehicle's payload can be increased by reducing the weight in a ready-to-drive condition. To do this, it is allowed for example to empty the fluid containers or to remove the gas bottles.

You will find explanations on the individual components of the payload in the following text.

## Conventional load

The conventional load is the weight specified by the manufacturer for the passengers.

Conventional load means: 75 kg are calculated for every seat specified by the manufacturer, regardless of how much the passengers actually weigh. The driver's seat is already included as part of the mass in ready-to-drive condition and must **not** be calculated as part of the conventional load.

In the vehicle documents, the manufacturer specifies the number of seats.

**Additional equipment** Additional equipment includes accessories and special equipment. Examples of additional equipment include:

- Caravan coupling
- Roof rail
- Awning
- Bike or motorcycle rack
- Satellite unit
- Microwave oven

Chapter 15 lists the weights of the various items of special equipment; they may also be obtained from the manufacturer.

**Personal equipment** Personal equipment includes all items in the vehicle that are not included in the conventional load or in the additional equipment. For example, personal equipment can include the following:

- Foodstuffs
- Crockery
- Television
- Radio
- Clothes
- Bedding
- Toys
- Books
- Toiletries

No matter where kept, personal equipment also includes:

- Animals
- Bikes
- Boats
- Surfboards
- Sports equipment

For the personal equipment, according to the applicable regulations, the manufacturer must use a minimum weight that is determined according to the following formula:

**Formula** Minimum weight  $M$  (kg) =  $10 \times N + 10 \times L$

**Explanation**  $N$  = maximum number of people including the driver, as stated by the manufacturer  
 $L$  = total length of the vehicle in metres

### 3.3.2 Calculating the payload



- ▶ The payload calculation at the factory is partly based on all-inclusive weights. For safety reasons, the maximum permissible gross weight in a laden condition must not be exceeded.
- ▶ Only the maximum permissible gross weight and the mass in a ready-to-drive condition, not the actual weight of the vehicle, is stated in the vehicle documents. For your own safety, we recommend that you have your loaded vehicle (with all passengers, luggage and personal objects) weighed on a public weighbridge before you set out on your journey.

The payload (see section 3.3.1) is the difference in weight between

- Maximum permissible gross weight in a laden condition and
- Vehicle mass complete in a ready-to-drive condition.

### Example for calculating the payload

|  | Mass in kg to be calculated | Calculation |
|--|-----------------------------|-------------|
| Maximum permissible gross weight according to vehicle documents                                      | 3500                        |             |
| Vehicle mass in a ready-to-drive condition, including basic equipment according to vehicle documents | - 3070                      |             |
| <b>This results in a permissible payload of</b>  | <b>430</b>                  |             |
| Conventional load e.g.: 3 persons each weighing 75 kg  | - 225                       |             |
| Additional equipment   | - 40                        |             |
| <b>For the personal equipment this results in</b>  | <b>= 165</b>                |             |

The calculation of the payload from the difference between the maximum permissible gross weight in laden condition and the mass specified by the manufacturer in ready-to-drive condition is however only a theoretical value.

Only if the vehicle is weighed with full tanks (fuel and water), full gas bottles and complete additional equipment on a public weighbridge, can the actual payload be determined.

To do this, proceed as follows:

- First only drive the vehicle on to the weighbridge with the front wheels and have it weighed.
- Then drive the vehicle on to the weighbridge with the back wheels and have it weighed.

The individual values give the current axle loads. These are important for the correct loading of the vehicle (see section 3.3.3). The sum of these values is the current weight of the vehicle.

The actual payload is the difference between the maximum permissible gross weight in laden condition and the weighed vehicle weight.

This can be used to determine the weight that remains for the personal equipment:

- Determine the weight of the passengers and subtract it from the value for the actual payload.

The result is the weight that is permitted for the actual load of the personal equipment.

### 3.3.3 Loading the vehicle correctly



- ▶ For safety reasons, never exceed the maximum permissible gross weight in a laden condition.
- ▶ Distribute the load evenly on the left and right sides of the vehicle.
- ▶ Distribute the load evenly on both axles. In doing so, observe the axle loads specified in the vehicle documents. Observe the permissible load-carrying capacity of the tyres (see chapter 13).
- ▶ Heavy loads behind the rear axle can reduce the load on the front axle due to the leverage effect ( $\frac{A}{R} \cdot G$ ). This applies especially to long rear extensions, if a motorbike is transported on the rear carrier or if there is a heavy load in the rear storage space. The release of the front axle negatively affects the driving quality, especially for front-driven vehicles.
- ▶ Store all objects in such a way that they cannot slip.
- ▶ Store heavy objects (awning, tin cans, etc.) close to the axles. Low-lying storage compartments whose doors do not open in the direction of travel are particularly suited for storing heavy objects.
- ▶ Stack light objects (laundry) in the roof storage cabinets.
- ▶ Load the bike rack with bicycles only (max. three units).

Large storage spaces, such as the rear garage, also have room for heavy objects (e.g. motorcycle). This might mean that the axle load on the rear axle is exceeded.

However, the individual axles may not be overloaded under any circumstances. That is why it is important, at which distance to the axles the load is stored.

To distribute the load correctly, you will need a scale, a tape measure, a calculator and some time.

Two simple formulas are needed to calculate the effect of the weight of the load on the axles:

#### Formulas

$A \times G : R =$  weight on the rear axle

Weight on the rear axle –  $G =$  weight on the front axle

#### Explanation

A = distance between storage compartment and front axle in cm

G = weight of the load in the storage compartment in kg

R = wheelbase of the vehicle (distance between axles) in cm



- ▶ Measure the external distances horizontally from the centre of the front wheel to the centre of the storage compartment or to the centre of the back wheel.

#### Calculating axle loads:

- Multiply the distance between storage compartment and front axle (A) with the weight of the load in the storage compartment (G) and divide the result by the wheelbase (R). The result is the weight of the load in the storage compartment on the rear axle. Make a note of this weight and of the storage compartment.
- In a second step, subtract the weight in the storage compartment (G) from the weight calculated beforehand. If the result is a **positive** value (example 1), this means that the load on the front axle is **reduced** by this value. If the result is a **negative** value (example 2), this means that the load on the front axle is **increased**. Make a note of this value, too.

- Calculate all storage compartments of the vehicle in the same way.
- In a last step, add all weights calculated for the rear axle to the rear axle load and add (or subtract) all weights calculated for the front axle to (from) the front axle load.  
How to determine rear axle load and front axle load is described in section 3.3.2.

If the calculated value exceeds the permissible axle load, the load must be distributed in a different way.

If the load on the front axle is too low, the grip of the tyres on the road is reduced (traction). This applies in particular to vehicles with front wheel drive. In this case, the load must be redistributed, too.

**Example calculation**

|  |   | <b>Example 1</b>  | <b>Example 2</b>  |
|--|---|-------------------|-------------------|
| Distance to the front axle   | A | (A1) 450 (cm)     | (A2) 250 (cm)     |
| Weight in the storage compartment                                      | G | x 100 (kg)        | x 50 (kg)         |
| Wheelbase of the vehicle   | R | ÷ 325 (cm)        | ÷ 325 (cm)        |
| <b>Load on the rear axle<br/>(add to the axle load)</b>                |   | <b>138.5 (kg)</b> | <b>38.5 (kg)</b>  |
| Weight in the storage compartment                                      |   | - 100 (kg)        | - 50 (kg)         |
| <b>Load relief to the front axle<br/>(subtract from the axle load)</b> |   | <b>38.5 (kg)</b>  |                   |
| <b>Load on the front axle<br/>(add to the axle load)</b>               |   |                   | <b>-11.5 (kg)</b> |

**3.3.4 Roof rail and ladder (partially special equipment)**



- ▶ Access the roof only when a roof rail has been fitted. Only climb onto the roof via a ladder.
- ▶ Take care when stepping onto the ladder. There is danger of slipping when the ladder is moist or icy.
- ▶ Take care when stepping onto the roof. There is danger of slipping when the roof is moist or icy.
- ▶ Do not overload the roof. Road behaviour and brake reaction deteriorate as the roof load increases.



- ▷ If the vehicle is equipped with a roof rail, load racks can be mounted on the roof rail for roof loads (e.g. for surfboards, rubber boats or light canoes). Special girder systems are available as accessory. The authorised dealer or service centre will be happy to advise you.
- ▷ The maximum permissible roof load is 200 kg.
- ▷ The maximum localised load is 90 kg/100 cm<sup>2</sup>.
- ▷ Before stepping on to the roof, extensively cover the area you will be treading on. Materials with a smooth or soft surface are suitable, for example, a thick polystyrene panel.
- ▷ Secure roof loads with tension belts. Do not use rubber expanders.
- ▷ Observe the overall height of the vehicle when the roof rack is loaded.



- ▷ The driver's cabin should have a clearly visible notice stating the overall height. This eliminates the need for calculations at bridges and thoroughfares.




Fig. 1 Rear ladder

*Climbing on to the roof  
(hook-in ladder):*

- Hook the lower part of the ladder (Fig. 1,1) in the part of the ladder (Fig. 1,2) which is fastened to the rear, and place it on the ground.
- Carefully climb the ladder.




Fig. 2 Foldable ladder, ladder folded upwards




Fig. 3 Foldable ladder, ladder folded downwards

*Climbing on to the roof  
(foldable ladder):*

- Open the strap (Fig. 2,1) on the ladder (Fig. 2,3) at the rear of the vehicle.
- Fold out the guard rail (Fig. 2,2).
- Extend the ladder downward.
- Place guard rail with the rubber knobs (Fig. 3,1) up against the back panel of the vehicle.
- Carefully climb the ladder.

*Climbing on to the roof  
(telescopic ladder):*

- Carefully place the telescopic ladder (special equipment) against the side of the vehicle.
- Carefully climb the ladder.

### 3.3.5 Rear garage/rear storage space



- ▶ Do not use storage compartments or rear garages as places for people or animals to stay or sleep in. These spaces are not forced-air ventilated. There is a danger of suffocation due to oxygen deprivation or exhaust from the heater.
- ▶ Observe the permissible axle loads and maximum permissible gross weight when loading the rear garage/the rear storage space.



- ▶ The maximum permitted load of the rear garage/the rear storage space is 200 kg. Do not exceed the permissible rear axle load.
- ▶ Observe: If the rear garage or (depending on the model) the rear storage space is **loaded** to its maximum capacity, this will **reduce the load** on the front axle due to the levering action. The driving quality is impaired.



- ▷ Depending on the vehicle equipment, clamping rails with clamping eyelets are mounted in the rear garage or in the rear storage space. Always secure loads onto the clamping eyelets. Always use tightening straps or lashing nets for securing the load, never rubber expanders.
- ▷ When clamping loads, always check that the clamping eyelets are placed tightly in the clamping rails. If the clamping eyelet is not anchored tightly in the clamping rail, the load may slide or loosen during forcible movements of the steering wheel or when braking.
- ▷ Distribute the load evenly. Excessive spot loads can lead to damages of the floor covering.
- ▷ Use the supporting system offered by your dealer if two-wheelers are transported in the rear garage.

### 3.3.6 Bike rack (special equipment)



- ▶ Observe the permissible axle loads and maximum permissible gross weight when loading the bike rack.
- ▶ Bicycles may protrude at the side by a maximum of 40 cm, measured from the outer edge of the tail lights. However, a total width of 2.5 m must not be exceeded. Adjust the attachments for the bikes accordingly. The lateral overhang must be marked with a red flag.
- ▶ Load the bike rack with bicycles only (max. three units).
- ▶ Fasten bicycles using the straps provided and check to see that they are secure after you have driven a few kilometres.
- ▶ Check the secure attachment of the bicycles on the bike rack after the first 10 km and then at each break in the journey.
- ▶ Do not use the bike rack as luggage rack or ladder.



- ▷ The bike rack is only to be used for transporting bicycles.
- ▷ The gross weight specified by the manufacturer must not be exceeded.
- ▷ The identification plate and rear lights must not be covered.
- ▷ The maximum permissible payload of the bike rack is 60 kg.
- ▷ When loading the bike rack, observe the centre of gravity. If the bike rack is only loaded with **one** bicycle, position the bicycle as closely as possible to the vehicle wall.
- ▷ Driving with a folded out bike rack without bicycles is not permitted.
- ▷ Before every journey, check:
  - Is the bike rack without bicycles folded in correctly?
  - Are the bicycles securely fastened to the bike rack using the bike rack belts?

#### Loading the bike rack with bicycles

When loading the bike rack, observe the centre of gravity. The centre of gravity of the bicycles must be as close as possible to the rear wall of the vehicle. The bike rack should always be loaded from the inside to the outside.

Loading the bike rack correctly:

- Depending on the model, fold the bike rack down or pull it out.
- Place the heaviest bicycle directly against the rear wall.
- Place the lightest bicycles in the centre or on the outside of the bike rack.
- Secure the front and rear wheels of each bicycle with the retaining straps on the bike rack.
- In addition, fasten the outermost bicycle depending on the model of the bike rack on the retaining clip or the retaining bracket and to the spacer respectively.

If the bike rack is only loaded with **one** bicycle, position the bicycle as closely as possible to the rear wall.

#### Bike rack, lowerable



- ▷ Also read the manufacturer's instruction manual.




Fig. 4 Bike rack, lowerable

The bike rack (Fig. 4) permits to easily transport 2 bicycles. Expansion for 3 bicycles is possible. A winding system may be used to lift and lower the bike rack approx. 40 cm. The winding system brings the bicycles to gripping height within seconds.

#### *Loading the bicycles:*

- Attach the manual crank to the bicycle rack and lower the bike rack to gripping height.
- Place the bicycles on top and secure them with quick straps.
- Fasten the bike-block spacer to the frame of the outermost bicycle.
- Use the manual crank to lift the bicycles back up.

#### Bike rack, not lowerable



- ▷ Also read the manufacturer's instruction manual.




Fig. 5 Bike rack, not lowerable

The bike rack (Fig. 5,2) permits to easily transport 2 bicycles. Expansion for 3 bicycles is possible.

*Loading the bicycles:*

- Fold the telescopic swivel clip (Fig. 5,4) down.
- Place the bicycles on top and secure them with quick straps (Fig. 5,3).
- Fasten the spacer (Fig. 5,1) to the frame of the outermost bicycle.

### 3.3.7 Bike/e-bike bike rack (special equipment)



- ▶ Observe the permissible axle loads and maximum permissible gross weight when loading the bike rack.
- ▶ Bicycles may protrude at the side by a maximum of 40 cm, measured from the outer edge of the tail lights. However, a total width of 2.5 m must not be exceeded. Adjust the attachments for the bikes accordingly. The lateral overhang must be marked with a red flag.
- ▶ Do not attach more than 2 bikes (including e-bikes, pedelecs) to the bike rack.
- ▶ Lock bike rack in drive position before starting your journey.
- ▶ Fasten bicycles using the straps provided and check to see that they are secure after you have driven a few kilometres.
- ▶ Check the secure attachment of the bicycles on the bike rack after the first 10 km and then at each break in the journey.
- ▶ Do not use the bike rack as luggage rack or ladder.



- ▷ The bike rack is designed only to carry bicycles and electrically assisted bicycles (e-bikes, pedelecs).
- ▷ The gross weight specified by the manufacturer must not be exceeded.
- ▷ The identification plate and rear lights must not be covered.
- ▷ The maximum permissible payload of the bike rack is 100 kg.
- ▷ When loading the bike rack, observe the centre of gravity. If the bike rack is only loaded with **one** bicycle, position the bicycle as closely as possible to the vehicle wall.
- ▷ Before fixing bicycles, check that the retaining arms and the wheel-holders of the bike rack are in the correct position. If necessary, adjust the retaining arm or wheel-holder to fit the bicycle.
- ▷ Driving with a folded out bike rack without bicycles is not permitted.



- ▷ Before every journey, check:
  - Is the bike rack without bicycles folded in correctly?
  - Are the bicycles securely fastened to the bike rack using the bike rack belts?
- ▷ If the bicycle rack is equipped with a charging unit:
  - Are the charging cables securely fastened? Otherwise, charging cables can tear off.

### Loading the bike rack with bicycles

When loading the bike rack, observe the centre of gravity. The centre of gravity of the bicycles must be as close as possible to the rear wall of the vehicle. The bike rack should always be loaded from the inside to the outside.

Loading the bike rack correctly:

- Place the heaviest bicycle directly against the rear wall.
- Position the lighter bicycle on the outside of the bike rack.
- Secure the front and rear wheels of each bicycle with the retaining straps on the bike rack.
- Fix every bicycle to the retaining arm.

If the bike rack is only loaded with **one** bicycle, position the bicycle as closely as possible to the rear wall.




Fig. 6 E-bike bike rack



Fig. 7 Positioning of e-bikes

- Loosen the strap and fold the e-bike bike rack (Fig. 6,2) down.
- Lift the first e-bike onto the bike rack and place it on the wheel-holders (with the front wheel pointing left).
- Swing out the shorter retaining arm (Fig. 6,1) and secure the e-bike's front frame tube (Fig. 7,1) with straps.
- Using the straps, fix both wheels to the wheel-holders.
- Lift the second e-bike onto the bike rack and place it on the wheel-holders (with the front wheel pointing right).
- Swing out the longer retaining arm (Fig. 6,1) and secure the e-bike's front frame tube (Fig. 7,1) with straps.
- Using the straps, fix both wheels to the wheel-holders.
- Check that both bicycles are securely fastened.



- ▷ The e-bike bike rack is equipped with a charging station for Ansmann brand e-bikes.

### Charging the (Ansmann) batteries:

- Connect the battery's charging cable to the charging station. The batteries are automatically charged during the journey.

### 3.3.8 Removable load rack AL-KO (special equipment)



- ▶ Do not exceed the rear axle load.
- ▶ Heavy loads behind the rear axle can reduce the load on the front axle due to the leverage effect ( $\frac{1}{2} \frac{L}{l}$ ). This applies especially to long rear extensions, if a motorbike is transported on the rear carrier or if there is a heavy load in the rear storage space. The release of the front axle negatively affects the driving quality, especially for front-driven vehicles.
- ▶ Always make sure to store the load roadworthy and secure it against falling.
- ▶ The load may not jut out beyond the maximum width of the vehicle. The lighting and the official licence plate on the load rack may not be covered by the load.



- ▷ The load rack and caravan coupling may not be used simultaneously.



- ▷ The load rack has a EG type approval number.
- ▷ Have your dealer or service centre install the load rack.
- ▷ Observe the country-specific regulations.
- ▷ Also read the manufacturer's instruction manual.

The load rack permits transport of a load (e.g. a motorcycle or a motor scooter) weighing up to 150 kg. Always remove the load rack after use.




Fig. 8 Quick closure

- Installation:**
- Apply the handbrake.
  - Insert the supports on the left and on the right into the holders on the frame and secure them with a quick closure (Fig. 8,1).
  - Connect the electrics between the load rack and the vehicle.

- Removal:**
- Apply the handbrake.
  - Disconnect the electrics between the load rack and the vehicle.
  - Open the quick closure (Fig. 8,1) and pull the support from the holders on the frame.

### 3.3.9 Load rack SAWIKO (special equipment)



- ▶ Do not exceed the rear axle load.
- ▶ Heavy loads behind the rear axle can reduce the load on the front axle due to the leverage effect ( $\frac{m}{l} \cdot \frac{L}{l}$ ). This applies especially to long rear extensions, if a motorbike is transported on the rear carrier or if there is a heavy load in the rear storage space. The release of the front axle negatively affects the driving quality, especially for front-driven vehicles.
- ▶ Always make sure to store the load roadworthy and secure it against falling.
- ▶ The load may not jut out beyond the maximum width of the vehicle. The lighting and the official licence plate on the load rack may not be covered by the load.



- ▷ The load rack and caravan coupling may not be used simultaneously.



- ▷ An entry must be made in the vehicle documents in order to attach a load rack. The required documents are enclosed with the load rack.
- ▷ Have your dealer or service centre install the load rack.
- ▷ Observe the country-specific regulations.
- ▷ Also read the manufacturer's instruction manual.

The load rack permits transport of a load weighing up to 130 kg. For the transport of the load different attachments are available. They are e.g. bike rack or a transport box. Our authorised dealers and service centres will be happy to advise you.




Fig. 9 Load rack




Fig. 10 Attachment to vehicle

The load rack (Fig. 9) permits transport of a motorcycle or a motor scooter weighing up to 130 kg.

#### Scope of delivery

The following parts belong to the scope of delivery:

- Rack trough (Fig. 9,3) and retaining clip (Fig. 9,1) with attachment to vehicle (Fig. 10)
- Rear lights (Fig. 9,4)
- Vehicle licence plate light (Fig. 9,5)
- 13-pole Jäger System plug
- Ramp (Fig. 9,2)

**Attachment to vehicle**

The two side members (Fig. 10,1) of the load rack are fixed to the floor of the vehicle by means of tommy screws (Fig. 10,2) on the square drives (Fig. 10,4). The load rack is secured by a bolt (Fig. 10,3) with locking ring.

**Entry in the vehicle documents**

Have your dealer or service centre install the add-on parts. They will also take care of all the formalities for you.

### 3.4 Towing



- ▶ Care is to be taken when connecting and detaching a trailer. Risk of accident and injury!
- ▶ No persons are to be between the towing vehicle and the trailer during positioning for connecting and detaching.
- ▶ Observe the permissible nose weight and rear axle load of the towing vehicle. Nose weight and rear axle load must not be exceeded. The values of the nose weight and rear axle load are included in the documents of the vehicle and the caravan coupling.



- ▷ Trailer with an overrun brake: Do not connect or detach trailer with the overrun brake on.
- ▷ Caravan coupling with detachable ball neck: If the ball neck is mounted incorrectly, there is the danger of the trailer breaking away. Observe the instruction manual for the caravan coupling.

### 3.5 Caravan coupling (special equipment)



- ▶ When mounting a caravan coupling, see the vehicle documents for information on maximum nose weight and caravan load.
- ▶ Retighten the caravan coupling fixing screws after 1000 operating hours.



- ▷ The load rack and caravan coupling may not be used simultaneously.



- ▷ An entry must be made in the vehicle documents in order to attach a caravan coupling. The required documents are enclosed with the caravan coupling.
- ▷ Also read the manufacturer's instruction manual.



Fig. 11 Caravan coupling

### Entry in the vehicle documents

Have your dealer or service centre install the add-on parts. They will also take care of all the formalities for you.

## 3.6 Electrically operated entrance step (partially special equipment)



- ▶ Before commencing the journey and after short interruptions of the journey, ensure that the entrance step is completely retracted.
- ▶ Do not stand in the direct range of the entrance step while it is being retracted or extended.
- ▶ Do not step on the entrance step until it has extended completely. There is a risk of injury.
- ▶ Do not under any circumstances raise or lower persons or loads with the entrance step.



- ▷ Take note of the different step heights and make certain that the ground is firm and even when exiting.
- ▷ Do not grease or lubricate the pivot bearing and joints of the entrance step (see chapter 11).



- ▷ The button to operate the entrance step is located on the inside of the vehicle in the area of the conversion door.
- ▷ If the entrance step is not retracted and locked in place correctly, a red indicator lamp lights up on the dashboard when the ignition is switched on.
- ▷ Follow the warning notice on the entrance step.




Fig. 12 Entrance step

The vehicles have a one-step, electrically extendable entrance step (Fig. 12,1).




Fig. 13 Warning notice for entrance step




Fig. 14 Operating button for entrance step

Before stepping on the entrance step, fully extend it (Fig. 13).

- Extending:*
- Press the rocker button (Fig. 14,1) down and hold it pressed (at least 3 seconds) until the entrance step has extended completely.
- Retracting:*
- Press the rocker button (Fig. 14,1) up until the entrance step has retracted completely.




Fig. 15 Indicator lamp

When the ignition is switched on and the entrance step is extended, an indicator lamp (Fig. 15,1) is illuminated on the dashboard.

### 3.7 TV unit (special equipment)



- ▶ Before commencing the journey, place and secure the flat screen and screen support in the initial position. If the screen holder is installed in a TV cabinet: Close TV cabinet.
- ▶ Before commencing the journey, ensure that the antenna is in park position. Danger of accidents! Park position means: The antenna points towards the back, is fully lowered and is locked in this position.



- ▶ If there is a risk of frost, do not leave the flat screen television in the vehicle.



- ▶ Further information on positioning the flat screen can be obtained from chapter 6.

### 3.8 Sink and drain basin covers



- ▶ In the event of an accident or emergency braking, the loose sink (Fig. 16,1) and drain basin covers could injure the occupants of the vehicle. Before commencing the journey, take the loose covers off and store them securely in the kitchen unit or wardrobe.



Fig. 16 Sink cover (example)

### 3.9 Securing add-on parts



- ▶ In the event of an accident or emergency braking, loose add-on parts could injure the occupants of the vehicle. Before setting off, secure loose add-on parts in the holders provided or stow them in a secure place inside the vehicle.



- ▷ Unsecured flaps and doors can spring open during the journey and damage parts of the interior. Secure all flaps and doors before setting off.

#### Add-on parts

Add-on parts include bed extensions, ladders or table extensions.




Fig. 17 Bed extension in the rear garage



Fig. 18 Access ladder in the wardrobe

#### Securing add-on parts:

- Place the add-on parts (Fig. 17,1 and Fig. 18,1) in the holders provided and secure them with the available means of attachment.
- If no holder is provided for the add-on part, stow the add-on part in a storage space the doors of which cannot be opened in the direction of travel (e.g. wardrobe or rear storage space).

#### Doors and flaps

Doors are, for example, inner doors or partition walls. See section 6.4 for furniture flaps.



Fig. 19 Shower partition

**Securing doors:** ■ Secure doors or partition walls (Fig. 19,1) with the locks or means of securing provided.

### 3.10 Snow chains (special equipment)



- ▷ Only mount snow chains if there is a clearance of at least 50 mm between the tyres and the vehicle body.
- ▷ When using snow chains, the tyres, wheel suspension and steering are subjected to an additional load. When using snow chains, drive slowly (maximum speed 50 km/h) and only on streets which are completely covered with snow. Otherwise the vehicle could be damaged.
- ▷ Observe the fitting instructions issued by the manufacturer of the snow chains.
- ▷ Do not fit snow chains on alloy wheel rims.

Only use suitable snow chains:

| Tyre size     | Snow chain size |
|---------------|-----------------|
| 215/70 R 15 C | 230             |
| 225/27 R 16 C | 245             |

The use of snow chains is subject to the legal regulations of the individual countries.

- Always mount snow chains to the drive wheels.
- After a few metres, check the tension of the snow chains.

### 3.11 Road safety



- ▶ Check tyre pressure before a journey or every 2 weeks. Wrong tyre pressure causes excessive wear and can lead to damage or even to tyre burst. You can lose control of the vehicle.

Before commencing the journey, work through the checklist:

Base vehicle

| No. | Checks   | Checked |
|-----|--|---------|
| 1   | All vehicle documents are on board                           |         |
| 2   | Tyres in proper condition                                    |         |
| 3   | Vehicle lighting, brake lights and reversing lights function |         |
| 4   | Oil levels for engine, gearbox and power steering controlled |         |
| 5   | Coolant and fluid for windscreen washers filled up           |         |

| No. | Checks  | Checked |
|-----|---|---------|
| 6   | Brakes function                               |         |
| 7   | Brakes react evenly                           |         |
| 8   | When braking, the vehicle remains in the lane |         |

**Housing body, outside**

|    |   |  |
|----|---|--|
| 9  | Awning completely retracted   |  |
| 10 | Roof free of snow and ice (in winter)   |  |
| 11 | External connections and lines disconnected and stored away   |  |
| 12 | External supports removed   |  |
| 13 | Fitted supports retracted and fixed in place  |  |
| 14 | Wheel chocks removed and stored away  |  |
| 15 | Entrance step is stored securely or retracted   |  |
| 16 | External flaps closed and locked  |  |
| 17 | Conversion door locked  |  |
| 18 | Overall height of the vehicle including roof rack when loaded measured and noted. Keep the height information close at hand in the driver's cabin |  |

**Housing body, inside**

|    |   |  |
|----|---|--|
| 19 | Windows and skylights closed and locked   |  |
| 20 | Television securely stored  |  |
| 21 | Flat screen secured   |  |
| 22 | Television antenna retracted (if one is built in)   |  |
| 23 | Loose parts and add-on parts stored away or fixed in position   |  |
| 24 | Open storage spaces empty   |  |
| 25 | No gas cartridges or other easily flammable materials stored in the roof cupboard of the awning light |  |
| 26 | Store sink and drain basin covers securely  |  |
| 27 | Refrigerator door secured   |  |
| 28 | Refrigerator set to 12 V operation  |  |
| 29 | All drawers and flaps closed  |  |
| 30 | All doors secured   |  |
| 31 | Pull-down bed secured   |  |
| 32 | Children's seats mounted to seats with three-point safety belts                                       |  |
| 33 | Swivel seat locking device for driver's seat and front passenger's seat locked                        |  |
| 34 | Shades in the driver's cabin opened and secured   |  |

**Gas system**

| No. | Checks  | Checked |
|-----|---|---------|
| 35  | Gas bottles firmly fixed in the gas bottle compartment so that they are unable to turn                          |         |
| 36  | If the gas bottles are not connected to the gas tube, always place the protective cap on top                    |         |
| 37  | If there is no supplied crash protection unit: Regulator tap on the gas bottle and gas isolator taps are closed |         |

**Electrical system**

|    |  |  |
|----|--|--|
| 38 | <p>Check the battery voltage of the starter and living area battery (see chapter 8). If the panel indicates that the battery voltage is too low, the respective battery will need to be recharged. Observe the notes and instructions in chapter 8</p> <p> ▷ Commence journey with fully charged starter and living area batteries.</p> |  |
|----|--|--|



## Chapter overview

This chapter contains instructions on how to drive the motorhome.

The instructions address the following topics:

- the parking distance control
- reversing camera with LCD monitor
- driving speed
- brakes
- seat belts
- child restraint system
- seats and headrests
- seating arrangement
- Roman shades in the driver's cabin
- filling the tank

### 4.1 Driving the motorhome



- ▶ The base vehicle is a commercial vehicle (small truck). Adjust your driving technique accordingly.
- ▶ Before commencing the journey and after short interruptions of the journey, ensure that the entrance step is completely retracted.
- ▶ A seat belt is fitted for each seat which is permitted for travel. Please keep your seat belt fastened during the journey.
- ▶ Never open your seat belts when travelling.
- ▶ Passengers must remain in the seats provided.
- ▶ The doors must remain locked.
- ▶ Avoid braking with a jerk.
- ▶ If a navigation system is used, only change the destination when the vehicle is stationary. Drive to a car park or stop in a safe area when changing the destination.
- ▶ Do not play DVDs using the monitor of the navigation system during the journey.



- ▷ Drive slowly on poor roads.
- ▷ Take extreme care when driving onto ferries, crossing uneven roads and driving in reverse. Because of the relatively large overhang, larger vehicles might swing out and "touch ground" in unfavourable conditions. This can cause damage to the underbody or to parts fitted there.



- ▷ If an accident occurs as a result of these instructions not being observed, the manufacturer will not be responsible for damages caused.
- ▷ The safety measures stipulated in chapter 2 have to be observed.
- ▷ If a reversing camera is installed in the vehicle, the camera is automatically switched on when driving in reverse gear.

## 4.2 Parking distance control Park Boy V (special equipment)



- ▶ Be particularly careful when driving backwards. Risk of accident and injury.
- ▶ The parking distance control is only an auxiliary appliance and may not necessarily recognise all obstacles. The driver of the vehicle is responsible for safety. If the device fails or there is a malfunction and damage occurs, then claims cannot be asserted against the vehicle manufacturer.
- ▶ Soil deposits, ice, snow and exhaust fumes can prevent the parking distance control from working properly.
- ▶ Only if you drive slowly (at inching speed) will a warning be emitted in time.
- ▶ Obstacles above or below the sensor measurement area will be ignored (e.g. projecting load ramps).
- ▶ Precipitous embankments or road edges (e.g. quay walls) are ignored.



- ▷ Reflections from the road (a change of surface, irregularities) can sometimes trigger false alarms. This is not due to an error in the parking distance control.



- 1 STOP symbol
- 2 Distance display in cm (in 5 cm intervals)
- 3 Distance to the obstacle (graphical display)
- 4 On/Off button for the sensors at the rear of the vehicle
- 5 Without function

Fig. 20 Park Boy V display unit

### Short description

The parking distance control serves as an aid for parking. The distance to possible obstacles is measured using the ultrasound echo sounder method. Four sensors at the rear of vehicle send ultrasound signals and the distance to the obstacle is measured according to the time taken by the reflected ultrasound signals.

In the passenger compartment, a display unit (Fig. 20) shows the distance to the obstacle. At the same time, an acute signal sounds as a warning.

The sensors and display unit are linked by radio.



- ▷ When you switch on the ignition, the parking distance control runs a self-test. If a sensor is defective, this is indicated on the display by rapid flashing of the sensor position. The parking distance control continues to function, with the exception of the defective sensor.

If the radio connection is faulty, this will be indicated on the display by means of a transmission mast symbol. Distance measurement is then not possible.

When reverse gear is disengaged, the transmission mast symbol is also briefly displayed.

Activation by engaging reverse:

- Switch on the ignition and start the motor.
- Engage reverse. The display illuminates and the vehicle symbol appears in the display. The parking distance control is ready to measure.

Activation by pressing the On/Off button on the display unit:

- Press the On/Off button (Fig. 20,4). The display illuminates and the vehicle symbol appears in the display. The parking distance control is ready to measure.

Switching off:

- Press the On/Off button (Fig. 20,4). The parking distance control can be switched off at all times independent of the selected switch-on method using the On/Off key.

### Distance display

The distance between the vehicle and the obstacle is issued in three ways: The display (Fig. 20) shows the distance in steps of 5 cm. The shortest distance measured by a sensor is shown.

Black measurement field blocks in the graphical distance display show an obstacle approaching.

In addition to the visual displays, an acoustic signal (melody) is emitted that changes according to the distance. As the distance between the vehicle and the obstacle grows shorter, so the length of time between the signals shortens until it becomes one continuous sound.



- ▷ Further information can be obtained in the device manufacturer's instruction manual.

### 4.3 Reversing camera (special equipment)



- ▷ Depending on the model, different systems can be installed in the vehicle. The basic functionality of the reversing camera is identical for all systems.



Fig. 21 Reversing camera (Pioneer)



Fig. 22 Reversing camera with infrared illumination (Waeco)

Depending on the equipment, a reversing camera (Fig. 21,1 or Fig. 22,1) with LCD monitor (Fig. 23,1 or Fig. 24) is installed in the vehicle.



Fig. 23 LCD monitor for reversing camera (Pioneer)



Fig. 24 LCD monitor for reversing camera (Waeco)

When it is dark, the infrared LEDs of the reversing camera (Fig. 22,1) illuminate the field of view.

If the engine is running or the ignition is switched on, the reversing camera and LCD monitor switch themselves on automatically when you engage reverse.

If the engine is running or the ignition is switched on, the reversing camera and LCD monitor can also be switched on manually via a pushbutton or a switch on the display.

The system can also be switched off via a pushbutton or the "OFF" button on the display.



- ▷ Further information can be obtained in the manufacturer's instruction manual.

#### 4.4 Driving speed



- ▶ The vehicle is equipped with a powerful engine. This means there are sufficient reserves in difficult traffic situations. This high power enables a high maximum speed and requires above-average driving ability.
- ▶ The vehicle provides a large contact surface for wind. A sudden crosswind can be especially dangerous.
- ▶ Uneven or one-sided loading affects road performance.
- ▶ Driving on unknown streets, you may encounter hazardous road conditions and unexpected driving situations. Therefore, in the interest of safety, make sure your driving speed is appropriate to any given driving situation and environment.
- ▶ Adhere to the national legal speed limits.

#### 4.5 Brakes



- ▶ Have defects on the braking system immediately remedied by an authorised specialist workshop.



- ▷ Avoid block brakings. Block braking gives the tyres "brake plates" of varying strength. This reduces driving comfort. It might even make the tyres unserviceable.

**Before each journey** Before each journey, check by means of a braking test:

- Do the brakes function?
- Do the brakes react evenly?
- Does the vehicle remain in the lane when braking?

## 4.6 Seat belts

The vehicle is equipped with seat belts in the living area on the seats for which seat belts are compulsory by law. National regulations apply seat-belt fastening.



- ▶ Fasten your seat belts before the beginning of the journey and keep them fastened during the journey.
- ▶ Do not damage or trap belts. Have damaged seat belts changed by an authorised specialist workshop.
- ▶ Do not alter the belt fixing devices, automatic seat belt winders and the belt clips.
- ▶ Inspect the screwed connections of the seat belts from time to time in order to ensure that they are correctly seated.
- ▶ Only use one seat belt for **one** adult person.
- ▶ Do not belt in objects together with persons.
- ▶ Seat belts are not sufficient for persons who are less than 150 cm tall. In these cases use additional restraining devices. Observe test certificate.
- ▶ Factory-set three-point safety belts must be used when attaching child restraint systems.
- ▶ After an accident, replace the seat belts.
- ▶ During the journey, do not tilt the backrest too far backwards. Otherwise the functionality of the seat belt is no longer guaranteed.

### 4.6.1 Fastening the seat belt correctly



- ▶ Do not twist the belt. The belt must be positioned smoothly against the body.
- ▶ When fastening the seat belt, adopt the correct sitting position.

The seat belt is fastened correctly when a fist can be passed between the body and the seat belt.

## 4.7 Child restraint systems



- ▶ When travelling, secure children under 13 years of age that are smaller than 150 cm, with a suitable and officially approved child restraint system.
- ▶ Factory-set three-point safety belts must be used when attaching child restraint systems.



- ▶ Fasten the childrens' seat belts before commencing the journey and make sure that their seat belts are kept fastened during the journey.
- ▶ Use a rear-facing child restraint system ("reboard system") only when the front and side air bags on the passenger side are switched off. Observe the separate operating instructions of the chassis manufacturer and the warning notices in the vehicle. If no rear-facing child restraint system is in use, switch the airbags back on again.

Child restraint systems are divided into five classes:

| Class | Body weight    | Approximate age      |
|-------|----------------|----------------------|
| 0     | Up to 10 kg    | Up to 9 months       |
| 0+    | Up to 13 kg    | Up to 18 months      |
| I     | 9 kg to 18 kg  | 9 months to 4 years  |
| II    | 15 kg to 25 kg | 3 years to 7 ½ years |
| III   | 22 kg to 36 kg | 6 years to 12 years  |

#### 4.8 Pilot seats for the driver's and front passenger's seats



- ▶ Before commencing the journey, rotate all swivel seats in the direction of travel and lock in position.
- ▶ The seats must remain fixed in position during the journey and are not to be rotated.



- ▷ Before rotating the seats in the pitched vehicle, always apply the hand-brake.



- ▷ The driver's seat and the front passenger's seat are part of the base vehicle. The adjustment of the seats is described in the instruction manual of the base vehicle.
- ▷ The possibilities of seat adjustment differ according to the model and equipment variants.

## 4.9 Seat heater (special equipment)



- ▷ The seat heater only works when the ignition is switched on.

Depending on equipment levels, the driver's seat and the front passenger's seat may have a 2-level seat heater.



Fig. 25 Switch for seat heater

*Switching on the seat heater:*

- Press the switch (Fig. 25,1) at the back on the left side of the seat console.
  - For minimal heating: Press the switch so that it is in the down position.
  - For the highest heat level: Press the switch so that it is in the up position.

The LED (Fig. 25,2) comes on when the seat heater is in use.

*Switching off the seat heater:*

- Set switch (Fig. 25,1) to the middle position. The LED goes out.

## 4.10 Headrests



- ▷ The headrests are not adjustable for all models.




Fig. 26 Bench headrest




Fig. 27 Bench headrest (alternative)

Before commencing the journey, adjust the headrests (Fig. 26,1) or the headrest (Fig. 27,1) so that the back of the head is supported at approximately ear height. Push the headrests upwards or downwards by hand.

### 4.11 Seating arrangement



- ▶ During the journey, persons are only to sit on the permitted seats. The authorised number of seats is stipulated in the vehicle documents.
- ▶ During the journey sitting on the divans is not permitted.
- ▶ Seat belts must be worn by all passengers.



Fig. 28 "Seat" symbol

Seats which may be used during travel are equipped with a sticker (Fig. 28).

### 4.12 Roman shade in the driver's cabin

#### 4.12.1 Pleated Roman shades



- ▶ When on the move, the Roman shades for the windscreen, driver's window and the front passenger's window respectively must be completely removed.



Fig. 29 Pleated Roman shades

*Removing the pleated shade:*

- Open the snap fasteners (Fig. 29,1), loosen the magnetic strips and detach the pleated shade from the window (shown here on the passenger window).
- Stow away the pleated shades in the living area.

### 4.12.2 Roman shades, Remis (partially special equipment)



- ▶ While travelling, the Roman shades for the windscreen, driver's window and front passenger's window must be open, in a fixed position and secured.



Fig. 30 Roman shade for the windscreen




Fig. 31 Roman shade for driver's and passenger's window

#### Securing:

- Use the handle (Fig. 30,2) to pull the two halves of the Roman shade for the windscreen outwards as far as they will go. When doing so, move the handle horizontally in the direction of the locking recess.
- Allow the release handles (Fig. 30,1) to engage.
- Use handle (Fig. 31,2) to push in the Roman shades for the driver's and passenger's window as far as possible.
- Allow the release handles (Fig. 31,1) to engage.

### 4.13 Filling up with diesel



- ▶ No appliance operated by a naked flame (e.g. heater or refrigerator) may be in operation when filling the tank, on ferries or in the garage. Danger of explosion!



- ▷ The fuel filler neck is part of the base vehicle.
- ▷ The fuel filler neck is labelled with the word "Diesel".

Refer to the instruction manual for the base vehicle for the position of the fuel filler neck.



## Chapter overview

This chapter contains instructions on how to pitch the vehicle.

The instructions address the following topics:

- handbrake
- entrance step
- ramps
- wheel chocks
- operation of the supports
- 230 V connection
- refrigerator
- aligning the antenna
- retracting and extending the awning



- ▷ Pitch the vehicle so that it is as horizontal as possible. Use ramps where necessary. Otherwise, the water from the shower tray will not be able to drain properly.
- ▷ Secure the vehicle to prevent it from rolling.
- ▷ Animals (especially mice) can cause great damage to the interior of the vehicle. To prevent this from happening, regularly check the vehicle for damages or animal traces after pitching.

### 5.1 Handbrake

Firmly apply the handbrake when parking the vehicle.

### 5.2 Entrance step



- ▷ Observe the instructions in section 3.6.

In order to exit the vehicle, first fully extend the electrically operated entrance step. Observe the indicator lamp on the dashboard.

### 5.3 Ramps



- ▷ Ramps are not included in the scope of delivery. Different models are available from accessory shops.

To enable the vehicle to be parked on the level, ramps can be used for height compensation when the vehicle is parked on a hill or on uneven ground.

### 5.4 Wheel chocks

When parking the vehicle on slopes or inclines use the wheel chocks.

If the maximum permissible gross weight of the vehicle exceeds 4 tonnes, wheel chocks must be used when parking on gradients. The wheel chocks are provided as standard for vehicles with a maximum permissible gross weight exceeding 4 tonnes.

## 5.5 Supports

### 5.5.1 General instructions



- ▶ The steady legs must not be used to jack up the vehicle in order to work beneath it, e.g. to change a wheel or carry out maintenance work.
- ▶ Whilst the vehicle is in a jacked up position, persons must not lie down under it.



- ▷ Always apply the handbrake before extending the steady legs.
- ▷ Do not use the fitted supports as a vehicle jack. They supports are only for stabilising the parked vehicle to prevent the rear axle from bottoming out.
- ▷ When pitching the vehicle, ensure that the supports are evenly loaded.
- ▷ Before driving away, wind up the supports as far as they can go, fully retract and secure them.



- ▷ When the ground is soft, place a pad or block under the supports in order to prevent the vehicle from sinking into the ground.
- ▷ Pitch the vehicle so that it is as horizontal as possible. Otherwise, the water from the shower tray will not be able to drain properly.

### 5.5.2 Steady legs (SAWIKO) (special equipment)



- ▷ Depending on the model, the hexagonal nut has a joint, which can be used to bring the attached socket spanner into a more convenient position for turning.

In order to ensure their correct function, clean and grease the interior tubes of the steady legs regularly.

The length of the steady legs can be adjusted according to the model.




Fig. 32 Steady leg

#### *Extending:*

- Place the socket spanner on the hexagon nut (Fig. 32,1) and rotate until the steady leg is in a perpendicular downward position.
- If the length of the steady leg can be adjusted, remove the splint (Fig. 32,4) out of the support foot extension (Fig. 32,5).
- Pull out the support foot extension until it has reached the required length.
- Insert the splint in the support foot extension.
- Rotate the hexagonal nut until the steady leg rests completely on the ground and the vehicle is in a horizontal position.

- Retracting:*
- Place the socket spanner on the hexagon nut (Fig. 32,1) and rotate until the steady leg is clear of the ground.
  - If the length of the steady leg can be adjusted, remove the splint (Fig. 32,4) out of the support foot extension (Fig. 32,5).
  - Push in the support foot extension (Fig. 32,5) and insert the splint (Fig. 32,4) in the drilled hole in the support foot extension.
  - Rotate the hexagonal nut (Fig. 32,1) until the steady leg has swung upwards and the guide (Fig. 32,2) has reached the very end of the slot (Fig. 32,3).



- ▷ Before commencing the journey, observe the following: Are all steady legs and support foot extensions retracted completely and secured with the splint?

### 5.5.3 Steady legs (AL-KO) (special equipment)

In order to ensure their correct function, clean and grease the interior tubes of the steady legs regularly.

The length of the steady legs can be adjusted according to the model.




Fig. 33 Steady leg

- Extending:*
- Place the socket spanner on the hexagon nut (Fig. 33,1) and rotate until the steady leg is in a perpendicular downward position.
  - Remove the splint (Fig. 33,4) out of the support foot extension (Fig. 33,5).
  - Extend the support foot extension until it has reached the required length.
  - Insert the splint in the support foot extension.
  - Rotate the hexagonal nut until the steady leg rests completely on the ground and the vehicle is in a horizontal position.

- Retracting:*
- Place the socket spanner on the hexagon nut (Fig. 33,1) and rotate until the steady leg is clear of the ground.
  - Remove the splint (Fig. 33,4) out of the support foot extension (Fig. 33,5).
  - Push in the support foot extension (Fig. 33,5) and insert the splint (Fig. 33,4) in the drilled hole in the support foot extension.
  - Rotate the hexagonal nut (Fig. 33,1) with the socket spanner until the steady leg has swung upwards and the guide disc (Fig. 33,3) has completely retracted into the notch (Fig. 33,2).



- ▷ Before commencing the journey, observe the following: Are all steady legs and support foot extensions retracted completely and secured with the splint?

### 5.5.4 Electrical steady legs (AL-KO) (special equipment)



- ▶ Always observe the electrical steady legs when extending or retracting them.
- ▶ When extending or retracting the steady legs, ensure that no one is in the vehicle. Risk of injury due to unexpected rolling motion.



- ▷ Never extend the steady legs so far that the tyres of the vehicle are not in contact with the ground. This could damage the body and chassis and the brakes will not work.
- ▷ The steady legs are designed only to support the vehicle, not to level it.
- ▷ Steady legs need sufficient ground clearance to be able to fold out vertically.
- ▷ If the vehicle is equipped with pneumatic springs, follow the indications for extending and retracting. Otherwise, the motor of the steady legs can become overloaded.



- ▷ The electrical steady legs can only be operated with the ignition switched off.
- ▷ If the remote control is not operated for two minutes after the controller has been activated, the controller automatically switches off.
- ▷ When a key on the remote control is pressed, the indicator lamp flashes.
- ▷ If the steady legs are extended and the ignition is switched on, a pulsating warning tone is heard. The warning tone stops after the ignition has been switched off.



Fig. 34 Remote control for electrical steady legs

#### Button functions

- Preselection: steady leg left (Fig. 34,4)
- Preselection: steady leg right (Fig. 34,2)
- Retract steady leg (Fig. 34,1)
- Extend steady leg (Fig. 34,3)
- Control LED (Fig. 34,5)

Each time a button is pressed, the control LED (Fig. 34,5) flashes.



Fig. 35 Push-button to activate remote control




Fig. 36 Electrical steady leg on vehicle



- ▷ Do not extend the steady leg to the end position without it being in contact with the ground.

*Extending:*

- If the vehicle is equipped with pneumatic springs: First lower the pneumatic spring (see the manufacturer's instruction manual), then extend the steady legs.
- Press the push button (Fig. 35,1) for approx. 2 seconds until a brief sound is emitted. The steady legs control is now activated.
- Press and hold the preselection button for the steady leg side (Fig. 34,2 or 4) for approx. 1 second.
- Within 2 seconds, press the "Extend steady leg" button (Fig. 34,3) and hold it until the support leg (Fig. 36,4) is touching the ground.
- Press the preselection button for the other steady leg side and repeat the procedure.

*Retracting:*

- If the vehicle is equipped with pneumatic springs: First raise the pressure in the pneumatic spring (see the manufacturer's instruction manual), then retract the steady legs.
- Press the push button (Fig. 35,1) for approx. 2 seconds until a brief sound is emitted. The steady legs control is now activated.
- Press and hold the preselection button for the steady leg side (Fig. 34,2 or 4) for approx. 1 second.
- Within 2 seconds, press the "Retract steady leg" button (Fig. 34,1) and hold it until the support leg (Fig. 36,4) is fully retracted. Once the support leg is fully retracted, a control signal sounds.
- Press the preselection button for the other steady leg side and repeat the procedure.

*Changing the remote control battery:*

- Remove the rear casing.
- Change the battery (CR2032). Observe the correct polarity ("+" to the outside).



- ▷ The battery must be changed if the control LED flashes more slowly or if it goes out.

**Emergency operation** If the electric drive breaks down, the steady legs can be moved with the hand crank.

*Extending/retracting:*

- Press the securing bracket (Fig. 36,2) inwards.
- Push the motor (Fig. 36,3) in the direction indicated as far as it will go.
- Extend or retract the steady leg like a mechanical steady leg via the hexagonal nut (Fig. 36,1).

When the fault has been rectified: Push the motor in the opposite direction of the arrow to its initial position. Pull out the securing bracket (Fig. 36,2) until it engages.



- ▷ Further information can be obtained in the manufacturer's instruction manual.

## 5.6 230 V connection

The vehicle can be connected to a 230 V power supply (see chapter 8).

## 5.7 Refrigerator



- ▶ If the refrigerator is set to 12 V operation, it will constantly consume current. Therefore, switch over to gas operation when the vehicle engine is **not** running, and the vehicle is **not** connected to the 230 V power supply.

For units with an automatic power selection, the 12 V operation of the refrigerator only functions in the automatic mode when the vehicle engine is running. When the vehicle engine is switched off, switch the refrigerator to 230 V operation or gas operation.

## 5.8 Satellite unit (special equipment)



- ▶ Before commencing the journey, ensure that the antenna is in park position. Danger of accidents!




- ▷ The vehicle must be still during the satellite search. Do not walk through the vehicle.
- ▷ Satellite reception is only possible, when the antenna is positioned in direct line of sight of the chosen satellite and the view is not blocked in any way.
- ▷ Further information can be obtained in the device manufacturer's instruction manual.

### 5.8.1 Equipment with automatic antenna alignment (Alden)

The satellite unit is equipped with an automatic positioning unit. This automatic positioning unit ensures that the antennas are aligned accurately.

The flat screen incorporates a digital receiver.

The satellite unit is operated via remote control.



- 1 TV button
- 2 On/Off key
- 3 Memory buttons
- 4 Function buttons

Fig. 37 Remote control

*Setting up the unit:*


- Switch on the television.
- Press the key "⏻" (Fig. 37,2) on the remote control. The satellite antenna repositions itself out of the park position and into search mode. When the unit finds the satellite, you will hear a signal tone.
- Use the memory buttons (Fig. 37,3) or the function buttons (Fig. 37,4) to set the required transmitter.

### 5.8.2 Equipment with semi-automatic antenna alignment (Alden)

The satellite unit is equipped with a semi-automatic positioning unit.

The flat screen incorporates a digital receiver.

The satellite unit is operated via remote control.



- 1 TV button
- 2 On/Off key
- 3 Memory buttons
- 4 Function buttons

Fig. 38 Remote control for television

*Switching on the satellite unit:*

- Switch on the television.
- Press the key "⏻" (Fig. 38,2) on the remote control for the television. The unit switches to search mode. You will hear a continuous tone.
- Press the key "⬆️" on the remote control for the antenna. The satellite antenna lifts out of the park position and moves to the last position entered.
- To switch to television reception on the TV remote control, press the TV button (Fig. 38,1). The signal tone will stop. An image will appear on the screen.

*Setting up the antenna:*

- Use the memory buttons (Fig. 38,3) on the TV remote control or the function buttons (Fig. 38,4) to select the desired station.
- On the remote control for the antenna, use the keys "⬆️" or "⬇️" to correct the angle of the antenna in accordance with the enclosed cards.
- Loosen antenna mast clamp.

*Lowering the antenna for driving:*

- Turn antenna slowly. When the antenna finds the satellite, you will hear a signal tone.
- Optimise the reception by turning and tilting the antenna.
- Slightly retighten the antenna mast clamp.
- Loosen antenna mast clamp.
- Turn the antenna until the slot in the clamp and the slot in the antenna mast are congruent with each other.
- Press the key "↓" on the remote control for the antenna. The satellite antenna moves into park position.
- Check whether the antenna is fully lowered and points to the rear of the vehicle.
- Slightly retighten the antenna mast clamp.
- Switch off the television.

### 5.8.3 Equipment with automatic antenna alignment (Oyster)



- ▶ Before commencing the journey, ensure that the antenna is in park position. Danger of accidents!



- ▷ The vehicle must be still during the satellite search. Do not walk through the vehicle.
- ▷ Satellite reception is only possible, when the antenna is positioned in direct line of sight of the chosen satellite and the view is not blocked in any way.
- ▷ Also read the manufacturer's instruction manual.

The satellite unit is equipped with an automatic positioning unit. This automatic positioning unit ensures that the antennas are precisely aligned to the desired satellites.

Operation is menu-controlled (TV screen) using the remote control.

*Setting up the unit:*

- Switch on the television.
- Use the mains switch to switch on the receiver. When the green LED on the receiver's infra-red receptor lights up, the receiver is ready to operate.
- Switch on the receiver with the remote control. The satellite antenna repositions itself out of the park position and into search mode.

When the system finds the satellite, the selected TV programme appears automatically.

## 5.9 Awning (special equipment)



- ▷ Retract the awning in strong wind, rain or snow.
- ▷ In the case of light rain, shorten one of the support legs so that water can run off.
- ▷ Only retract the awning when the fabric is dry. When the awning must be retracted while the fabric is still wet: Extend the awning as soon as possible, in order to dry out the fabric.
- ▷ Before retracting, remove leaves and coarse dirt from the awning.



- ▷ Only use the awning for protection against the sun.
- ▷ Also read the manufacturer's instruction manual.

### Advantages of the awning

The advantages of an awning are:

- The awning provides shade.
- The awning creates a covered vestibule and thus expands the space.
- The vehicle thus becomes more homelike.



Fig. 39 Awning

### Putting up the awning:

- Use the manual crank to open up the awning (Fig. 39,1).
- Set up the brackets (Fig. 39,2) when the awning is open.



## Chapter overview

This chapter contains instructions about living in the vehicle.

The instructions address the following topics:

- opening and closing the doors and flaps
- light switches
- adjusting the spotlights
- positioning the television
- ventilation of the vehicle
- opening and closing the windows and blinds
- opening and closing the Roman shades in the driver's cabin
- opening and closing the skylights
- modifying the table surfaces
- converting tables
- use of the beds
- use of the external shower

### 6.1 Central locking system (special equipment)



- ▷ The central locking mechanism locks the driver's door, the passenger's door and the conversion entrance door.
- ▷ The central locking system has no function, if the battery cut-off switch on the transformer/rectifier is switched off.
- ▷ If, after you press the release button, a door is not opened within 40 seconds, the central locking system automatically locks the doors again.



Fig. 40 Remote control for central locking system

*Unlocking:* ■ Press the  button (Fig. 40,1) once briefly. The door locks are unlatched.

*Locking:* ■ Press the  button (Fig. 40,2) once briefly. The door locks are locked.

### 6.2 Conversion door



- ▶ Only drive with locked doors.



- ▷ Locking the doors can prevent them from opening of their own accord, e.g. during an accident.
- ▷ Locked doors also prevent forced entry, e.g. when waiting at traffic lights. However, in an emergency, locked doors make it more difficult for helpers to enter the vehicle.
- ▷ When leaving the vehicle, always lock the doors.

### 6.2.1 Conversion door, outside (Hartal M1)




Fig. 41 Door lock of conversion door, outside

- Opening:**
- Insert the key into locking cylinder (Fig. 41,1) and turn until the door lock is unlatched.
  - Return the key to the central position and remove it.
  - Pull on the handle (Fig. 41,2). The door is open.
- Locking:**
- Insert the key into locking cylinder (Fig. 41,1) and turn until the door lock is engaged.
  - Return the key to the central position and remove it.

### 6.2.2 Conversion door, inside (Hartal M1)



Fig. 42 Door lock of conversion door, inside, locked

- Opening:**
- Press lever (Fig. 42,2).
- Locking:**
- Push the sliding trap (Fig. 42,1) down.

### 6.2.3 Conversion door, outside (Hartal Premium) (partially special equipment)



Fig. 43 Door lock of conversion door, outside

- Opening:**
- Insert the key into locking cylinder (Fig. 43,1) and turn until the door lock is unlatched.
  - Return the key to the central position and remove it.
  - Pull on the handle (Fig. 43,2). The door is open.
- Locking:**
- Insert the key into locking cylinder (Fig. 43,1) and turn until the door lock is engaged.
  - Return the key to the central position and remove it.

### 6.2.4 Conversion door, inside (Hartal Premium) (partially special equipment)




Fig. 44 Door lock of conversion door, inside

- Opening:**
- Pull on the handle (Fig. 44,2). The door lock is unlatched.
- Locking:**
- Press the upper part of the handle (Fig. 44,2) in the direction of the recessed handle (Fig. 44,1).

### 6.2.5 Window of conversion door (Hartal Premium) (partially special equipment)

The conversion door window is fitted with a Roman shade.



Fig. 45 Roman shade

**Closing:** ■ Grip the Roman shade (Fig. 45,2) in the middle of the holding bar (Fig. 45,1), pull it upwards and then release it at the desired height. The Roman shade will stay at this height.

**Opening:** ■ Grip the Roman shade in the middle of the holding bar and push it down.

### 6.2.6 Folding insect screen on the conversion door (partially special equipment)



▷ Open the insect screen completely before closing the conversion door.



Fig. 46 Insect screen

**Closing:** ■ Pull out the insect screen completely by the bar (Fig. 46,1).

**Opening:** ■ Push the insect screen into its initial position by the bar (Fig. 46,1).

### 6.3 External flaps



▷ Before commencing the journey, close all external flaps and lock them.  
▷ To open and close the external flap, open or close all locks that are fitted to the external flap.



▷ When leaving the vehicle, close all external flaps.

The external flaps fitted to the vehicle are all fitted with identical locking cylinders. Therefore, all locks can be opened with a single key.

### 6.3.1 Flap lock with recessed handle



- ▷ To open the external flap, pull all the lock handles fitted to that particular external flap at the same time.




Fig. 47 Flap lock with recessed handle

- Opening:**
- Insert key into locking cylinder (Fig. 47,1) and turn a quarter turn. The flap lock is unlatched.
  - Remove the key.
  - Pull on the lock handle (Fig. 47,2). The external flap is open.
- Closing:**
- Firmly close the external flap.
  - Insert key into locking cylinder and turn a quarter turn. The flap lock is locked.
  - Remove the key.

### 6.3.2 Flap lock with push button

Depending on the flap size the service flap is equipped with one or two lockable push-button locks.




Fig. 48 Push-button lock service flap

- Opening:**
- Insert the key into locking cylinder of the lockable push-button lock (Fig. 48,1) and turn a quarter turn. The push-button lock is unlatched.
  - Remove the key.
  - If equipped, unlock the second lockable push-button lock as well.
  - Press the two push buttons of the push-button locks simultaneously with the thumb and open the service flap.

- Closing:*
- Close the service flap and press it shut. The push-button locks are now engaged but not locked.
  - Insert the key into locking cylinder of the lockable push-button lock (Fig. 48,1) and turn a quarter turn. The push-button lock is locked.
  - Remove the key.
  - If equipped, lock the second lockable push-button lock as well.

### 6.3.3 Flap for the 230 V connection, square



- 1 Recessed grip
- 2 External flap

Fig. 49 Flap for the 230 V connection

- Opening:*
- Reach into the recessed grip (Fig. 49,1) on the external flap (Fig. 49,2) and swing the external flap upward.

- Closing:*
- Swivel the external flap downwards and press it shut.

### 6.3.4 Cap for the drinking water filler neck



Fig. 50 Cap for the drinking water filler neck



- ▷ The drinking water filler neck is indicated by the symbol "☞" (Fig. 50,1).

- Opening:*
- Insert the key in the locking cylinder (Fig. 50,2) and turn it in an anticlockwise direction.

- Remove cap.

- Closing:*
- Insert the cap in the drinking water filler neck.

- Turn key in a clockwise direction.

- Remove the key.

## 6.4 Furniture flaps



- ▷ Before commencing the journey, close all furniture flaps and inner doors and lock them.
- ▷ The furniture flaps shown in this section are examples. Depending on the model, the locks and handles on the furniture flaps may differ to those displayed here.


### 6.4.1 Furniture flaps with push button



Fig. 51 Furniture flap with push button

- Opening:*
- Press inner part of the lock. The push button jumps out (Fig. 51).
  - Hold push button and open furniture flap.
- Closing:*
- Press furniture flap shut.
  - Press push button in until it locks. The furniture flap is closed correctly when the fastener locks into place.

### 6.4.2 Furniture flaps with unlocking bar



- 1 Lock
- 2 Unlocking bar

Fig. 52 Furniture flap with unlocking bar

- Opening:*
- Press and hold the unlocking bar (Fig. 52,2) on the inside of the furniture flap.
  - Open the flap.
- Closing:*
- Press down furniture flap until the lock (Fig. 52,1) snaps into place with a click.

### 6.4.3 Furniture flaps with handle and push button




Fig. 53 Furniture flap with handle (example)




Fig. 54 Furniture flap with handle (example)

- Opening:**
- Press the release knob (Fig. 53,1 or Fig. 54,1) on the handle (Fig. 53,2 or Fig. 54,2) and hold it down.
  - Pull handle until furniture flap is open.
- Closing:**
- Press the furniture flap down until you can feel the flap hinge close and hear the lock snap into place.

## 6.5 Light switch

### 6.5.1 Entrance area



- ▷ The light switches shown in this section are examples. Depending on the model, the type and allocation of the light switches may differ to those displayed here.




Fig. 55 Light switch




Fig. 56 Awning light

The entrance area has light switches (Fig. 55,1-4) for the following lamps:

- Entrance lights
- Awning light (light points downwards)
- Awning light (light points upwards)
- Living area lights

### 6.5.2 Interior



- ▷ The lamps shown in this section are examples. Not all lamps used in the vehicle are shown. The examples are intended to clarify the possible positions for the light switches. The type and appearance of the light switches can deviate from those shown here.



Fig. 57 Spotlight, switch mounted directly on the lamp



Fig. 58 Spotlight, switch mounted directly on the lamp




Fig. 59 Switch, separate from the lamp



Fig. 60 Recessed light, light switch in the lamp

The interior light switches are located either directly on each lamp (Fig. 57, 1 and Fig. 58, 1) or near the lamp (Fig. 59, 1).

To switch the recessed light on and off, press the interior of the recessed light (Fig. 60, 1).

### 6.5.3 Wardrobe light



- ▷ The wardrobe light can be removed from its holder (Fig. 61, 1) and used as a torch.
- ▷ When the wardrobe door is closed, the wardrobe light switches off automatically.
- ▷ A brightness sensor ensures that the wardrobe light comes on only when it is dark. This prevents the wardrobe light from being accidentally switched on during daylight hours, which would waste the batteries.




Fig. 61 Wardrobe light

The On/Off switch (Fig. 61, 2) is located directly on the wardrobe light (Fig. 61, 3).

## 6.6 Spotlight



- ▶ Bulbs and light fittings can be extremely hot.
- ▶ Allow the light bulbs and lamp holders to cool down before touching them.
- ▶ If the light is switched on or still hot, there must always be a safety distance of at least 30 cm between stores or curtains and flammable objects. Fire hazard!

The spotlight can be rotated, moved or detached.




Fig. 62 Spotlight

**Rotating:** ■ Grasp the housing (Fig. 62,2) and turn it.

The housing can be turned in different directions:

- To the left and to the right
- Up and down

**Shifting:** ■ Grip holder (Fig. 62,1) and turn by approx. 45°.  
■ Push spotlight along the rail system to desired position.

**Removal:** ■ Grip holder (Fig. 62,1) and turn by approx. 90°.  
■ Remove spotlight from rail.

The spotlight can be installed in any position into the rails.

## 6.7 Holder for flat screen



- ▶ Before commencing the journey, place and secure the flat screen and screen support in the initial position. If the screen holder is installed in a TV cabinet: Close TV cabinet.



- ▷ If there is a risk of frost, do not leave the flat screen television in the vehicle.

### 6.7.1 Holder on the column

The holder for the flat screen is attached to a column.




Fig. 63 Holder on the column

*Positioning:*

- Push the release lever (Fig. 63,2) to the side and turn the holder (Fig. 63,3) with the flat screen to the desired position.
- Press flat screen slightly upward and swivel it to the desired position. Three different inclination angles may be used.

*Storing away:*

- Turn flat screen back until the holder (Fig. 63,3) engages in the lock (Fig. 63,1).

### 6.7.2 Holder with jointed arm

The flat screen is fastened to a jointed arm.




Fig. 64 Holder with jointed arm

*Positioning:*

- Pull the release knob (Fig. 64,3). The jointed arm (Fig. 64,4) is unlocked.
- Swivel flat screen into the desired position.
- Take hold of the flat screen at the top and bottom edge with both hands and set the desired angle of inclination.

*Storing away:*

- Turn the flat screen back into the original position until the holder (Fig. 64,1) engages in the lock (Fig. 64,2).

### 6.7.3 Holder in the TV cabinet

The flat screen is attached to a console in the TV cabinet.




Fig. 65 Holder in the TV cabinet

*Positioning:*

- Push the unlocking bar (Fig. 65,1) in.
- Pull out the extension (Fig. 65,2) as far as possible.
- Swivel flat screen into the desired position.

*Storing away:*

- Swing back flat screen into its original position.
- Push in the extension (Fig. 65,2) until the unlocking bar (Fig. 65,1) engages.

### 6.7.4 Holder in the TV compartment

The flat screen is fixed to a lifting mechanism in the TV compartment.




Fig. 66 TV compartment




Fig. 67 Lifting mechanism

*Positioning:*

- Lightly depress the cover (Fig. 66,1) of the TV compartment in the centre. The extension column (Fig. 67,3) is released and starts to move upwards.
- Pull the release knob (Fig. 67,1) and swivel holder (Fig. 67,2) with flat screen to the desired position.

*Storing away:*

- Turn the flat screen back into the original position until holder (Fig. 67,2) engages in the lock.
- Press the middle of the cover (Fig. 66,1) downwards against the resistance of the extension column (Fig. 67,3) until the locking mechanism engages.

## 6.8 Ventilation



- ▶ The oxygen in the vehicle interior is used up by breathing and the use of gas operated appliances. That is why the oxygen needs to be replaced on a constant basis. For this purpose, forced ventilation options (e.g. skylights with forced ventilation, mushroom-shaped vents or floor vents) are fitted to the vehicle. Never cover or block forced ventilations from the inside or outside with objects such as e.g. a winter mat. Keep forced ventilations clear of snow and leaves. There is a danger of suffocation due to increased CO<sub>2</sub> levels.



- ▷ Although sufficient ventilation is provided, in certain weather conditions, condensation can form on metal objects (e.g. screwed connections in the floor).
- ▷ Additional cold spots can occur at thermal "bridges" (e.g. mushroom-shaped vents, skylight edges, sockets, filler necks, flaps, etc.).

### Condensation

Ensure that there is a continuous exchange of air by providing frequent and efficient ventilation. This is the only method for ensuring that condensation and resulting mould is not formed during cool weather. During the colder season, a pleasant living climate is created if heating output, air distribution and ventilation are synchronised. To avoid draft close the air outlet nozzles on the dashboard and set the air distribution of the base vehicle to air circulation.

If the vehicle is laid up for a longer period, occasionally ventilate it well, especially in summer as heat accumulation can occur. Do not only air the interior, but also the storage compartments which are accessible from the outside. Air the parking place as well if the vehicle is parked in a closed space (e.g. garage). The occurrence of condensation could lead to the formation of mould.

## 6.9 Windows



- ▷ The windows are fitted with a blind or Roman shade and with an insect screen or folding insect screen. After the latch has been released, the blind and insect screen automatically spring back to the initial position by tensile force. In order not to damage the tension mechanics, hold onto the blind or insect screen and allow it to slowly return to the initial position. The Roman shade and folding insect screen are made of thin woven fabric. In order not to damage the Roman shade or the insect screen, grasp the respective handle and carefully return it to the initial position.
- ▷ Do not keep blinds closed over a longer period of time as that can cause increased material wear.
- ▷ If the blind or the Roman shade is completely closed, exposure to direct sunlight can cause heat to accumulate between the blind/the Roman shade and the window. The window could be damaged.  
Therefore, if the shade is installed in the bottom blind box, close the shade only 2/3 when sunlight is intense. This allows the heat to escape between the window and the shade.  
If the shade is installed in the top blind box, close the shade fully and open it regularly.  
Also move the window into the "continuous ventilation" position.
- ▷ Before commencing the journey, close the windows.



- ▷ Depending on the weather, close the windows far enough to prevent moisture from entering.
- ▷ To open and close the window, open or close all catch levers which are fitted to the window.



- ▷ When leaving the vehicle, always close the windows.
- ▷ In extreme weather conditions or if the temperature fluctuates strongly, a light condensation film can form on the double-glazed acrylic glass. The glass is designed in such a way that condensation can evaporate when the external temperature increases. There is no danger of the double-glazed acrylic glass being damaged by condensation.

### 6.9.1 Hinged window with rotary hinges



- ▷ When opening the hinged windows, ensure that there are no torsional forces. Open and close the hinged windows evenly.
- ▷ If the catch lever is equipped with a safety knob, press the safety knob when operating the catch lever.




Fig. 68 Catch lever with safety knob in "closed" position




Fig. 69 Catch lever in "closed" position

- Opening:**
- Press and hold the security button (Fig. 68, 1), if present.
  - Turn the catch lever (Fig. 68, 2 or Fig. 69, 3) a quarter turn towards the centre of the window.




Fig. 70 Hinged window with rotary hinges

- Open the hinged window until the required position has been reached and use knurled knob (Fig. 70, 1) to secure in position.

The hinged window remains locked in the required position.

- Closing:**
- Turn knurled knob (Fig. 70, 1) until the latch is released.
  - Close the hinged window.

- Press and hold the security button (Fig. 68,1), if present.
- Turn the catch lever (Fig. 68,2 or Fig. 69,3) a quarter turn towards the window frame. The locking catch (Fig. 68,3 or Fig. 69,2) on the catch lever is entirely on the inner side of the window catch (Fig. 68,4 or Fig. 69,1).




Fig. 71 Catch lever with safety knob in "continuous ventilation" position




Fig. 72 Catch lever in the "continuous ventilation" position

### Continuous ventilation

With the catch lever, the hinged window can be placed in two positions:

- "Continuous ventilation" (Fig. 71 and Fig. 72)
- Firmly closed (Fig. 68 and Fig. 69)

To place the hinged window into the "continuous ventilation" position:

- Press and hold the security button (Fig. 71,1), if present.
- Turn the catch lever (Fig. 71,2 or Fig. 72,3) a quarter turn towards the centre of the window.
- Slightly open the hinged window outwards.
- Return the catch lever to its initial position. Move the locking catch (Fig. 71,3 or Fig. 72,2) on the catch lever into the recess of the window catch (Fig. 71,4 or Fig. 72,1).
- Press and hold the security button (Fig. 71,1), if present.
- Make certain that the safety knob is not pushed in but rather that it secures the catch lever.

During the journey, the hinged window may not be in "continuous ventilation" position.

If it rains, the "continuous ventilation" hinged window position could lead to splashing water penetrating the living area. Therefore, close the hinged windows completely.

### 6.9.2 Hinged window with automatic hinges



- ▷ Open the window completely, to release the lock. If the locking device is not released and the window is closed nevertheless, there is the danger of the window breaking due to the massive counter-pressure.
- ▷ When opening the hinged windows, ensure that there are no torsional forces. Open and close the hinged windows evenly.
- ▷ If the catch lever is equipped with a safety knob, press the safety knob when operating the catch lever.




Fig. 73 Catch lever with safety knob in "closed" position




Fig. 74 Catch lever in "closed" position

- Opening:*
- Press and hold the security button (Fig. 73,1), if present.
  - Turn the catch lever (Fig. 73,2 or Fig. 74,3) a quarter turn towards the centre of the window.



Fig. 75 Hinged window with automatic hinges

- Open the hinged window to the desired latched position. The automatic hinge (Fig. 75,1) locks in place automatically.

The hinged window remains locked in the required position.

- Closing:*
- Open the hinged window as wide as is necessary to release the lock.
  - Close the hinged window.
  - Press and hold the security button (Fig. 73,1), if present.
  - Turn the catch lever (Fig. 73,2 or Fig. 74,3) a quarter turn towards the window frame. The locking catch (Fig. 73,3 or Fig. 74,2) on the catch lever is entirely on the inner side of the window catch (Fig. 73,4 or Fig. 74,1).




Fig. 76 Catch lever with safety knob in "continuous ventilation" position




Fig. 77 Catch lever in the "continuous ventilation" position

### Continuous ventilation

With the catch lever, the hinged window can be placed in two positions:

- "Continuous ventilation" (Fig. 76 and Fig. 77)
- Firmly closed (Fig. 73 and Fig. 74)

To place the hinged window into the "continuous ventilation" position:

- Press and hold the security button (Fig. 76,1), if present.
- Turn the catch lever (Fig. 76,2 or Fig. 77,3) a quarter turn towards the centre of the window.
- Slightly open the hinged window outwards.
- Return the catch lever to its initial position. Move the locking catch (Fig. 76,3 or Fig. 77,2) on the catch lever into the recess of the window catch (Fig. 76,4 or Fig. 77,1).
- Press and hold the security button (Fig. 76,1), if present.
- Make certain that the safety knob is not pushed in but rather that it secures the catch lever.

During the journey, the hinged window may not be in "continuous ventilation" position.

If it rains, the "continuous ventilation" hinged window position could lead to splashing water penetrating the living area. Therefore, close the hinged windows completely.

### 6.9.3 Blind and insect screen



- ▷ Open blinds before commencing the journey. When the blinds are closed, vibrations can damage the spring shaft.

The windows are fitted with a blind and an insect screen. The blind and insect screen are adjusted separately.




Fig. 78 Hinged window

**Blind** The blind is located in the upper blind box.

- Closing:*
- Pull blind at the handle (Fig. 78,2) downwards. If the blind is to be completely closed, it is suspended into the locking devices (Fig. 78,3) situated on both sides of the window frame.
- Opening:*
- If the blind is completely closed: Press handle (Fig. 78,2) downwards and, at the same time, tilt it slightly inward. The blind can be taken out of the locking devices situated on both sides of the window frame.
  - If the blind is in an intermediate position: Pull the handle (Fig. 78,2) slightly downwards until the locking device releases.
  - Use handle to return blind slowly to its initial position.

**Insect screen** The insect screen is located in the upper blind box.

- Closing:*
- Pull insect screen at the handle (Fig. 78,1) down and hang it into the locking devices (Fig. 78,3) situated on both sides of the window frame.
- Opening:*
- Press handle (Fig. 78,1) downwards and, at the same time, tilt it slightly inward. The insect screen can be taken out of the locking devices situated on both sides of the window frame.
  - Use handle to return the insect screen slowly to its initial position.

### 6.9.4 Roman shade and insect screen

The windows are fitted with a Roman shade and an insect screen. Roman shade and insect screen are fixed to each other.




Fig. 79 Hinged window

**Roman shade** The Roman shade is located in the upper window frame.

- Closing:*
- Hold the Roman shade in the centre of the bottom rod (Fig. 79,2) and carefully draw it downwards.
  - Release the Roman shade at the desired position. The Roman shade will stay in that position.

- Opening:*
- Hold the bottom rod (Fig. 79,2) of the Roman shade in the centre and carefully slide the Roman shade upwards.

**Insect screen** The insect screen is located in the upper window frame.

- Closing:*
- Carefully pull down the insect screen by the handle (Fig. 79,1).
  - Move the insect screen continuously.

If the insect screen is not drawn fully to the bottom, the Roman shade can be stretched up to the end of the side window frame.

- Opening:*
- Slowly push the insect screen on the bottom rod of the Roman shade (Fig. 79,2) all the way up.

### 6.9.5 Roman shades for windscreen, driver's window and front passenger's window

Depending on the model, the driver's cabin is shaded either with pleated shades or with Remis Roman shades (special equipment).

**Pleated shades** The pleated shades are standard equipment on the vehicle.



Fig. 80 Pleated shades on passenger window



Fig. 81 Fixing of pleated shades

The pleated shades (Fig. 80,2) are fixed with snap fasteners (Fig. 80,1 and Fig. 81,1).

### Remis Roman shades (special equipment)

The Roman shades are fixed with magnetic strips and are permanently fitted to the vehicle inside the frame.

Proceed as described below to open or close permanently installed Roman shades.

#### Windscreen



Fig. 82 Roman shade for the windscreen

- Shading:*
- Press the release handles (Fig. 82,1) and hold them down.
  - Use the handle (Fig. 82,2) to pull the Roman shade for the windscreen towards the centre of the window.
  - Close the second Roman shade for the windscreen in the same way. A magnetic catch holds both parts of the Roman shade together in the centre.

- Opening the Roman shade:*
- Press the release handles (Fig. 82,1) and hold them down.
  - Use the handle (Fig. 82,2) to pull the two halves of the Roman shade for the windscreen outwards as far as they will go. As you do so, lift the handle up as high as the locking recess.
  - Let go of the release handles (Fig. 82,1) and let them engage.

#### Driver's window and front passenger's window




Fig. 83 Roman shade for driver's and passenger's window

- Shading:*
- Press the release handles (Fig. 83,1) and hold them down.
  - Using the handle (Fig. 83,2), draw the Roman shades for the driver's and passenger's window to the other side of the window and secure them to the magnetic strips.

Opening the Roman shade:

- Press the release handles (Fig. 83,1) and hold them down.
- Use handle (Fig. 83,2) to push in the Roman shades for the driver's and passenger's window as far as possible.
- Let go of the release handles (Fig. 83,1) and let them engage.

## 6.10 Skylights

Depending on the model, skylights with or without forced ventilation are fitted to the vehicle. If a skylight is fitted without forced ventilation, the forced ventilation is performed using mushroom-shaped vents.



- ▶ The apertures for forced ventilation must always be kept open. Never cover or block forced ventilations with objects such as e.g. a winter mat. Keep forced ventilations clear of snow and leaves.



- ▷ The skylights are fitted with a blind or Roman shade and with an insect screen or folding insect screen. After the latch has been released, the blind and insect screen automatically spring back to the initial position by tensile force. In order not to damage the tension mechanics, hold onto the blind or insect screen and allow it to slowly return to the initial position. The Roman shade and folding insect screen are made of thin woven fabric. In order not to damage the Roman shade or the insect screen, grasp the respective handle and carefully return it to the initial position.
- ▷ Do not keep blinds closed over a longer period of time as that can cause increased material wear.
- ▷ If the blind or the Roman shade is completely closed, exposure to direct sunlight can cause heat to accumulate between the blind/the Roman shade and the skylight. The skylight could be damaged. For that reason, close the blind/Roman shade only 2/3 of the way in direct sunlight. Open the skylight slightly or move it to ventilation position.
- ▷ Depending on the weather, close the skylights far enough to prevent moisture from entering.
- ▷ Do not climb on the skylights.
- ▷ Before commencing the journey, close the skylights.
- ▷ Before commencing the journey, check that the skylights are closed and locked.



- ▷ When leaving the vehicle, always close the skylights.

### 6.10.1 Heki skylight (mini and midi) (partially special equipment)




Fig. 84 Safety knob on the Heki skylight




Fig. 85 Heki skylight, guide

The Heki skylight is opened on one side only.

- Opening:**
- Press the safety knob (Fig. 84,2) and pull the bar (Fig. 84,1) down with both hands.
  - Pull the bar (Fig. 85,1) in the guides (Fig. 85,2) to the rearmost position (Fig. 85,3).

- Closing:**
- Use both hands to push the bar (Fig. 85,1) slightly upwards.
  - Push the bar back in the guides.
  - Push the bar upwards with both hands until it is above the safety knob (Fig. 84,2).




Fig. 86 Heki skylight in ventilation position




Fig. 87 Ventilation position locking mechanism

#### Ventilation position

The Heki skylight can be put in two ventilation positions: Bad weather position (Fig. 86,1) and central position (Fig. 86,2). Depending on the model, the skylight can be locked in the central position with the latch (Fig. 87,1).

- Press the safety knob (Fig. 84,2) and pull the bar (Fig. 84,1) down with both hands.
- Pull the bar in the guides (Fig. 85,2) to the desired position.
- Push the bar slightly upwards and into the selected guide (Fig. 86,1 or 2) and lock if necessary.

#### Roman shade

To close and open the Roman shade:

- Closing:**
- Pull out Roman shade at the handle and release in the required position. The Roman shade will stay in that position.

*Opening:* ■ Slowly push the Roman shade at the handle to its initial position.

**Insect screen** To close and open the insect screen:

*Closing:* ■ Pull the insect screen by the handle to the opposite handle of the Roman shade.

*Opening:* ■ Press the rear part of the handle of the insect screen. The latch is released.  
 ■ Use handle to return the insect screen slowly to its initial position.

### 6.10.2 Wind-up skylight (special equipment)




Fig. 88 Wind-up skylight

The wind-up skylight can be opened using the manual crank.

*Opening:* ■ Rotate the hand crank (Fig. 88,2) until a resistance can be felt.

*Closing:* ■ Rotate the hand crank until the wind-up skylight is closed. The wind-up skylight can be locked after rotating two or three more times.  
 ■ Check the locking mechanism. To do so, press your hand against the acrylic glass.

**Roman shade** The Roman shade can be closed in any position, as desired. If the Roman shade is locked with the insect screen, the insect screen is also moved along on closing the Roman shade.

*Closing:* ■ Pull the handle of the Roman shade (Fig. 88,3) and release in the desired position. The Roman shade will stay in that position.

*Opening:* ■ Slowly push the Roman shade at the handle to its initial position.

**Insect screen** If the insect screen is locked with the Roman shade, the Roman shade is also moved along on closing the insect screen.

*Closing:* ■ Pull insect screen at the handle (Fig. 88,1) to the opposite handle of the Roman shade (Fig. 88,3) and allow to engage.

*Opening:* ■ Press the handle of the insect screen (Fig. 88,1) at the back upwards and detach the insect screen from the Roman shade (Fig. 88,3).  
 ■ Slowly push insect screen at the handle to its initial position.

### 6.10.3 Omni-Vent skylight with fan (special equipment)



- ▷ To save the battery, after one hour the fan automatically switches from level 6 down to level 1.

The skylight is equipped with an insect screen, blind and an adjustable fan for ventilation.




Fig. 89 Skylight Omni-Vent




Fig. 90 Control panel for fan

**Opening:** ■ Turn the knob (Fig. 89,1) until the desired opening angle is reached.

**Closing:** ■ Turn the knob (Fig. 89,1) until the skylight is fully closed.

**Insect screen** To close and open the insect screen:

**Closing:** ■ Using the handle (Fig. 89,4) pull the insect screen across to the other side of the frame.

**Opening:** ■ Press the handle of the insect screen together. The latch is released.  
■ Use handle to return the insect screen slowly to its initial position.

**Shade** To close and open the shade:

**Closing:** ■ Press together the handle (Fig. 89,5) of the shade.  
■ Pull out the shade to the desired position and release. The shade will stay in that position.

**Opening:** ■ Press together the handle of the shade.  
■ Slowly return the shade to its initial position.

**Fan** If the skylight is open, the interior can be ventilated with the 6-speed fan (Fig. 89,3). The fan is operated via the operating panel (Fig. 89,2).

**Switching on:** ■ Press the On/Off button (Fig. 90,2). The fan runs in comfort mode (venting at slowest fan speed).

**Venting:** ■ To increase the fan speed: Press the Vent button (Fig. 90,1). The fan speed in the venting direction increases by one level. LEDs (Fig. 90,4) show the operating levels.  
■ To lower the fan speed: Press the Aerate button (Fig. 90,3). The fan speed decreases by one level.

- Aerating:*
- To increase the fan speed: Press the Aerate button (Fig. 90,3). The fan speed in the aerating direction increases by one step. LEDs (Fig. 90,4) show the operating levels.
  - To lower the fan speed: Press the Vent button (Fig. 90,1). The fan speed decreases by one level.

- Boost function:*
- Press and hold the Aerate button for approx. 3 seconds. The fan switches to the maximum aeration level and then, after approximately 5 minutes, automatically switches back to the previously selected level.
  - Press and hold the Vent button for approx. 3 seconds. The fan switches to the maximum venting level and then, after approximately 5 minutes, automatically switches back to the previously selected level.

- Switching off:*
- Press the On/Off button (Fig. 90,2). The fan stops, the LEDs go out.

#### 6.10.4 Skyroof skylight (partially special equipment)



- ▷ When opening the skylight, ensure that there are no torsional forces. Open and close the skylight evenly.




Fig. 91 Catch lever in "closed" position



Fig. 92 Skylight with rotary hinges, open

- Opening:*
- Turn all catch levers (Fig. 91,3) a quarter turn towards the centre of the skylight.
  - Open the skylight until the required position has been reached and use knurled knob (Fig. 92,1) to secure in position.

The skylight remains locked in the desired position.

- Closing:*
- Turn knurled knob (Fig. 92,1) until the latch is released.
  - Close the skylight.
  - Turn all catch levers (Fig. 91,3) a quarter turn towards the frame. The locking catch (Fig. 91,2) is located on the inside of the skylight lock (Fig. 91,1).




Fig. 93 Catch lever in the "continuous ventilation" position

**Continuous ventilation** With the catch levers, the skylight can be placed in 2 different positions:

- "Continuous ventilation" (Fig. 93)
- "Firmly closed" (Fig. 91)

To place the skylight into the "continuous ventilation" position:

- Turn all catch levers (Fig. 93,3) a quarter turn towards the centre of the skylight.
- Slightly push the skylight outwards.
- Return all catch levers to their initial position. The locking catch (Fig. 93,2) has to be moved into the recess of the skylight lock (Fig. 93,1).

During the journey, the skylight may not be in the "continuous ventilation" position.

If it rains, the "continuous ventilation" skylight position could lead to splashing water penetrating the living area. Therefore, close the skylight completely.



Fig. 94 Skyroof skylight

**Roman shade** The Roman shade is fitted in the frame, at the bottom.

- Closing:*
- Hold the Roman shade in the centre of the bottom rod and carefully draw it upwards.
  - Release the Roman shade at the desired position. The Roman shade will stay in that position.
- Opening:*
- Carefully return the bottom rod of the Roman shade downwards to the limit stop on the frame.

**Insect screen** The insect screen is fitted in the frame, at the top.

- Closing:*
- Hold the insect screen in the centre of the bottom rod and carefully pull it down.
  - Continuous adjustment of the insect screen may be made by moving the bottom rod.

- Opening:*
- Carefully return the bottom rod of the insect screen upwards to the limit stop on the frame.

## 6.11 Tables

Depending on the model and equipment, various types of tables may be installed. The tables' features differ in the following ways:

|                         | Table leg   | Table-top   | Conversion to bed foundation   |
|-------------------------|---|---|--|
| <b>Fixed table</b>      | Screwed into the floor  | <ul style="list-style-type: none"> <li>● Extendible</li> <li>● Moveable</li> <li>● Rotatable</li> </ul> | Not possible   |
| <b>Suspension table</b> | <ul style="list-style-type: none"> <li>● Changeable</li> <li>● Foldable</li> <li>● Divisible</li> </ul> | <ul style="list-style-type: none"> <li>● Extendible</li> <li>● Moveable</li> </ul>                      | Hang the table-top from the top into the bottom mounting rail <ul style="list-style-type: none"> <li>● Unfold the table leg</li> <li>● Change the table leg</li> <li>● Divide the table leg</li> </ul> |
| <b>Lift-off table</b>   | Lifting mechanism   | <ul style="list-style-type: none"> <li>● Moveable</li> <li>● Rotatable</li> </ul>                       | Lower the table  |



- ▷ Depending on the model, the tables can be adjusted in one or more of the aforementioned ways.

The tables' main operation is described below. The type and position of the operating controls may vary slightly.

### 6.11.1 Fixed table

**Table leg** The table leg is screwed into the floor.  
The fixed table cannot be used as a bed foundation.

**Table-top** Depending on the model, the table-top can be extended, slid or rotated.

### Swing-out table extension

The table surface can be expanded by swinging out the table extension.




Fig. 95 Swing-out table extension

#### Expanding the table:

- Pull the knob (Fig. 95,3) of the lock down and swing out the table extension (Fig. 95,2).

#### Reducing the table size:

- Swing the table extension (Fig. 95,2) under the table-top (Fig. 95,1) until the lock latches in place audibly.

### Unfolding table extension

The foldable table-top can be rotated and moved crossways.



- ▷ Pull out the support frame before folding down the table-top. The hinges could otherwise be damaged.




Fig. 96 Supporting frame




Fig. 97 Adjusting mechanism

#### Folding out the table top:

- Pull out the support frame (Fig. 96,2) below the table top (Fig. 96,1) to the end position.
- Fold out the table top and carefully rest it on the support frame.

#### Folding the table-top closed:

- Lift up the part of the table top that is folded out and place it carefully on the fixed part of the table top.
- Push in the support frame to the end position underneath the table top.

### Adjusting the table-top

Depending on the model, the table-top can be rotated, slid in one direction or slid both lengthwise and crosswise.

#### Moving the table-top:

- Loosen knurled screw (Fig. 97,1).
- Move the table-top to the desired position.
- Tighten the knurled screw.

*Rotating table-top:*

- Raise the adjustment knob (Fig. 97,2).
- Rotate the table-top into the desired position (locks in place depending on the model).
- Allow the adjustment knob to click back into position.



- ▷ The adjustment knob for rotating the table-top may also be located below on the table leg. If so, the adjustment knob is operated by foot.




Fig. 98 Moving the table-top (alternative)

*Moving in a lengthways direction:*

- Loosen knurled screw (Fig. 98,1).
- Move table-top (Fig. 98,2) to the desired position.
- Tighten the knurled screw.

*Moving in a crossways direction:*

- Loosen knurled screw (Fig. 98,3).
- Move table-top (Fig. 98,2) to the desired position.
- Tighten the knurled screw.

### 6.11.2 Suspension table

#### Table leg

The table leg can be set up at two different heights:

- Normal table height
- Decreased table height (when converting to a bed foundation)

To lower the table, there are the following possibilities (depending on model):

- Replace the long table leg with a short one
- Fold in one part of the table leg
- Remove one part of the table leg

#### Table-top

Depending on the model, the table-top can be extended.

### Swing-out table extension

The table surface can be expanded by swinging out the table extension.




Fig. 99 Swing-out table extension




Fig. 100 Lock

#### Expanding the table:

- Pull the knob (Fig. 99,3) of the lock down and swing out the table extension (Fig. 99,2).

#### Reducing the table size:

- Swing the table extension (Fig. 99,2) under the table-top (Fig. 99,1) until the lock latches (Fig. 100,1) in place audibly.

### Insertable table extension

The suspension table size can be enlarged by inserting a table extension.



Fig. 101 Insertable table extension




Fig. 102 Catch

#### Expanding the table:

- Open catches (Fig. 102,1).
- Raise the table-top (Fig. 101,2) slightly and pull it out as far as possible.
- Set down the table.
- Insert the table extension (Fig. 101,1) and secure it with the catch (Fig. 102,1).
- Lift the table-top slightly and push back as far as possible.
- Secure the table-top with the catches.

#### Reducing the table size:

- Open catches (Fig. 102,1).
- Slightly lift the front of the table-top and pull out.
- Remove table extension (Fig. 101,1) and lay it aside.
- Lift the table-top slightly and push back as far as possible.
- Set down the table.
- Secure the table-top with the catches.



- ▷ The extension frame beneath the table-top is locked into the mounting rail. Release the lock before lifting the table-top.

*Conversion to bed foundation:*

- Lift the front of the table-top by approx. 45°.
- Depending on the model, shorten the table leg to the conversion level.
- Release the lock (Fig. 100,1) on the table top.
- Take the table-top out of the upper retainer.
- Hook the table-top at a 45° angle to the supports into the lower retainer and place on the floor with the shortened table leg.
- Lock the table-top.

### 6.11.3 Lift-off table

**Table leg**

The table leg is screwed into the floor. The table can be lowered via a lifting mechanism to become a bed foundation.

**Adjusting the table-top**

Depending on the model, the table-top can be rotated, slid in one direction or slid both lengthwise and crosswise.




Fig. 103 Adjustment of lift-off table




Fig. 104 Adjustment of lift-off table (alternative)

*Moving in a lengthways direction:*

- Loosen the knurled screw (Fig. 103,5) or push the lever (Fig. 104,1) down.
- Push the table-top (Fig. 103,1) into the desired position.
- Turn the knurled screw tight or release the lever.

*Moving in a crossways direction:*

- Loosen the knurled screw (Fig. 103,3) or push the lever (Fig. 104,1) down.
- Push the table-top (Fig. 103,1) into the desired position.
- Turn the knurled screw tight or release the lever.



Fig. 105 Rotating the table-top

*Rotating table-top:*

- Press the adjustment knob (Fig. 105,1) with your foot.
- Rotate the table-top into the desired position (locks in place depending on the model).
- Allow the adjustment knob to click back into position.



- ▷ Before lowering the table-top, remove the cushions from the benches or adjust the table-top depending on the installation dimensions.

#### *Conversion to bed foundation:*

- Swivel the lever (Fig. 103,2 or Fig. 104,2) underneath the table-top by 180° in an anticlockwise direction. The lifting mechanism in the table leg (Fig. 103,4) is unlocked.
- Push the table-top downwards as far as possible and hold it in that position. In doing so, press from the centre of the table-top.
- Swivel back the lever by 180° in a clockwise direction. The table-top remains in the lowest position.

#### *Moving the table-top upwards:*

- Swivel the lever (Fig. 103,2 or Fig. 104,2) underneath the table-top by 180° in an anticlockwise direction. The table-top moves upwards to the limit stop.
- Swivel back the lever by 180° in a clockwise direction. The table-top remains in the uppermost position.

## 6.12 Beds

### 6.12.1 Fixed bed (gas-pressure springs)



Fig. 106 Fixed bed

A storage compartment is underneath the bed. Lift up the slatted frame to place items in the storage compartment or to empty it from the inside of the vehicle.

- Opening:*
- Lift the mattress forwards.
  - Lift slatted frame. The gas-pressure springs (Fig. 106,1) hold the slatted frame open.
- Closing:*
- Press the slatted frame downwards against the resistance of the gas-pressure springs.

### 6.12.2 Fixed bed (adjustable head section)



▶ Do not let the slatted frame fall down when closing the bed!



Fig. 107 Adjustable head section

Depending on the configuration, the head section of the slatted frame can be adjusted in several stages.

*Raising the head section:*

- Raise the head section (Fig. 107,2) of the slatted frame to the desired position. The support (Fig. 107,1) locks automatically into place.

The head section remains locked in the required position.

*Lowering the head section:*

- Raise the head section (Fig. 107,2) of the slatted frame until the lock is released.
- Guide the head section downwards slowly.

### 6.12.3 Fixed bed, electrically adjustable (partially special equipment)



Fig. 108 Fixed bed, pulled out



Fig. 109 Fixed bed, retracted

The fixed bed (Fig. 108) can be adjusted in length via a manual control unit. This simplifies passage around the bed. When the foot section of the bed is shortened, the head sections are positioned at the same time (Fig. 109).




Fig. 110 Manual control unit

**Retracting:**

- On the manual control unit (Fig. 110,3) push the "▼" button (Fig. 110,2) and keep it pressed. The foot section is retracted. The head sections are raised.

**Extending:**

- On the manual control unit (Fig. 110,3) push the "▲" button (Fig. 110,1) and keep it pressed. The foot section is extended. The head sections are lowered.

**Adjusting the head sections:**

- On the manual control unit (Fig. 110,3), press the "▼" button (Fig. 110,2) or "▲" button (Fig. 110,1) until the desired position is reached.

The head sections remain in the desired position.




Fig. 111 Drive

### Emergency operation

Proceed as follows if the bed can no longer be adjusted via the manual control unit:

- Remove the connection (e.g. pin and cotter pin (Fig. 111,1 and 3)) between the push rod (Fig. 111,2) and the slatted frame (Fig. 111,4).
- Slowly push the slatted frame all the way forward. When doing this, hold onto the head sections of the slatted frames.
- Contact customer service.

#### 6.12.4 Bunk bed



- ▶ Only use the upper bunk bed if the safety guard is fitted.
- ▶ The maximum permitted bunk bed load is 100 kg.
- ▶ The upper bunk bed must not be used by children under 6 years of age.
- ▶ Never allow small children to remain in the bunk bed without supervision.



- ▶ But in particular with regard to small children less than 6 years of age, users should ensure that they cannot fall out of the bunk bed.
- ▶ Use separate children's beds or travel cots suitable for children.

Depending on the model, the vehicle is fitted with a bunk bed. The bunk bed can be used immediately, without additional conversion.

Always use the access ladder provided to climb up to the top bed.

### 6.12.5 Pull-down bed, manually operated (Ixeo series)



- ▶ Switch off the reading lamps in the pull-down bed before the bed is pushed up. Fire hazard!
- ▶ Switch off the reading lamps on the underside of the pull-down bed when the bed is lowered. Fire hazard!
- ▶ The maximum permitted pull-down bed load is 200 kg.
- ▶ Before commencing the journey, secure the pull-down bed. To do this, lock the pull-down bed.
- ▶ Before use, pull the pull-down bed into the lower end position. Ensure that the pull-down bed is not resting on obstacles such as headrests, cushions or similar.
- ▶ Only use the pull-down bed, if the safety net is set up.
- ▶ Never allow small children to remain in the pull-down bed without supervision.
- ▶ But in particular with regard to small children less than 6 years of age, users should ensure that they cannot fall out of the pull-down bed.
- ▶ Use separate children's beds or travel cots suitable for children.



- ▷ You must be able to close the pull-down bed without any great effort, so that there is no tension in the locking position. Objects on the pull-down bed can distort the lifting mechanism on one side, resulting in damage.




Fig. 112 Release



Fig. 113 Pull-down bed complete with applied safety net

The pull-down bed is located above the front seating group.

The pull-down bed has two locking positions in the uppermost position. The pull-down bed is securely locked in both locking positions.

#### Opening the pull-down bed:

- Remove obstacles from the space into which the pull-down bed extends (e.g. push the seats forward and rotate, remove or move cushions).
- Switch off the lamps underneath the pull-down bed.

- Pull out the release area (Fig. 112,1) at the bottom. The lock is released.
- With both hands, pull the pull-down bed down as far as it will go.
- If the pull-down bed was in the uppermost locking position: Pull the release area out again to override the second locking position. With both hands, pull the pull-down bed down as far as it will go.
- Make sure that the pull-down bed is in the lower end position and is not resting on obstacles such as headrests or cushions.



- ▷ When closing the pull-down bed, pull the side fabric panels inwards. This prevents the fabric from getting trapped in the lock of the pull-down bed.

#### *Closing the pull-down bed:*

- Switch off the reading lamps in the pull-down bed.
- Using both hands, push the pull-down bed upwards as far as the first locking position. If necessary, push the pull-down bed further upwards as far as the uppermost locking position. When doing this, ensure that the snap latch engages audibly in the locking bracket.
- Check that the pull-down bed is locked correctly. To do this, pull down the pull-down bed firmly.

#### **Safety net**

The safety net (Fig. 113,2) and the retaining belts are located underneath the mattress in the pull-down bed. Only use the safety net if persons are already in the pull-down bed.

#### *Setting up:*

- Attach the retaining belts (Fig. 113,1) to the hooks on the ceiling.

#### **Access ladder**

Always use the provided access ladder (Fig. 113,5) to climb up to the pull-down bed.

#### *Attaching:*

- Hook access ladder (Fig. 113,5) to the pull-down bed by attaching the two hooks (Fig. 113,4) in the holding bar (Fig. 113,3).

#### *Storing away:*

- Hang the access ladder (Fig. 113,5) from the holding bar (Fig. 113,3) on the pull-down bed.
- Store the access ladder securely.

### **6.12.6 Pull-down bed, electrically operated (special equipment, Ixeo series)**



- ▶ Switch off the reading lamps in the pull-down bed before the bed is pushed up. Fire hazard!
- ▶ Switch off the reading lamps on the underside of the pull-down bed when the bed is lowered. Fire hazard!
- ▶ The maximum permitted pull-down bed load is 200 kg.
- ▶ Do not reach into the area between the bed and the side wall when lowering or raising. Danger of bruises!
- ▶ Do not lower or lift the bed when there are people using the pull-down bed.
- ▶ Only lower the bed if the lowering area is clear.



- ▶ Bring the pull-down bed into the lower end position before use. Ensure that the pull-down bed is not resting on obstacles such as headrests, cushions or similar.
- ▶ Do not allow children to play with the pull-down bed.
- ▶ Store the remote control in a safe place inaccessible to children.
- ▶ Only use the pull-down bed, if the safety net is set up.
- ▶ Use separate children's beds or travel cots suitable for children.
- ▶ Never allow small children to remain in the pull-down bed without supervision.
- ▶ But in particular with regard to small children less than 6 years of age, users should ensure that they cannot fall out of the pull-down bed.



- ▷ Only raise or lower the pull-down bed if it is loaded with a maximum of 15 kg. This maximum load includes the contents of the wall-mounted cupboard at the base of the pull-down bed. If the pull-down bed is overloaded, the overload protection switches off the lifting motor. However, the lifting mechanism can still be damaged.
- ▷ Before starting a journey, the pull-down bed must be brought into the uppermost end position. No objects must be stuck between the roof and the pull-down bed.



Fig. 114 Manual control unit



Fig. 115 Pull-down bed complete with applied safety net



- ▶ When making ready for operation, overload protection is not in use.

**Making ready for operation**

*Carrying out a reference run:*

After every power interruption (e.g. lay-up over winter), the electrical drive must be made ready for operation again. To do so carry out a reference run.

- Using the arrow key (Fig. 114,3) on the manual control unit, bring the pull-down bed down as far as it will go or into any intermediate position.
- Press the "R" key (Fig. 114,2) three times in a row.
- Within 10 seconds, bring the pull-down bed upwards using the arrow key (Fig. 114,4).
- When the end position is reached, a beeping noise is emitted. Release the arrow key.

*Opening the pull-down bed:*

- Remove obstacles from the space into which the pull-down bed extends (e.g. push the seats forward and rotate, remove or move cushions).
- Switch off the lamps underneath the pull-down bed.

- On the manual control unit (Fig. 114,1), press the arrow key (Fig. 114,3) and keep it pressed until the pull-down bed has moved downwards to its end position.
- Make sure that the pull-down bed is in the lower end position and is not resting on obstacles such as headrests or cushions.

*Closing the pull-down bed:*

- Switch off the reading lamps in the pull-down bed.
- On the manual control unit (Fig. 114,1), press the arrow key (Fig. 114,4) and keep it pressed until the pull-down bed has moved up into its end position.
- Ensure that there are no objects stuck between the roof and the pull-down bed.

**Overload protection**

If the pull-down bed meets an obstacle during opening or closing (e.g. a person or a headrest), the overload protection stops the movement. For release, move the pull-down bed with the arrow key in the opposite direction.

**Safety net**

The safety net (Fig. 115,2) and the retaining belts are located underneath the mattress in the pull-down bed. Only use the safety net if persons are already in the pull-down bed.

*Setting up:*

- Attach the retaining belts (Fig. 115,1) to the hooks on the ceiling.

**Access ladder**

Always use the provided access ladder to climb up to the pull-down bed.

*Attaching:*

- Hook access ladder (Fig. 115,5) to the pull-down bed by attaching the two hooks (Fig. 115,4) in the holding bar (Fig. 115,3).

*Storing away:*

- Hang the access ladder (Fig. 115,5) from the holding bar (Fig. 115,3) on the pull-down bed.
- Store the access ladder securely.




Fig. 116 Access to drive




Fig. 117 Drive

**Emergency operation**

If the pull-down bed can no longer be moved via the manual control unit (e.g. due to loss of the vehicle's power supply), it can also be operated manually. To do this, proceed as follows:

- Depending on the model, open the flap of the wall-mounted cupboard (Fig. 116,1) and remove the cover from the access port (Fig. 116,2).
- Detach the pin and cotter pin (Fig. 117,2) between the push rod (Fig. 117,1) and lever (Fig. 117,3).
- Open or close the pull-down bed manually.
- Contact customer service.

### 6.12.7 Bed widening (short) for single beds (special equipment)



- ▶ Make sure that the access ladder is correctly locked in place in both side rails. Otherwise there is a danger of injury from the access ladder pulling out.

The bedside table surface can be lengthened. Then an extra cushion connects the two sleeping areas.




Fig. 118 Pull out bed widening




Fig. 119 Bed widening with access ladder

- Reach under the panel (Fig. 118,2) and pull out the extension (Fig. 118,1) as far as possible.
- Swivel panel (Fig. 119,3) downwards. The panel is held in place with magnet fasteners.
- Unlock the access ladder (Fig. 119,4) and pull it out slightly from the rails (Fig. 119,2).
- Pull the access ladder out of the rails until the axle of the running pole has stable seating in the rails and is locked in place.
- Place the access ladder on the floor.
- Place the additional cushion (Fig. 119,1) on the bed widening.

### 6.13 Converting seating groups for sleeping

The seating groups installed in the vehicles can be divided into three categories:

- Individual bench seats that can be converted into an emergency bed.
- Seating groups with a lateral individual seat or lateral bench seat, which can be converted into a transverse bed.
- Seating groups with bed widening, which can be converted into a length-wise bed.

The following table gives an overview of the seating groups installed in the different models and names the section in which the bed conversion is described.



- ▷ The ground plans for the individual models are shown in chapter 16.

| Model  | Seating group                            | Table type                              | Bed            | Section |
|--------|--|---|----------------|---------|
| T 569  | Individual bench                         | Suspension table with rotating platform | Guest bed      | 6.13.1  |
| T 571  | Individual bench with lateral seat       | Suspension table with extension         | Transverse bed | 6.13.6  |
| T 620  | Individual bench with lateral seat       | Suspension table with extension         | Transverse bed | 6.13.6  |
| T 660  | Individual bench with lateral bench seat | Suspension table with rotating platform | Transverse bed | 6.13.5  |
| T 660  | L-seating group with lateral bench seat  | Lift-off table                          | Transverse bed | 6.13.9  |
| T 687  | Individual bench with lateral seat       | Suspension table with rotating platform | Guest bed      | 6.13.1  |
| T 687  | L-seating group with individual seat     | Lift-off table                          | Guest bed      | 6.13.1  |
| T 715  | Individual bench with lateral bench seat | Suspension table with rotating platform | Transverse bed | 6.13.4  |
| T 715  | L-seating group with lateral bench seat  | Lift-off table                          | Transverse bed | 6.13.12 |
| T 720  | Individual bench with lateral seat       | Suspension table with rotating platform | Transverse bed | 6.13.5  |
| T 720  | L-seating group with lateral seat        | Lift-off table                          | Transverse bed | 6.13.9  |
| T 728  | Individual bench with lateral seat       | Suspension table with rotating platform | Transverse bed | 6.13.3  |
| T 728  | L-seating group with lateral seat        | Lift-off table                          | Transverse bed | 6.13.14 |
| T 729  | Individual bench with lateral bench seat | Suspension table                        | Transverse bed | 6.13.3  |
| T 729  | L-seating group with lateral seat        | Lift-off table                          | Transverse bed | 6.13.14 |
| T 740  | Individual bench with lateral seat       | Suspension table with rotating platform | Transverse bed | 6.13.6  |
| T 740  | L-seating group with lateral seat        | Lift-off table                          | Transverse bed | 6.13.14 |
| IT 585 | L-seating group with lateral bench seat  | Lift-off table                          | Transverse bed | 6.13.12 |
| IT 590 | L-seating group with lateral bench seat  | Lift-off table                          | Transverse bed | 6.13.10 |

| Model  | Seating group                            | Table type                              | Bed                              | Section |
|--------|--|---|----------------------------------|---------|
| IT 650 | Facing seating unit                      | Suspension table                        | Lengthwise bed with bed widening | 6.13.2  |
| IT 660 | Facing seating unit                      | Suspension table                        | Lengthwise bed with bed widening | 6.13.2  |
| IT 664 | Individual bench with lateral bench seat | Suspension table with rotating platform | Transverse bed                   | 6.13.12 |
| IT 670 | Individual bench                         | Suspension table with rotating platform | Guest bed                        | 6.13.1  |
| IT 695 | L-seating group with lateral bench seat  | Fixed table                             | -                                | -       |
| IT 700 | L-seating group with lateral bench seat  | Fixed table                             | -                                | -       |
| IT 710 | Individual bench with lateral bench seat | Suspension table with rotating platform | Transverse bed                   | 6.13.4  |
| IT 710 | L-seating group with lateral bench seat  | Lift-off table                          | Transverse bed                   | 6.13.12 |
| IT 724 | Individual bench with lateral bench seat | Suspension table with rotating platform | Transverse bed                   | 6.13.4  |
| IT 724 | L-seating group with lateral bench seat  | Lift-off table                          | Transverse bed                   | 6.13.12 |
| IT 726 | Individual bench with lateral bench seat | Suspension table with rotating platform | Transverse bed                   | 6.13.4  |
| IT 726 | L-seating group with lateral bench seat  | Lift-off table                          | Transverse bed                   | 6.13.12 |
| IT 734 | Individual bench with lateral bench seat | Suspension table with rotating platform | Transverse bed                   | 6.13.3  |
| IT 734 | L-seating group with lateral seat        | Lift-off table                          | Transverse bed                   | 6.13.14 |
| IT 735 | Individual bench with lateral bench seat | Suspension table with rotating platform | Transverse bed                   | 6.13.3  |
| IT 735 | L-seating group with lateral seat        | Lift-off table                          | Transverse bed                   | 6.13.14 |
| IT 740 | Individual bench with lateral bench seat | Suspension table with rotating platform | Transverse bed                   | 6.13.4  |
| IT 740 | L-seating group with lateral bench seat  | Lift-off table                          | Transverse bed                   | 6.13.12 |

| Model  | Seating group                            | Table type       | Bed            | Section |
|--------|--|------------------|----------------|---------|
| IT 745 | Individual bench with lateral bench seat | Suspension table | Transverse bed | 6.13.7  |
| IT 745 | L-seating group with lateral bench seat  | Lift-off table   | Transverse bed | 6.13.13 |
| IT 875 | L-seating group with lateral bench seat  | Lift-off table   | Transverse bed | 6.13.8  |

### 6.13.1 Small central seating group




Fig. 120 Prior to conversion




Fig. 121 After conversion

- Turn the driver's seat (Fig. 120,4) and push it all the way forward.
- Convert the table (Fig. 120,3) to a bed foundation (see section 6.11).
- Lay the back cushion (Fig. 120,1) aside.
- Place the additional cushion (Fig. 121,5) on the table.
- If required, push the driver's seat (Fig. 121,4) back to the rear.

### 6.13.2 Central seating group with bed widening




Fig. 122 Prior to conversion




Fig. 123 During conversion




Fig. 124 After conversion

- Extend the table (Fig. 122,3) and convert it into a bed foundation (see section 6.11).
- Widen bench seat (Fig. 123,4).
- Remove the back cushions (Fig. 123,1) and lay them aside.
- Pull the seat cushions (Fig. 123,2) into the centre.
- Insert the additional cushion (Fig. 124,5) onto the table between the seat cushions.
- Insert the additional cushions (Fig. 124,6) between the seat cushions and the wall.

### 6.13.3 Central bench with divan (with bed widening)




Fig. 125 Prior to conversion




Fig. 126 During conversion




Fig. 127 After conversion

- Convert the table (Fig. 125,3) to a bed foundation (see section 6.11).
- Remove the back cushion (Fig. 125,1) and place them on the table.
- Place the seat cushion (Fig. 127,5) in the centre.
- Place the back cushion (Fig. 127,4) between the seat cushion and the wall.
- Hook the bed widening (Fig. 127,6) into the recesses on the bench seats.
- Place the additional cushion (Fig. 127,7) on the bed widening.

### 6.13.4 Central bench with divan




Fig. 128 Prior to conversion




Fig. 129 During conversion




Fig. 130 After conversion

- Convert the table (Fig. 128,3) to a bed foundation (see section 6.11).
- Remove the back cushion (Fig. 128,1) and lay it aside.



- ▷ Depending on the model, the back cushion (Fig. 128,1) can be used instead of the additional cushion (Fig. 129,6).

- Unfold the additional cushion (Fig. 129,6) and lay it on the table.
- Place the seat cushion (Fig. 130,5) in the centre.
- Place the back cushion (Fig. 130,4) between the seat cushion and the wall.

### 6.13.5 Central bench with divan (with bed widening)




Fig. 131 Prior to conversion




Fig. 132 During conversion




Fig. 133 After conversion

- Convert the table (Fig. 131,3) to a bed foundation (see section 6.11).
- Remove the back cushion (Fig. 131,1) and lay it aside.
- Unfold the additional cushion (Fig. 132,6) and lay it on the table.
- Place the seat cushion (Fig. 133,5) in the centre.
- Place the back cushion (Fig. 133,4) between the seat cushion and the wall.
- Hook the bed widening (Fig. 133,7) into the recesses on the bench seats.
- Place the additional cushion (Fig. 133,8) on the bed widening.

### 6.13.6 Central bench with divan (Van)




Fig. 134 Prior to conversion

- 1 Back cushion
- 2 Seat cushion
- 3 Table
- 4 Back cushion
- 5 Seat cushion
- 6 Bedding box extension
- 7 Additional cushion (foldable)
- 8 Seat base extension
- 9 Bed widening
- 10 Additional cushion




Fig. 135 During conversion




Fig. 136 After conversion

- Convert the table (Fig. 134,3) to a bed foundation (see section 6.11).
- Remove the back cushion (Fig. 134,1) and lay it aside.



- ▷ Depending on the model, the back cushion (Fig. 134,1) can be used instead of the additional cushion (Fig. 135,7).

- Remove the back cushion (Fig. 134,4) and the seat cushion (Fig. 134,5) and lay them aside.
- Pull out the bedding box extension (Fig. 135,6).
- Fold the seat base extension (Fig. 135,8) outwards.
- Unfold the additional cushion (Fig. 135,7) and lay it on the table.
- Place the seat cushion (Fig. 136,5) in the centre.
- Place the back cushion (Fig. 136,4) between the seat cushion and the wall.
- Hook the bed widening (Fig. 135,9) into the recesses on the bench seats.
- Place the additional cushion (Fig. 136,10) on the bed widening.

### 6.13.7 Centre bench with divan on the left




Fig. 137 Prior to conversion




Fig. 138 During conversion




Fig. 139 After conversion

- Convert the table (Fig. 137,3) to a bed foundation (see section 6.11).
- Remove and put aside the back cushions (Fig. 137,1 and Fig. 137,5) and the seat cushion (Fig. 137,2).
- Fold open both bench seat covers (Fig. 138,6) and lay them down on the table and the supports on the bench.
- Place the back cushions (Fig. 138,1) on the bench seat.
- Place the seat cushions (Fig. 139,2) on the unfolded bench seat cover.
- Unfold the extra cushion (Fig. 139,7) and lay it on the table in front of the seat cushion (Fig. 139,4).

### 6.13.8 L-shaped bench with divan




Fig. 140 Prior to conversion




Fig. 141 During conversion




Fig. 142 After conversion

- Convert the table (Fig. 140,3) to a bed foundation (see section 6.11).
- Remove the back cushions (Fig. 140,1 and 4) and lay them aside.
- Place the additional cushion (Fig. 141,8) on the table.
- Place the seat cushion (Fig. 142,7) in the centre.
- Place the back cushion (Fig. 142,6) between the seat cushion and the wall.

### 6.13.9 L-shaped bench with divan (with bed widening)




Fig. 143 Prior to conversion




Fig. 144 During conversion




Fig. 145 After conversion

- Convert the table (Fig. 143,3) to a bed foundation (see section 6.11).
- Remove the back cushion (Fig. 143,1) and lay it aside.
- Place the back cushion (Fig. 144,4) next to the seat cushion (Fig. 144,2).
- Unfold the supports of the bed extension (Fig. 144,8) and hang the bed extension from the holders on the bench seat.
- Place the seat cushion (Fig. 145,7) in the centre.
- Insert the back cushion (Fig. 145,6) between the seat cushion (Fig. 145,7) and the wall.
- Place the additional cushion (Fig. 145,9) on the bed widening.

**6.13.10 L-shaped bench (long) with divan**




Fig. 146 Prior to conversion




Fig. 147 During conversion




Fig. 148 After conversion

- Convert the table (Fig. 146,3) to a bed foundation (see section 6.11).
- Remove the back cushions (Fig. 146,1, 4 and 8) and lay them aside.
- Unfold the additional cushion (Fig. 148,9) and lay it on the table.

### 6.13.11 L-shaped bench with divan (without extra cushions)




Fig. 149 Prior to conversion




Fig. 150 During conversion




Fig. 151 After conversion

- Convert the table (Fig. 149,3) to a bed foundation (see section 6.11).
- Remove the back cushions (Fig. 149,1 and 8) and lay them aside.
- Place the back cushion (Fig. 151,4) on the table.
- Place the back cushion (Fig. 151,9) on the table.

### 6.13.12 L-shaped bench with divan




Fig. 152 Prior to conversion




Fig. 153 During conversion




Fig. 154 After conversion

- Convert the table (Fig. 143,3) to a bed foundation (see section 6.11).
- Remove the back cushion (Fig. 143,1) and lay it aside.
- Place the back cushion (Fig. 144,4) next to the seat cushion (Fig. 144,2).
- Place the seat cushion (Fig. 145,7) in the centre.
- Place the back cushion (Fig. 145,6) between the seat cushion and the wall.

### 6.13.13 L-shaped bench on the right with a divan on the left




Fig. 155 Prior to conversion




Fig. 156 During conversion




Fig. 157 After conversion

- Convert the table (Fig. 155,3) to a bed foundation (see section 6.11).
- Remove the back cushions (Fig. 155,5, 6 and 9) and lay them aside.
- Remove the seat cushions (Fig. 155,2), fold the seat box extension (Fig. 156,10) outward and rest it in the holder.
- Lay the back cushions (Fig. 156,1) on the divan.
- Lay the seat cushions (Fig. 157,2) on the table and the seat box extension.
- Place the back cushion (Fig. 157,6) on the table.

### 6.13.14 L-shaped bench with divan (with angled bed widening)




Fig. 158 Prior to conversion




Fig. 159 During conversion




Fig. 160 After conversion

- Convert the table (Fig. 158,3) to a bed foundation (see section 6.11).
- Remove the back cushion (Fig. 158,1) and lay it aside.
- Place the back cushion (Fig. 159,4) next to the seat cushion (Fig. 159,2).
- Unfold the support of the bed extension (Fig. 159,8) and hang the bed extension into the holders on the bench seats.
- Place the seat cushion (Fig. 160,7) in the centre.
- Insert the back cushion (Fig. 160,6) between the seat cushion (Fig. 160,7) and the wall.
- Place the additional cushion (Fig. 160,9) on the bed widening.

## 6.14 Shower connection point for external shower (special equipment)



- ▶ Only use the external shower if there is a gap of at least 1.20 m between the shower and the nearest electrical device or connection. Risk of electric shock!



- ▷ If decommissioned for a longer time or if there is a risk of frost, drain the water system.




Fig. 161 External shower connection point

### Connecting an external shower:

- Unlock and open the cover (Fig. 161,4).
- Attach hose of the external shower to the quick closure (Fig. 161,3).

### Using the shower:

- Switch on the water pump using the switch (Fig. 161,2).
- Adjust the water temperature with the rotary knob (Fig. 161,1) as desired.
- Switch off the water pump using the switch (Fig. 161,2).

### Shutting off the shower connection point:

- Switch off the water pump using the switch (Fig. 161,2).
- Disconnect the hose from the quick closure. The quick closure is equipped with a check valve to prevent any further water from escaping.
- Close the cover (Fig. 161,4) and lock with key.

### Emptying:

- Attach hose of external shower to quick closure. The check valve is opened and the connections can run dry.
- Turn knob (Fig. 161,1) to the centre position.
- Empty the water system (see section 10.5).

## Chapter overview

This chapter contains instructions regarding the gas system of the vehicle. The instructions address the following topics:

- safety
- changing the gas bottles
- gas isolator taps
- external gas connection
- automatic switching facility

The operation of the gas operation appliances of the vehicle is described in chapter 9.

### 7.1 General



- ▶ Before commencing the journey, when leaving the vehicle or when gas equipment is not in use, close all gas isolator taps and the main isolator tap on the gas bottle.
- ▶ No appliance operated by a naked flame (e.g. heater or refrigerator) may be in operation when filling the tank, on ferries or in the garage. Danger of explosion!
- ▶ Do not use appliances operated with a naked flame in closed spaces (e.g. garages). Danger of poisoning and suffocation!
- ▶ Only have the gas system maintained, repaired or altered by an authorised specialist workshop.
- ▶ Have the gas system checked by an authorised specialist workshop according to the national regulations before commissioning. This also applies for not registered vehicles. For modifications to the gas system have the gas system immediately checked by an authorised specialist workshop.
- ▶ The gas pressure regulator and exhaust gas pipes must also be inspected. The gas pressure regulator has to be replaced after 10 years at the latest. The vehicle owner is responsible for seeing that this is carried out.
- ▶ In case of a defect of the gas system (gas odour, high gas consumption) there is danger of explosion! Close regulator tap on the gas bottle immediately. Open doors and windows and ventilate well.
- ▶ If the gas system is defective: Do not smoke; do not ignite any open flames, and do not operate electric switches (light switches etc.).
- ▶ Before using the cooker make sure that there is sufficient ventilation. Open windows or the skylight.
- ▶ Do not use the gas cooker or gas oven for heating purposes.
- ▶ If there are several gas devices, each gas device must have its own gas isolator tap. If individual gas devices are not in use, close the respective gas isolator tap.
- ▶ Ignition safety valves must close within 1 minute after the gas flame has extinguished. A clicking sound is audible. Check function from time to time.
- ▶ The built-in gas devices are exclusively meant for use with propane or butane gas or a mixture of both. The gas pressure regulator as well as all built-in gas devices are designed for a gas pressure of 30 mbar.



- ▶ Propane gas is capable of gasification up to  $-42\text{ °C}$ , whereas butane gas gasifies at  $0\text{ °C}$ . Below these temperatures no gas pressure is available. Butane gas is unsuitable for use in winter.
- ▶ Regularly inspect the gas tube fitted to the gas bottle connection for tightness. The gas tube must not have any tears and must not be porous. Have the gas tube replaced by an authorised specialist workshop no later than ten years after the manufacturing date. The operator of the gas system must see to it that the parts are replaced.
- ▶ Due to its function and construction, the gas bottle compartment is a space which is open to the exterior. Never cover or block up the standard forced ventilations. Otherwise gas that is emitted can not be diverted to the outside.
- ▶ Do not use the gas bottle compartment as storage space as it is not moisture-proof.
- ▶ Secure the gas bottle compartment against unauthorised access. To do this, lock the compartment.
- ▶ The regulator tap on the gas bottle must be accessible.
- ▶ Only connect gas-operated devices (e.g. gas grill) which have been designed for a gas pressure of 30 mbar.
- ▶ The exhaust gas pipe must be fitted tightly to the heating system and to the vent and must be sealed. The exhaust gas pipe must not show any evidence of damage.
- ▶ Exhaust fumes must be able to escape into the atmosphere unhindered and fresh air must be able to enter unhindered. For this reason, keep the exhaust pipe and intake openings clean and unobstructed (e.g. free from snow and ice). For this reason, no snow walls or aprons may lie against the vehicle.

## 7.2 Gas bottles



- ▶ Gas bottles are only to be transported within the designated gas bottle compartment.
- ▶ Place the gas bottles in vertical position in the gas bottle compartment.
- ▶ Fasten the gas bottles so that they are unable to turn or tilt.
- ▶ If the gas bottles are not connected to the gas tube, always place the protective cap on top.
- ▶ Close the regulator tap on the gas bottle before the gas pressure regulator or gas tube are removed from the gas bottle.
- ▶ Use your hands only to connect the gas pressure regulator or the gas tube to the gas bottles. Do not use any tools.
- ▶ Only use special gas pressure regulators with a safety valve designed for vehicle use. Other gas pressure regulators are not permitted and cannot meet the demanding requirements.
- ▶ Use the gas pressure regulator defroster if the temperature falls below  $5\text{ °C}$ .
- ▶ Use only 11 kg or 5 kg gas bottles. Camping gas bottles with built-in check valve (blue bottle with max. 2.5 or 3 kg content) are can be used in exceptional cases with a safety valve.



- ▶ Use the shortest possible tube lengths (150 cm max.) for external gas bottles.
- ▶ Never block the floor ventilation openings below the gas bottles.



- ▷ With some models, the gas bottle compartment is located right next to the conversion door. With these models, only open the gas bottle compartment when the conversion door is closed. Danger from damages.



- ▷ For gas-operated units the gas pressure must be reduced to 30 mbar.
- ▷ Connect gas pressure regulator complete with safety valve directly to bottle valve.

The gas pressure regulator reduces the gas pressure in the gas bottle down to the operating pressure of the gas devices.

- ▷ For filling and connecting the gas bottles in Europe the accessories shops have corresponding Euro filling sets and Euro bottle sets.
- ▷ Information available at the dealers or service centre.
- ▷ For information on the gas supply in Europe see chapter 17.

### 7.3 Changing gas bottles



- ▶ When changing gas bottles, do not smoke or create any open fire.
- ▶ When you have changed the gas bottle, check whether gas escapes at the connection points and unions. Use a leakage search spray to spray the relevant connection point or union. These agents are available at the accessories shop.





Fig. 162 Gas bottle compartment

- Open external gas bottle compartment (see chapter 6).
- Close the regulator tap (Fig. 162,1) on the gas bottle (Fig. 162,2). Pay attention to the direction of the arrow.
- Unscrew the gas tube (Fig. 162,3) by hand from the gas bottle.
- Release the fixing belts and remove the gas bottle.
- Place a filled gas bottle in the gas bottle compartment.
- Fix gas bottle in place with the fixing belts.
- Screw gas tube on gas bottle by hand.

## 7.4 Gas isolator taps



- 1 Oven
- 2 Refrigerator
- 3 Heater/boiler
- 4 Cooker

Fig. 163 Symbols for the gas isolator taps

A gas isolator tap (Fig. 163) for every gas device is built into the vehicle. The gas isolator taps are located in the vehicle at different positions, and can also be fitted separately.

## 7.5 External gas connection (special equipment)



- ▶ If the external gas connection is not in use, always close the gas isolator tap.
- ▶ Only gas appliances with a suitable adapter should be connected to the external gas connection.
- ▶ Connect only external gas appliances which are designed for an operation pressure of 30 mbar.
- ▶ Once you have made the connection and opened the gas isolator tap, make sure that no gas is escaping at the connection point. If there is a leak in the external gas connection, gas will escape into the open air. Immediately close the gas isolator tap and the regulator tap on the gas bottle. Have the external gas connection checked by an authorised specialist workshop.
- ▶ When connecting an external gas appliance, make sure that there is nothing near the external gas connection that could cause a spark.
- ▶ Do not use the external gas connection to fill gas bottles. Observe the information stickers on the external gas connection.




Fig. 164 External gas connection, gas isolator tap closed

The external gas connection (Fig. 164) is located at the rear or to the left or right of the vehicle depending on the model.

- Connect the external gas device to the connection point (Fig. 164,1).
- Open the gas isolator tap (Fig. 164,2).

## 7.6 Crash protection unit switching facility (special equipment)



▶ Do not use the switching facility in closed spaces.



- ▷ When the vehicle is equipped with the crash protection unit the living area heater may be operated during the journey.
- ▷ If the vehicle is equipped with a panel of the DT series and the switching facility is operated via this panel, the operating unit is redundant.
- ▷ Also read the manufacturer's instruction manual.

The crash protection unit is an automatic switching facility with a control unit for a two-bottle gas system. The switching facility automatically switches gas supply from the primary bottle to the reserve bottle as soon as the primary bottle is either empty or no longer ready for operation. The gas appliances may still continue operation. The switching facility is suitable for all commercial gas bottles from 3 kg to 33 kg. In the event of an accident or a too high angle of the vehicle the gas supply will automatically be interrupted.




Fig. 165 Crash protection unit switching facility

### Construction of the unit

The crash protection unit consists of two flow restrictors with manual release button (Fig. 165,6) a reversing valve (Fig. 165,4) with pressure regulator (Fig. 165,2), an electrovalve (Fig. 165,5) and the operating unit with tricoloured LED. The reversing valve is installed between the two gas tubes (Fig. 165,1).

Use the knob (Fig. 165,3) on the reversing valve to select which of the gas bottles is to be used as a primary bottle and which is to be used as a reserve bottle.



Fig. 166 Operating unit




Fig. 167 Operating unit with remote display

Only the electrical functions can be switched at the operating unit (Fig. 166). The regulator taps on the gas bottles (Fig. 165,7) and the release buttons (Fig. 165,6) must be opened manually.

The reversing valve provides a constant gas pressure, regardless of which gas bottle is being drawn upon. The display in the reversing valve shows the filling level of the primary bottle. The gas supply comes from the primary bottle when the display is green. When the display is red the primary bottle is empty. In this case, the reserve bottle is used for the gas supply.

#### Without remote display

The indicator lamp on the operating unit shows the condition of the gas system. The system is okay when the indicator lamp (Fig. 166,1) lights up green. When the indicator lamp lights up or flashes red a fault has occurred. The gas supply is interrupted.

#### With remote display

The indicator lamp on the operating unit (Fig. 167,1) shows the condition of the gas system:

| Indicator lamp          | Signification  |
|-------------------------|--|
| Off                     | System switched off, gas supply switched off   |
| Green                   | System switched on, gas supply switched on   |
| Red                     | Gas supply switched off, triggered by sloping position or excessive acceleration, e.g. in the event of an accident |
| Yellow                  | System switched on; gas supply switched on, primary bottle empty   |
| Flashes yellow          | Self-check, approx. 2 seconds long, after switching on   |
| Flashes red once        | Valve not connected to control device or internal error  |
| Flashes red twice       | Overvoltage determined, gas supply interrupted   |
| Flashes red three times | Undervoltage determined, gas supply interrupted  |

#### Putting into operation:

- Open the regulator taps of the gas bottles (Fig. 165,7).
- Press the release buttons (Fig. 165,6) successively for 10 seconds.
- Use the knob (Fig. 165,3) on the reversing valve (Fig. 165,4) to select the gas bottle which is to be the primary source of gas (primary bottle). Always turn the knob as far as it will go.
- Switch on the switching facility on the operating unit. For this, set the rocker switch (Fig. 166,2 or Fig. 167,2) to "ON". The reversing valve is now deaerated. The indicator lamp (Fig. 166,1 or Fig. 167,1) flashes yellow (system test) and lights up green.

- Switching off:*
- Set the rocker switch (Fig. 166,2 or Fig. 167,2) to "OFF". The indicator lamp (Fig. 166,1 or Fig. 167,1) goes out.
  - Close the regulator taps of the gas bottles (Fig. 165,7).



- ▶ When changing gas bottles, do not smoke or create any open fire.

- Changing gas bottles:*
- Turn the knob on the reversing valve. The display is green again. Should the display stay red the reserve bottle is also empty and has to be changed as well.
  - Close regulator tap on the empty gas bottle.
  - Unscrew the gas tube of the gas bottle.
  - Release the fixing belts and remove the gas bottle.
  - Place a new gas bottle in the gas bottle compartment.
  - Fix gas bottle in place with the fixing belts.
  - Connect the full gas bottle to the gas tube.
  - Open regulator tap on the gas bottle.
  - Press the release button for 10 seconds.
  - Turn the knob on the reversing valve to the changed bottle. Open the release button when the display is green.
  - Set the knob on the reversing valve with a half-turn, so that the newly replaced gas bottle will serve as a reserve bottle.



## Chapter overview

This chapter contains instructions regarding the electrical system of the vehicle.

The instructions address the following topics:

- safety
- explanations of terms relating to the battery
- 12 V power supply
- the radio selector switch
- starter battery
- living area battery
- transformer/rectifier
- panel
- fuel cell
- solar installation
- 230 V power supply
- connection to the 230 V power supply
- fuse rating
- external socket
- electrical wiring

The operation of the electrical appliances of the housing body is described in chapter 9.

### 8.1 General safety instructions



- ▶ Only allow qualified personnel to work on the electrical system.
- ▶ All electronic devices (e.g. mobile telephones, radios, televisions or DVD players) which have been retrofitted to the vehicle and are operated during the journey must have certain features: These are the CE certification, the EMC inspection (electromagnetic compatibility) and the "e"-inspection.

Only in this way can the functional reliability of the vehicle be ensured. Otherwise the airbag may be triggered or interference to the on-board electronics may result.



- ▷ After the vehicle is started, delays to the output or forwarding of electrical impulses are possible.

The control unit of the basic vehicle does not release the D+ signal until the engine has reached full performance. In the event of a cold start in winter, this can take up to 15 seconds.

For this reason, output of warning signals (such as "entrance step extended") may sometimes be delayed.

The automatic retraction of a SAT antenna can also be delayed.

- ▷ During a storm, to protect the electrical devices disconnect the 230 V connection and retract the antennae.

### 8.2 Terms

#### Off-load voltage

The off-load voltage is the voltage of the battery in idle condition, i. e. no current is consumed and the battery is not being charged.



- ▷ The battery must remain idle for a while before measuring. After charging the last time, or after the last current has been drained by consumers, wait approximately 2 hours before measuring the idle voltage.

#### Closed circuit current

Some electrical appliances, such as the clock and the indicator lamps, require continuous electric current, for this reason they are referred to as inactive appliances. This closed circuit current flows even if the device has been switched off.

#### Total discharge

Total discharge of the battery is imminent, if a battery is completely discharged by an active appliance and by closed circuit current and the off-load voltage falls below 12 V.



- ▷ Total discharge damages the battery.

#### Capacity

Capacity refers to the amount of electricity which can be stored in a battery. The capacity of a battery is given in ampere hours (Ah). The so-called K20 value is normally used.

The K20 value indicates how much current a battery is able to dispense over a time period of 20 hours without causing damage, or how much current is required to charge a flat battery within 20 hours.

For example, if a battery can dispense 4 amps for 20 hours, then it has a capacity of  $4 \text{ A} \times 20 \text{ h} = 80 \text{ Ah}$ .

If more current flows, the capacity of the battery reduces proportionately.

External influences, such as temperature and age may alter the storage capacity of the battery. Capacity details refer to new batteries operating at room temperature.



- ▷ Depending on battery technology, capacity details have a conversion factor of 1.3 to 1.7, which lowers the real capacity by this value.

### 8.3 12 V power supply



- ▷ Only connect devices with a maximum of 10 A to the sockets (Fig. 168,1) of the 12 V power supply.




Fig. 168 Socket 12 V/10 A

### 8.3.1 Selector switch for radio (special equipment)



- ▷ Depending on the equipment level, a radio with integrated navigation device or a multimedia station will be present, referred to below simply as a "radio".



Fig. 169 Selector switch for operating behaviour

*Switching the radio on and off with the ignition:*

- Set the selector switch to the "0" position. The radio will be switched on and off with the ignition.

*Operating the radio from the living area battery:*

- Set the selector switch to the "1" position. The radio will be powered at all times from the living area battery.

### 8.3.2 Starter battery

The starter battery serves for starting the engine and supplies the electrical appliances of the base vehicle as well as optional devices such as the radio, navigation system or central locking system with voltage. See the instruction manual of the base vehicle for the position of the starter battery.



- ▷ The radio device in the driver's cabin is connected to the living area battery.

#### **Discharging**

This section contains information regarding the discharge of the starter battery.



- ▷ Total discharge damages the battery.
- ▷ Once a battery with acid is discharged, it can freeze in temperatures of below zero. This damages the battery.
- ▷ Recharge battery in good time.

The starter battery will be totally discharged via a closed circuit current (inactive appliances). Inactive appliances are optional devices such as a radio, alarm system, navigation system or a central locking system. Inactive appliances discharge the starter battery when the vehicle engine is switched off. Low temperatures outside reduce the capacity available.

**Charging** This section contains information regarding the charging of the starter battery.



- ▶ The acid in the battery is poisonous and corrosive. Any contact with the skin or the eyes is to be avoided.
- ▶ In the case of charging with an external charger there is danger of explosion. Sparks can be caused by attaching the battery terminals. Only charge the battery in a well ventilated area and away from naked flames or possible sources of sparks. Batteries can develop and release gases.



- ▷ Before a temporary lay-up, charge the battery fully.
- ▷ Do not connect the battery cables to the wrong poles.
- ▷ If the starter battery or living area battery are disconnected, do not apply the ignition. There is a danger of short circuit from exposed cable ends.
- ▷ Before disconnecting or connecting the terminals of the battery, switch off the vehicle engine as well as the 230 V and 12 V power supplies and all appliances. Danger of short circuit!
- ▷ Observe the instruction manuals for the base vehicle and the charger.

The starter battery can only be fully charged with an external charger. When the vehicle is connected to the 230 V power supply, the transformer/rectifier charges the starter battery with a float charge only. Even in mobile operation, the vehicle engine alternator has a limited capability of completely charging the starter battery.

When charging the starter battery with an external charger, proceed as follows:

- Turn off the vehicle engine.
- Switch off the 12 V power supply on the panel. The indicator lamps or the displays on the panel go out.
- Switch off all gas appliances, all gas isolator taps and close the regulator tap on the gas bottle.
- Disconnect the starter battery from the vehicle (e.g. remove the battery terminals). There is a danger of short circuit when disconnecting the battery poles. For this reason, first disconnect the negative terminal on the starter battery and then the positive.
- Check that the external charger is turned off.
- Connect the external charger to the starter battery. Pay attention to the polarity: First connect the positive terminal "+" to the positive terminal of the starter battery, then connect the negative terminal "-" to the negative pole of the starter battery.
- Switch on the external charger.
- See the instructions for use of the connected charger for information concerning charge period required for the battery.
- See the specifications on the battery for information concerning its strength.
- Disconnect the charger in reverse order (the negative terminal first).
- Connect the battery terminals again (first the positive terminal).

### 8.3.3 Living area battery



- ▷ Use only the built-in transformer/rectifier to load the living area battery.
- ▷ After the trip, charge the living area battery fully.
- ▷ Before a temporary lay-up, charge the battery fully.
- ▷ When the living area battery is changed, only use batteries of the same type.
- ▷ If there are several living area batteries, always change all the batteries together. The batteries must **always** be the same age and have the same capacity.
- ▷ When changing the living area battery, use only batteries which meet the minimum capacity of the charger. Observe the separate instruction manual for the charger. Lower-capacity batteries will generate a great deal of heat when they are charged. Danger of explosion!
- ▷ If the living area battery is replaced and the charging unit does not provide at least 10 % of the rating of a new battery, install an auxiliary charging unit. Example: With a battery capacity of 80 Ah, the charging unit must supply at least 8 A charging current.
- ▷ Before disconnecting or connecting the terminals of the battery, switch off the vehicle engine as well as the 230 V and 12 V power supplies and all appliances. Danger of short circuit!
- ▷ If the starter battery or living area battery are disconnected, do not apply the ignition. There is a danger of short circuit from exposed cable ends.



- ▷ If possible, begin the trip with a fully charged living area battery. Therefore, charge the living area battery before starting the trip.
- ▷ During the trip, use every available opportunity to charge the living area battery.
- ▷ The radio device in the driver's cabin is connected to the living area battery.

When the vehicle is not connected to the 230 V power supply or the 230 V power supply is switched off, the living area battery supplies the living area with 12 V DC. The living area battery has a limited power supply only. For this reason, electrical appliances such as the radio and the lights should not be operated for a long time without using the 230 V power supply.

**Position** See chapter 16.

**Discharging** The living area battery is discharged by the closed circuit current which some electrical appliances continuously require.



- ▷ Total discharge damages the battery.
- ▷ Recharge battery in good time.

A completely charged living area battery will be totally discharged via a closed circuit current (inactive appliances).

Low temperatures outside reduce the capacity available.

The self-discharge rate of the battery is also dependant on temperature. At 20 to 25 °C the self-discharge rate is approx. 3 % of the capacity per month. The self-discharge rate will increase with rising temperatures: At 35 °C the self-discharge rate is approx. 20 % of the capacity per month.

An older battery no longer has the complete capacity available.

The higher the number of active electrical appliances, the faster the energy of the living area battery is consumed.

### Charging

Only use the transformer/rectifier to charge the living area battery. Therefore, connect the vehicle to a 230 V power supply system as often as possible.



- ▷ Charge the battery for at least 48 hours after a total discharge.



- ▷ Further information can be obtained in the separate documentation for the living area battery.

## 8.4 Transformer/rectifier (EBL 99)



- ▷ Do not cover the ventilation slots. Danger of overheating!



- ▷ Depending on the model, not all slots for the fuses are occupied.
- ▷ If there are several living area batteries, use an auxiliary charging unit.
- ▷ Further information can be obtained in the manufacturer's instruction manual.




Fig. 170 Transformer/rectifier (EBL 99)

- 1 Main supply socket 230 V~
- 2 Block 1: Refrigerator output (D+, heating cartridge)
- 3 Block 2: Refrigerator output from starter battery, alternator D+
- 4 Block 4: Heating output, basic light (lighting in the entrance area), entrance step
- 5 Block 3: Panel outlet
- 6 Block 5: Reserve output 2, reserve 3, reserve 4, appliance with constant positive (e.g. satellite device, defroster)
- 7 Block 6: Solar charge regulator input (if fitted)
- 8 Block 7: Auxiliary charging unit input, fuel cell
- 9 Block 8: Appliance circuit output 1, appliance circuit 2, TV, water pump, reserve 1, reserve 5, reserve 6
- 10 Battery selector switch ("Blei-Säure/Blei-Gel" (lead acid/dryfill))
- 11 Fuses
- 12 Battery cut-off switch ("Batterie Ein/Aus" (battery On/Off))

**Functions**

The transformer/rectifier has the following functions:

- The transformer/rectifier charges the living area battery. The transformer/rectifier charges the starter battery with a float charge only.
- The transformer/rectifier monitors the voltage in the living area battery.
- The transformer/rectifier distributes the current to the 12 V circuits and secures them. Devices with a maximum of 10 A can be connected to the sockets.
- The transformer/rectifier provides connections for a solar charge regulator, an auxiliary charging unit, as well as other control and monitoring functions.
- When the engine is turned off, the transformer/rectifier separates the starter battery electrically from the living area battery. This prevents the 12 V living area appliances from discharging the starter battery.
- The battery cut-off switch in the transformer/rectifier separates all the appliances from the living area battery.

The transformer/rectifier only works in conjunction with a panel.

The power in the transformer/rectifier (> 18 A) is divided into charging current and current to the appliances. The charging current is always just the portion that is not being used by any appliances. If the current to the appliances exceeds the current available, then the living area battery is discharged.

**Position**

See chapter 16.

### 8.4.1 Battery cut-off switch

The battery cut-off switch switches off **all** the appliances in the living area, even inactive ones. Even appliances such as the entrance step, basic lighting or the refrigerator will stop working. This prevents the living area battery from slowly discharging if the vehicle is not used for a longer period of time (e.g. temporary lay-up).

If the vehicle is connected to the 230 V power supply, the batteries can then be charged from the transformer/rectifier, even if the battery cut-off switch is switched off.

This also applies for charging via a solar installation or fuel cell.

### 8.4.2 Battery selector switch



- ▶ If the battery selector switch is set incorrectly, there is the danger of the formation of detonating (oxy-hydrogen gas). Danger of explosion!



- ▷ Incorrect setting of the battery selector switch damages the living area battery.
- ▷ The factory settings of the battery selector switch must not be changed.

### 8.4.3 Battery monitor



- ▷ You must fully recharge a discharged living area battery as soon as possible.

The battery monitor in the transformer/rectifier monitors the voltage in the living area battery.

If the battery voltage falls below 10.5 V, the battery monitor in the transformer/rectifier switches off all the 12 V appliances. The battery cut-off switch is activated.

- Measures:*
- Switch off all electrical appliances that are not absolutely essential at the corresponding switch.
  - If necessary, use the 12 V main switch to switch the 12 V power supply back on for a short while. This is only possible, however, when the battery voltage is above 11 V. If the voltage is below this level, the 12 V power supply cannot be switched on again until the living area battery has been recharged.

#### 8.4.4 Charging the battery

When the vehicle engine is running, a relay in the transformer/rectifier alternator switches on the living area battery and the starter battery together and recharges them with the vehicle generator. When the vehicle engine is switched off, the batteries are automatically disconnected from one another again by the transformer/rectifier. This prevents the starter battery from being run down by electrical appliances in the living area. The starting capability of the vehicle is thus preserved. The terminal voltage of the living area battery or the starter battery can be read on the panel.

If the vehicle is connected to the 230 V power supply, the living area battery and the starter battery are automatically charged by the charger module on the transformer/rectifier. The starter battery is only charged with a float charge. The charging current is adapted to suit the charging condition of the battery. This ensures that it is not possible to overload the battery.

To make use of the maximum output from the charger module on the transformer/rectifier, switch off all electrical appliances during charging.

### 8.5 Panel IT 96-2




Fig. 171 Panel IT 96-2

- 1 "ALARM" warning light for the living area battery
- 2 V/tank gauge
- 3 230 V indicator lamp
- 4 Rocker switch for water pump On/Off
- 5 Switch for reading the filling level in the water tank
- 6 Switch for reading the filling level in the waste water tank
- 7 12 V main switch OFF
- 8 12 V indicator lamp
- 9 12 V main switch ON
- 10 Switch for reading the battery voltage of the living area battery
- 11 Switch for reading the battery voltage of the starter battery

#### 8.5.1 12 V main switch

The 12 V main switch (Fig. 171,7 and 9) switches the panel and the 12 V power supply to the living area on and off.

Exception: Depending on the model, heater, basic light (lighting in the entrance area), entrance step, spare 4 and a refrigerator with automatic power selection system (AES) remain ready to operate.

**Switching on:** ■ Press switch (Fig. 171,9) "12 V": The 12 V living area power supply is switched on. The indicator lamp (Fig. 171,8) lights up green.

**Switching off:** ■ Press switch (Fig. 171,7) "O": The 12 V living area power supply is switched off. The indicator lamp (Fig. 171,8) goes out.



- ▷ When leaving the vehicle, switch off the main 12 V power supply at the panel. This prevents any unnecessary discharge of the living area battery.
- ▷ Appliances, such as control units (e.g. solar charge regulator, defroster or panel) or fitted appliances (e.g. heating, refrigerator or step) continue to take power from the battery capacity, even if the 12 V power supply on the panel is switched off. Therefore disconnect the living area battery from the 12 V power supply via the switch on the transformer/rectifier if the vehicle will not be used for a long period of time.

### 8.5.2 V/tank gauge for battery voltage and water or waste water levels

**Battery voltage** The V/tank gauge is for the indication of the battery voltage of the starter battery or the living area battery.

With the V/tank gauge (Fig. 171,2), note the top scale. The gauge automatically lights up as soon as a switch is pressed.

- Displays:**
- Press switch (Fig. 171,11) : The battery voltage of the starter battery is displayed.
  - Press switch (Fig. 171,10) : The battery voltage of the living area battery is displayed.

The following tables will help you correctly interpret the battery voltage of the living area battery displayed on the panel IT 96.

**Danger of total discharge (battery alarm)**

| Battery voltage (values during operation) | Mobile operation (vehicle moving, no 230 V connection)                                | Battery operation (vehicle stationary, no 230 V connection)                                     | Power operation (vehicle stationary, 230 V connection)  |
|---|---|---|---|
| 11 V or less <sup>1)</sup>                | 12 V power supply overload  | If appliances are switched off: Battery flat<br>If appliances are switched on: Battery overload | 12 V power supply overload  |
|   | The battery is not charged by the alternator, the alternator's regulator is defective |   | The battery is not charged by the transformer/rectifier, the transformer/rectifier is defective |
| 11.5 V to 13.2 V                          | 12 V power supply overload <sup>2)</sup>  | Normal range  | 12 V power supply overload <sup>2)</sup>  |
|   | The battery is not charged by the alternator, the alternator's regulator is defective |   | The battery is not charged by the transformer/rectifier, the transformer/rectifier is defective |

| Battery voltage (values during operation) | Mobile operation (vehicle moving, no 230 V connection) | Battery operation (vehicle stationary, no 230 V connection) | Power operation (vehicle stationary, 230 V connection)   |
|---|--|---|--|
| 13.3 V to 13.7 V                          | Battery is being charged (main charge)                 | Occurs only briefly after charging                          | Battery is being charged (main charge)                   |
| 13.8 V to 14.4 V                          | Battery being charged (float charge)                   | –   | Battery being charged (float charge)                     |
| Over 14.5 V                               | Battery is over-charged, defective alternator control  | –   | Battery is over-charged, defective transformer/rectifier |

- 1) The battery guard switches all the appliances off (at 10.5 V).
- 2) If the voltage does not exceed this range for several hours.

| Values for off-load voltage | Charging condition of the battery |
|-----------------------------|-----------------------------------|
| Less than 11 V              | Totally discharged                |
| 12.0 V                      | 0 %                               |
| 12.2 V                      | 25 %                              |
| 12.3 V                      | 50 %                              |
| 12.5 V                      | 75 %                              |
| More than 12.8 V            | 100 %                             |



- ▷ Total discharge causes irreparable damage to the battery.



- ▷ Measure the off-load voltage preferably several hours after the previous charging (e.g. in the morning) and not directly after a current drain.

### Volume of water/waste water

The V/tank gauge is for the indication of the quantity of water or waste water. With the V/tank gauge (Fig. 171,2), use the bottom scale. The gauge automatically lights up as soon as a switch is pressed.

*Displays:*

- Press switch (Fig. 171,5) : The volume of water is displayed.
- Press switch (Fig. 171,6) : The volume of waste water is displayed.
- ▷ Only read the tank levels briefly. Keeping the reading option on for a long time can damage the transducers.



### 8.5.3 Switch for water pump

*Switching on:* ■ Press the upper part of the rocker switch (Fig. 171,4) "I": The water supply is ON.

*Switching off:* ■ Press the lower part of the rocker switch (Fig. 171,4) "O": The water supply is OFF.



- ▷ If the vehicle is not connected to the 230 V power supply and the water pump is not used for a longer period of time: Switch off the power supply for the water pump. The pump relay uses around 4 Ah current each day.

### 8.5.4 Battery alarm for the living area battery

The red "ALARM" warning light (Fig. 171,1) flashes as soon as the voltage of the living area battery falls below 11 V (measured under operation) and there is a risk of a total discharge.



- ▷ Total discharge damages the battery.



- ▷ If the battery voltage falls below 10.5 V, the battery monitor in the transformer/rectifier switches off all the 12 V appliances. The battery cut-off switch is activated.

*Measures:* ■ When the battery alarm comes on, switch off the appliances and charge the living area battery, either by mobile operation or by connection to a 230 V power supply.

### 8.5.5 12 V indicator lamp

The 12 V indicator lamp (Fig. 171,8) illuminates whenever the 12 V main switch (Fig. 171,9) is switched on.

### 8.5.6 230 V indicator lamp

The yellow 230 V indicator lamp (Fig. 171,3) illuminates whenever line voltage is available at the transformer/rectifier input.



- ▷ Further information can be obtained in the manufacturer's instruction manual.

## 8.6 Panel IT 994



- ▷ Further information can be obtained in the manufacturer's instruction manual.




Fig. 172 Panel IT 994

- 1 V/tank gauge
- 2 Digital clock/temperature gauge
- 3 230 V indicator lamp
- 4 Current gauge
- 5 12 V indicator lamp
- 6 12 V main switch
- 7 Rocker switch for water pump On/Off
- 8 Rocker switch °C for reading internal temperature or external temperature
- 9 Setting the digital clock - minutes
- 10 Setting the digital clock - hours
- 11 Rocker switch display On/Off
- 12 Rocker switch for reading the level in the water or waste water tanks
- 13 Rocker switch for reading the battery voltage of the starter and living area batteries
- 14 ALARM warning light for the living area battery

### 8.6.1 V/tank gauge for battery voltage and water or waste water levels

#### Battery voltage

The V/tank gauge is for the indication of the battery voltage of the starter battery or the living area battery.

With the V/tank gauge (Fig. 172,1), note the top scale. The gauge automatically lights up as soon as a switch is pressed.

#### Displays:

- Press the lower part of the rocker switch (Fig. 172,13): The battery voltage of the starter battery is displayed.
- Press the upper part of the rocker switch (Fig. 172,13): The battery voltage of the living area battery is displayed.

The following tables will help you correctly interpret the battery voltage of the living area battery displayed on the panel IT 994.

**Danger of total discharge (battery alarm)**

| Battery voltage (values during operation) | Mobile operation (vehicle moving, no 230 V connection)                                | Battery operation (vehicle stationary, no 230 V connection) | Power operation (vehicle stationary, 230 V connection)  |
|---|---|---|---|
| 11 V or less <sup>1)</sup>                | 12 V power supply overload  | If appliances are switched off: Battery flat                | 12 V power supply overload  |
|   | The battery is not charged by the alternator, the alternator's regulator is defective | If appliances are switched on: Battery overload             | The battery is not charged by the transformer/rectifier, the transformer/rectifier is defective |
| 11.5 V to 13.2 V                          | 12 V power supply overload <sup>2)</sup>  | Normal range  | 12 V power supply overload <sup>2)</sup>  |
|   | The battery is not charged by the alternator, the alternator's regulator is defective |   | The battery is not charged by the transformer/rectifier, the transformer/rectifier is defective |
| 13.3 V to 13.7 V                          | Battery is being charged (main charge)  | Occurs only briefly after charging                          | Battery is being charged (main charge)  |
| 13.8 V to 14.4 V                          | Battery being charged (float charge)  | –   | Battery being charged (float charge)  |
| Over 14.5 V                               | Battery is overcharged, defective alternator control                                  | –   | Battery is overcharged, defective transformer/rectifier   |

<sup>1)</sup> The battery guard switches all the appliances off (at 10.5 V).

<sup>2)</sup> If the voltage does not exceed this range for several hours.

| Values for off-load voltage | Charging condition of the battery |
|-----------------------------|-----------------------------------|
| Less than 11 V              | Totally discharged                |
| 12.0 V                      | 0 %                               |
| 12.3 V                      | 50 %                              |
| 12.5 V                      | 75 %                              |
| More than 12.8 V            | Full                              |



▷ Total discharge causes irreparable damage to the battery.



▷ Measure the off-load voltage preferably several hours after the previous charging (e.g. in the morning) and not directly after a current drain.

### Volume of water/waste water

The V/tank gauge is for the indication of the quantity of water or waste water. With the V/tank gauge (Fig. 172,1), use the bottom scale. The gauge automatically lights up as soon as a switch is pressed.

#### Displays:

- Press the upper part of the rocker switch (Fig. 172,12): The volume of water is displayed.
- Press the lower part of the rocker switch (Fig. 172,12): The volume of waste water is displayed.



- ▷ Only read the tank levels briefly. Keeping the reading option on for a long time can damage the transducers.

### 8.6.2 Battery alarm for the living area battery

The red ALARM warning light (Fig. 172,14) flashes as soon as the voltage of the living area battery falls below 11 V (measured under operation) and there is a risk of a total discharge.



- ▷ Total discharge damages the battery.



- ▷ If the battery voltage falls below 10.5 V, the battery monitor in the transformer/rectifier switches off all the 12 V appliances. The battery cut-off switch is activated.

#### Measures:

- When the battery alarm comes on, switch off the appliances and charge the living area battery, either by mobile operation or by connection to a 230 V power supply.

### 8.6.3 Digital clock/temperature gauge

#### Digital clock

The buttons under the gauge can be used to switch the digital clock on and off and to set it.

#### Switching on:

- Press the upper part of the rocker switch (Fig. 172,11): Digital clock display is switched on. Temperature display is ready to operate.

#### Switching off:

- Press the lower part of the rocker switch (Fig. 172,11): Digital clock display and temperature display are switched off.

#### Adjusting:

- Press a thin device, such as a biro, into the opening for the hour display (Fig. 172,10) until the correct hours are displayed.
- Press a thin device, such as a biro, into the opening for the minute display (Fig. 172,9) until the correct minutes are displayed.



- ▷ The digital clock will go on running even when the digital clock display is switched off. The actual time can always be read.
- ▷ The digital clock loses the current time when the living area battery is disconnected. When the living area battery is reconnected, the display reads 00:00 and must be re-set.

**Temperature display**

The digital clock/temperature gauge is for the indication of the internal or external temperature.

The temperature display is only ready for operation if the digital clock display is switched on. After a reading, the respective temperature will be displayed for approx. 6 seconds.

*Displays:*

- Press the upper part of the rocker switch (Fig. 172,8): The internal temperature is displayed.
- Press the lower part of the rocker switch (Fig. 172,8): The external temperature is displayed.

### 8.6.4 Current gauge for charging/discharging the living area battery

The battery current actually flowing is permanently displayed on the current gauge (Fig. 172,4). The gauge automatically lights up as soon as a switch is pressed.

- Red "discharging" zone: Battery is being discharged at the discharging current indicated between 0 and 30 A.
- Indicator "0": Battery is neither being charged nor discharged.
- Green "charging" zone: Battery is being charged at the charging current indicated between 0 and 30 A.

**Notes for charging/  
discharge display**

| Display  | Mobile operation<br>(vehicle moving,<br>no 230 V con-<br>nection)                                | Battery opera-<br>tion<br>(vehicle station-<br>ary, no 230 V<br>connection) | Power operation<br>(vehicle station-<br>ary, 230 V con-<br>nection)                                     |
|--|--|---|---|
| Red "discharg-<br>ing" zone (dis-<br>charging current) | No charge!<br>Too many appli-<br>ances are<br>switched on or the<br>alternator is de-<br>fective | Appliances are on<br>Battery is being<br>discharged                         | No charge!<br>Too many appli-<br>ances are<br>switched on   |
| 0 A (there is no<br>current)                           | Battery fully or vir-<br>tually charged <sup>1)</sup>  | Appliances are<br>switched off  | Battery fully or vir-<br>tually charged <sup>2)</sup>   |
| Green zone<br>(charging current)                       | Battery is being<br>charged (up to<br>30 A possible)   | Battery is being<br>charged (only<br>possible with solar<br>power)          | Battery is being<br>charged (up to<br>max. 16 A possi-<br>ble; with 32 A<br>auxiliary charging<br>unit) |

<sup>1)</sup> If the indicator falls from the green range to 0 and all appliances are switched off (apart from the refrigerator).

<sup>2)</sup> If the indicator falls from the green range to 0 and all appliances are switched off.

### 8.6.5 12 V main switch

The 12 V main switch (Fig. 172,6) switches the panel and the 12 V power supply of the living area on and off.

Exception: Depending on the model, heater, basic light (lighting in the entrance area), entrance step, spare 4 and a refrigerator with automatic power selection system (AES) remain ready to operate.

*Switching on:* ■ Press the upper part of the rocker switch (Fig. 172,6): The 12 V living area power supply is switched on. The indicator lamp (Fig. 172,5) lights up green.

*Switching off:* ■ Press the lower part of the rocker switch (Fig. 172,6): The 12 V living area power supply is switched off. The indicator lamp (Fig. 172,5) goes out.



- ▷ When leaving the vehicle, switch off the main 12 V power supply at the panel. This prevents any unnecessary discharge of the living area battery.
- ▷ Appliances, such as control units (e.g. solar charge regulator, defroster or panel) or fitted appliances (e.g. heating, refrigerator or step) continue to take power from the battery capacity, even if the 12 V power supply on the panel is switched off. Therefore disconnect the living area battery from the 12 V power supply via the switch on the transformer/rectifier if the vehicle will not be used for a long period of time.

### 8.6.6 12 V indicator lamp

The 12 V indicator lamp (Fig. 172,5) illuminates whenever the 12 V main switch (Fig. 172,6) is switched on.

### 8.6.7 230 V indicator lamp

The yellow 230 V indicator lamp (Fig. 172,3) illuminates whenever line voltage is available at the transformer/rectifier input.

### 8.6.8 Switch for water pump

*Switching on:* ■ Press the upper part of the rocker switch (Fig. 172,7): The water supply is ON.

*Switching off:* ■ Press the lower part of the rocker switch (Fig. 172,7): The water supply is OFF.



- ▷ If the vehicle is not connected to the 230 V power supply and the water pump is not used for a longer period of time: Switch off the power supply for the water pump. The pump relay uses around 4 Ah current each day.

## 8.7 Fuel cell (EFOY) (special equipment)



- ▶ Methanol is toxic. Avoid inhaling, swallowing or any contact with the skin or the eyes.
- ▶ If methanol leaks, there is a danger of fire. Keep away from sources of ignition and ventilate well. Methanol evaporates without residue.
- ▶ Always adhere to the safety data sheet from the manufacturer.
- ▶ The fuel cell must not be opened.



- ▶ The tank cartridge must not be opened with force or refilled.
- ▶ Keep fuel cell and tank cartridges – including empty or half-empty tank cartridges – out of the reach of children.
- ▶ When used in vehicles, the fuel cell and the tank cartridges must be secured to avoid accidents.



- ▷ Do not store the fuel cell at temperatures above 45 °C or below 1 °C.
- ▷ Do not operate the fuel cell at temperatures above 40 °C or below -20 °C.
- ▷ When the appliance is connected to an intact battery, the frost protection switches on automatically if the ambient temperature drops below 3 °C, even if the fuel cell is switched off. Therefore always connect a full tank cartridge and a sufficiently charged battery, if it is stored below 3 °C.
- ▷ If the fuel cell freezes despite taking all precautions, leave the appliance to defrost at room temperature for approx. 24 hours in a switched off state. Then it can be used again.
- ▷ Do not cover the ventilation holes on the fuel cell. Danger of overheating!
- ▷ The fuel cell is not waterproof. Clean casing only with a slightly damp cloth and ensure that water does not enter the device.



- ▷ The minimum running time of the fuel cell is 30 minutes. If the On/Off button is pressed during this period, the fuel cell only shuts down when this minimum operating time expires. The LEDs light up on during this time.
- ▷ Further information can be obtained in the instruction manual for the fuel cell.




Fig. 173 Fuel cell with tank cartridge




Fig. 174 Connector panel of the fuel cell

The fuel cell consists of several components that are installed in the rear storage space (Fig. 173) and of an operating unit (Fig. 175) in the living area.


The following components are on the fuel cell (Fig. 173,6):

- The connector for the air discharge hose (Fig. 173,4) or the filling hole for the service fluid
- the off-heat tube (Fig. 173,5)
- electrical connections (Fig. 173,3) with data interface (Fig. 174,2), device connection (Fig. 174,3) and connection for the operating panel (Fig. 174,1)

A tank cartridge belongs to the fuel cell (Fig. 173,6). It is connected to the fuel cell via a tank connection (Fig. 173,2).

The tank cartridge is firmly fixed in the tank cartridge holder (Fig. 173,1).

The fuel cell automatically charges the living area batteries if their voltage falls below 12,3 V and if the fuel cell is switched on using the On/Off key (Fig. 175,8).



- 1 Display
- 2 Scroll upwards through menu
- 3 Scroll downwards through menu
- 4 Confirmation/OK
- 5 Fault display (red LED)
- 6 Back
- 7 Menu
- 8 On/Off

Fig. 175 Operating unit fuel cell

### Operating unit

The display (Fig. 175,1) of the operating unit has four lines.

The first line displays the selected operating mode:

- Automatic
- On
- Off

The second line displays the current operating status:

- Standby
- Charging mode
- Shutdown procedure
- Battery protection
- Antifreeze

The other two rows show information such as battery voltage, charging current and filling level of the tank cartridge.

The main menu can be accessed with the menu key (Fig. 175,7):

- Operating mode
- Fuel cartridge
- System information
- Language
- System reset

In the event of faults, the red fault indicator (Fig. 175,5) lights up and a message appears on the display. The message consists of an error code and information on how to rectify the fault.

After rectifying the fault, carry out a system reset.

If the tank cartridge needs to be changed or service fluid replenished, this will also be indicated.

#### Switching on:

- Press the On/Off key.
- Select the desired operating mode and confirm with "OK".

#### Switching off:

- Press the On/Off key.
- Select the "Manual Off" operating mode and confirm with "OK". The fuel cell switches itself off in a controlled way. This procedure can take a while. "Shutdown procedure" appears on the display.

### Automatic mode

Automatic mode starts as soon as the device is attached to the power supply. The device monitors the battery voltage independently.

The fuel cell switches itself on automatically when the battery voltage falls below 12.3 Volts. The battery is then charged to reach the switch-off threshold (14.2 Volts).

When started, the device runs through a start phase lasting up to 20 minutes. Only after this period is its full nominal power reached.

**Battery protection**

This function prevents the battery from discharging completely when the operating mode is set to "Off".

Battery protection is activated automatically when the battery voltage falls below 11.2 Volts for more than 15 minutes. The "Battery protection" charge mode ends when the voltage of 12.8 Volts is reached.

**Frost protection**

This mode is triggered automatically as soon as the temperature falls below 3 °C. It prevents the device from freezing.



- ▶ Observe the safety instructions for methanol.

**Replacing the tank cartridge:**

- Unscrew the tank cartridge connection from the empty tank cartridge.
- Loosen the securing belt on the tank cartridge.
- Remove empty tank cartridge from the tank cartridge holder.
- After use, firmly close the cap of the tank cartridge.
- Insert a new, sealed original tank cartridge into the tank cartridge holder.
- Secure the tank cartridge with the securing belt.
- Open cap and keep safe.
- Screw tank cartridge connection onto the new tank cartridge.
- In the "Main Menu > Fuel Cartridge" menu, specify the tank cartridge size used and confirm with "OK".

## 8.8 Solar installation (special equipment)



- ▷ Protect the solar collectors (solar module) against mechanical overload.



- ▷ The solar installation supplies the most current under optimal sunlight conditions.
- ▷ Provide the solar collectors (solar module) open access to sunlight.
- ▷ Sunlight is greater in the open air than under trees and bridges.
- ▷ Tarpaulins block out sunlight.
- ▷ Always keep collector surfaces free of contamination.
- ▷ Also read the manufacturer's instruction manual.

The solar installation provides an environmentally compatible power supply independent of the mains. It converts energy from sunlight into electric current. The solar installation supplies additional current for the battery and appliances.

The solar charge regulator has an integrated overload protection and back flow valve. The charging current is automatically reduced or the solar collectors (solar modules) are switched off if the solar power is not sufficient (e.g. at night).




Fig. 176 Solar charge regulator 100 W

**Solar installation 100 W**

Two LEDs (Fig. 176,1 and 2) indicate the current operating status by means of different brightness. The higher the charge status of the battery, the brighter the LED lights "100 % ↑" (Fig. 176,1) and, the lower the charge status of the battery, the lower the LED lights "20 % ↓" (Fig. 176,2).

| LED     | Status          | Signification  |
|---------|-----------------|--|
| 100 % ↑ | Off             | Solar power insufficient                             |
| 20 % ↓  | Off             |  |
| 100 % ↑ | Lights          | Battery being charged                                |
| 20 % ↓  | Lights          |  |
| 100 % ↑ | Lights brightly | Charging current limited to trickle charging current |
| 20 % ↓  | Glows weakly    |  |




Fig. 177 Solar charge regulator 200 W

**Solar installation 200 W**

Two LEDs (Fig. 177,1 and 2) indicate the current operating status by means of different brightness. The higher the charge status of the battery, the brighter the "Batt. Full" LED (Fig. 177,2) lights up and the weaker the "Charge" LED lights up (Fig. 177,1).

| LED        | Status          | Signification  |
|------------|-----------------|--|
| Batt. Full | Off             | Solar power insufficient                             |
| Charge     | Off             |  |
| Batt. Full | Lights          | Battery being charged                                |
| Charge     | Lights          |  |
| Batt. Full | Lights brightly | Charging current limited to trickle charging current |
| Charge     | Glows weakly    |  |

## 8.9 230 V power supply



- ▶ Only allow qualified personnel to work on the electrical system.
- ▶ Have the vehicle's electrical system checked by a qualified electrician at least once every 3 years. If the vehicle is used frequently, an annual check is recommended.

The 230 V power supply provides electricity for:

- sockets with earth contact for appliances with maximum 16 A
- refrigerator
- transformer/rectifier
- an auxiliary charging unit
- air conditioning unit

The electrical appliances connected to the 12 V power supply of the living area are supplied with voltage by the living area battery.

Connect the vehicle to an external 230 V power supply system as often as possible. The charger module in the transformer/rectifier automatically charges the living area battery. In addition to this, the starter battery is charged with a float charge of approx. 2 A.

Depending on the equipment, the air conditioning unit and other optional devices are fuse-protected by their own safety cut-out (16 A).

### 8.9.1 230 V connection



- ▷ Overvoltage can damage connected devices. Overvoltage can be caused by lightning, irregular voltage sources (e.g. petrol-operated generators) or power connections on ferries for example.

#### Requirements concerning the 230 V connection

- The connection cable, the plug connectors at the point of supply and the plug connector to the vehicle must comply with IEC 60309. The standard designation for the plug connectors is "CEE blue".
- Use H07RN-F rubber sheathed cable with a minimum cable cross-section of 2.5 mm<sup>2</sup> and a maximum length of 25 m.
- Earth contact connectors (safety) are not permitted. The interconnection of CEE/safety adapters is also prohibited.

### 8.9.2 Connecting 230 V power supply



- ▶ The external 230 V power supply must be protected by fuse with a fault current protection switch (FI-switch, 30 mA).
- ▶ To prevent overheating, the cable must be fully uncoiled from the cable reel.
- ▶ In case of doubt or if the 230 V supply is not available or is faulty, contact the operator of the power supply device.



- ▷ The 230 V connection in the vehicle is equipped with a fault current protection switch (FI-switch).
- ▷ For the connection points on camp sites (camping distributors) fault current protection switches (FI-switches, 30 mA) are obligatory.

The vehicle can be connected to an external 230 V power supply.



Fig. 178 230 V fuse box with safety cut-out and FI-switch



Fig. 179 230 V connection on vehicle

#### Connecting the vehicle:

- Check whether the power supply device is suitable regarding connection, voltage, frequency and current.
- Check whether the cables and connections are suitable.
- Check the plug connectors and cables for visible damage.
- Switch off the safety cut-out (Fig. 178,1 and 2) in the fuse box (Fig. 178,3).
- Open the cover of the 230 V connection on the vehicle (Fig. 179) and insert the plug connector. Ensure that the detent of the spring-mounted pivoting cover is engaged in position.
- Plug the connector of the connecting cable into the socket of the power supply device. Ensure that the detent of the spring-mounted pivoting cover is engaged in position.
- Switch on the safety cut-out in the fuse box.

#### Checking the fault current protection switch:

- When the vehicle is connected to the 230 V supply, press the check button (Fig. 178,5) of the fault current protection switch (FI-switch) (Fig. 178,4) in the fuse box (Fig. 178,3). The fault current protection switch must trip.
- Switch the fault current protection switch back on again.

#### Unplugging the connection:

- Switch off the safety cut-outs (Fig. 178,1 and 2) in the fuse box (Fig. 178,3).
- Loosen the detent on the power supply device and unplug the connection cable from the socket.
- Loosen the detent on the vehicle, unplug the plug connector and close the cover of the 230 V connection.


## 8.10 Fuses



- ▶ Only replace defective fuses when the cause of the defect is known and has been remedied.
- ▶ Replace defective fuses only after the power supply has been turned off.
- ▶ Never bridge or repair fuses.
- ▶ Only replace faulty fuses with a new fuse with the same rating.

### 8.10.1 12 V fuses

The appliances connected to the 12 V power supply in the living area are fused individually. The fuses can be accessed in the driver's cabin, on the batteries, on or next to the transformer and on the appliances.




- 1 Unbroken fuse element
- 2 Broken fuse element

Fig. 180 12 V fuse

An intact 12 V fuse can be detected by the unbroken fuse element (Fig. 180,1). If the fuse element is broken (Fig. 180,2), change the fuse. Before changing fuses, take the function, value and colour of the relevant fuses from the following specifications. When changing fuses, only use flat fuses with the values shown below.

### Fuses on the starter battery

The fuses are installed in the footwell in front of the driver's seat below a cover.




- 1 Flat fuse 20 A/yellow (for the refrigerator)
- 2 Jumbo flat fuse 50 A/red

Fig. 181 Fuses on the starter battery

### Fuses on the living area battery

The fuses are fitted next to the living area battery.



- 1 Jumbo flat fuse 50 A/red (for the transformer/rectifier)
- 2 Flat fuse 2 A/grey (for battery sensor, living area battery)

Fig. 182 Fuses on the living area battery

### Fuses on the relay box AD01 Fiat base vehicle

A relay box (AD01) is installed in one of the two seat consoles. The relay box helps generate the signals for the chassis lighting not provided by the base vehicle. The relay box can be used anywhere.

The circuit used by us can vary from the circuit provided by the manufacturer. Consequently, the circuit can also vary from the display on the relay box type plate, which the manufacturer affixed.


| FuNo | Function                             | Value/colour              |
|------|--------------------------------------|---------------------------|
| B2   | Cl. 15 (Ignition On)                 | 15 A blue                 |
| B3   | Cl. 30 (constant position)           | 15 A blue                 |
| B5   | D+ Signal                            | Internal polyswitch (2 A) |
| B6   | Spare                                | 15 A blue                 |
| B7   | Front side marker lights (white/red) | 5 A light brown           |

### Fuses on the transformer/rectifier (EBL 99)

| Function  | Value/colour    |
|---|-----------------|
| Internal charger module                               | 20 A yellow     |
| Compressor/AES refrigerator                           | 20 A yellow     |
| Heater  | 10 A red        |
| Basic light/electrically operated entrance step/radio | 25 A white      |
| Spare 4   | 25 A white      |
| Spare 3   | 25 A white      |
| Spare 2   | 15 A blue       |
| Spare 1   | 15 A blue       |
| Solar   | 15 A blue       |
| Spare 5   | 15 A blue       |
| Spare 6   | 15 A blue       |
| Auxiliary charging unit                               | 20 A yellow     |
| Circuit 1   | 10 A red        |
| Circuit 2   | 10 A red        |
| TV  | 10 A red        |
| Water pump  | 5 A light brown |

### Fuse for the Thetford toilet (swivel toilet)

The fuse is located in the locker wall of the Thetford cassette.




1 Flat fuse 3 A/purple

Fig. 183 Fuse for the Thetford toilet

- Changing:**
- Open the flap for the Thetford cassette on the outside of the vehicle.
  - Pull out the Thetford cassette completely.
  - Replace fuse (Fig. 183,1).

**Fuse for the Thetford toilet (fixed seat)**

The fuse is located in the locker wall of the Thetford cassette.



- 1 Flat fuse 3 A/purple


Fig. 184 Fuse for the Thetford toilet

*Changing:*

- Open the flap for the Thetford cassette on the outside of the vehicle.
- Remove the Thetford cassette and swing out the flap in the housing panel.
- Replace fuse (Fig. 184,1).

**Fuse for the Dometic toilet**

The fuse is located on the rear side of the control unit for the toilet.



- 1 Control unit
- 2 Flat fuse 10 A/red


Fig. 185 Fuse for toilet

*Changing:*

- Lift the control unit for the toilet (Fig. 185,1) with a suitable tool and pull it from the wall.
- Replace fuse (Fig. 185,2).

**Fuel cell fuse (special equipment)**

Two fuses are located next to the living area battery.



- 1 Flat fuse 2 A/grey
- 2 Flat fuse 15 A/blue

Fig. 186 Fuses for fuel cell

### Fuse on the solar charge regulator (special equipment)

The fuse is located on the solar charge regulator.




Fig. 187 Solar charge regulator fuse 100 W




Fig. 188 Solar charge regulator fuse 200 W

*Replacing the fuse on the solar charge regulator 100 W:*

- Disconnect all 12 V appliances.
- Replace flat fuse 5 A/light brown (Fig. 187,1).

*Replacing the fuse on the solar charge regulator 200 W:*

- Disconnect all 12 V appliances.
- Replace flat fuse 15 A/blue (Fig. 188,1).

### 8.10.2 230 V fuse



- ▷ Check the fault current protection switch for each connection to the 230 V power supply, at least once every 6 months.



Fig. 189 230 V fuse box with safety cut-out and FI-switch

A fault current protection switch (FI-switch) (Fig. 189,4) in the fuse box (Fig. 189,3) protects the complete vehicle from fault current (0.03 A).

The downstream safety cut-out (10 A) (Fig. 189,2) secures the 230 V sockets, the power supply unit, the auxiliary charging unit and the refrigerator.


For vehicles with special equipment, e.g. air conditioning unit, an additional safety cut-out (16 A) (Fig. 189,1) secures the device.

**Position** See chapter 16.

*Checking fault current protection switch:*

- When the vehicle is connected to the 230 V power supply, press the test button (Fig. 189,5). The fault current protection switch (RCD) must be activated.

### 8.11 External socket (special equipment)



- 1 TV socket
- 2 12 V socket
- 3 SAT socket
- 4 230 V socket

Fig. 190 External socket

The 230 V socket and the 12 V socket can be used to power electrical devices in the awning.

#### Connection possibilities

TV socket and SAT socket offer various possibilities for TV operation:




Fig. 191 TV inside the vehicle




Fig. 192 TV in the awning

- TV inside the vehicle (Fig. 191,4): Connection to roof antenna (Fig. 191,1) with connection cable (Fig. 191,2)
- TV inside the vehicle (Fig. 191,4): Connection to external antenna (Fig. 191,3)
- TV inside the awning (Fig. 192,4): Connection to roof antenna (Fig. 192,1) with connection cable (Fig. 192,2)
- TV inside the awning (Fig. 192,4): Connection to external antenna (Fig. 192,3)

## 8.12 Circuit diagrams

## 8.12.1 Circuit diagrams, interior




Fig. 193 Circuit diagram, interior (EBL 99)




Fig. 194 Connection diagram, panel (IT 96-2)

|          |                                     |
|----------|-------------------------------------|
| <b>A</b> | <b>2 x AMP flat pins 4.8 x 0.8</b>  |
| 1        | + 12 V                              |
| 2        | Pump                                |
| <b>B</b> | <b>Lumberg MSFQ 5-pin</b>           |
| 1        | Full                                |
| 2        | 3/4                                 |
| 3        | 1/2                                 |
| 4        | 1/4                                 |
| 5        | Base waste water tank               |
| <b>C</b> | <b>Lumberg MSFQ 6-pin</b>           |
| 1        | Full                                |
| 2        | 3/4                                 |
| 3        | 1/2                                 |
| 4        | 1/4                                 |
| 5        | Base water tank                     |
| 6        | n. c.                               |
| <b>D</b> | <b>Lumberg MSFQ 9-pin</b>           |
| 1        | 12 V indicator                      |
| 2        | 12 V main switch off                |
| 3        | 12 V main switch on                 |
| 4        | + Starter battery 12 V              |
| 5        | + Living area battery sensor        |
| 6        | Negative living area battery sensor |
| 7        | 230 V indicator                     |
| 8        | n. c.                               |
| 9        | n. c.                               |




Fig. 195 Block diagram for panel (IT 994)

|            |   |
|------------|---|
| <b>A</b>   | <b>2 x AMP flat pins 4.8 x 0.8</b>  |
| 1          | + 12 V  |
| 2          | Pump  |
| <b>B</b>   | <b>Lumberg MSFQ 9-pin</b>   |
| 1          | 12 V indicator  |
| 2          | 12 V main switch off  |
| 3          | 12 V main switch on   |
| 4          | + Starter battery 12 V  |
| 5          | + Living area battery sensor  |
| 6          | Negative living area battery sensor   |
| 7          | 230 V indicator   |
| 8          | Shunt for appliances  |
| 9          | Shunt battery   |
| <b>C</b>   | <b>Lumberg MSFQ 5-pin</b>   |
| 1          | Full  |
| 2          | 3/4   |
| 3          | 1/2   |
| 4          | 1/4   |
| 5          | Base waste water tank   |
| <b>D</b>   | <b>Lumberg MSFQ 6-pin</b>   |
| 1          | Full  |
| 2          | 3/4   |
| 3          | 1/2   |
| 4          | 1/4   |
| 5          | Base water tank   |
| 6          | n. c.   |
| <b>E</b>   | <b>2 x Lumberg MSFQ 2-pin plugs</b>   |
| <b>IN</b>  | <b>External internal temperature sensor (optional)</b>  |
| <b>OUT</b> | <b>External temperature sensor</b>  |
|            |  ▷ If an external internal temperature sensor is used, both gray stranded wires of the internal internal temperature sensor are separated. |

### 8.12.2 Circuit diagram, exterior

Fiat




Fig. 196 Circuit diagram, exterior

Left side

| Bürstner colours | Connection               |
|------------------|--------------------------|
| Grey             | Left direction indicator |
| Blue             | Fog tail light           |
| White            | Earth return             |
| Green            | Back-up light            |
| Red              | Brake light              |
| Black            | Left rear light          |

Right side

|       |                           |
|-------|---------------------------|
| Grey  | Right direction indicator |
| Blue  | Fog tail light            |
| White | Earth return              |
| Green | Back-up light             |
| Red   | Brake light               |
| Black | Right rear light          |



## Chapter overview

This chapter contains instructions regarding the appliances of the vehicle.

The instructions refer exclusively to the operation of the appliances.

Further information about the appliances can be found in the instruction manuals for the appliances, included separately with the vehicle.

The instructions address the following topics:

- heater
- air conditioning unit
- boiler
- gas cooker
- gas oven
- microwave oven
- extractor hood
- refrigerator

### 9.1 General



- ▷ The heat exchanger of the Truma hot-air heater has to be replaced after 30 years. The heat exchanger of the Alde hot-water heater has to be replaced after 10 years. Only the manufacturer of the heater or an authorised specialist workshop is allowed to replace the heat exchanger. The operator of the heater must see to it that the parts are replaced.
- ▷ For safety reasons, spare parts for pieces of heating appliances must correspond with manufacturer's instructions and be permitted by the manufacturer as a spare part. These spare parts may only be fitted by the manufacturer or an authorised specialist workshop.




- ▷ Further information can be obtained in the instruction manual for the respective appliance.

The heater, air conditioning unit, boiler, cooker and refrigerator are fitted depending on the model of the vehicle.

In this instruction manual a description is given only for the operation of the appliances and their particular features.

To operate gas appliances, first open the regulator tap on the gas bottle and the gas isolator tap corresponding to the appliance.



- 1 Oven
- 2 Refrigerator
- 3 Heater/boiler
- 4 Cooker

Fig. 197 Symbols for the gas isolator taps

## 9.2 Heater



- ▶ Never let gas escape unburned due to danger of explosion.
- ▶ Never run the heater in gas operation when refuelling, on ferries or in the garage. Danger of explosion!
- ▶ Never operate the heater in gas operation in closed spaces (e.g. garages). Danger of poisoning and suffocation!
- ▶ The waste gas vent may neither be closed nor blocked.
- ▶ Do not use the space behind the heater as a storage compartment.



- ▷ The circulation fan of the hot-air heater automatically goes on when the hot-air heater is activated and is automatically switched off and on during operation by means of a thermostat control. This puts an immense strain on the living area battery, if the vehicle is connected to an external 230 V power supply. Take into consideration that the living area battery only has limited reserves of energy.

### Initial start-up

When lighting the heater for the first time a small amount of smoke and odour will occur. Immediately set the operating switch of the heater to its highest position. Open doors and windows and ventilate well. Smoke and odour will disappear by themselves after a while.

### 9.2.1 Models with waste gas vent on the right-hand side of the vehicle



- ▶ If the awning is put up and the heater is running in gas operation, exhaust gases from the heater can escape into the awning area. Danger of suffocation! Make sure the area is sufficiently ventilated.

### 9.2.2 To heat properly



Fig. 198 Air outlet nozzle

### Hot air distribution

Several air outlet nozzles (Fig. 198) are built into the vehicle. Pipes conduct the warm air to the air outlet nozzles. Turn the air outlet nozzles in a suitable position so the air can escape as required. To avoid draft close the air outlet nozzles on the dashboard and set the air distribution of the base vehicle to air circulation.

### Adjusting the air outlet nozzles

- Fully open: Full hot air stream
- Half or partially open: Reduced hot air stream


When five air outlet nozzles are completely opened, less warm air escapes through each nozzle. However, if only three air outlet nozzles are opened, more warm air flows out of each nozzle.

### 9.2.3 Truma Combi hot-air heater



▷ If there is a risk of frost and the heater is not in operation, empty the boiler.

Depending on the equipment, different heaters are installed in the vehicles. The heaters differ with regard to the energy type with which they can be operated.



- 1 Temperature control knob
- 2 Summer operation water temperature 40 °C or 60 °C
- 3 Rotary switch
- 4 Off
- 5 Winter operation "Heater without boiler"
- 6 Winter operation "Heater and boiler"
- 7 Green indicator lamp "Heating operation"
- 8 Red indicator lamp "Fault"
- 9 Yellow indicator lamp "Boiler heating-up phase"

Fig. 199 Operating unit for heater/boiler

#### Operating modes

All heaters have two operating modes:

- Winter operation
- Summer operation

It is only possible to heat the vehicle in the "Winter" operating mode. With the "Summer" operating mode only water in the boiler is heated. It is not possible to heat the vehicle in this operating mode.

#### Selecting operating mode:

- Set the operating mode using the rotary switch (Fig. 199,3).

The power supply of the heater cannot be interrupted by means of the 12 V main switch.

#### Variant: Heater with gas operation

The heater is operated exclusively with gas.

#### Winter operation

The heater selects the necessary burner setting according to the required room temperature. When the required room temperature is reached, the burner is switched off. In "Heater and boiler" operating mode (Fig. 199,6) water in the boiler is also heated. In the operating mode "Heater without boiler" (Fig. 199,5) the heater can be operated with an empty boiler.

#### Switching on:

- Open the regulator tap on the gas bottle and the gas isolator tap "Heater/boiler".
- Turn the temperature control knob (Fig. 199,1) on the operating unit to the desired heating level.
- Set rotary switch (Fig. 199,3) to winter operation "Heater without boiler" (Fig. 199,5) or to winter operation "Heater and boiler" (Fig. 199,6).

Green indicator lamp (Fig. 199,7) is on.

The circulation fan automatically switches on when the heater is activated.

*Switching off:*

- Set the rotary switch (Fig. 199,3) to "O" (Fig. 199,4).
- Close the gas isolator tap "Heater/boiler" and the regulator tap on the gas bottle.

After switching off the heater, the circulation fan may still run for a moment to use up the residual heat.


**Summer operation**

It is not possible to heat the vehicle in "Summer" operating mode. In "Summer" operating mode, only the water in the boiler is heated.

**Variant: Heater with gas and 230 V electrical operation**



- ▷ 230 V electrical operation is only possible when the vehicle is connected to the 230 V power supply.
- ▷ Select the output level for 230 V electrical operation so that it corresponds to the fuse protection of the 230 V connection (900 W for 3.9 A fuse, 1800 W for 7.8 A fuse).
- ▷ When the heater on the operating unit is set to summer operation and the energy selector switch is set to mixed operation, the heater will only heat the water in the boiler. For this, the heater only runs in 230 V operation. The gas burner is not switched on. The vehicle is not heated.



- 1 230 V electrical operation (1800 W)
- 2 230 V electrical operation (900 W)
- 3 Gas operation
- 4 Gas and 230 V electrical operation (900 W)
- 5 Gas and 230 V electrical operation (1800 W)
- 6 Yellow indicator lamp "230 V electrical operation"

Fig. 200 Energy selector switch for heater/boiler

The heater can be operated with different types of energy:

- Gas operation (Fig. 200,3)
- 230 V electrical operation with the output levels 900 W (Fig. 200,2) or 1800 W (Fig. 200,1)
- Gas and 230 V electrical operation (mixed operation) with the output levels 900 W (Fig. 200,4) or 1800 W (Fig. 200,5)

The combination gas operation and 230 V electrical operation reduces the heating-up time of the vehicle (only possible when the heater on the operating unit (Fig. 199) is set to winter operation).

When 230 V electrical operation is selected, the yellow indicator lamp (Fig. 200,6) illuminates.



- ▷ Further information can be obtained in the manufacturer's instruction manual.
- ▷ For further information about the use of the boiler see section "Boiler".


### 9.2.4 Truma Combi hot-air heater D



- ▶ Take the device out of operation by removing the fuse and contact customer service if one of the following events occurs: Long lasting, strong development of smoke; unusual combustion noises; smell of fuel; continuous fault shut-down with error message (blink code).



- ▷ The heater is powered with diesel fuel from the fuel tank of the base vehicle. The heater is not approved for operation with biodiesel (PME, RME, AME).
- ▷ During heating, do not empty the fuel tank down to the reserve mark of the fuel gauge in order to avoid air entering the supply lines.
- ▷ Operate the heater every 4 weeks for approx. 10 minutes in order to prevent a blockage of moving parts.
- ▷ If there is a risk of frost and the heater is not in operation, empty the boiler.



- 1 Temperature control knob
- 2 Summer operation water temperature 40 °C or 60 °C
- 3 Rotary switch
- 4 Off
- 5 Winter operation "Heater without boiler"
- 6 Winter operation "Heater and boiler"
- 7 Green indicator lamp "Heating operation"
- 8 Yellow indicator lamp "Boiler heating phase" or red indicator lamp "Fault"

Fig. 201 Operating unit for heater/boiler

#### Operating modes

All heaters have two operating modes:

- Winter operation
- Summer operation

It is only possible to heat the vehicle in the "Winter" operating mode. With the "Summer" operating mode only water in the boiler is heated. It is not possible to heat the vehicle in this operating mode.

#### Selecting operating mode:

- Set the operating mode using the rotary switch (Fig. 201,3).

The power supply of the heater cannot be interrupted by means of the 12 V main switch.

#### Winter operation

The heater selects the necessary burner setting according to the required room temperature. When the required room temperature is reached, the burner is switched off. The room temperature is measured by the temperature sensor next to the panel. In "Heater and boiler" operating mode (Fig. 201,6) water in the boiler is also heated. In the operating mode "Heater without boiler" (Fig. 201,5) the heater can be operated with an empty boiler.

#### Switching on:

- Turn the temperature control knob (Fig. 201,1) on the operating unit to the desired temperature range.
- Set rotary switch (Fig. 201,3) to winter operation "Heater without boiler" (Fig. 201,5) or to winter operation "Heater and boiler" (Fig. 201,6).

Green indicator lamp (Fig. 201,7) comes on and indicates at the same time the selected temperature range.

When the boiler is filled, the yellow indicator lamp (Fig. 201,8) indicates the water heating phase.

The circulation fan automatically switches on when the heater is activated.

**Switching off:** ■ Set the rotary switch (Fig. 201,3) to "O" (Fig. 201,4).

After switching off the heater, the circulation fan may still run for a moment to use up the residual heat.

### Summer operation

It is not possible to heat the vehicle in "Summer" operating mode. In "Summer" operating mode, only the water in the boiler is heated.



▷ Further information can be obtained in the manufacturer's instruction manual.

### 9.2.5 Alde hot-water heater (special equipment)



- ▷ Never run hot-water heater without heating fluid. Observe notes in chapter 12.
- ▷ Never drill holes in the floor. This might damage the hot-water pipes.




- ▷ The circulating pump must always be turned on when the hot-water heater is in operation.
- ▷ We recommend to bleed the heating system after the initial heater operation and to check the glycol content. Observe notes in chapter 12.
- ▷ When the heater is turned on, it starts with the last settings used.
- ▷ For further information, see the separate manufacturer's instruction manual and observe the maintenance instructions found in chapter 12.
- ▷ For further information about the use of the boiler see section "Boiler".

The hot-water heater is installed at the bottom of the wardrobe or under the beds.

### Operating unit

The operating unit is divided into two sections:

- Display (touch screen)
- Control buttons



- 1 Display (touch screen)
- 2 "Menu" button
- 3 On/Off button

Fig. 202 Operating unit for hot-water heater



- ▷ When no button is pressed, the operating unit automatically switches to home position after two minutes.
- ▷ Changes to the settings are saved automatically after 10 seconds.

**Control buttons** The control buttons have the following functions:

| Pos. in Fig. 202 | Button | Function             |
|------------------|--------|----------------------|
| 2                | MENU   | Open adjustment menu |
| 3                |        | Activate heating     |

**Display** The display (Fig. 202,1) is designed as a touch screen. Touching the symbols calls up the relevant function.



Fig. 203 Start screen

**Start screen** The Start screen appears on the display after the heater is switched on. The Start screen contains the following information:

| Symbol | Signification   |
|--------|---|
|        | This symbol appears when the circulating pump is activated                                |
|        | This symbol appears when a switching facility for gas cylinders is activated              |
|        | This symbol appears when a voltage of 230 V is present at the heater                      |
|        | The internal temperature is displayed next to this symbol                                 |
|        | The external temperature is displayed next to this symbol if an external sensor is fitted |

**Adjustment menu** The "MENU" button calls up the adjustment menu. The meanings of the individual symbols are described in the following table.

The values can be increased or reduced via the "+" or "-" symbols.

| Symbol | Signification                                    |
|--------|--|
|        | Set the desired temperature of +5 °C to +30 °C   |
|        | Set the water temperature in the boiler          |
|        | Set the heat output in electrical operation      |
|        | Activate the function "Heating in gas operation" |
|        | Call up the enabling menu for the tool menus     |

**Tool menus** The various heater functions can be called up and adjusted via the tool menus. The arrow symbols are used to change between the menus. The meanings of the individual symbols are described in the manufacturer's instruction manual.

### Selecting the operating mode

The hot-water heater can be operated with the following energy sources:

- Gas operation
- 230 V electrical operation
- Gas and 230 V electrical operation

The operating mode is selected from the operating unit.

#### Selecting gas operation:

- Press the "On" button next to the "🔥" symbol. The gas operation is activated.

#### Selecting 230 V electrical operation:

- Press the "+" button next to the "⚡" symbol until the desired heat output is reached.



- ▷ Select the output level during 230 V electrical operation in such a way that it corresponds to the 230 V connection protection:

Level 1 (1 kW) at 6 A

Level 2 (2 kW) at 10 A

Level 3 (3 kW) at 16 A

#### Selecting gas and 230 V electrical operation:



- Select gas operation and 230 V electrical operation on the operating unit.

- ▷ If gas and 230 V electrical operation is selected and if the vehicle is connected to the 230 V power supply, then the hot-water heater at first only operates in 230 V electric operation. Only if the heat output is insufficient does the gas operation also automatically switch on.
- ▷ The gas operation is only possible when the regulator tap on the gas bottle and the gas isolator tap are opened.
- ▷ 230 V electrical operation is only possible when the vehicle is connected to the 230 V power supply.

When the heater is turned on, it starts with the last set operating mode.

#### Switching on the heater:

- Press "⏻" button. The Start screen appears in the display. The heater starts automatically.

#### Switching the heater off:

- Press "⏻" button. The heater is turned off.

**Heat distribution**

Depending on the model, the temperature of the convectors in the rear area can be controlled separately. A stopcock is located in the rear of the vehicle for this purpose.

The flow to the convectors in the rear area is controlled with the stopcock.




Fig. 204 Stopcock is open




Fig. 205 Stopcock is closed

*Opening the line to the convectors:*

- Set the lever (Fig. 204,1) of the stopcock parallel to the pipe (Fig. 204). The wider the stopcock is opened, the higher is the heat output.

*Closing the line to the convectors:*

- Set the lever (Fig. 205,1) of the stopcock at right angles to the pipe.

**Setting the rotational speed of the circulating pump**


- ▷ The hot-water heater is equipped with a very powerful pump. In smaller vehicles, the pump can only be operated at full power if the pipes are bled. Otherwise, this will increase wear; loud operating noises are the result.



Fig. 206 Speed reduction

The rotational speed of the circulating pump can be set with the control knob (Fig. 206,2). At a lower rotary speed, the operating sounds of the pump are quieter.

The control knob is located on the circulating pump (Fig. 206,1).

*Setting the output:*

- Turn the control knob (Fig. 206,2) in an anticlockwise direction. The output is reduced.
- Rotate the control knob in a clockwise direction. The output is increased.

### Alde heat exchanger (special equipment)



- ▷ The heat exchanger only works when the vehicle engine is running.
- ▷ If the heat exchanger is not being used (as in the summer), the heat exchanger on the stopcock should be shut off.

The heat exchanger can be used to heat the living area of the vehicle during travel without operating the hot-water heater in the living area.

The heat exchanger is connected to the vehicle engine's cooling circuit and thus has the same function as the vehicle heater.

Heat output is set with the living area's heating regulator.

The heat exchanger stopcock is located directly on the exchanger.

#### *Turning on the vehicle heating by heat exchanger:*

- Make sure the heat exchanger stopcock is open.
- Press the "⏻" (Fig. 202,3) button on the operating unit (Fig. 202). The Start screen appears in the display. That turns on the heating control system and makes the circulating pump run.
- Press "MENU" button (Fig. 202,2).
- Turn off gas operation or 230 V electrical operation (if turned on).
- Set the desired room temperature. To do that, press the "+" or "-" button next to the "🏠" symbol.

#### *Turning off the heat exchanger vehicle heating:*

- Press the "⏻" (Fig. 202,3) button on the operating unit (Fig. 202).



Fig. 207 Alde heat exchanger

*Turning on:* ■ Set stopcock handle (Fig. 207,1) parallel to the pipe.

*Shutting off:* ■ Set drain cock handle (Fig. 207,1) at a right angle to the pipe.

**Position** The heat exchanger is installed in the rear bench seat of the central seating group.

**Alde auxiliary circulating pump (special equipment)**


- ▷ The auxiliary circulating pump works only if the heat exchanger has been installed and started, and the hot-water heater is running.




Fig. 208 Auxiliary circulating pump

The auxiliary circulating pump (Fig. 208,1) can be used to heat the vehicle engine when parked.

The auxiliary circulating pump is connected to the vehicle engine's cooling circuit and thus functions as an engine heater.



Fig. 209 Operating switch for auxiliary circulating pump

The auxiliary circulating pump switch (Fig. 209) is located next to the hot-water heater operating unit. The yellow indicator lamp illuminates when the pump is operated.

**9.2.6 Auxiliary heat exchanger (partially special equipment)**


- ▷ The fan on the auxiliary heat exchanger can be used for ventilation.
- ▷ The heat output is continuously adjusted.

The auxiliary heat exchanger is built into the bench seat.

The auxiliary heat exchanger may be used to provide the vehicle's living area with additional heat during the journey.

The auxiliary heat exchanger is integrated into the heat circulation of the base vehicle and is therefore only in operation when the vehicle engine is running.



Fig. 210 Operating controls for auxiliary heat exchanger

- Switching on:**
- Push the sliding regulator (Fig. 210,1) of the flow control downward to the desired position. The water circulation is open.
  - Turn the fan switch (Fig. 210,2) for the circulation fan in a clockwise direction.
- Switching off:**
- Turn the fan switch (Fig. 210,2) to "0".
  - Push the sliding regulator (Fig. 210,1) of the flow control upward as far as it goes.

### 9.2.7 Electrical floor warming unit (special equipment)



- ▶ On models with electrical floor warming unit, never drill holes in the floor or screw in any screws. Careful with sharp objects. There is danger of a power cut or a short circuit due to damage to a heater wire.



- ▶ Do not cover the transformer. Danger of overheating!



- ▶ The electrical floor warming unit only operates if the vehicle is connected to the 230 V power supply.
- ▶ The output of the electrical floor warming unit alone is not sufficient to heat the living area.



Fig. 211 Transformer for electrical floor warming unit



Fig. 212 Switch for electrical floor warming unit

The transformer (Fig. 211,1) for the electrical floor warming unit is installed either in the bench seat or in the bedding box, depending on the model.

- Switching on:*
- Connect the vehicle to the 230 V power supply (see chapter 8).
  - Press the rocker switch (Fig. 212,2). The indicator lamp (Fig. 212,1) on the switch is illuminated.

- Switching off:*
- Press the rocker switch (Fig. 212,2). The indicator lamp (Fig. 212,1) on the switch goes off.

After switching off, the floor remains warm for a while, due to residual heat. If the transformer is overloaded, the overload protection is actuated. The pin (Fig. 211,2) jumps out.

- Switching on overload protection:*
- Press the pin (Fig. 211,2) on the overload protection when the transformer is cooled.

### 9.2.8 Independent vehicle heater (special equipment)



- ▶ Do not operate the heater in closed spaces. Danger of suffocation!
- ▶ Do not operate the heater at petrol stations. Danger of explosion!

The inside and the engine can be heated with the independent vehicle heater. The heating of the engine can be switched off.

The independent vehicle heater can be turned on and off manually or with a timer. The time for the heating to start can be exactly preselected from 1 minute to 24 hours. It is possible to program three switching on times, of which only one can be activated. The maximum permitted operation time is 60 minutes.




Fig. 213 Operating unit for independent vehicle heater

- Switching on the heater for the base vehicle:*
- Set the heater control to "Warm".
  - Switch on the fan.
  - For continuous operation: Set the fan to the lowest fan setting (due to battery capacity).
  - To quickly heat up the vehicle: Set the fan to a higher fan setting.
  - Open and close the base vehicle's air outlet nozzles as desired.

- Switching on the independent vehicle heater manually:*
- Press the button (Fig. 213,7). The heating mode is displayed by the symbol (Fig. 213,9). The fan will only be switched on when there is a coolant temperature of 30 °C.

- Switching off the independent vehicle heater manually:*
- Press the button (Fig. 213,7). The symbol (Fig. 213,9) goes off.

- Switching on the engine heating:*
- Press the lower part of the switch (Fig. 213,4). Engine is preheated. The fan is switched on immediately.
- Switching off the engine heating:*
- Press the upper part of the switch (Fig. 213,4). Engine stays cold.
- Setting the time:*
- Press the button (Fig. 213,2). The time setting is displayed by the symbol (Fig. 213,8).
  - Set the time with the buttons (Fig. 213,3 and 6).
- Programming heating start:*
- Press the button (Fig. 213,5).
  - Set the switching on time within ten seconds, with the buttons (Fig. 213,3 and 6).
- Selecting programmed switching on time:*
- Keep pressing the button (Fig. 213,5) until the selected programme number (Fig. 213,1) appears in the display.

## 9.3 Air conditioning unit (special equipment)

### 9.3.1 Dometic



- ▷ If the unit is operating, always open at least one ventilation flap.



- ▷ In the winter, vehicle heating can be supported but not replaced by the air conditioning unit.
- ▷ Also read the manufacturer's instruction manual.




Fig. 214 Remote control

- 1 Symbol for automatic mode
- 2 Symbol for cold mode
- 3 Symbol for warm mode
- 4 Symbol for ventilation mode
- 5 Symbol for discharged batteries
- 6 Time
- 7 Temperature display
- 8 Fan speed display
- 9 ON/OFF button
- 10 Fan speed button
- 11 "MODE" button
- 12 "CLOCK" button
- 13 Reset key
- 14 Interior temperature display button "ROOM"
- 15 Store button "SET"
- 16 Light button "LIGHT"(optional)
- 17 Temperature unit change button "F/C"
- 18 Temperature decrease button "-"
- 19 Temperature increase button "+"
- 20 Display

To execute the individual switching commands, always point the remote control in the direction of the ceiling unit.

### Operating modes

The air conditioning unit has the following operating modes:

- Automatic
- Ventilation, manual

- Cooling, manual
- Heating, manual

- Switching on:*
- Press the ON/OFF button (Fig. 214,9).
  - Press the "Mode" button (Fig. 214,11) as often as required until the required mode (Fig. 214,1, 2, 3 or 4) is indicated on the display (Fig. 214,20).
  - Use the "+" (Fig. 214,19) and "-" (Fig. 214,18) buttons to set the desired temperature.
  - Use the fan speed button (Fig. 214,10) to select the desired fan level.

- Switching off:*
- Press the ON/OFF button (Fig. 214,9).



Fig. 215 Air conditioning unit (Dometic)

**LED** The LED (Fig. 215,4) on the ceiling unit (Fig. 215,1) displays the operating status of the air conditioning unit:

| Status LED                         | Signification                           |
|------------------------------------|---|
| Off                                | Air conditioning unit off               |
| Orange                             | Air conditioning unit ready to operate  |
| Green                              | Air conditioning unit in operation      |
| Red (continuous)                   | No 230 V power connection               |
| Red (flashes once intermittently)  | Fault in the interior temperature gauge |
| Red (flashes twice intermittently) | Fault in the exterior temperature gauge |

**Air current** The air current can be directed in different directions. The distribution of the air current toward the front or back is continuously adjustable.

- Adjusting air current:*
- Align the two deflectors (Fig. 215,3 and 5) in the desired position.
  - Rotate knob (Fig. 215,2) on sliding regulator in an anticlockwise direction. The sliding regulator for air distribution is released.
  - Slide the sliding regulator forwards or backwards to the desired position. The side on which the sliding regulator is located is closed.
  - Turn the knob tight in the clockwise direction.


### 9.3.2 Telair



- ▷ Always wait at least 2 minutes between switching off and switching on again. Otherwise the compressor will be damaged.
- ▷ If the unit is operating, always open at least one ventilation flap.




- ▷ The air conditioning unit only runs if the vehicle is connected to a 230 V power supply.
- ▷ In the winter, vehicle heating can be supported but not replaced by the air conditioning unit.
- ▷ Following switch-on the air conditioning unit needs approx. 3 minutes until the compressor starts to run and cold air or hot air is output.
- ▷ Also read the manufacturer's instruction manual.



- 1 Symbol for automatic
- 2 Symbol for cooling
- 3 Symbol for heater
- 4 Temperature (set) display
- 5 Fan speed display
- 6 Temperature increase button
- 7 "ON/OFF" button
- 8 Temperature reduction button
- 9 Ventilation speed button
- 10 "Mode" button
- 11 Display

Fig. 216 Remote control



- 1 Mains connection indicator lamp
- 2 Temperature (current) display
- 3 Mode indicator lamp  
Green: Cooling  
Red: Heater

Fig. 217 Display on the diffuser

To execute the individual switching commands, always point the remote control in the direction of the receiver.

#### Operating modes

- Automatic
- Cooling
- Heater

#### Switching on:

- Press the "ON/OFF" button (Fig. 216,7).
- Press the "Mode" button (Fig. 216,10) as often as required until the required mode (Fig. 216,1, 2 or 3) is indicated on the display. The corresponding indicator lamp on the diffuser display (Fig. 217,3) lights up.
- Use the temperature increase button (Fig. 216,6) or temperature reduction button (Fig. 216,8) to set the required temperature.
- Use the ventilation speed button (Fig. 216,9) to select the required ventilation level.

Switching off:

- Press the "ON/OFF" button (Fig. 216,7).



- ▷ If the air conditioning unit has run in heating mode, the blower will run on for some minutes in order to dissipate the heat completely.

## 9.4 Boiler



- ▶ Never let gas escape unburned due to danger of explosion.
- ▶ Never run the boiler in gas operation when refuelling, on ferries or in the garage. Danger of explosion!
- ▶ Never operate the boiler in gas operation in closed spaces (e.g. garages). Danger of poisoning and suffocation!
- ▶ The water in the boiler can be heated up to 65 °C. Risk of scalding!



- ▷ Never use boiler when empty.
- ▷ If the boiler is not being used, empty it if there is any risk of frost.
- ▷ Only operate the boiler with the maximum temperature setting if you require a large quantity of warm water. This protects the boiler against the build-up of limescale.




- ▷ Do not use the water from the boiler as drinking water.

### 9.4.1 Models with waste gas vent on the right-hand side of the vehicle



- ▶ If the awning is put up and the boiler is running in gas operation, exhaust gases from the boiler can escape into the awning area. Danger of suffocation! Make sure the area is sufficiently ventilated.

### 9.4.2 Truma Combi boiler



- 1 Summer operation water temperature 40 °C or 60 °C
- 2 Rotary switch
- 3 Winter operation "Heater and boiler"
- 4 Red indicator lamp "Fault"
- 5 Yellow indicator lamp "Boiler heating-up phase"

Fig. 218 Operating unit for heater/boiler

The boiler is integrated into the heater and is operated with gas (gas operation) or with gas and/or electricity (gas and 230 V electrical operation). The boiler is switched on by turning the rotary switch (Fig. 218,2) on the operating unit (Fig. 218). The type of energy is pre-selected (gas and 230 V electrical operation) with the energy selector switch (Fig. 220).

In winter operation "Heater and boiler" (Fig. 218,3) the water is automatically heated up when the heater is switched on. If the heater switches off after the required room temperature has been reached, the boiler will continue to heat up until the set water temperature has been reached.

In summer operation (Fig. 218,1) only the water in the boiler is heated up to either 40 °C or 60 °C. The water is heated to 60 °C in approx. 25 minutes. The yellow indicator lamp (Fig. 218,5) illuminates during the boiler heating-up period.

The power supply for the appliance cannot be interrupted by means of the 12 V main switch. When there is a fault, the red indicator lamp (Fig. 218,4) on the operating unit illuminates (see chapter 14).

### Safety/drainage valve

The boiler is equipped with a safety/drainage valve (Fig. 219). The safety/drainage valve prevents water in the boiler from freezing, when there is frost and the heater is not switched on.



- ▷ When the vehicle is not used for a long period of time, open the safety/drainage valve and empty the boiler.
- ▷ At temperatures below 2 °C the safety/drainage valve opens automatically. Only if the temperature of the safety/drainage valve lies above 6 °C can it be shut again.
- ▷ The water pump and the water fittings are not protected against freezing by the safety/drainage valve.



- ▷ The drainage neck of the safety/drainage valve has to be free of dirt (e.g. leaves, ice) at all times.



Fig. 219 Safety/drainage valve of the boiler

**Position** See chapter 16.

### Variant: Boiler with gas operation

The boiler is operated exclusively with gas.

### Winter operation

In the "heater and boiler" switch setting in winter operation, the boiler is already switched on.

### Summer operation

In summer operation the water can be heated up to 40 °C or 60 °C.

### Switching on:

- Open the regulator tap on the gas bottle and the gas isolator tap "Heater/boiler".
- Set the rotary switch (Fig. 218,2) on the operating unit (Fig. 218) to "Summer operation" (Fig. 218,1).

The yellow indicator lamp (Fig. 218,5) is illuminated during the heating up period. When the set water temperature is reached, the period of heating up is finished and the yellow indicator lamp fades.


*Switching off:*

- Set the rotary switch (Fig. 218,2) on the operating unit (Fig. 218) to "O".
- Close the gas isolator tap "Heater/boiler" and the regulator tap on the gas bottle.

**Variant: Boiler with gas and 230 V electrical operation**



- ▷ 230 V electrical operation is only possible when the vehicle is connected to the 230 V power supply.
- ▷ Select the output level for 230 V electrical operation so that it corresponds to the fuse protection of the 230 V connection (900 W for 3.9 A fuse, 1800 W for 7.8 A fuse).
- ▷ When the boiler on the operating unit is set to summer operation and the energy selector switch is set to mixed operation, the heater will only heat the water in the boiler. For this, the heater only runs in 230 V operation. The gas burner is not switched on.



- 1 230 V electrical operation (1800 W)
- 2 230 V electrical operation (900 W)
- 3 Gas operation
- 4 Gas and 230 V electrical operation (900 W)
- 5 Gas and 230 V electrical operation (1800 W)
- 6 Yellow indicator lamp "230 V electrical operation"

Fig. 220 Energy selector switch for heater/boiler

The boiler can be operated with different types of energy:

- Gas operation (Fig. 220,3)
- 230 V electrical operation with the output levels 900 W (Fig. 220,2) or 1800 W (Fig. 220,1)
- Gas and 230 V electrical operation (mixed operation) with the output levels 900 W (Fig. 220,4) or 1800 W (Fig. 220,5)

The combination gas operation and 230 V electrical operation reduces the heating-up time for the boiler (only possible when the boiler the operating unit (Fig. 218) is set to winter operation).

When 230 V electrical operation is selected, the yellow indicator lamp (Fig. 220,6) illuminates.

**Filling/emptying the boiler**

The boiler can be supplied with water from the water tank.

*Filling the boiler with water:*

- Switch on 12 V power supply on the panel.
- Close the safety/drainage valve. Turn the knob (Fig. 219,1) perpendicular to the safety/drainage valve and push the push button (Fig. 219,2) in.
- Set all the water taps to "Hot" and open them. The water pump is turned on. The warm water pipes are filled with water.

- Keep the taps open until the water flowing out of the taps has no bubbles in it. This is the only way to ensure that the boiler is full of water.
- Close all water taps.

*Emptying the boiler:*

- Set the rotary switch (Fig. 218,2) on the operating unit (Fig. 218) to "O".
- Open the safety/drainage valve. To do this turn the knob (Fig. 219,1) parallel to the safety/drainage valve. The push button (Fig. 219,2) jumps out. The boiler is drained to the outside by the safety/drainage valve.
- Check whether the water has been drained completely from the boiler (approx. 12 litres).




- ▷ Further information can be obtained in the manufacturer's instruction manual.

### 9.4.3 Truma Combi boiler D



- ▶ Take the device out of operation by removing the fuse and contact customer service if one of the following events occurs: Long lasting, strong development of smoke; unusual combustion noises; smell of fuel; continuous fault shut-down with error message (blink code).



- 1 Summer operation water temperature 40 °C or 60 °C
- 2 Rotary switch
- 3 Winter operation "Heater and boiler"
- 4 Yellow indicator lamp "Boiler heating phase" or red indicator lamp "Fault"

Fig. 221 Operating unit for heater/boiler

The boiler is integrated in the heater and is powered with diesel fuel from the fuel tank. The boiler is switched on by turning the rotary switch (Fig. 221,2) on the operating unit (Fig. 221).

In winter operation "Heater and boiler" (Fig. 221,3) the water is automatically heated up when the heater is switched on. If the heater switches off after the required room temperature has been reached, the boiler will continue to heat up until the set water temperature has been reached.

In summer operation (Fig. 221,1) only the water in the boiler is heated up to either 40 °C or 60 °C. The water is heated to 60 °C in approx. 25 minutes. The yellow indicator lamp (Fig. 221,4) illuminates during the boiler heating-up period.

The power supply for the appliance cannot be interrupted by means of the 12 V main switch. When there is a fault, the red indicator lamp (Fig. 221,4) on the operating unit illuminates (see chapter 14).

#### Safety/drainage valve

The boiler is equipped with a safety/drainage valve (Fig. 222). The safety/drainage valve prevents water in the boiler from freezing, when there is frost and the heater is not switched on.



- ▷ When the vehicle is not used for a long period of time, open the safety/drainage valve and empty the boiler.
- ▷ At temperatures below 2 °C the safety/drainage valve opens automatically. Only if the temperature of the safety/drainage valve lies above 6 °C can it be shut again.
- ▷ The water pump and the water fittings are not protected against freezing by the safety/drainage valve.



- ▷ The drainage neck of the safety/drainage valve has to be free of dirt (e.g. leaves, ice) at all times.



Fig. 222 Safety/drainage valve of the boiler

**Position** See chapter 16.

**Winter operation** In the "Heater and boiler" switch setting in winter operation, the boiler is already switched on.

**Summer operation** In summer operation the water can be heated up to 40 °C or 60 °C.

*Switching on:* ■ Set the rotary switch (Fig. 221,2) on the operating unit (Fig. 221) to "Summer operation" (Fig. 221,1).

The yellow indicator lamp (Fig. 221,4) is illuminated during the heating up period. When the set water temperature is reached, the period of heating up is finished and the yellow indicator lamp fades.

*Switching off:* ■ Set the rotary switch (Fig. 221,2) on the operating unit (Fig. 221) to "O".

**Filling/emptying the boiler** The boiler can be supplied with water from the water tank.

- Filling the boiler with water:*
- Switch on 12 V power supply on the panel.
  - Switch on the water pump power supply at the panel, if necessary.
  - Close the safety/drainage valve. Turn the knob (Fig. 222,1) perpendicular to the safety/drainage valve and press the button (Fig. 222,2) in.
  - Set all the water taps to "Hot" and open them. The water pump is turned on. The warm water pipes are filled with water.
  - Keep the taps open until the water flowing out of the taps has no bubbles in it. This is the only way to ensure that the boiler is full of water.
  - Close all water taps.

### Emptying the boiler:

- Switch off the water pump power supply at the panel, if necessary.
- Set the rotary switch (Fig. 221,2) on the operating unit (Fig. 221) to "O".
- Set all the water taps to "Hot" and open them.
- Open the safety/drainage valve. To do this turn the knob (Fig. 222,1) parallel to the safety/drainage valve. The snap fastener (Fig. 222,2) jumps out. The boiler is drained to the outside by the safety/drainage valve.
- Check whether the water has been drained completely from the boiler (approx. 10 litres).



- ▷ Further information can be obtained in the manufacturer's instruction manual.

### 9.4.4 Alde boiler (special equipment)

#### Switching the boiler on/off

The boiler is integrated in the hot-water heater. A separate operation is not possible. For operating the hot-water heater, see section 9.2.5.

#### Filling/emptying the boiler

The boiler can be supplied with water from the water tank.



- ▷ Depending on the model, the vehicle is fitted with one or two drain cocks.




Fig. 223 Drain cock

#### Filling the boiler with water:

- Close the drain cock(s). Position the rocking lever (Fig. 223,1) horizontally.
- Switch on 12 V power supply on the panel.
- Set all the water taps to "Hot" and open them. The water pump is turned on. The warm water pipes are filled with water.
- Keep the taps open until the water flowing out of the taps has no bubbles in it. This is the only way to ensure that the boiler is full of water.
- Close all water taps.

#### Emptying the boiler:

- Switch off boiler.
- Open all water taps and set to the central position.
- Open drain cock(s) (Fig. 223). To do so, set the rocking lever (Fig. 223,1) in a vertical position. The boiler is drained to the outside.
- Check whether the water has been drained completely from the boiler (approx. 10 litres).



- ▷ For further information, see the separate manufacturer's instruction manual and observe the maintenance instructions found in chapter 12.

**Position of the drain  
cock(s)**

See chapter 16.

## 9.5 Cooker



- ▶ Never let gas escape unburned due to danger of explosion.
- ▶ Before using the cooker make sure that there is sufficient ventilation. Open windows or the skylight.
- ▶ Do not use gas cooker or gas oven for heating.
- ▶ Do not fit any curtains in the immediate proximity of the cooker. Fire hazard!
- ▶ Always protect your hands with cooking gloves or potholders when handling hot pots, pans and similar items. There is a risk of injury.

### 9.5.1 Gas cooker



- ▶ During activation and operation of the gas cooker, no flammable objects or highly inflammable objects such as dishcloths, napkins etc. must be near the gas cooker. Fire hazard!
- ▶ The process of ignition must be visible from above and must not be covered by cooking pans placed on the cooker.
- ▶ If there is a flame protection, always put it up when using the gas cooker.
- ▶ The gas cooker lid is held closed by a spring. When closing there is danger of getting injured!



- ▷ Do not place hot objects such as cooking pans on the sink cover. The plastic can become deformed.
- ▷ Do not use the glass gas cooker lid as a hob.
- ▷ Do not close the gas cooker lid while the gas cooker is in operation.
- ▷ Do not apply pressure on the gas cooker lid when it is closed.
- ▷ Do not place hot cooking pans on the gas cooker lid.
- ▷ Keep the gas cooker lid open after cooking until the burners are cool. Otherwise the glass plate could shatter.



- ▷ Only use pots and pans whose diameter is appropriate for the gas cooker burners.
- ▷ When the flame goes out, the thermocouple automatically cuts the gas supply.
- ▷ Further information can be obtained in the device manufacturer's instruction manual.

The vehicle kitchen unit is fitted with a three-burner gas cooker.

The operating controls for the gas cooker are located directly at the gas cooker.

**Manual ignition** The gas cooker must be lit manually.



Fig. 224 Gas cooker

- Switching on:*
- Open the regulator tap on the gas bottle and the gas isolator tap "Cooker".
  - Open the gas cooker lid (Fig. 224,1).
  - Turn the control knob (Fig. 224,2) on the burner you wish to use to the ignition position (large flame).
  - Press the control knob down and hold it.
  - Light the burner with a gas lighter, a match or other suitable means of lighting.
  - Once the flame is burning, the control knob must be held down for 10 to 15 seconds, until the thermocouple automatically keeps the gas supply open.
  - Release the control knob and turn to the desired setting.
  - If ignition is unsuccessful, repeat the entire procedure.

- Switching off:*
- Turn the control knob to the 0-position. The flame fades.
  - Close the gas isolator tap "Cooker" and the regulator tap on the gas bottle.

**Automatic ignition** The gas cooker is equipped with electronic ignition.



Fig. 225 Operating controls for gas cooker

- Switching on:*
- Open the regulator tap on the gas bottle and the gas isolator tap "Cooker".
  - Open the gas cooker lid.
  - Depending on the model, fold out and lock the flame protection.
  - Turn the control knob (Fig. 225,1) on the burner you wish to use to the ignition position (large flame).
  - Press the control knob down and hold it.  
The automatic ignition produces ignition sparks. A clicking noise can be heard.

- Once the flame is burning, the control knob must be held down for 10 to 15 seconds, until the thermocouple automatically keeps the gas supply open.
- Release the control knob and turn to the desired setting.

*Switching off:*

- Turn the control knob to the 0-position. The flame fades.
- Close the gas isolator tap "Cooker" and the regulator tap on the gas bottle.

### 9.5.2 Gas oven (Dometic) (special equipment)



- ▶ Keep the ventilation openings on the gas oven open at all times.
- ▶ There must be no flammable or highly inflammable objects such as dishcloths, clothes, etc. near the gas oven when it is being lit or during operation. Fire hazard!
- ▶ If ignition has not taken place, repeat the entire procedure. If necessary, check if there is gas and/or current in the gas oven.
- ▶ If the gas oven still does not work, close the gas isolator tap and notify your service centre.
- ▶ If the burner flame is accidentally extinguished, turn the control knob to "0" and leave the burner off for at least 1 minute. Then ignite it again.
- ▶ Parts of the gas oven become very hot during operation. Never touch hot parts with bare hands.
- ▶ Place the meals, wire rack and drip pan into the gas oven so that they do not come into contact with the flame.
- ▶ Only ignite the oven and grill when the oven door is open.
- ▶ Always leave the oven door half open when grilling.
- ▶ Do not use the grill for longer than 25 minutes.



- ▷ There are two different versions of the gas oven, depending on the model. Although their appearance is not identical, operation is the same for both.
- ▷ Depending on the model the gas oven may come equipped with a grill.
- ▷ Before using the gas oven for the first time run it for 30 minutes at maximum temperature without any contents.
- ▷ When the flame goes out, the thermocouple automatically cuts the gas supply.
- ▷ A safety switch prevents ignition when the oven door is closed.
- ▷ If the ignition procedure fails repeatedly, turn the control knob to "0". Wait at least 1 minute and then ignite the gas oven manually. If necessary, check if there is gas and/or current in the gas oven. If the gas oven still does not work, close the gas isolator tap and notify your service centre.
- ▷ Further information can be obtained in the manufacturer's instruction manual.

The gas oven is equipped with electronic ignition.



Fig. 226 Gas oven (Dometic TecTower)



Fig. 227 Gas oven (Dometic)

The meaning of the symbols on the control knobs (Fig. 226,1 and Fig. 227,1) of the two gas ovens is identical:

-  and  mean oven
-  and  mean grill.

*Switching the oven on:*

- Open the regulator tap on the gas bottle and the gas isolator tap "Oven".
- Open oven door completely. The safety switch then releases the ignition.
- Press and hold control knob and turn it anti-clockwise to the required setting. Keep control knob pressed for a further 5-10 seconds. Ignition will take place automatically.
- Release control knob.
- Close oven door.

*Switching the grill on:*

- Open the regulator tap on the gas bottle and the gas isolator tap "Oven".
- Open the oven door to at least the first locking position (approx. 45°).
- Press and hold control knob and turn it clockwise to the grill symbol. Keep control knob pressed for a further 5-10 seconds. Ignition will take place automatically.
- Release control knob.
- ▷ Do not close the oven door when grilling.



*Switching off:*

- Turn the control knob to "O". The flame fades.
- Close the gas isolator tap "Oven" and the regulator tap on the gas bottle.

### 9.5.3 Microwave oven (special equipment)



- ▶ Only qualified personnel may repair the microwave oven. Improper repairs can cause major risks to the user.
- ▶ The protection device against the escape of microwave energy should never be removed.
- ▶ Use the microwave oven only if it has been properly installed.
- ▶ Only use the microwave oven when the door seal is free of damage.
- ▶ Never leave the microwave oven unattended when it is in operation.
- ▶ If there is smoke, keep the microwave oven closed, switch it off and interrupt the power supply.



- ▷ Operate the microwave oven only with the rotary plate and the rotary cross in place.
- ▷ Use only crockery suitable for microwave use.
- ▷ Only operate the microwave with appropriate contents and never run it empty.



- ▷ For cooking times under 2 minutes: First twist the cooking time control knob past "2" and then twist it back to the desired cooking time.
- ▷ Further information can be obtained in the manufacturer's instruction manual.



Fig. 228 Operating controls for microwave oven

*Switching on:*

- Press the key (Fig. 228,3) to open the door and place food into the cooking area.
- Close the door. A clicking noise can be heard when it engages.
- Select the output on the control knob (Fig. 228,1).
- Select the cooking time with the control knob (Fig. 228,2). Cooking begins.

The end of the cooking process is signaled by a signal tone. The microwave oven will switch off automatically.

*Switching off:*

- Press the key (Fig. 228,3) to open the door and take out the food.

**9.5.4 Extractor hood (special equipment)**



Fig. 229 Extractor hood

The cooking area is equipped with an extractor hood. The powerful fan blows the cooking steam directly outside. To switch on the extractor hood, press the right flip switch (Fig. 229,2).

Use the left flip switch (Fig. 229,1) to switch on the two lights in the extractor hood.

## 9.6 Refrigerator

During the journey, only operate the refrigerator via the 12 V power supply. At high ambient temperatures the refrigerator is unable to reach its full cooling power. At high external temperatures, the full cooling power of the cooling unit is only guaranteed if the refrigerator is ventilated sufficiently. In order to achieve a better ventilation the refrigerator ventilation grill can be removed.



- ▷ When leaving the vehicle, always mount the refrigerator ventilation grill. Otherwise water can enter during rain.
- ▷ The cooling power of the refrigerator depends on the vehicle setup. The cooling power can decrease if the vehicle is inclined by 5° or more. Therefore, always park the vehicle on level ground.
- ▷ Absorption refrigerators operate at normal room temperature (approx. 21 °C) within the specified temperature range. At significantly higher ambient temperatures (> 30 °C), the cooling power is reduced. This is because the "evaporating temperature" of the refrigerant is lower in absorption refrigerators than it is in compressor refrigerators.

### 9.6.1 Refrigerator ventilation grill




Fig. 230 Refrigerator ventilation grill (with sliding trap)



Fig. 231 Refrigerator ventilation grill (with screw)

- Removal:**
- Depending on the design, push the sliding trap (Fig. 230,1) upwards or turn the screw (Fig. 231,1) a quarter turn using a coin.
  - Remove refrigerator ventilation grill.




Fig. 232 Refrigerator ventilation grill (Thetford large)




Fig. 233 Refrigerator ventilation grill (Thetford small)

- Removal:**
- Move the locking device (Fig. 232,1 or Fig. 233,1) to the middle.
  - Remove refrigerator ventilation grill.

### 9.6.2 Operation (Dometic 8 series with manual power selection MES)

**Operating modes** The refrigerator has 3 operating modes:

- Gas operation
- 230 V AC
- 12 V DC

The operating mode is set with the operating controls on the refrigerator panel.




- ▷ Select only one energy source.
- ▷ The refrigerator always requires a 12 V control voltage, regardless of which type of energy it is using. The control voltage is present as soon as the transformer/rectifier is switched on. Therefore the closed circuit current always flows even if the refrigerator is switched off. Always switch off the transformer/rectifier for a temporary lay-up.

**Gas operation**



▶ Never let gas escape unburned due to danger of explosion.



HYW07971

Fig. 234 Operating controls for the refrigerator (Dometic 8 series with MES)

- 1 On/off switch/energy selector switch
- 2 Display-LED "open door" (only for central locking system of the refrigerator door)
- 3 Display-LED "fault"
- 4 Operating indicators
- 5 Display-LED "temperature range"
- 6 Switch for temperature setting
- 7 Door opener (only for refrigerator door central locking system)

**Switching on:**

- Open the regulator tap on the gas bottle and the gas isolator tap "Refrigerator".
- Press the on/off switch/energy selector switch (Fig. 234,1) down for 2 seconds in order to switch on the appliance. The LED of the operating mode chosen most recently lights up.
- If appropriate press the on/off switch/energy selector switch (Fig. 234,1) until the gas operating indicator "🔥" lights up. Gas supply is open. Ignition will take place automatically. A ticking sound can be heard until ignition has been completed successfully.
- Use switch (Fig. 234,6) to adjust refrigerating temperature.

- Switching off:*
- Press down the on/off switch/energy selector switch for 2 seconds. Refrigerator is switched off.
  - Close the gas isolator tap "Refrigerator" and the regulator tap on the gas bottle.

### Electrical operation



- ▷ Close the gas isolator tap "Refrigerator" when the refrigerator is operated electrically.

The refrigerator can be operated with the following voltages:

- 230 V AC
- 12 V DC

- Switching the 230 V operation on:*
- Press the on/off switch/energy selector switch (Fig. 234,1) down for 2 seconds in order to switch on the appliance. The LED of the operating mode chosen most recently lights up.
  - If appropriate press the on/off switch/energy selector switch (Fig. 234,1) several times until the operating indicator 230 V "" lights up.
  - Use switch (Fig. 234,6) to adjust refrigerating temperature.

- Switching the 230 V operation off:*
- Press down the on/off switch/energy selector switch for 2 seconds. Refrigerator is switched off.

- Switching the 12 V operation on:*
- Press the on/off switch/energy selector switch (Fig. 234,1) down for 2 seconds in order to switch on the appliance. The LED of the operating mode chosen most recently lights up.
  - If appropriate press the on/off switch/energy selector switch (Fig. 234,1) several times until the operating indicator 12 V "" lights up.
  - Use switch (Fig. 234,6) to adjust refrigerating temperature.

- Switching the 12 V operation off:*
- Press down the on/off switch/energy selector switch for 2 seconds. Refrigerator is switched off.

When operated with 12 V, the refrigerator draws power only from the starter battery of the vehicle. The starter battery only supplies the refrigerator with 12 V when the vehicle engine is running. When the vehicle engine is not running, the refrigerator is cut off from the power supply in the living area. For this reason, change over to gas operation during prolonged driving breaks.



- ▷ Further information can be obtained from the separate instruction manual "Refrigerator".

### 9.6.3 Operation (Dometic 8 series with automatic power selection AES)

#### Operating modes




Fig. 235 Operating controls for the refrigerator (Dometic 8 series with AES)

- 1 On/off switch/energy selector switch
- 2 Display-LED "open door" (only for central locking system of the refrigerator door)
- 3 Display-LED "fault"
- 4 Operating indicator
- 5 Display-LED "temperature range"
- 6 Switch for temperature setting
- 7 Door opener (only for refrigerator door central locking system)

The refrigerator is equipped with automatic power selection (AES). If automatic operation (AU) is selected, the AES automatically selects the optimum energy source and regulates the refrigerator operation. Manual intervention to select the type of power is possible but not required.

The AES selects from the following types of power:

- 230 V AC
- Gas
- 12 V DC

Choosing the available energy source highest on the list.

In the case of a fault, the LED display fault will flash "⚠" (Fig. 235,3).



- ▷ The refrigerator always requires a 12 V control voltage, regardless of which type of energy it is using. The control voltage is present as soon as the transformer/rectifier is switched on. Therefore the closed circuit current always flows even if the refrigerator is switched off. Always switch off the transformer/rectifier for a temporary lay-up.

#### 230 V operation

If the automatic mode is selected and the 230 V supply is switched on, the AES selects this energy source first.

#### 12 V operation

If the automatic mode is selected, the AES selects the 12 V operation only if the vehicle engine is running.

#### Gas operation



- ▶ Never let gas escape unburned due to danger of explosion.



- ▷ Open the regulator tap on the gas bottle and the gas isolator tap "Refrigerator".

If the automatic mode is selected, 230 V power supply is **not** connected and the vehicle's engine is **not running**, the AES selects the gas supply. When selecting gas operation the ignition fuse is opened automatically so gas can get into the burner. At the same time the electronic ignition is activated. If the gas flame is extinguished, e.g. by blast of wind, the ignition is activated immediately and re-ignites the gas. In the case of a fault in gas operation the text "GAS" flashes in the operating indicator (Fig. 235,4).

### Change-over between energy sources



- ▶ Open flames are prohibited at petrol stations. If the stop takes longer than 15 minutes, the refrigerator has to be turned off at the energy selector switch.

When changing over from 230 V or 12 V to gas, delay times are built into the AES. For example, when changing over from 12 V operation to gas operation, a 15 minute delay is built in the AES. This prevents a change-over to gas operation when the vehicle is stopped briefly and the engine is switched off (e.g. stop to fill tank).

### Refrigerating temperature control

When turned on the first time the refrigerator automatically selects the middle thermostat position. This position can be adjusted manually by using the switch for temperature setting (Fig. 235,6). The indicator LEDs (Fig. 235,5) show the selected thermostat position. The refrigerating temperature for the three types of energy is set with the switch. It takes a few hours till the refrigerator reaches its normal operating temperature. When changing over the operating mode the thermostat setting will be maintained. The refrigerating temperature is retained regardless of the type of power being used.

### Manual operation

#### Switching on:

- Open the regulator tap on the gas bottle and the gas isolator tap "Refrigerator".
- Press the on/off switch/energy selector switch (Fig. 235,1) down for 2 seconds in order to switch on the appliance. The operating mode selected most recently is shown in the operating indicator (Fig. 235,4).
- Select the energy type with the on/off switch/energy selector switch (Fig. 235,1).
- Set the refrigerating temperature on the switch for temperature setting (Fig. 235,6). The indicator LEDs (Fig. 235,5) show the selected thermostat position.

When operated with 12 V, the refrigerator draws power only from the living area battery.



- ▷ If the refrigerator is manually set to "12 V", it will constantly consume current. Therefore, switch over to gas operation when the vehicle engine is **not** running, and the vehicle is **not** connected to the 230 V power supply.

#### Switching off:

- Press down the on/off switch/energy selector switch (Fig. 235,1) for 2 seconds. All displays close.
- Close the gas isolator tap "Refrigerator" and the regulator tap on the gas bottle.



▷ Further information can be obtained from the separate instruction manual "Refrigerator".

**9.6.4 Operation (Thetford with SES)**



▷ Further information can be obtained from the separate instruction manual "Refrigerator".

**Operating modes**


The refrigerator is equipped with an automatic system to select the type of power (SES). The "SES" automatically selects the optimal energy source and regulates the refrigerator operation. Manual operation to select the type of power is not required.

The SES selects from the following energy sources in the "Automatic" operating mode:

- 230 V AC
- 12 V DC
- Gas

Choosing the available energy source highest on the list.

The previously set operating mode is preselected when the refrigerator is switched on.



- 1 Operating mode button
- 2 Display
- 3 Operating indicator (blue)
- 4 On/Off button
- 5 Temperature selection button

Fig. 236 Operating controls for the refrigerator (Thetford with SES)

If there is a fault in the energy source that is set, the system switches to the next available energy source. If no other energy source is available, the operating indicator flashes and an error code appears on the display.

**230 V operation**

If the 230 V power supply is connected, this energy source is selected as the first priority by the SES.

**12 V operation**

12 V operation is only selected by the "SES" if the vehicle's engine is running and the alternator supplies sufficient 12 V operating voltage.

**Gas operation**



▶ Never let gas escape unburned due to danger of explosion.



- ▷ Open the regulator tap on the gas bottle and the gas isolator tap "Refrigerator".

If the 230 V power supply is disconnected and the vehicle's engine is not running the "SES" selects the gas supply. When selecting gas operation the ignition fuse is opened automatically so gas can get into the burner. At the same time the electronic ignition is activated. If the gas flame is extinguished, e.g. by blast of wind, the ignition is activated immediately and re-ignites the gas.

### Change-over between energy sources



- ▶ Open flames are prohibited at petrol stations. If the stop takes longer than 15 minutes, the refrigerator has to be turned off at the On/Off button.

When changing over between the different energy sources there are forced delays built in the "SES". This means, that after a change-over to a new energy source the refrigerator can not be operated immediately. When changing over from 12 V operation to gas operation, a 15-minute delay is built in the SES. This prevents a change-over to gas operation when the vehicle is stopped briefly and the engine is switched off (e.g. stop to fill tank).

### Undervoltage operation

During electric operation the "SES" constantly checks the voltage of the power supply. If the voltage is too low over a longer period of time the "SES" automatically switches over to gas operation. The "SES" remains in this operating mode until the voltage is back to normal.

### Refrigerating temperature control

When it is switched on, the refrigerator automatically selects the thermostat setting selected last. This setting can be adjusted manually using the temperature selection button (Fig. 236,5). The bars on the display (Fig. 236,2) indicate the selected thermostat position.

The height of the bar indicates the cooling power selected:

- Small bar = low cooling setting
- Tall bar = high cooling setting

The refrigerating temperature for the three types of energy is set with the button. It takes a few hours till the refrigerator reaches the set operating temperature. When changing over the operating mode the thermostat setting will be maintained. The refrigerating temperature is retained regardless of the type of power being used.

### Operation

#### Switching on:

- Press On/Off button (Fig. 236,4). The operating indicator (Fig. 236,3) lights up in blue. All the symbols in the display light up briefly.

You can use the operating mode button (Fig. 236,1) to select automatic mode or a specific energy source. When pressing the button, the operating mode is selected in the following order:

- Automatic power selection (recommended)
- 12 V DC
- Gas
- 230 V AC

The selection is shown on the display.

- Set the refrigerating temperature using the temperature selection button (Fig. 236,5). The bars on the display (Fig. 236,2) indicate the selected thermostat position.

*Switching off:*

- Press On/Off button (Fig. 236,4). The operating indicator (Fig. 236,3) is no longer lit up.
  - Close the gas isolator tap "Refrigerator" and the regulator tap on the gas bottle.
- ▷ Further information can be obtained in the manufacturer's instruction manual.



### 9.6.5 Refrigerator door locking mechanism

With some models, the refrigerator has a separate freezer compartment. The specifications in this section correspondingly also apply to the door of the freezer compartment.



- ▷ During the journey the refrigerator door must always be closed and locked in the closed position.



- ▷ Lock the refrigerator door in ventilation position when the refrigerator is switched off. This prevents mould forming.

There are two positions for locking the refrigerator door in place:

- Closed refrigerator door during travel and when the refrigerator is in operation
- Slightly opened refrigerator door as a ventilation position when the refrigerator is switched off

#### Dometic 8 series



Fig. 237 Release button of the refrigerator door (Dometic 8 series)



Fig. 238 Lock hook fixture

*Opening:*

- Press the release button (Fig. 237,1) and open the refrigerator door.

*Closing:*

- Close the refrigerator door. The lock hook engages audibly.

When the vehicle has been positioned, the lock hook can be fixed. The refrigerator door can now be opened without having to press the release button.

*Fixing the lock hook:*

- Press the fixture (Fig. 238,1) upwards. The lock hook (Fig. 238,2) is pressed upwards and has no function.

*Unlocking the lock hook:*

- Push the lock hook (Fig. 238,2) down. The lock hook functions again.




Fig. 239 Locking device in normal position




Fig. 240 Locking device in ventilation position

*Locking in the ventilation position:*

- Open the refrigerator door.
- Press down the unlocking device (Fig. 239,2).
- Push locking device (Fig. 239,1) forwards (Fig. 240).

If the refrigerator door is closed now, a gap will remain between the refrigerator door and the refrigerator.

### Thetford




Fig. 241 Lock of refrigerator door, closed (Thetford)




Fig. 242 Refrigerator door in ventilation position (Thetford)

*Opening:*

- Open the refrigerator door at the handle (Fig. 241,2). The lock (Fig. 241,1) is released automatically.

*Closing:*

- Fully close the refrigerator door. Ensure that the lock is engaged.

*Locking in the ventilation position:*

- Slightly open refrigerator door.
- Open the lock (Fig. 242,2) and snap it into the locking catch (Fig. 242,1). The refrigerator door will then stay slightly open.

## Chapter overview

This chapter contains instructions regarding the sanitary fittings of the vehicle. The instructions address the following topics:

- water tank
- waste water tank
- waste water tank heater
- complete water system
- toilet compartment
- toilet

### 10.1 Water supply, general



- ▶ Fill water tank from supply systems that have been verified to provide drinking water quality.
- ▶ Only use such hoses or containers when filling that have been approved for use with drinking water.
- ▶ Thoroughly rinse filling hose or container with drinking water before use (2 to 3 times capacity).
- ▶ Empty filling hose or container completely after use and close openings of the filling hose or container.
- ▶ Water left standing in the water tank or in the water pipes becomes undrinkable after a short period. Therefore, before each use of the vehicle, thoroughly clean the water pipes and the water tank. After each use of the vehicle completely empty the water tank and the water pipes.
- ▶ In the case of lay-ups lasting more than a week disinfect the water system before using the vehicle (see chapter 11).



- ▷ If the vehicle is not used for several days or if it is not heated when there is a risk of frost, empty the entire water system. Make certain that the water pump is switched off on the panel. Otherwise, the water pump will overheat and may get damaged. Leave the water taps on in central position. Leave the safety/drainage valve (if there is one) and all drain cocks open. Frost damage to appliances, frost damage to the vehicle and deposits in water-carrying components can be avoided in this way.
- ▷ The water pump will overheat without water and can get damaged. Never operate water pump when the water tank is empty.

The vehicle is equipped with a fitted water tank. An electric water pump pumps the water to the individual water taps. Opening a water tap automatically switches on the water pump and pumps water to the tap.

The waste water tank collects the waste water. The water level in the water and waste water tanks can be checked on the panel.



- ▷ Before the water fittings can be used, the 12 V power supply and water pump on the panel must be turned on. Otherwise the water pump will not work.
- ▷ When the water tank is re-filled, an air bubble may form at the bottom of the pump. This air bubble will prevent water from being drawn in. Shake the water pump up and down energetically in the water.

## 10.2 Water tank

### 10.2.1 Volumes



- ▷ The water tank contains 120 litres. However, the volume has been limited to 60 litres (overflow installed) for payload reasons. The panel has not been adjusted to this volume. The level indicator on the panel shows the actual amount of water in the tank.

If necessary or if there is a sufficiently large residual vehicle payload, the water tank can be filled up to its actual capacity. To do this, close overflow. The handle is on the water tank.

### 10.2.2 Drinking water filler neck with cap




Fig. 243 Cap for the drinking water filler neck

The drinking water filler neck is on the right or left side of the vehicle, depending on the model.

The drinking water filler neck is indicated by the symbol "☰" (Fig. 243,1). The cap is open and closed using the key for the external flap locks.

- Opening:*
- Insert key into locking cylinder (Fig. 243,2) and turn a quarter turn in an anticlockwise direction.
  - Remove cap.
- Closing:*
- Place cap on the drinking water filler neck.
  - Turn key one quarter turn in a clockwise direction.
  - Remove the key.
  - Check that the cap sits firmly on the drinking water filler neck.

### 10.2.3 Closing/opening the overflow



- ▶ When filling the water tank, observe the maximum permissible gross weight of the vehicle. Luggage must be reduced accordingly when the water tank is full.




Fig. 244 Water tank with handle

- Closing:*
- Turn the handle (Fig. 244, 1) on the water tank in a clockwise direction as far as it will go.
  - Fill the water tank with drinking water.
- Opening:*
- Turn the handle (Fig. 244, 1) on the water tank in an anticlockwise direction as far as it will go. Excess water will drain away leaving 60 litres in the tank.

### 10.2.4 Filling with water



- ▶ When filling the water tank, observe the maximum permissible gross weight of the vehicle. Luggage must be reduced accordingly when the water tank is full.

- Open drinking water filler neck.
- Fill the water tank with drinking water. Use a water hose, a water canister with a funnel or similar for filling.
- Close drinking water filler neck.

### 10.2.5 Draining water (handle with overflow)




Fig. 245 Water tank with handle

- Turn the handle (Fig. 245, 1) on the water tank in an anticlockwise direction as far as possible beyond the resistance to fully open the drainage opening.

### 10.3 Waste water tank



- ▷ Never pour boiling water directly into the sink outlet. Boiling water could cause deformation and leaks in the waste water pipe system.



- ▷ Only empty the waste water tank at disposal stations, camping sites or caravan sites especially provided for this purpose.

#### 10.3.1 Draining waste water



- ▷ In case of frost add so much anti-freeze (such as kitchen salt) to the waste water tank so that the waste water cannot freeze.




Fig. 246 Drain cock

The waste water tank is in the rear area of the vehicle. It is located underneath the floor of the vehicle.

Waste water from the kitchen and washing unit flows through plastic pipes into the waste water tank.

The drain cock and the cleaning opening are located on the underside of the waste water tank.

The waste water tank holds 90 litres.

#### *Emptying:*

- Attach the waste water hose to the drain pipe.
- Turn the handle (Fig. 246,1) of the drain cock in flow direction.
- Completely empty waste water tank.
- Turn the drain cock handle perpendicular to the flow direction.
- Remove the waste water hose.

### 10.3.2 Waste water tank heater (special equipment)



Fig. 247 Operating switch

The waste water tank may be heated and is insulated. The integrated frost guard prevents waste water from freezing.

A switch (Fig. 247) on the front of the bench seat or bed may be used to switch the frost guard on and off.

The frost guard begins to heat the waste water as soon as the water temperature drops to approx. 5 °C. The frost guard ends the heating process when the waste water reaches a temperature of approx. 10 °C.

### 10.4 Filling the water system



- ▶ When filling the water tank, observe the maximum permissible gross weight of the vehicle. Luggage must be reduced accordingly when the water tank is full.



- ▷ The water pump will overheat without water and can get damaged. Never operate water pump when the water tank is empty.



- ▷ The Truma system (heater/boiler) has a safety/drainage valve and, depending on the model, one or two drain cocks for emptying.
- ▷ Depending on the model, the Alde system (heater/boiler) has one or two drain cocks for emptying.
- ▷ The water quantity can be monitored on the panel while the water tank is filled.




Fig. 248 Drain cock (with rocking lever)




Fig. 249 Drain cock (with twist cap)

- Position the vehicle horizontally.
- Switch on 12 V power supply on the panel.

- If necessary, switch on the water pump on the panel.
- Clean or disinfect water system.
- Close the safety/drainage valve (Truma). Turn the knob perpendicular to the safety/drainage valve and press the push button in.  
If the temperature is below 6 °C, the safety/drainage valve cannot be closed. Therefore switch on the living area heater and wait until the temperature of the safety/drainage valve exceeds 6 °C.
- Close all drain cocks. To do this, position the drain cock's rocking lever (Fig. 248,1) horizontally or turn the drain cock's cap (Fig. 249,1) in a clockwise direction.
- Close the drainage opening of the water tank.
- Close all water taps.
- Open the drinking water filler neck on the outside of the vehicle.
- Fill the water tank with drinking water. Use a water hose, a water canister with a funnel or similar for filling.
- Set all the water taps to "Hot" and open them. The water pump is turned on. The warm water pipes are filled with water.
- Keep the taps open until the water flowing out of the taps has no bubbles in it. This is the only way to ensure that the boiler is full of water.
- Set all water taps to "Cold" and leave them open. This will fill the cold water pipes with water.
- Keep the taps open until the water flowing out of the taps has no bubbles in it.
- Close all water taps.
- Close drinking water filler neck.
- Check that the cap on the water tank is not leaking.

#### Position of the drain cocks and safety/drainage valve

See chapter 16.

### 10.5 Emptying the water system



- ▷ If the vehicle is not used for several days or if it is not heated when there is a risk of frost, empty the entire water system. Make certain that the water pump is switched off on the panel. Otherwise, the water pump will overheat and may get damaged. Leave the water taps on in central position. Leave the safety/drainage valve (if there is one) and all drain cocks open. Frost damage to appliances, frost damage to the vehicle and deposits in water-carrying components can be avoided in this way.
- ▷ If the water pump can be turned off from the panel, always turn off the water pump from the panel before you empty the water system. Otherwise the water pump runs until it overheats or the battery is empty.



- ▷ The Truma system (heater/boiler) has a safety/drainage valve and, depending on the model, one or two drain cocks for emptying.
- ▷ Depending on the model, the Alde system (heater/boiler) has one or two drain cocks for emptying.




Fig. 250 Drain cock (with rocking lever)




Fig. 251 Drain cock (with twist cap)

To empty and ventilate the water system, proceed as follows. This will avoid frost damage:

- Position the vehicle horizontally.
- Switch off water pump on panel.
- Switch off the 12 V power supply on the panel.
- Shut off the boiler (see section 9.4).
- Open all drain cocks. To do this, position the drain cock's rocking lever (Fig. 250,1) vertically or turn the drain cock's cap (Fig. 251,1) in an anti-clockwise direction.
- Open the safety/drainage valve (Truma). To do this turn the knob parallel to the safety/drainage valve. The push button jumps out.
- Open the water tank drain.
- Open all water taps and set to the central position.
- Hang the shower handset up in the shower position.
- Hold the water pump up until the water pipes are completely empty.
- Check whether the water tank is completely empty.
- Blow out the remaining water in the water pipes (max. 0.5 bar). To do this, remove the pipe from the water pump and blow into the pipe.
- Empty the waste water tank. Take note of the environmental tips in this chapter.
- Empty toilet cassette or sewage tank. Take note of the environmental tips in this chapter.
- Clean the water tank and then rinse it out thoroughly.
- Let the water system dry for as long as possible.
- After emptying, leave all water taps on in the central position.
- Leave all drain cocks open.

**Position of the drain cocks and safety/drainage valve**

See chapter 16.

## 10.6 Toilet compartment



- ▷ Do not transport any loads in the shower tray. The shower tray or other items of equipment in the toilet compartment can be damaged.



- ▷ For ventilation purposes during or after a shower, and for drying wet clothing, close the toilet compartment door and open the window or the toilet compartment skylight. This improves the air circulation.
- ▷ Close the shower curtain completely when showering, so that no water is able to enter the area between the wash room wall and the shower tray.
- ▷ After taking a shower, rinse soap residue from the shower tray, otherwise cracks can appear in the shower tray over time.
- ▷ After using the shower, wipe it dry to prevent moisture from collecting.
- ▷ Further information about cleaning the toilet compartment can be found in the section 11.2.

## 10.7 Toilet



- ▷ If there is any risk of frost and the vehicle is not heated, empty the sewage tank (cassette).
- ▷ Do not sit on the lid of the toilet. The lid is not designed to bear the weight of a person and could break.
- ▷ Use a suitable chemical for this toilet. The ventilation will merely remove the odour but not germs and gases. Germs and gases will have a detrimental effect on the sealing rubbers.
- ▷ Never put the sanitary liquid directly in the toilet bowl.



- ▷ Further information can be obtained in the device manufacturer's instruction manual.



- ▷ Only empty the sewage tank (cassette) at disposal stations, at camping sites or caravan sites, that are especially provided for this purpose.

The flushing of the toilet is fed directly from the water system of the vehicle.

### 10.7.1 Swivel toilet (Thetford C-200)



- ▷ The Thetford cassette can only be taken out if the sliding trap is closed.




Fig. 252 Pulling the retaining clip

*Preparing toilet:*

- Open the flap for the Thetford cassette and pull the retaining clip upwards to remove the Thetford cassette.




Fig. 253 Removing the Thetford cassette

- Pull out the Thetford cassette as far as it can go.
- Tip the Thetford cassette slightly and then pull it out completely.




Fig. 254 Turning drainage neck

- Place the Thetford cassette upright.
- Turn the drainage neck upwards.
- Remove the cap of the drainage neck.
- ▷ Never put the sanitary liquid directly in the toilet bowl.




Fig. 255 Filling with sanitary liquid

- Fill the Thetford cassette with the specified quantity of sanitary liquid.
- Then add enough water to completely cover the bottom of the Thetford cassette.
- Close drainage neck with the cap.
- Return the drainage neck to its original position.



- ▷ When inserting, do not use force. The Thetford cassette can be damaged.




Fig. 256 Inserting the Thetford cassette

- Push the Thetford cassette back to its original position.




Fig. 257 Thetford cassette secured

- Ensure that the Thetford cassette is secured by the retaining clip.
- Lock the flap for the Thetford cassette.



Fig. 258 Rotating the toilet bowl

- Using the toilet:*
- Move the toilet bowl into a convenient position.




Fig. 259 Pre-flush

- Fill the toilet bowl with some water. Press the flush button. Flushing continues as long as the button is pressed.
- Use the toilet.

**C-200 S cassette** With the C-200 S cassette, proceed as follows to flush the toilet:




Fig. 260 Operating the sliding trap

- Open the sliding trap. To do this, turn the slide lever in an anticlockwise direction.




Fig. 261 Operating the flush

- Flush the toilet. Press the flush button.
- After flushing close the sliding trap.

**C-200 E cassette** With the C-200 E cassette, proceed as follows to flush the toilet:




Fig. 262 Opening the sliding trap

- Open the sliding trap. To do this, press the left side of the sliding trap button.




Fig. 263 Closing the sliding trap

- Flush the toilet. Press the flush button.
- After flushing close the sliding trap. To do this, press the right side of the sliding trap button.



- ▷ The Thetford cassette can only be taken out if the sliding trap is closed.




Fig. 264 Removing the Thetford cassette

*Emptying the Thetford cassette:*

- Open the flap for the Thetford cassette and pull the retaining clip upwards to remove the Thetford cassette.
- Pull out the Thetford cassette as far as it can go.
- Tip the Thetford cassette slightly and then pull it out completely.




Fig. 265 Carrying the Thetford cassette

- Take the Thetford cassette to a proper disposal area. As you do this, point the drainage neck upwards.




Fig. 266 Emptying the Thetford cassette

- Turn the drainage neck upwards.
- Remove the cap of the drainage neck.
- Point the Thetford cassette with the drainage neck downwards.
- Activate the aeration knob with your thumb. The Thetford cassette empties.
- Rinse the Thetford cassette thoroughly with fresh water.
- Close drainage neck with the cap.
- Return the drainage neck to its original position.




Fig. 267 Inserting the Thetford cassette

- Prepare the Thetford toilet for use.
- Push the Thetford cassette back to its original position.
- Ensure that the Thetford cassette is secured by the retaining clip.
- Lock the flap for the Thetford cassette.

### 10.7.2 Toilet with fixed seat (Thetford C-402)



- ▷ The Thetford cassette can only be taken out if the sliding trap is closed.




Fig. 268 Pulling the retaining clip

*Preparing toilet:*

- Open the flap for the Thetford cassette and pull the retaining clip upwards to remove the Thetford cassette.




Fig. 269 Removing the Thetford cassette

- Pull out the Thetford cassette as far as it can go.
- Tip the Thetford cassette slightly and then pull it out completely.




Fig. 270 Turning drainage neck

- Place the Thetford cassette upright.
  - Turn the drainage neck upwards.
  - Remove the cap of the drainage neck.
- ▷ Never put the sanitary liquid directly in the toilet bowl.






Fig. 271 Filling with sanitary liquid

- Fill the Thetford cassette with the specified quantity of sanitary liquid.
  - Then add enough water to completely cover the bottom of the Thetford cassette.
  - Close drainage neck with the cap.
  - Return the drainage neck to its original position.
- ▷ When inserting, do not use force. The Thetford cassette can be damaged.




Fig. 272 Inserting the Thetford cassette

- Push the Thetford cassette back to its original position.




Fig. 273 Thetford cassette secured

- Ensure that the Thetford cassette is secured by the retaining clip.
- Lock the flap for the Thetford cassette.




Fig. 274 Pre-flush

*Using the toilet:*

- Fill the toilet bowl with some water. Press the flush button. Flushing continues as long as the button is pressed.
- Use the toilet.




Fig. 275 Operating the sliding trap

- Open the sliding trap. To do this, turn the slide lever in an anticlockwise direction.




Fig. 276 Operating the flush

- Flush the toilet. Press the flush button.
- After flushing close the sliding trap again. To do this turn the slide lever in a clockwise direction.



- ▷ The Thetford cassette can only be taken out if the sliding trap is closed.




Fig. 277 Removing the Thetford cassette

*Emptying the Thetford cassette:*

- Open the flap for the Thetford cassette and pull the retaining clip upwards to remove the Thetford cassette.
- Pull out the Thetford cassette as far as it can go.
- Tip the Thetford cassette slightly and then pull it out completely.



Fig. 278 Transporting the Thetford cassette

- Place the Thetford cassette upright on the wheels.
- Press down the handle of the draw bar and move away from the Thetford cassette. The lock of the draw bar releases itself.
- Pull the draw bar out completely by the handle.
- Take the Thetford cassette to a proper disposal area.
- Insert the draw bar completely using the handle.




Fig. 279 Emptying the Thetford cassette

- Turn the drainage neck upwards.
- Remove the cap of the drainage neck.
- Point the Thetford cassette with the drainage neck downwards.

- Activate the aeration knob with your thumb. The Thetford cassette empties.
- Rinse the Thetford cassette thoroughly with fresh water.
- Close drainage neck with the cap.
- Return the drainage neck to its original position.




Fig. 280 Inserting the Thetford cassette

- Prepare the Thetford toilet for use.
- Push the Thetford cassette back to its original position.
- Ensure that the Thetford cassette is secured by the retaining clip.
- Lock the flap for the Thetford cassette.

### 10.7.3 Toilet (Dometic)



- ▷ The sewage tank (cassette) can only be taken out if the sliding trap is closed.




Fig. 281 Flap for sewage tank



Fig. 282 Sewage tank

#### *Preparing toilet:*

- Open the flap for the sewage tank on the outside of the vehicle. Insert the key into the locking cylinder of the push-button lock (Fig. 281, 1) and turn a quarter turn.
- Remove the key.
- Press both push-button locks (Fig. 281, 2) simultaneously with your thumb and open the flap.
- Pull up the retaining clip (Fig. 282, 3) and use the handle (Fig. 282, 2) to lift the sewage tank (Fig. 282, 1) straight up.
- Tilt the sewage tank slightly and remove fully.




Fig. 283 Turning drainage neck




Fig. 284 Filling with sanitary liquid

- Put the sewage tank down vertically.
- Turn the drainage neck upwards.
- Remove the cap of the drainage neck.
- Fill the stated amount of sanitary liquid into the sewage tank.
- Then add enough water to completely cover the bottom of the sewage tank.
- Close drainage neck with the cap.
- Return the drainage neck to its original position.
- Push the sewage tank back to its original position without applying any force.
- Ensure that the sewage tank is secured by the retaining clip.
- Lock the flap for the sewage tank.



Fig. 285 Toilet bowl with control and operating unit




Fig. 286 Control and operating unit toilet

Let some water run into the toilet bowl before using the toilet. In order to do so press the flush button (Fig. 286,3) on the control and operating unit (Fig. 285,2).

*Flushing:*

- Before flushing open the sliding trap of the toilet. For this pull out the slide lever (Fig. 285,1).
- For flushing, press the flush button (Fig. 286,3).
- After flushing close the sliding trap. To do so, push the slide lever back.

The indicator lamp (Fig. 286,2) goes on whenever the sewage tank is filled up to 3/4.

The indicator lamp (Fig. 286,1) goes on whenever the sewage tank has to be emptied.

- Removal of sewage tank:*
- Push the slide lever (Fig. 285,1) in. The sliding trap is closed. To empty, the sliding trap of the toilet **must** be closed.
  - Open the flap for the sewage tank on the outside of the vehicle.
  - Pull up the retaining clip (Fig. 282,3) and use the handle (Fig. 282,2) to lift the sewage tank (Fig. 282,1) straight up.
  - Tilt the sewage tank slightly and remove fully. The display "Sewage tank removed" (Fig. 286,4) lights up on the control and operating unit.




Fig. 287 Emptying the sewage tank

- Emptying the sewage tank:*
- Take the sewage tank to a disposal point especially provided for this purpose.
  - Turn the drainage neck as far upwards as possible.
  - Remove the cap of the drainage neck.
  - Point the sewage tank with the drainage neck downwards.
  - Activate the aeration knob with your thumb. The sewage tank empties.
  - Flush the sewage tank with water.
  - Close drainage neck with the cap.
  - Return the drainage neck to its original position.
  - Push the sewage tank back to its original position without applying any force.
  - Ensure that the sewage tank is secured by the retaining clip.
  - Lock the flap for the sewage tank.

## Chapter overview

This chapter contains instructions regarding the care of the vehicle.

The instructions address the following topics:

- exterior of the vehicle
- interior
- water system
- extractor hood
- air conditioning unit
- winter operation

At the end of the chapter there is a checklist of measures you must carry out if you are not going to use the vehicle for an extended period of time.

The checklist address the following topics:

- temporary lay-up
- winter lay-up
- start-up after a lay-up

### 11.1 External care

#### 11.1.1 General

Standard external care consists of regular washing. The use and the environmental conditions will determine how often the vehicle needs to be washed. Wash the vehicle more frequently in areas which are exposed to heavy air pollution or heavy traffic or roads treated with de-icing salts. If the vehicle is exposed to salty and humid air (coastal areas, humid climates), wash the vehicle more frequently.

Do not park under trees if at all possible. The resin-like discharge which many trees secrete, give the paintwork a matt look and can promote the onset of corrosion.

Wash off bird droppings straight away and thoroughly, as the acid it contains is extremely corrosive.

#### 11.1.2 Washing with a high-pressure cleaner



- ▷ Do not clean the tyres with a high-pressure cleaner. The tyres might be damaged.
- ▷ Do not spray external applications (deco-films) directly with the high-pressure cleaner. The external applications could come off.

Before cleaning the vehicle with a high-pressure cleaner, observe the operating instructions of the high-pressure cleaner.

When cleaning with the nozzle for circular jet between the vehicle and the cleaning nozzle, maintain a minimum distance of approx. 700 mm.

Take into consideration that the jet of water comes out of the cleaning nozzle with pressure. The vehicle may be damaged by incorrect handling of the high-pressure cleaner. The temperature of the water should not be above 60 °C. Keep the jet of water in constant movement during the washing process. Do not direct the water jet at clearances, built-in electrical parts, plugs, seals, the ventilation grill or the skylights. The vehicle may be damaged or water may enter the interior.

### 11.1.3 Washing the vehicle



- ▷ Never clean the vehicle in the car wash. Water can enter the refrigerator grills, the waste gas vents, the ventilation of the extractor hoods or the forced ventilations. The vehicle could be damaged.
- Wash the vehicle only on a washing site intended for this purpose. Avoid full sunshine. Observe environmental measures.
- Only clean external applications and synthetic parts with plenty of warm water, dish washing liquid and soft cloth.
- Wash down the vehicle with plenty of water, a clean sponge or a soft brush. In the case of stubborn dirt add dish washing liquid to the water.
- Painted exterior walls may also be cleaned with a caravan cleaner.
- Add-on parts made of glass-fibre reinforced plastic (GRP) require a regular follow-up treatment with a polisher. This way these parts will not turn yellow and the sealing of the surface remains intact.
- Treat rubber seals of doors and storage flaps with talc.
- Treat locking cylinder of doors and storage flaps with graphite dust.

### 11.1.4 Windows of acrylic glass



Acrylic glass windows are delicate and require very careful handling.

- ▷ Never rub acrylic glass windows dry as dust particles might damage the surface!
- ▷ Only clean acrylic glass windows with plenty of warm water, some dish washing liquid and a soft cloth.
- ▷ Never use glass cleaning agents with chemical, abrasive or alcohol-containing additives. Premature brittleness of the panes and associated cracks may result from their use.
- ▷ Avoid contact of cleansing agents used for the body (e.g. tar- or silicone-removing agents) with acrylic glass.
- ▷ Do not clean vehicle in car wash.
- ▷ Do not attach stickers to the acrylic glass windows.
- ▷ Having cleaned the vehicle rinse acrylic glass with sufficient clear water.
- ▷ Apply talcum powder to rubber seals.



- ▷ An acrylic glass cleanser with antistatic effect is suitable for a follow-up treatment. Small scratches can be treated with an acrylic glass polish. These agents are available at the accessories shop.

### 11.1.5 Underbody

The underbody of the vehicle is partly coated with an age-resistant underbody protection. Should the underbody protection be damaged, repair immediately. Do not treat areas coated with underbody protection with spray oil.



- ▷ Only use products approved by the manufacturer. Our authorised dealers and service centres will be happy to advise you.

### 11.1.6 Waste water tank

Clean the waste water tank after every use.

- Cleaning:*
- Empty the waste water tank.
  - Open the cleaning opening on the waste water tank and the drain cock.
  - Thoroughly rinse out the waste water tank with fresh water.
  - If possible, clean waste water sensors through the cleaning opening by hand.

### 11.1.7 Entrance step

If the entrance step is lubricated, coarse particles of dirt can settle on the lubricant during the journey and cause damage to the operating mechanism of the entrance step. Therefore, do not lubricate the moving parts of the entrance step.

## 11.2 Interior care



- ▷ If possible, treat stains immediately.
- ▷ Acrylic glass windows are delicate and require very careful handling (see section 11.1.4).
- ▷ Synthetic parts in the toilet and living area are very delicate and should be treated with care. Do not use solvents, alcohol-containing cleansers or scourers. This procedure will help you to avoid brittleness and formation of cracks.
- ▷ Hair colourants, nail varnish, cigarette ash and similar substances may cause permanent stains or discolouration. For this reason, you should prevent these substances from getting onto plastic parts. If they do get onto plastic parts, you should remove these substances immediately.
- ▷ Do not pour any corrosive agents into the drain holes. Never pour boiling water directly into the drain holes. Corrosive agents and boiling water cause damage to drainage pipes and siphon traps.
- ▷ Do not use vinegar based products to clean the toilet and water system, or for decalcification of the water system. Vinegar-based products may cause damage to seals or parts of the installation. Use standard decalcifying products for decalcification.
- ▷ Save water. Mop up all remaining water.
- ▷ Vacuum off carpets and cushions with a suitable brush attachment.



- ▷ For information about the use of maintenance products, our representatives and service centres will be glad to advise.
- Surface and knobs of furniture, lamps and synthetic parts in the toilet and living area should be cleaned with water and a wool cloth. A mild cleanser may be added to the water. If required, use furniture polish for the painted surfaces.
- Clean upholstery with dry foam specially manufactured for the use on upholstery or with the foam of a mild detergent. Do not wash upholstery. Always have it cleaned. Protect upholstery from direct sunlight so that it does not lose its colour.
- Clean upholstery made of novalife® with clear water only.

- Leather covers should be cleaned with a cotton cloth and a mild soap (curd soap). Make sure that the leather is not soaked through and that no water seeps through the seams of the leather covers.
- Curtains and net curtains should be dry cleaned.
- Vacuum clean the carpet, if necessary clean with carpet shampoo.
- Clean PVC-floor covering with a mild, soapy cleanser for PVC floors. Do not place carpet on wet PVC-floor covering. The carpet and the PVC-floor covering may stick together.
- Never clean the sink or the gas cooker with a scourer. Avoid anything which may cause scratching or grooves.
- Clean the burners on the gas cooker using a damp cloth only. Prevent any water from penetrating the burner covers. Water may damage the burners on the gas cooker.
- Brush insect screens on doors, windows and skylights with a soft brush or vacuum with the brush attachment of the vacuum cleaner.
- Brush blinds with a soft brush or vacuum with the brush attachment of the vacuum cleaner. Grease or stubborn dirt may be removed with a mild soap at 30 °C (curd soap).
- Brush Roman shades with a soft brush or vacuum with the brush attachment of the vacuum cleaner. Grease or stubborn dirt may be removed with a mild soap at 30 °C (curd soap).
- Unrolled seat belts can be cleaned with warm soapsuds. The seat belt must be completely dry before being rolled up.
- Wipe the fuel cell with a soft, damp cloth.

## 11.3 Water system

### 11.3.1 Cleaning the water tank

- Empty the water tank and close the drainage opening.
- Remove the cap of the water tank.
- Fill water tank with water and some washing-up liquid (do not use any scourers).
- Using a trade standard brush for washing dishes, scrub the water tank until there is no longer any visible deposit.
- Scrub also the pump housing.
- If possible, clean fresh water sensors through the cleaning openings by hand.
- Rinse water tank with copious amounts of drinking water.

### 11.3.2 Cleaning the water pipes



- ▷ Only use suitable cleaning agents as sold by the specialist trade.
- ▷ The cleaning agent must meet national regulations and be approved (if required).



- ▷ Collect any emerging mixture of water and cleaning agent for correct disposal.

- Empty the water system.
- Close all drain holes and drain cocks.
- Fill mixture of water and cleaning agent into the water tank. Observe the manufacturer's instructions regarding the mixing ratio.
- Open the drain cocks one by one.
- Leave the drain cocks open until the mixture of water and cleaning agent has reached the respective drain.
- Close the drain cocks.
- Set all the water taps to "Hot" and open them.
- Leave the water taps open until the mixture of water and cleaning agent has reached the drain.
- Set all water taps to "Cold" and open them.
- Leave the water taps open until the mixture of water and cleaning agent has reached the drain.
- Close all water taps.
- Flush the toilet several times.
- Allow the cleaning agent to act in accordance with the manufacturer's instructions.
- Empty the water system. Collect the mixture of water and cleaning agent for correct disposal.
- For rinsing fill the entire water system with drinking water and empty again several times over.

### 11.3.3 Disinfecting the water system



- ▷ Only use suitable disinfectants as sold by the specialist trade.
- ▷ The disinfectant must meet national regulations and be approved (if required).



- ▷ Collect any emerging mixture of water and disinfectant for correct disposal.

- Empty the water system.
- Close all drain holes and drain cocks.
- Fill mixture of water and disinfectant into the water tank. Observe the manufacturer's instructions regarding the mixing ratio.
- Open the drain cocks one by one.
- Leave the drain cocks open until the mixture of water and disinfectant has reached the respective drain.
- Close the drain cocks.
- Set all the water taps to "Hot" and open them.
- Leave the water taps open until the mixture of water and disinfectant has reached the drain.
- Set all water taps to "Cold" and open them.
- Leave the water taps open until the mixture of water and disinfectant has reached the drain.
- Close all water taps.
- Flush the toilet several times.

- Allow the disinfectant to act in accordance with the manufacturer's instructions.
- Empty the water system. Collect the mixture of water and disinfectant for correct disposal.
- For rinsing fill the entire water system with drinking water and empty again several times over.

## 11.4 Extractor hood

Clean the extractor hood filter occasionally. How often cleaning is necessary depends on how often the extractor hood is used. Do not wait to clean the filter until the performance of the extractor hood has noticeably decreased.

*Cleaning the filter:* ■ Wash the filter with warm water and some washing-up liquid.

## 11.5 Air conditioning unit

### 11.5.1 Dometic



Fig. 288 Air conditioning unit (Dometic)

A lint filter and an activated carbon filter are each located in the lower part of the air conditioning system ceiling unit (Fig. 288,2) behind the ventilation grilles (Fig. 288,1 and 3). The lint filters must be cleaned at regular intervals and replaced if necessary. The manufacturer recommends replacing the activated carbon filter yearly.

On the left side of the ceiling unit (outside of the vehicle) is located the drainage opening for the condensation. Keep the drain openings free from dirt, leaves or similar to allow the condensation to be drained.

### 11.5.2 Telair

Every now and then clean the filter and the ventilation grilles on the outside of the housing. How often cleaning is necessary depends on how often the air conditioning unit is used. Do not wait to clean the filter and the ventilation grill until the performance of the air conditioning unit has noticeably decreased.



- ▷ Only use mild cleaning solutions to clean the filter, never use benzene or solvents.

*Cleaning the filter:* ■ Wash the filter with warm water and some washing-up liquid.  
 ■ Allow the filter to dry thoroughly before reassembly.

*Cleaning the ventilation grill:*

- Use a brush to remove coarse dirt or deposits from the external ventilation grilles. If a cleaning solution is used, ensure that no water ingresses into the inside of the housing.

## 11.6 Winter care

De-icing salt damages the underbody and the parts open to water spray. We recommend that you wash the vehicle more frequently during wintertime. Mechanical and surface treated parts and the underside are under particular strain, and should therefore be cleaned thoroughly.



- ▷ If there is any risk of frost, always run heater at a minimum of 15 °C. Switch the circulation fan (if there is one) to automatic. In the case of extreme external temperatures, the furniture flaps and doors should be left slightly open. The inflowing warm air can help prevent the freezing of water pipes, for example, and counteract the formation of condensation in the storage spaces.
- ▷ If there is any risk of frost, cover the outside surface of the windows with winter insulation mats.
- ▷ Keep waste gas vents and forced ventilations free of snow. Use a vent extension, if necessary.

### 11.6.1 Preparations

- Check the vehicle for paint and rust damage. Repair damage as necessary.
- Make certain that water cannot penetrate the automatic floor ventilation system and the heater.
- Use a wax-based rust inhibitor to protect the metal parts of the underbody.
- Use appropriate protection for external painted surfaces.

### 11.6.2 Winter operation

During winter operation, condensation develops when the vehicle is occupied under low-temperature conditions. To ensure good interior air quality and avoid vehicle damage from condensation, sufficient ventilation is essential.

- When heating the vehicle, the heater should be at the highest setting and roof storage cabinets, curtains and blinds should be opened. This ensures optimal ventilation.
- Only heat if the circulation system is switched on.
- In the morning, lift up all cushions, air out storage boxes and dry any damp areas.



- ▷ If condensation has still developed, just wipe it off.
- ▷ It is only possible to guarantee unrestricted operation during winter for models without double floor in connection with the "winter package" from the original equipment.

### 11.6.3 At the end of the winter season

- Thoroughly clean the underbody of the vehicle and the engine. When this is done, corrosion-inducing anti-freeze agents (salts, alkaline residues) are removed.
- Clean the exterior and use regular car wax to protect metal surfaces.

## 11.7 Lay-up

### 11.7.1 Temporary lay-up



- ▶ If the vehicle has been stationary for a long period (approx. 10 months) have the braking and gas systems checked by an authorised specialist workshop.
- ▶ Take into consideration that water is undrinkable after only a short time.
- ▶ Animal damage to cables can lead to short circuits. Fire hazard!

Before laying up the vehicle, go through the following checklist:

**Base vehicle**

| Activities   | Done |
|--|------|
| Completely fill fuel tank. This prevents corrosion damage within the fuel tank system  |      |
| Jack up vehicle so that the wheels do not bear any load, or move vehicle every 4 weeks. This prevents any pressure points from occurring on tyres and wheel bearings                                   |      |
| Protect the tyres from direct exposure to the sun. Danger of formation of cracks!  |      |
| Inflate tyres up to the recommended maximum pressure   |      |
| Always provide for sufficient ventilation in the underbody area  |      |
|  ▶ Humidity or lack of oxygen e.g. by covering with plastic film may cause optical irregularities to the underbody. |      |
| In addition observe the notes in the operating manual of the base vehicle  |      |

**Body**

|  |  |
|--|--|
| All vents should be sealed with the appropriate caps and all other openings (apart from forced ventilations) should also be sealed. This prevents animals (e.g. mice) from gaining entry                   |  |
| Air the interior, all storage compartments accessible from the outside, and the parking space (e.g. garage) every 3 weeks in order to prevent the occurrence of condensation and resulting mould formation |  |

**Interior**

|   |  |
|---|--|
| Place upholstery in an upright position for ventilation, and cover                      |  |
| Clean refrigerator  |  |
| Allow refrigerator and freezer compartment doors to remain slightly open                |  |
| Search for traces of animals that have gained entry                                     |  |
| Disconnect the flat screen from the mains and, if necessary, remove it from the vehicle |  |

|                          | Activities   | Done |
|--------------------------|--|------|
| <b>Gas system</b>        | Close regulator tap on the gas bottle  |      |
|                          | Close all gas isolator taps  |      |
|                          | Always remove gas bottles from the gas bottle compartment, even if they are empty  |      |
| <b>Electrical system</b> | Fully charge living area and starter battery<br> ▷ Charge the battery for at least 20 hours before laying up.   |      |
|                          | Disconnect the living area battery from the 12 V power supply. To do this, switch off the battery cut-off switch on the transformer/rectifier (see chapter 8)  |      |
| <b>Water system</b>      | Empty the entire water system. Blow out the residual water from the water pipes (0.5 bar max.). Leave the water taps on in central position. Leave the safety/drainage valve (if there is one) and all drain cocks open. Observe the notes in chapter 10 |      |

### 11.7.2 Winter lay-up

Additional measures are required if laying up the vehicle over winter:

|                     | Activities   | Done |
|---------------------|--|------|
| <b>Base vehicle</b> | Clean body and underbody thoroughly and spray with hot wax or protect with varnish |      |
|                     | Fill fuel tank with winter diesel  |      |
|                     | Check antifreeze in the cooling water  |      |
|                     | Rectify damage to the paintwork  |      |
| <b>Body</b>         | Clean vehicle from outside thoroughly  |      |
|                     | Keep the forced ventilation open   |      |
|                     | Clean and grease installed supports  |      |
|                     | Clean and grease all door and flap hinges  |      |
|                     | Brush oil or glycerine on all locking mechanisms                                   |      |
|                     | Rub all rubber seals with talc   |      |
|                     | Use graphite dust to treat locking cylinders                                       |      |
| <b>Interior</b>     | Position de-humidifiers  |      |
|                     | Remove upholstery from the vehicle and store in a dry place                        |      |
|                     | Air the interior every 3 weeks   |      |
|                     | Empty all cabinets and storage compartments, open flaps, doors and drawers         |      |
|                     | Thoroughly clean the interior  |      |
|                     | If there is a risk of frost, do not leave the flat screen in the vehicle           |      |

|                          | Activities   | Done |
|--------------------------|--|------|
| <b>Electrical system</b> | Remove the starter battery and the living area battery and store them in a place protected from frost (see chapter 8) or connect the vehicle to a 230 V supply |      |
| <b>Water system</b>      | Clean the water system using a cleaning agent from a specialised store   |      |
| <b>Complete vehicle</b>  | Arrange the tarpaulins in such a way that the ventilation openings are not covered, or use porous tarpaulins   |      |

### 11.7.3 Starting up the vehicle after a temporary lay-up or after lay-up over winter

Go through the following checklist before start-up:

|                          | Activities  | Done |
|--------------------------|---|------|
| <b>Base vehicle</b>      | Check the tyre pressure on all tyres<br>Check the tyre pressure of the spare wheel  |      |
| <b>Body</b>              | Clean the pivot bearing of the entrance step<br>Check the functioning of the fitted supports<br>Check that the doors, windows and skylights are working properly<br>Check that all the external locks are working, such as the external flaps, the filler neck and the conversion door<br>Remove the cover from the waste gas vent of the heater (if there is one)<br>Remove the winter cover from the refrigerator grills (if there is one)  |      |
| <b>Gas system</b>        | Put the gas bottles in the gas bottle compartment, tie down and connect to the gas pressure regulator   |      |
| <b>Electrical system</b> | Connect to 230 V power supply using the external socket<br>Fully charge living area and starter battery<br> ▷ Charge the battery for at least 20 hours after lay-up.<br>Connect the living area battery with the 12 V power supply. To do this, switch on the battery cut-off switch on the transformer/rectifier (see chapter 8)<br>Check that the electrical system are working, e.g. interior light, socket and all installed electrical appliances |      |
| <b>Water system</b>      | Disinfect water pipes and water tank<br>Check the functionality of the operating lever for the waste water tank<br>Close safety/drainage valve (if there is one), drain cocks and water taps  |      |

| <b>Activities</b>            | <b>Done</b> |
|------------------------------|-------------|
| Check water system for leaks |             |

**Appliances**

|                                      |  |
|--------------------------------------|--|
| Check the function of the appliances |  |
|--------------------------------------|--|



## Chapter overview

This chapter contains instructions about inspection and maintenance work concerning the vehicle.

The maintenance instructions address the following topics:

- doors
- living area battery
- fuel cell
- Alde hot-water heater
- independent vehicle heater
- replacing light bulbs

At the end of the chapter you will find important instructions on how to obtain spare parts.

### 12.1 Inspection work

Like any technical appliance, the vehicle must be inspected at regular intervals.

This inspection work must be carried out by qualified personnel.

Special technical knowledge, which cannot be taught within the framework of this instruction manual, is required for these tasks. Personnel possessing this technical knowledge are available for assistance at all our service centres. Their experience and regular technical instruction by the factory as well as equipment and tools guarantee expert and up-to-date inspection of the vehicle.

Have the "First Programmed Inspection" carried out at one of our service centres 12 months after initial registration.

Further inspections should be carried out once a year.

The service centre in charge will confirm the work performed.

Have chassis inspections confirmed in the chassis manufacturer's customer service booklet.



- ▷ Observe the inspections indicated by the manufacturer and have them carried out at the specified intervals. The value of the vehicle is thus preserved.
- ▷ The confirmation of the inspection work carried out serves as valid proof in the event of damage and guarantee claims.

### 12.2 Maintenance work

As with every machine, this vehicle requires maintenance. The extent and frequency of the maintenance work required depend on conditions of operation and use. More difficult operating conditions make it necessary to service the vehicle more often.

Have the base vehicle and the appliances serviced at the intervals specified in the corresponding instruction manuals.

### 12.3 Doors

To maintain gliding capability between springs and hinges, grease the conversion door hinges occasionally.



- ▷ We recommend either Molykote PG 65 or Vaseline as lubricants.

### 12.4 Living area battery



- ▷ When replacing the battery, only use the same type of battery (same capacity and voltage, cycle stability).
- ▷ Never use conventional car batteries (starter batteries). A lead acid battery must not be replaced by a dryfill battery.
- ▷ Do not use so-called improvers.

Observe the following to extend battery life:

- Keep the battery surface clean and dry.
- Check the acid level periodically and top up with desalinated or distilled water as necessary. Never top up with acids.
- If water loss is considerable, have the controller voltage checked by an authorised specialist workshop.
- Use an acid density measurement to check the battery's charging condition.

#### Acid density

- The battery must be recharged if the acid density falls below 1.21 kg/l. If battery acid with a density of 1.23 kg/l is used, the battery must be recharged when the acid density falls below 1.18 kg/l.
- With acid density of 1.21 kg/l, the battery is protected against freezing at temperatures up to -15 °C (at 1.28 kg/l up to -70 °C).

The battery has cycle stability and is thus particularly suited for vehicle power supply. Cycle stability means that several discharge/charging processes are possible.

### 12.5 Fuel cell

#### 12.5.1 Replacing the tank cartridge



- ▶ When changing tank cartridges, do not smoke and avoid unshielded flames. Fire hazard!
- ▶ Methanol is toxic. Avoid inhaling, swallowing or any contact with the skin or the eyes.



- ▷ When connecting the tank, make sure that the tank hose has no kinks and that it is not squashed.
- ▷ Only use original SFC tank cartridges.



- ▷ The tank cartridge may only be replaced if the system is running.
- ▷ Any methanol emerging will evaporate without residue.
- ▷ Original tank cartridges are available from all authorised dealers and service centres.

- Unscrew the tank cartridge connection from the empty tank cartridge.
- Loosen the securing belt on the tank cartridge.
- Remove empty tank cartridge from the tank cartridge holder.
- After use, firmly close the cap of the tank cartridge.
- Insert a new, sealed original tank cartridge into the tank cartridge holder.
- Secure the tank cartridge with the securing belt.
- Open cap and keep safe.
- Screw tank cartridge connection onto the new tank cartridge.
- In the "Main Menu > Fuel Cartridge" menu, specify the tank cartridge size used and confirm with "OK".

### 12.5.2 Refilling service fluid



- ▷ Only use original SFC refill sets.
- ▷ Only replenish service fluid if a message to do so appears on the operating panel.
- ▷ Ensure that no dirt or foreign bodies enter the filling hole.



- ▷ Original refill sets are available from all authorised dealers and service centres.
- ▷ Wipe up any spilled service fluid with a cloth.
- Turn off fuel cell and remove the device's connector plug.
- Remove the air discharge hose.
- Cut off the tip of the nozzle on the refill bottle.
- Pour the entire content of the refill bottle into the connection for the air discharge hose.
- Re-insert the air discharge hose.
- Plug the device's connector plug back on again.
- Press the reset button.

### 12.6 Alde hot-water heater



- ▷ Check the level of the heating fluid regularly on the compensator reservoir.
- ▷ During or after the first operating hours of the hot-water heater, the filling level may fall below the minimum mark. If this is the case, top up the heating fluid.
- ▷ We recommend to bleed the heating system after the initial heater operation and to check the glycol content.
- ▷ Have heating fluid changed by an authorised dealer or a service centre at intervals of approximately two years as corrosion-protection wears off after some time.
- ▷ Top up heating system with a water-glycol mixture (60 : 40) only. This mixture offers frost protection up to approx. -25 °C. When topping up hot-water heaters that are connected to the engine's cooling circuit, please observe the instructions in the instruction manuals of the manufacturers.



- ▷ Further information can be obtained in the manufacturer's instruction manual.

### 12.6.1 Checking the fluid level



Fig. 289 Compensator reservoir hot-water heater

- Switch off the hot-water heater and allow it to cool down.
- Check if the fluid level is between the marks "MIN" (Fig. 289,3) and "MAX" (Fig. 289,2) on the compensator reservoir (Fig. 289).

### 12.6.2 Topping up heating fluid

- Position the vehicle horizontally. This prevents the formation of bubbles.
- Switch off the hot-water heater and allow it to cool down.
- Unscrew or pull off the panel.
- Open the rotary lid (Fig. 289,1) on the compensator reservoir.
- Remove cover.
- Check anti-freeze with an anti-freeze hydrometer. The frost protection content must be 40 % or correspond to a frost protection of -25 °C.
- Fill water frost protection mixture slowly into the compensator reservoir.



- ▷ The optimum fluid level is reached when the fluid in the compensator reservoir is 1 cm above the "MIN" mark when it is cooled down.

### 12.6.3 Bleeding the heating system



Fig. 290 Bleeding valve of hot-water heater

The bleeding valves are built in nearby the radiators.

- Switch off the hot-water heater and allow it to cool down.
- Open bleeding valve (Fig. 290,1) and leave open until no more air escapes.

- Close bleeding valve.
- Repeat this procedure at all bleeding valves.
- Check to see if the hot-water heater warms up.

## 12.7 Independent vehicle heater

Use the independent vehicle heater for 10 minutes at least once a month with a cold engine and smallest fan settings.

Before the heating season starts, have the independent vehicle heater checked by an authorised specialist workshop.

## 12.8 Replacing bulbs, external



- ▶ Bulbs and light fittings can be extremely hot. Therefore, allow lights to cool down before changing bulbs.
- ▶ Store bulbs in a safe place inaccessible to children.
- ▶ Do not use any bulb that has been dropped or which shows scratches in its glass. The bulb might burst.



- ▷ A new bulb should not be touched with the fingers. Use a cloth when installing the new bulb.
- ▷ Use only bulbs of the same type and with the correct wattage (see table "Types of bulbs for exterior lighting").
- ▷ If LEDs in lights are defect, contact an authorised dealer or service centre.

### Types of bulbs

Different types of bulbs are used in the vehicle. Below, we have described how to change the different types of bulbs.




Fig. 291 Types of bulbs


| Pos. in Fig. 291 | Fixture type/bulb type | Changing  |
|------------------|------------------------|---|
| 1                | Plug-in fixture        | To remove, pull out the bulb  |
|                  |                        | To mount, push the bulb into the socket with gentle pressure              |
| 2                | Bayonet socket         | To remove, press the bulb down and turn in an anticlockwise direction     |
|                  |                        | To insert, place the bulb in the socket and turn in a clockwise direction |

| Pos. in Fig. 291 | Fixture type/bulb type | Changing  |
|------------------|------------------------|---|
| 3                | Cylindrical bulbs      | To remove and to insert, carefully bend the contacts of the lamp holder outwards          |
| 4                | Halogen bulb           | To remove, release retaining springs<br>After inserting, hook the retaining springs again |

### 12.8.1 Front lights

The lamps for low beam, main beam and parking light as well as for the direction indicator are part of the basic vehicle. Replacement of light bulbs is described in the instruction manual of the base vehicle.

### 12.8.2 Rear lights




- 1 Housing screws
- 2 Rear light
- 3 Brake light
- 4 Direction indicator
- 5 Reverse light
- 6 Fog tail light

Fig. 292 Rear lights

- Undo the five housing screws (Fig. 292,1).
- Remove housing.
- Remove bulb.
- Put in a new bulb.
- Reassemble the lamp in the reverse order.

### 12.8.3 Side lights



- 1 Side marker light
- 2 Awning light
- 3 Marker light

Fig. 293 Side lights

#### Side marker light

The side marker light (Fig. 293,1) is located at the top of the side wall area at the back of the vehicle.

- Remove housing.
- Remove bulb.
- Put in a new bulb.
- Reassemble the lamp in the reverse order.

**Marker lights** The marker lights (Fig. 293,3) are fitted in the lower part of the vehicle.

**Awning light** The awning light (Fig. 293,2) is located above the entrance door.



- ▷ The lights have LEDs. To change the LEDs, contact an authorised dealer or a service centre.

### 12.8.4 Types of bulbs for exterior lighting

|             | Exterior lighting          | Type of bulb                        |
|-------------|----------------------------|-------------------------------------|
| <b>Rear</b> | Brake light                | Ba15s 12 V 21 W                     |
|             | Rear light                 | Ba15s 12 V 5 W                      |
|             | Direction indicator        | Ba15s 12 V 21 W orange              |
|             | Fog tail light             | Ba15s 12 V 21 W                     |
|             | Licence plate light        | Soffitte 12 V 5 W                   |
|             | Reverse light              | Ba15s 12 V 21 W                     |
|             | Third brake light          | LED                                 |
| <b>Side</b> | Marker light, awning light | LED                                 |
|             | Side marker light          | Ba15s 12 V 5 W or Soffitte 12 V 5 W |

### 12.9 Replacing bulbs, internal



- ▶ Bulbs and light fittings can be extremely hot. Therefore, allow lights to cool down before changing bulbs.
- ▶ Shut off the power supply on the safety cut-out in the 230 V fuse box before changing bulbs.
- ▶ Store bulbs in a safe place inaccessible to children.
- ▶ Do not use any bulb that has been dropped or which shows scratches in its glass. The bulb might burst.
- ▶ Lights can get very hot. When the light is switched on, there must always be a safety distance of 30 cm between light and flammable objects. Fire hazard!
- ▶ Do not replace the LEDs in lamps with standard light bulbs. Risk of fire due to intense heat build up.



- ▷ A new bulb should not be touched with the fingers. Use a cloth when installing the new bulb.
- ▷ Only use bulbs of the same type and with the correct wattage.
- ▷ If LEDs in lights are defect, contact an authorised dealer or service centre.

### 12.9.1 Recessed halogen light



Fig. 294 Recessed halogen light (flat)




Fig. 295 Changing the halogen bulb

Halogen bulb 12 V/10 W

The recessed halogen light (Fig. 294,1) is installed flush.

*Changing bulbs:*

- Use a screwdriver to remove the inner cover ring (Fig. 295,1) from the housing.
- Use a screwdriver to remove the cover ring with the glass (Fig. 295,2) from the lower section of the recessed halogen light.
- Remove halogen bulb (Fig. 295,3).
- Put in a new halogen bulb.
- Reassemble the lamp in the reverse order.

### 12.9.2 Recessed halogen light (flat)



Fig. 296 Recessed halogen light (flat)

Halogen bulb G4 12 V/10 W

The recessed halogen light (Fig. 296,2) is installed flush with the panel.

*Changing bulbs:*

- Use a suitable tool (e.g. a screwdriver) to lever out the internal cover ring with glass disk (Fig. 296,1) from the housing.
- Remove halogen bulb.
- Put in a new halogen bulb.
- Reassemble the lamp in the reverse order.

### 12.9.3 Recessed light with LED




Fig. 297 Recessed light



Fig. 298 Recessed light (alternative)



- ▷ LED lamps have a very long life. It is not normally necessary to replace a lamp.

*Changing bulbs:*

- Contact a dealer or service centre.

### 12.9.4 Halogen spotlight (movable)




Fig. 299 Halogen spotlight (movable)



Fig. 300 Suction cup for replacing the lamp

Halogen bulb 12 V/10 W

*Changing bulbs:*

- Turn the halogen spotlight (Fig. 299,1) by 90° and remove from rail.
- Turn the lamp shade (Fig. 299,3) in an anticlockwise direction.
- Withdraw lamp shade complete with halogen bulb (Fig. 299,4) carefully from the holder (Fig. 299,2).
- Remove halogen bulb.
- Screw lamp shade onto holder.
- Insert new halogen spot light into the lamp shade and press into holder.
- Insert halogen lamp into the rail.



- ▷ A suction cup (Fig. 300,1) is included to help with changing the lamp.

### 12.9.5 Halogen spotlight (movable)




Fig. 301 Halogen spotlight (movable)

Halogen bulb 12 V/10 W

- Changing bulbs:*
- Turn outer ring (Fig. 301,1) in an anticlockwise direction until it separates from the housing.
  - Remove retaining ring.
  - Remove halogen bulb.
  - Put in a new halogen bulb.
  - Reassemble the lamp in the reverse order.

### 12.9.6 Garage light




Fig. 302 Garage light

Halogen bulb 12 V/16 W

- Changing bulbs:*
- Carefully push the transparent cover (Fig. 302,1) together from both sides, pull it lightly from the switch and pull it off forwards.
  - Remove halogen bulb.
  - Put in a new halogen bulb.
  - Reassemble the lamp in the reverse order.

## 12.10 Spare parts



- ▶ Every alteration of the original condition of the vehicle can alter road behaviour and jeopardize road safety.
- ▶ The special equipment and original spare parts recommended by us have been specially developed and supplied for your vehicle. These products are available at the authorised dealer or service centre. The authorised dealer or service centre is informed about admissible technical details and carries out the required work correctly.
- ▶ The use of accessories, parts and fittings not supplied by us may cause damage to the vehicle and jeopardize road safety. Even if an expert's report, a general type approval or a design certification exists, there is no guarantee for the proper quality of the product.
- ▶ No liability can be assumed for damage caused by products which have not been released by us. This also applies to impermissible alterations to the vehicle.

For safety reasons, spare parts for pieces of equipment must correspond with manufacturer's instructions and be permitted by the manufacturer as a spare part. These spare parts may only be fitted by the manufacturer or an authorised specialist workshop. The authorised dealers and service centres are available for any spare parts requirement.


Here are some suggestions of important spare parts:

- Fuses
- V-belt
- Windscreen blades
- Bulbs
- Water pump (submerged pump)

When ordering spare parts please indicate the chassis number and the vehicle type to the dealer.

The vehicle described in this instruction manual is built and equipped to factory standards. Special equipment is offered depending on its purpose or use. When fitting special equipment check if such equipment has to be entered in the vehicle documents. Observe the max. permissible gross weight. The authorised dealer or service centre will be happy to advise you.

## 12.11 Vehicle identification plate



1 Chassis number

Fig. 303 Vehicle identification plate

The vehicle identification plate (Fig. 303) with the chassis number is located inside in the entrance area.

Do not remove the vehicle identification plate. The vehicle identification plate:

- Identifies the vehicle
- Helps with the procurement of spare parts
- Together with the vehicle documents identifies the vehicle owner



- ▷ Always include the **chassis number** with all inquiries for the customer service office.

## 12.12 Warning and information stickers

There are warning and information stickers on and inside the vehicle. Warning and information stickers are for the sake of safety and must not be removed.



- ▷ Replacement stickers can be obtained from an authorised dealer or a service centre.

## Chapter overview

This chapter contains instructions regarding the tyres of the vehicle.

The instructions address the following topics:

- tyre selection
- handling of tyres
- changing wheels
- spare wheel support

At the end of the chapter there is a table you can use to find the correct tyre pressure for your vehicle.

### 13.1 General



- ▶ Check tyre pressure before a journey or every 2 weeks. Wrong tyre pressure causes excessive wear and can lead to damage or even to tyre burst. You can lose control of the vehicle.



- ▷ Only check the tyre pressure on cold tyres.
- ▷ Tubeless tyres have been installed on the vehicle. Never install tubes in these tyres.
- ▷ Read the instruction manual for the base vehicle.



- ▷ Depending on the base vehicle and model the vehicles are only equipped with tyre repair kit as standard.
- ▷ In the case of a puncture, pull over to the side of the road. Make vehicle safe with a hazard warning triangle. Switch on the warning lights.
- ▷ Tyres on vehicles with tandem axles may wear faster.
- ▷ Tyres must not be older than 6 years as the material will become brittle over time. The four-digit DOT number on the tyre flank indicates the date of manufacture. The first two digits designate the week, the last two digits the year of manufacture.

Example:  $\textcircled{0512}$  Week 05, year of manufacture 2012.

- Observe:**
- Check the tyres regularly (every 2 weeks) for equal tread wear, tread depth and external damage.
  - Replace tyres at the latest, when the minimum depth of tread stipulated by law is reached.
  - Always use tyres of the same model, same brand and same style (summer and winter tyres).
  - Only use tyres approved for the wheel rim type fitted. The permitted rim and tyre sizes are quoted in the vehicle documents and the authorised dealer or service centre will always be glad to give you advice.
  - Run-in new tyres for approx. 100 km (60 miles) at low speed since only then do they reach full strength.




Fig. 304 Tighten the wheel nuts or wheel bolts cross-wise

- Check regularly that the wheel nuts or wheel bolts are firmly seated. Retighten the wheel nuts or wheel bolts of a changed wheel cross-wise (Fig. 304) after 50 km (30 miles). See section 13.5.2 for tightening torque.
- When using new or newly painted rims, re-tighten the wheel nuts or wheel bolts once again after approx. 1,000 to 5,000 km (600 miles to 3,000 miles).
- For lay-ups or long periods of inactivity, keep the tyres and tyre bearings free from pressure points:  
Jack up the vehicle so that the wheels do not bear any load, or move the vehicle every 4 weeks in such a way that the position of the wheels is changed.

## 13.2 Tyre selection



- ▶ A wrong tyre can damage the tyres during the journey and even cause it to burst.



- ▷ If tyres that are not approved for the vehicle are used, then the type approval for the vehicle and subsequently the insurance coverage can lapse. The authorised dealer or service centre will be happy to advise you.

The tyre sizes approved for the vehicle are given in the vehicle documents or can be obtained from the authorised dealers or service centres. Each tyre must fit the vehicle on which it will be driven. This applies to the external dimensions (diameter, width), which are indicated with the standardised size designations. In addition, the tyres must meet the requirements of the vehicle with regard to weight and speed.

Weight refers to the maximum permissible axle load which can be distributed on two tyres. The maximum load-carrying capacity of a tyre is indicated by its load index (= LI, load index code).

The axle geometry of a vehicle, such as wheel camber and track, is also important for tyre selection. The maximum permissible speed for a tyre (with full load-carrying capacity) is indicated by the speed index (= SI). Together, load index and speed index form the operating code of a tyre. This is an official component of the complete, standardised dimensions description which appears on every tyre. The information on the tyres must correspond to the specifications which appear in the vehicle papers.

### 13.3 Tyre specifications

**215/70 R 15C 109/107 Q**  
(example)

| Description | Explanation                           |
|-------------|---------------------------------------|
| 215         | Tyre width in mm                      |
| 70          | Height-to-width proportion in percent |
| R           | Tyre design (R = radial)              |
| 15          | Rim diameter in inches                |
| C           | Commercial (transporter)              |
| 109         | Load index code for single tyres      |
| 107         | Load index code for twin tyres        |
| Q           | Speed index (Q = 160 km/h)            |

### 13.4 Handling of tyres

- Drive over kerbs at an obtuse angle. Otherwise the flanks of the tyres may get pinched. Driving over a kerb at a sharp angle can damage the tyre and result in it getting ruptured.
- Drive over high manhole covers at a slow speed. Otherwise the tyres may get pinched. Driving over a high manhole cover at high speed can damage the tyre and result in it getting ruptured.
- Check the shock absorbers regularly. Driving with poor shock absorbers significantly increases wear.
- If the tread wear is uneven, have the toe-in and the wheel camber checked. Driving with an incorrectly set toe-in or a one-sided wheel camber leads to a significant increase in wear.
- Avoid block brakings. Block braking gives the tyres "brake plates" of varying strength. This reduces driving comfort. It might even make the tyres unserviceable.
- Do not clean the tyres with a high-pressure cleaner. The tyres can suffer serious damage within just a few seconds and rupture as a result.
- Drive in such a way as to protect your tyres. Avoid braking sharply, revving up too strongly and long journeys on poor roads.

### 13.5 Changing wheels

#### 13.5.1 General instructions



- ▶ The vehicle must be on level, firm ground, secure from slipping.
- ▶ Go into first gear. In the case of automatic transmission, change gear to "P" position.
- ▶ Before jacking up the vehicle firmly apply the handbrake.
- ▶ Prevent the vehicle from rolling away by blocking the opposite wheel with the wheel chocks.
- ▶ Under no circumstances jack the vehicle with the fitted supports.
- ▶ If a trailer is connected: Detach the trailer before lifting the vehicle.
- ▶ Position the vehicle jack underneath the axle, not under any circumstances on the bodywork.



- ▶ Never overload the vehicle jack. The maximum permissible load is specified on the vehicle jack's identification plate.
- ▶ Use the vehicle jack only for lifting the vehicle briefly while changing the tyre.
- ▶ No persons may be in the vehicle while it is raised.
- ▶ Do not start the motor while the vehicle is jacked up.
- ▶ Whilst the vehicle is in a jacked up position, persons must not lie down under it.



- ▷ Do not damage the thread of the thread bolt or wheel bolt when changing the wheel.
- ▷ Tighten the wheel nuts or wheel bolts cross-wise (Fig. 304).
- ▷ When changing wheels (e.g. alloy wheel rims or wheels with winter tyres), use the correct wheel bolts of the correct length and shape. Otherwise the wheels may not be securely fixed or the braking system may not work correctly.
- ▷ The use of wheel rims or tyres that are not approved for the vehicle can make it less than fully roadworthy; such wheel rims or tyres must be separately inspected and approved by an accredited test centre.
- ▷ Do not replace wheels cross-wise.



- ▷ Protect the vehicle according to the national regulations, e.g. with a hazard warning triangle.
- ▷ Before changing the wheel, check the wheel rim and tyre size, the max. tyre load and the speed index on the tyres. Only use the wheel rim and tyre sizes stated in the vehicle documents.
- ▷ Further information can be found in the instruction manual of the base vehicle.

### 13.5.2 Tightening torque

Depending on the wheel rim type and the wheel manufacturer, the wheels must be tightened with different tightening torques.

#### Steel wheel rim

- Steel wheel rim 15": Tightening torque 160 Nm
- Steel wheel rim 16": Tightening torque 180 Nm

#### Alloy wheel rim Borbet



Fig. 305 Alloy wheel rim Borbet

- Alloy wheel rim 15" Borbet HW65560: Tightening torque 130 Nm
- Alloy wheel rim 16" Borbet HW65660: Tightening torque 130 Nm

**Alloy wheel rim Tomason**

Fig. 306 Alloy wheel rim Tomason

- Alloy wheel rim 15" Tomason TN3F-6515: Tightening torque 180 Nm
- Alloy wheel rim 16" Tomason TN3F-6516: Tightening torque 180 Nm

**Alloy wheel rim  
Goldschmitt**

Fig. 307 Alloy wheel rim Goldschmitt

- Alloy wheel rim 15" Goldschmitt GSM1-1560: Tightening torque 180 Nm
- Alloy wheel rim 16" Goldschmitt GSM1-1665: Tightening torque 180 Nm

### 13.5.3 Changing a wheel



- ▶ The footplate of the vehicle jack must be levelly positioned on the ground.
- ▶ Do not tilt the vehicle jack.



- ▷ The wheel you have replaced should be repaired immediately.
- ▷ Take note of the general instructions in this chapter.




Fig. 308 Securing vehicle

- Park the vehicle on as even and stable a surface as possible.
- Switch off the engine and safeguard the area.
- Go into first gear. In the case of automatic transmission, change gear to "P" position.
- Apply the handbrake.
- Place wheel chocks or other appropriate objects beneath the opposite wheel of the vehicle to secure it (Fig. 308).
- Remove the spare wheel from the spare wheel support.
- If the ground is soft, place a stable support such as a wooden board beneath the vehicle jack.
- Apply the vehicle jack to the designated mounting points (refer to the instruction manual for the base vehicle).
- Turn the wheel bolts several times to loosen them, but do not remove them.
- Lift the vehicle until the wheel has been lifted 2 to 3 cm above the ground.
- Remove the wheel bolts and take off the wheel.
- Place the spare wheel on the wheel hub and adjust.
- Screw in the wheel bolts and slightly tighten them cross-wise.
- Crank down the vehicle jack and remove it.
- Using the wheelbrace, tighten the wheel bolts evenly (see section 13.5.2 for tightening torque).
- Have the tightening torque checked by an authorised specialist workshop.

### 13.6 Spare wheel support (special equipment)

The spare wheel support is built into the rear garage.




Fig. 309 Spare wheel support in the rear garage

*Removing the spare wheel:*

- Open external flap of the rear garage.
- Loosen and remove both fixing screws (Fig. 309,2) with the on-board tool set.
- Remove the spare wheel (Fig. 309,1) from the support (Fig. 309,3).

### 13.7 Tyre pressure



- ▶ Tyres overheat if the tyre pressure is too low. This can cause serious tyre damage.
- ▶ Check tyre pressure before a journey or every 2 weeks. Wrong tyre pressure causes excessive wear and can lead to damage or even to tyre burst. You can lose control of the vehicle.
- ▶ Use only valves that are approved for the specified tyre pressure.




- ▷ Only check the tyre pressure on cold tyres.

The payload and the durability of tyres is directly dependent on the tyre pressure. Air is a volatile medium. It is unavoidable that it will escape from tyres.

As a rule of thumb it can be assumed that a filled tyre loses pressure at a rate of 0.1 bar every two months. To prevent the tyres becoming damaged or burst, check the tyre pressure regularly.

The contact surface of the tyre changes, depending on the tyre pressure.



- 1 Correct tyre pressure
- 2 Tyre pressure too low
- 3 Tyre pressure too high

Fig. 310 Contact surface of the tyre



- ▷ The information on pressure levels is valid for cold tyres and loaded vehicles.
- ▷ Pressure in hot tyres must be 0.3 bar higher than in cold tyres. Recheck the pressure when the tyres are cold.
- ▷ Tyre pressures in bar.
- ▷ Over 4.75 bar requires a metal valve.
- ▷ The tyre pressure tolerance is +/- 0.05 bar.

| Types                             | Tyre size                                      | Front air pressure in bar | Rear air pressure in bar |
|-----------------------------------|--|---------------------------|--------------------------|
| All types                         | 215/70 R 15 C<br>(109/107) Q                   | 4.1                       | 4.5                      |
| All types with motorhome tyres    | 215/70 R 15 CP<br>(109/107) Q                  | 5.0                       | 5.5                      |
| All types with winter tyres (M+S) | 215/70 R 15 C<br>(109/107) Q                   | 4.3                       | 4.75                     |
| All types                         | 225/75 R 16 C<br>(116/114) Q                   | 4.5                       | 5.0                      |
| All types with motorhome tyres    | 225/75 R 16 CP<br>(116/114) Q                  | 5.5                       | 5.5                      |
| All types with winter tyres (M+S) | 225/75 R 16 C<br>(116/114) Q                   | 5.2                       | 5.2                      |
| All types                         | 225/75 R 16 C<br>(116/114) Q<br>(tandem axle)  | 4.5                       | 3.5                      |
| All types with motorhome tyres    | 225/75 R 16 CP<br>(116/114) Q<br>(tandem axle) | 5.5                       | 3.5                      |
| All types with winter tyres (M+S) | 225/75 R 16 C<br>(116/114) Q<br>(tandem axle)  | 5.2                       | 3.5                      |

The vehicles are constantly brought up to the newest technical standards. It is possible that new tyre sizes are not yet included in this table. If this is the case, any authorised dealer or service centre will be happy to provide the newest values.

## Chapter overview

This chapter contains instructions about possible faults in your vehicle. The faults are listed with their possible causes and corresponding remedies. The instructions address the following topics:

- braking system
- electrical system
- fuel cell
- gas system
- heater
- boiler
- air conditioning unit
- gas cooker
- gas oven
- microwave oven
- refrigerator
- water supply
- body

The specified faults can be remedied with relative ease and without a great deal of specialised knowledge. In the event that the remedies detailed in this instruction manual should not be successful, an authorised specialist workshop must find and eliminate the cause of the fault.

### 14.1 Braking system



- ▶ Have defects on the braking system immediately remedied by an authorised specialist workshop.

### 14.2 Electrical system



- ▷ When the living area battery is changed, only use batteries of the same type.



- ▷ See chapter 8 for changing the fuses.

| Fault   | Cause  | Remedy  |
|---|--|---|
| Road light system does no longer work correctly                   | Bulb is defective                              | Replace bulb. Note volts and watts specifications |
| Interior lighting does no longer work correctly                   | Bulb is defective                              | Replace bulb. Note volts and watts specifications |
|   | Fuse on the transformer/rectifier is defective | Replace fuse on the transformer/rectifier         |
| The electrically operated entrance step cannot be moved in or out | Fuse on the transformer/rectifier is defective | Replace fuse on the transformer/rectifier         |
| No 230 V power supply despite connection                          | 230 V automatic circuit breaker has triggered  | Switch on the 230 V automatic circuit breaker     |

| Fault   | Cause   | Remedy   |
|---|---|--|
| Starter or living area battery is not charged when operated in 230 V mode | Jumbo flat fuse (50 A) on the starter or living area battery is defective | Replace jumbo flat fuse (50 A) on the starter or living area battery |
|   | Charger module in the transformer/rectifier is defective                  | Contact customer service   |
| Living area battery is not charged during vehicle operation               | Fuse on terminal D+ of the alternator is defective                        | Replace fuse   |
|   | Disconnecter relay in the transformer/rectifier is defective              | Contact customer service   |
| 12 V power supply does not work   | 12 V power supply switched off  | Switch 12 V power supply on  |
|   | Battery cut-off switch on the transformer/rectifier is switched off       | Set battery cut-off switch to on                                     |
|   | Living area battery is discharged   | Charging the living area battery                                     |
|   | Jumbo flat fuse (50 A) on the living area battery is defective            | Replace jumbo flat fuse (50 A) on the living area battery            |
|   | Disconnecter relay in the transformer/rectifier is defective              | Contact customer service   |
| 12 V power supply does not work in 230 V operation                        | 12 V power supply switched off  | Switch 12 V power supply on  |
|   | Battery cut-off switch on the transformer/rectifier is switched off       | Set battery cut-off switch to on                                     |
|   | Charger module in the transformer/rectifier is defective                  | Contact customer service   |
|   | 230 V automatic circuit breaker has triggered                             | Contact customer service   |
|   | Jumbo flat fuse (50 A) on the living area battery is defective            | Replace jumbo flat fuse (50 A) on the living area battery            |
| Starter battery is discharged in 12 V operation                           | Disconnecter relay in the transformer/rectifier is defective              | Contact customer service   |
|   | Battery cut-off switch on the transformer/rectifier is switched off       | Set battery cut-off switch to on                                     |

| Fault   | Cause   | Remedy   |
|---|---|--|
| No voltage is supplied by the living area battery | Living area battery is discharged                                   | Charge living area battery immediately<br><br> ▷ Total discharge damages the battery.<br><br>If the vehicle is to be laid up for a long period, fully charge the living area battery beforehand<br><br>Discharging is caused by inactive appliances (see chapter 8) |
| 12 V indicator lamp does not light up             | 12 V power supply switched off                                      | Switch 12 V power supply on  |
|   | Battery cut-off switch on the transformer/rectifier is switched off | Set battery cut-off switch to on   |
|   | Starter or living area battery is not charged                       | Charge the starter or living area battery  |
|   | Disconnecter relay in the transformer/rectifier is defective        | Contact customer service   |
|   | Flat fuse (2 A) in the living area battery is defective             | Replace flat fuse (2 A) in the living area battery   |
| Extractor hood does not work                      | 230 V automatic circuit breaker is switched off                     | Switch on the 230 V automatic circuit breaker  |
|   | Fuse (15 A) at the transformer/rectifier is defective               | Replace fuse (15 A)  |
|   | Extractor hood defective  | Contact customer service   |

### 14.3 Fuel cell



- ▷ Do not open the fuel cell. The fuel cell contains no parts that could be repaired by itself.
- ▷ All faults are not displayed. If the faults cannot be rectified using the following table or the instruction manual for the fuel cell, please contact the customer service.

| Fault (display)                 | Cause   | Remedy  |
|---------------------------------|---|---|
| Fuel cell cannot be switched on | No battery connected, battery connected incorrectly or totally discharged | Inspect the connection  |
|                                 | Fuse is defective   | Replace fuse; if it happens again, contact the customer service           |
| Failure: Environment too warm   | Ambient temperature too high (40 °C)                                      | Fuel cell restarts when the ambient temperature is between 0 °C and 40 °C |

## 14.4 Gas system



- ▶ In case of a defect of the gas system (gas odour, high gas consumption) there is danger of explosion! Close regulator tap on the gas bottle immediately. Open doors and windows and ventilate well.
- ▶ If the gas system is defective: Do not smoke; do not ignite any open flames, and do not operate electric switches (light switches etc.).
- ▶ Have the defective gas system repaired by an authorised specialist workshop.

| Fault  | Cause   | Remedy                                |
|--------|---|---------------------------------------|
| No gas | Gas bottle is empty   | Change gas bottle                     |
|        | Gas isolator tap closed   | Open the gas isolator tap             |
|        | Regulator tap on the gas bottle is closed                                     | Open regulator tap on the gas bottle  |
|        | External temperature is too low (-42 °C for propane gas, 0 °C for butane gas) | Wait for higher external temperatures |
|        | Built-in appliance is defective   | Contact customer service              |

## 14.5 Heater/boiler

In the event of a defect contact the nearest customer service workshop of the relevant appliance manufacturer. The list of addresses is enclosed with the accompanying appliance documentation. Only authorised qualified personnel may repair the appliance.

### 14.5.1 Truma heater/boiler (gas heater)

| Fault                                  | Cause   | Remedy  |
|--|---|---|
| Heater does not ignite                 | Temperature sensor on operating unit or remote sensor defective | Pull out plug on operating unit. The heater then works without thermostat. Contact the customer service as soon as possible |
| Red indicator lamp "Fault" illuminates | Air in the gas pipe system                                      | Switch off and on again. After two futile ignition attempts, wait for 10 minutes before trying again                        |
|  | Lack of gas   | Open regulator tap and gas isolator tap   |
|  |   | Connect a full gas bottle   |
| Red indicator lamp "Fault" is flashing | Defect of a safety element                                      | Contact customer service  |
|  | Operating voltage too low                                       | Charge or replace the living area battery (or have it charged or replaced)  |

| Fault   | Cause  | Remedy   |
|---|--|--|
| Green indicator lamp behind knob is not lit                             | Fuse on the transformer/rectifier is defective         | Replace fuse on the transformer/rectifier                                  |
|   | Fuse in the electronic control unit has been triggered | Contact customer service   |
|   | Living area battery defective                          | Charge or replace the living area battery (or have it charged or replaced) |
| Yellow indicator lamp on the energy selector switch does not illuminate | No supply voltage                                      | Check 230 V connection and fuses   |
|   | Overheating switch was triggered                       | Press overheating switch   |
| Boiler empties, safety/drainage valve has opened                        | Internal temperature below 8 °C                        | Heat inside  |
| Safety/drainage valve cannot be closed                                  | Temperature at safety/drainage valve below 8 °C        | Heat inside  |
| Red and green indicator lamps are not lit                               | Fuse is defective                                      | Replace fuse on the transformer/rectifier                                  |
| Fan wheel runs noisily or not steadily                                  | Fan wheel is soiled                                    | Contact Truma service department   |

### 14.5.2 Truma heater/boiler (diesel heater)

| Fault  | Cause  | Remedy   |
|--|--|--|
| No indicator lamp comes on after switching on          | Fuse on the transformer/rectifier is defective                 | Replace fuse on the transformer/rectifier  |
|  | Fuse in the electronic control unit of the boiler is defective | Replace the fuse on the appliance. Call customer service if the fuse blows again |
|  | No operating voltage   |  |
| Check all plug connectors                              |  |  |
| Heater does not ignite (green indicator lamp comes on) | Room temperature is higher than the preset temperature range   | Set a higher temperature range   |
|  | Temperature sensor defective                                   | Contact customer service   |
| Red indicator lamp "Fault" is flashing                 | Operating voltage too low                                      | Charge or replace the living area battery (or have it charged or replaced)       |
|  | Warm air louvres blocked                                       | Open air outlet louvres  |
|  | Air circulation suction system blocked                         | Remove blocking of air circulation suction system                                |

| Fault   | Cause  | Remedy  |
|---|--|---|
| Red indicator lamp "Fault" illuminates                  | Summer operation with boiler empty                 | Fill the boiler with water  |
|   | Combustion air inlet or exhaust gas outlet blocked | Remove blockage (e.g. snow or dust)   |
|   | Low fuel   | Fill tank with fuel   |
|   | Wrong fuel   | Replace fuel  |
| Green and red indicator lamps flash after switching off | Appliance was switched off by a fault              | Wait for the appliance to run down. Then switch on the appliance and switch off again |
| Green indicator lamp flashes after switching off        | Run-down for cooling of the appliance active       | Wait for appliance to run down (approx. 5 minutes)                                    |
| Safety/drainage valve opens after switching off         | Internal temperature below 3 °C                    | Heat inside   |
| Safety/drainage valve cannot be closed                  | Temperature at safety/drainage valve below 7 °C    | Heat inside   |
|   | Rotary switch in "Off" position                    | Turn rotary switch to an operating mode   |
| Water flows intermittently from the drain neck          | Water pressure too high (over 2.8 bar)             | If connected to a central water supply, install a pressure reducer                    |
|   |  | Contact customer service  |

### 14.5.3 Aide heater/boiler



- ▷ If a fault occurs in the system, the cause is shown on the display.

| Fault  | Cause                   | Remedy  |
|--|-------------------------|---|
| Heater does not ignite with gas operation            | Lack of gas             | Open regulator tap and gas isolator tap   |
|  |                         | Connect a full gas bottle   |
| Heater does not ignite                               | Battery voltage too low | Charge battery. If the battery voltage rises above 11 V, the heater is switched on automatically                          |
| Heater does not ignite at 230 V electrical operation | No 230 V power supply   | Switch on the 230 V automatic circuit breaker   |
|  |                         | Connect the 230 V power supply  |
| Heater switches off                                  | Overheating             | Allow the heater to cool. To reset the display, interrupt the 12 V power supply to the heater and switch it back on again |

| Fault  | Cause                          | Remedy                    |
|--|--------------------------------|---------------------------|
| Heater running, but no heat at the convectors                      | Circulating pump does not work | Switch on room thermostat |
|  |                                | Contact customer service  |
| Heater and circulating pump running, but no heat at the convectors | Air in the heating system      | Bleed hot-water heater    |

## 14.6 Air conditioning unit

### 14.6.1 Dometic

| Fault                                   | Cause   | Remedy  |
|---|---|---|
| Air conditioning unit does not start up | No 230 V power supply                         | Connect the vehicle to the local power supply |
|   | 230 V automatic circuit breaker has triggered | Switch on the 230 V automatic circuit breaker |
|   | Remote control batteries empty                | Change remote control batteries               |
| Air conditioning unit does not cool     | Temperature below 16 °C                       | –   |
|   | Temperature has been set incorrectly          | Adjust the temperature                        |
|   | Thermostat defective                          | Contact customer service                      |
| Air conditioning unit does not warm up  | Temperature above 30 °C                       | –   |
|   | Temperature has been set incorrectly          | Adjust the temperature                        |
|   | Thermostat defective                          | Contact customer service                      |
| Water is entering the vehicle           | Drainage holes for condensation are clogged   | Clean air conditioning unit                   |
|   | Seal is defective                             | Contact customer service                      |
| No more air circulation                 | Air filter clogged                            | Clean air filter                              |
|   | Fan wheel defective                           | Contact customer service                      |

### 14.6.2 Telair

| Fault                                   | Cause   | Remedy  |
|---|---|---|
| Air conditioning unit does not start up | No 230 V power supply                                 | Connect 230 V power supply                    |
|   | 230 V automatic circuit breaker has triggered         | Switch on the 230 V automatic circuit breaker |
|   | Remote control batteries empty                        | Change batteries (2 x AAA)                    |
| Air conditioning unit does not cool     | Room temperature is lower than the preset temperature | Reset temperature                             |

| Fault                               | Cause  | Remedy                             |
|-------------------------------------|--|------------------------------------|
| Air conditioning unit does not heat | Room temperature is higher than the preset temperature | Reset temperature                  |
| Insufficient ventilation rating     | Ventilation flaps closed                               | Open at least one ventilation flap |
|                                     | Filter dirty   | Clean the filter                   |
| Water is entering the vehicle       | Drainage holes for condensation are clogged            | Clean air conditioning unit        |

## 14.7 Cooker

### 14.7.1 Gas cooker/gas oven

| Fault   | Cause                                  | Remedy  |
|---|--|---|
| Ignition fuse does not operate (flame does not burn after the control knobs are released) | Heat-up time is too short              | Keep control knob pressed for approx. 15 to 20 seconds after ignition   |
|   | Ignition fuse is defective             | Contact customer service  |
| Flame extinguishes when being reduced to its minimum setting                              | Thermocouple sensor is incorrectly set | Correctly reset thermocouple sensor (do not bend). The sensor tip should protrude by 5 mm beyond the burner. The sensor neck should not be more than 3 mm away from the burner ring; if necessary, contact customer service |

### 14.7.2 Microwave oven



- Only qualified personnel may repair the microwave oven. Improper repairs can cause major risks to the user.

| Fault                          | Cause   | Remedy  |
|--------------------------------|---|---|
| Microwave oven does not cut in | Fuse is defective                                 | Replace fuse  |
|                                | Door of the microwave oven is not properly closed | Remove foreign bodies stuck in the door of the microwave oven and close door properly |

## 14.8 Refrigerator

In the event of a defect contact the nearest customer service workshop of the relevant appliance manufacturer. The list of addresses is enclosed with the accompanying appliance documentation. Only authorised qualified personnel may repair the appliance.

**14.8.1 Dometic 8 series with MES**


▷ In the case of a fault the LED display fault will always light up "⚠".

| Fault   | Cause  | Remedy   |
|---|--|--|
| LED "⚡" flashes   | No 230 V power supply  | Connecting 230 V power supply  |
|   | 230 V automatic circuit breaker has triggered                | Switch on the 230 V automatic circuit breaker  |
|   | 230 V operating voltage too low                              | Have the 230 V power supply checked by an authorised specialist workshop                 |
| LED "⊕" flashes   | Fuse on the transformer/rectifier is defective               | Replace fuse on the transformer/rectifier  |
|   | Disconnecter relay in the transformer/rectifier is defective | Contact customer service   |
|   | 12 V operating voltage too low                               | Have the 12 V power supply checked by an authorised specialist workshop                  |
| LED "🔥" flashes   | Lack of gas  | Open regulator tap and gas isolator tap  |
|   |  | Connect a full gas bottle  |
| LEDs for display of the temperature range flash             | Cobwebs or burnt residue in the burning chamber              | Remove the ventilation grill on the outside of the vehicle and clean the burning chamber |
|   |  | Temperature sensor defective   |
| LED "⚡" and LEDs for display of the temperature range flash | 230 V heater element defective                               | Contact customer service   |
| LED "⊕" and LEDs for display of the temperature range flash | 12 V heater element defective                                | Contact customer service   |
| Refrigerator does not refrigerate sufficiently              | Insufficient ventilation of unit                             | Check if ventilation grills are covered; remove covers if necessary                      |
|   |  | Remove ventilation grills and clean the space behind them (of leaves etc.)               |
|   | Ambient temperatures are too high                            | Remove the ventilation grills periodically   |

### 14.8.2 Dometic 8 series with AES



▷ In the case of a fault the LED display fault will always light up "⚠".

| Fault   | Cause  | Remedy   |
|---|--|--|
| Text "230 V" flashes                            | No 230 V power supply  | Connecting the 230 V power supply  |
|   | 230 V automatic circuit breaker has triggered                | Switch on the 230 V automatic circuit breaker  |
|   | 230 V operating voltage too low                              | Have the 230 V power supply checked by an authorised specialist workshop                 |
| Text "12 V" flashes                             | Fuse on the transformer/rectifier is defective               | Replace fuse on the transformer/rectifier  |
|   | Disconnecter relay in the transformer/rectifier is defective | Contact customer service   |
|   | 12 V operating voltage too low                               | Have the 12 V power supply checked by an authorised specialist workshop                  |
| Text "GAS" flashes                              | Lack of gas  | Open regulator tap and gas isolator tap  |
|   |  | Connect a full gas bottle  |
|   | Cobwebs or burnt residue in the burning chamber              | Remove the ventilation grill on the outside of the vehicle and clean the burning chamber |
| LEDs for display of the temperature range flash | Temperature sensor defective                                 | Contact customer service   |
| Text "HE1" flashes                              | 230 V heater element defective                               | Contact customer service   |
| Text "HE2" flashes                              | 12 V heater element defective                                | Contact customer service   |
| Refrigerator does not refrigerate sufficiently  | Insufficient ventilation of unit                             | Check if ventilation grills are covered; remove covers if necessary                      |
|   |  | Remove ventilation grills and clean the space behind them (of leaves etc.)               |
|   | Ambient temperatures are too high                            | Remove the ventilation grills periodically   |

## 14.9 Thetford refrigerator

| Error code | Cause   | Remedy   |
|------------|---|--|
| 1          | The 230 V power supply is 75 % under the required operating voltage                                     | Contact customer service   |
| 2          | The 12 V power supply is 75 % under the required operating voltage                                      | Contact customer service   |
| 3          | The refrigerator is operated at 230 V, even though no 230 V mode has been selected                      | Contact customer service   |
| 4          | The refrigerator is operated at 12 V, even though no 12 V mode has been selected                        | Contact customer service   |
| 5          | The refrigerator is operated in gas operation mode even though gas operation mode has not been selected | Contact customer service   |
| 6          | The gas valve has been identified as open even though it should be closed                               | Contact customer service   |
| 7          | The gas valve has been identified as closed even though it should be open                               | Contact customer service   |
| 8          | The 230 V power supply is 20 % under the required operating voltage                                     | Check 230 V power supply   |
| 9          | The gas supply has been cut off. The flame has not been ignited within 30 seconds in gas operation mode | <ul style="list-style-type: none"> <li>● Check the gas supply</li> <li>● Repeat ignition 3 to 4 times</li> <li>● Contact customer service</li> </ul> |
| 10         | The refrigerator is set to 12 V mode and the vehicle engine is not running                              | Start the vehicle engine or select a different energy source   |
| 11         | The refrigerator is set to "AUTO" mode and no energy source is available                                | Provide an energy source and reset the refrigerator. Switch the refrigerator off and on again for this purpose                                       |
| 12         | –   | Contact customer service   |
| 13         | The temperature sensor is defective   | Check whether the plug is inserted properly above the fin inside the refrigerator. If so: Contact customer service                                   |
| 14         | The connection between operating controls and control device is interrupted                             | Contact customer service   |

## 14.10 Water supply

| Fault   | Cause  | Remedy   |
|---|--|--|
| Leakage water inside the vehicle                                  | A leak has occurred  | Identify leak, re-connect water pipes  |
| No water  | Water tank is empty  | Replenish drinking water   |
|   | Drain cock not closed                                      | Close drain cock   |
|   | 12 V power supply switched off                             | Switch 12 V power supply on  |
|   | Fuse of the water pump is defective                        | Replace fuse on the transformer/rectifier  |
|   | Water pump defective                                       | Exchange water pump (have it exchanged)  |
|   | Water pipe snapped off                                     | Straighten water pipe or replace   |
|   | Transformer/rectifier defective                            | Contact customer service   |
|   | Water pump switched off on panel                           | Switch water pump on   |
| Toilet has no flush water   | Water tank is empty  | Replenish drinking water   |
|   | Fuse for toilet is defective                               | Replace fuse   |
| Display for water and waste water indicates a wrong value         | Measuring probe in the waste water or water tank is soiled | Clean water/waste water tank   |
|   | Measuring probe is defective                               | Replace measuring probe  |
| Waste water tank cannot be emptied                                | Drain cock is clogged                                      | Open the cleaning cap on the waste water tank and drain the waste water. Rinse the waste water tank well     |
| Drain on the single lever mixer tap is clogged                    | Perlator calcified   | Unclip the perlator, de-calcify in vinegar water (only for products made from metal)                         |
| Water jets on the shower nozzle clogged                           | Water jets calcified                                       | De-calcify shower nozzle in vinegar water (only for products made from metal) or rub off soft nozzle burling |
| Water drains from the shower tray slowly or does not drain at all | The vehicle is not in a horizontal position                | Position the vehicle horizontally  |
| Milkieness of the water   | Tank filled with dirty water                               | Clean water tank mechanically and chemically; then disinfect and rinse copiously with drinking water         |
|   | Residues in the water tank or water system                 | Clean water system mechanically and chemically; then disinfect and rinse copiously with drinking water       |

| Fault   | Cause   | Remedy   |
|---|---|--|
| Any change in the taste or odour of the water               | Tank filled with dirty water  | Clean water system mechanically and chemically; then disinfect and rinse copiously with drinking water   |
|   | Fuel filled into the water tank by mistake                                | Clean water system mechanically and chemically; then disinfect and rinse copiously with drinking water. If not successful: Contact a specialist workshop |
|   | Microbiological deposits in the water system                              | Clean water system mechanically and chemically; then disinfect and rinse copiously with drinking water   |
| Deposits in the water tank and/or water-carrying components | Water excessively long in the water tank and in water-carrying components | Clean water system mechanically and chemically; then disinfect and rinse copiously with drinking water   |

### 14.11 Body

| Fault   | Cause  | Remedy  |
|---|--|---|
| Flap hinges/door hinges are difficult to operate  | Flap/door hinges are not sufficiently lubricated           | Lubricate flap hinges/door hinges with acid-free and resin-free grease  |
| Hinges/joints in the bathroom unit/toilet compartment are difficult to operate/make a grating noise | Hinges/joints are not sufficiently lubricated              | Lubricate hinges/joints with solvent-free and acid-free grease<br> ▷ Spray cans often contain solvents |
| Storage compartment hinges are difficult to operate/make a grating noise                            | Storage compartment hinges are not sufficiently lubricated | Lubricate storage compartment hinges with acid-free and resin-free grease   |
| Wind-up skylight is difficult to operate  | Threaded spindle not lubricated                            | Lubricate threaded spindle  |
|   | Threaded spindle defective                                 | Have threaded spindle replaced  |



- ▷ The authorised dealers and service centres are available for any spare parts requirement.



## 15.1 Weight details for special equipment



- ▶ The use of accessories, parts and fittings not supplied by us may cause damage to the vehicle and jeopardize road safety. Even if an expert's report, a general type approval or a design certification exists, there is no guarantee for the proper quality of the product.
- ▶ Every alteration of the original condition of the vehicle can alter road behaviour and jeopardize road safety.
- ▶ No liability can be assumed for damage caused by products which have not been released by us. This also applies to impermissible alterations to the vehicle.

Weight details for factory-provided special equipment are listed in the table below. If these objects are either carried in or on the vehicle and are not part of the standard equipment, they must be taken into consideration when calculating the payload.

All weight details are approximate.

Observe the max. permissible gross weight.

| Item designation  | Surplus weight (kg) |
|---|---------------------|
| Waste water pipes insulated and heated                                    | 2                   |
| Waste water tank, heated with heating coils                               | 1                   |
| Airbag (front passenger)  | 3                   |
| Alloy wheel rims  | -15                 |
| Caravan coupling  | 40                  |
| Caravan coupling, detachable  | 30                  |
| Dashboard upgrade   | 2                   |
| Single-section conversion door with window and insect screen              | 30                  |
| External shower   | 1                   |
| External mirrors, electric  | 2                   |
| External socket   | 1                   |
| Automatic transmission  | 17                  |
| Car radio and CD  | 1                   |
| Fuel cell   | 7                   |
| Heki skylight midi  | 8                   |
| Skyroof skylight  | 12                  |
| Roof rail   | 5                   |
| Three-point seat belts in opposite direction to direction of travel (2 x) | 30                  |
| Extractor hood  | 1                   |
| Electric entrance step  | 5                   |
| Electrical stability program (ESP)  | 3                   |
| Spare wheel with 15" support  | 20                  |
| Spare wheel with 16" support  | 21                  |
| External gas connection   | 1                   |

| Item designation                            | Surplus weight (kg) |
|---|---------------------|
| Bike rack for 2 bicycles                    | 10                  |
| Bike rack for 2 bicycles, lowerable         | 18                  |
| Bike rack for 3 bicycles                    | 11                  |
| Bike rack for 3 bicycles, lowerable         | 20                  |
| Bike racks for e-bikes                      | 25                  |
| Roman shade, driver's cabin                 | 4                   |
| Floor warming unit                          | 4                   |
| Gas oven                                    | 17                  |
| Gas bottle (11 kg) made of aluminium        | 12                  |
| GRP roof                                    | 30                  |
| Rear window                                 | 3                   |
| Rear garage door, left                      | 3                   |
| Rear ladder                                 | 10                  |
| Alde heater                                 | 30                  |
| Truma Combi 6 EH heater                     | 3                   |
| Truma D altitude kit                        | 1                   |
| Pull-down bed, electrically operated        | -                   |
| Insect screen, door (full height)           | 4                   |
| Air conditioning unit (Dometic)             | 40                  |
| Driver's cabin air conditioning unit        | 18                  |
| Air conditioning unit (Telair)              | 34                  |
| Fuel tank 120 l                             | 50                  |
| Refrigerator (160 l)                        | 14                  |
| Refrigerator (Tec-Tower)                    | 16-30               |
| Wind-up skylight (Heki 3)                   | 15                  |
| L-seating group                             | 10                  |
| Alternator 180 Ah                           | 2                   |
| Pneumatic spring                            | 79                  |
| Pneumatic spring, rear                      | 45                  |
| Awning 260 cm                               | 27                  |
| Awning 300 cm                               | 28                  |
| Awning 350 cm                               | 33                  |
| Awning 400 cm                               | 38                  |
| Awning 450 cm                               | 41                  |
| Awning 550 cm                               | 58                  |
| Microwave oven                              | 14                  |
| Minisafe                                    | 12                  |
| Central seating group, convertible into bed | 2                   |
| Motorcycle rack                             | 38                  |

| Item designation                                   | Surplus weight (kg) |
|--|---------------------|
| Motorcycle rack in the rear garage                 | 12                  |
| Pioneer multimedia system                          | 3-5                 |
| Navigation system                                  | 1                   |
| Fog light  | 4                   |
| Parking distance control                           | 1                   |
| Radio preparation                                  | 4                   |
| Reversing camera                                   | 4                   |
| Satellite unit (automatic) + LCD television        | 14-25               |
| Satellite unit (semi-automatic) + LCD television   | 10                  |
| Seat, variable height                              | 2                   |
| Solar installation 1 x 100 W                       | 10                  |
| Solar installation 2 x 100 W                       | 20                  |
| Special paint finish                               | -                   |
| Independent vehicle heater                         | 3                   |
| Storage compartment, larger (due to lowered rear)  | 12                  |
| Steadies, electrically operated                    | 20                  |
| Rear steadies                                      | 5                   |
| Bedsread   | 2                   |
| Daytime running light                              | 1                   |
| Telescopic ladder                                  | 10                  |
| Tempomat   | 3                   |
| Carpet in driver's cabin                           | 2                   |
| Carpet in the living area                          | 3                   |
| Switching facility, gas                            | 2                   |
| Winter insulation mat, outside                     | 3                   |
| Auxiliary battery                                  | 27                  |
| Additional cushion                                 | 2                   |
| Auxiliary heat exchanger (heater) for body         | 3                   |
| Two cross beams and slip protection for roof racks | 3                   |

**Engine variants**

The vehicle mass in a ready-to-drive state relates to the base vehicle. If a more powerful engine is fitted, the mass increases in a ready-to-drive state.

| Engine variant | Surplus weight (kg) |
|----------------|---------------------|
| 2.3 Mjet       | 15                  |
| 3.0 Mjet       | 50                  |
| 2.3 Mjet Maxi  | 55                  |
| 3.0 Mjet Maxi  | 90                  |

**Equipment packages**

The equipment packages depend on the model. To calculate the additional weight, add the additional weights of the individual special equipment per package.




## 16.1 View of ground plans

### Explanations


- (1) 230 V fuse
- (2) Transformer/rectifier with 12 V fuses
- (3) Living area battery with main fuse
- (4) Water pump mounted in the tank area
- (5) Drain cock, waste water tank
- (6) Safety/drainage valve
- (7) Boiler/heater
- (8) Water drain cock - yellow
- (9) Water tank
- (10) Additional heater (partially special equipment)
- (11) Water drain cock - white
- \* Access via service flap
- \*\* Beneath the vehicle
- \*\*\* Access via kitchen floor cupboard

Specifications without guarantee




BUE01291

Fig. 311 Ground plan T 569 Nexxo




BUE01115

Fig. 312 Ground plan T 571 Travel Van




BUE01282

Fig. 313 Ground plan IT 585 Ixeo Time




BUE01503

Fig. 314 Ground plan IT 590 Ixeo Time




BUE00963

Fig. 315 Ground plan T 620 Travel Van




BUE01285

Fig. 316 Ground plan IT 650 Ixeo Time




BUE01383

Fig. 317 Ground plan IT 660 Ixeo Time




BUE01292

Fig. 318 Ground plan T 660 Nexxo




BUE01034

Fig. 319 Ground plan IT 664 Ixeo




BUE01286

Fig. 320 Ground plan IT 670 Ixeo Time




BUE01293

Fig. 321 Ground plan T 687 Nexxo




BUE01504

Fig. 322 Ground plan IT 695 Ixeo Time




BUE01384

Fig. 323 Ground plan IT 700 Ixeo




BUE01505

Fig. 324 Ground plan IT 700 Ixeo Plus




BUE01287

Fig. 325 Ground plan IT 710 Ixeo




BUE01385

Fig. 326 Ground plan T 715 Nexxo




BUE01288

Fig. 327 Ground plan T 720 Nexxo




BUE01394

Fig. 328 Ground plan IT 724 Ixeo Plus




BUE01183

Fig. 329 Ground plan IT 726 Ixeo/Ixeo Plus




BUE01294

Fig. 330 Ground plan T 728 Nexxo




BUE01506

Fig. 331 Ground plan T 729 Nexxo




BUE01387

Fig. 332 Ground plan IT 734 Ixeo Time




BUE01388

Fig. 333 Ground plan IT 735 Ixeo




BUE01390

Fig. 334 Ground plan T 740 Nexxo




BUE01391

Fig. 335 Ground plan IT 740 Ixeo



BUE01507

Fig. 336 Ground plan IT 745 Ixeo Time



BUE01392

Fig. 337 Ground plan IT 875 Ixeo Plus

## 16.2 Table of linear measures

| Type                 | Body width, exterior | Total length without ladder <sup>1)</sup> | Wheelbase | Overall height without antenna |
|----------------------|----------------------|---|-----------|--------------------------------|
| T 569                | 2300                 | 5690                                      | 3450      | 2750                           |
| T 571                | 2180                 | 6320                                      | 3450      | 2900                           |
| IT 585               | 2300                 | 5990                                      | 3800      | 2750                           |
| IT 590               | 2300                 | 5990                                      | 3800      | 2750                           |
| T 620                | 2180                 | 6600                                      | 3450      | 2900                           |
| IT 650               | 2300                 | 6540                                      | 3800      | 2750                           |
| T 660                | 2300                 | 6790                                      | 3800      | 2750                           |
| IT 660               | 2300                 | 6700                                      | 3800      | 2750                           |
| IT 664               | 2300                 | 6740                                      | 3800      | 2750                           |
| IT 670               | 2300                 | 6740                                      | 3800      | 2750                           |
| T 687                | 2300                 | 6890                                      | 3800      | 2750                           |
| IT 695               | 2300                 | 7040                                      | 4035      | 2750                           |
| IT 700               | 2300                 | 7040                                      | 4035      | 2750                           |
| IT 700 <sup>2)</sup> | 2300                 | 7040                                      | 4035      | 2850                           |
| IT 710               | 2300                 | 7140                                      | 4035      | 2750                           |
| T 715                | 2300                 | 7140                                      | 4035      | 2750                           |
| T 720                | 2300                 | 7440                                      | 4035      | 2750                           |
| IT 724               | 2300                 | 7610                                      | 4600      | 2850                           |
| IT 726               | 2300                 | 7400                                      | 4035      | 2750                           |
| IT 726 <sup>2)</sup> | 2300                 | 7410                                      | 4035      | 2850                           |
| T 728                | 2300                 | 7440                                      | 4035      | 2750                           |
| T 729                | 2300                 | 7390                                      | 4035      | 2750                           |
| IT 734               | 2300                 | 7390                                      | 4035      | 2750                           |
| IT 735               | 2300                 | 7390                                      | 4035      | 2750                           |
| T 740                | 2300                 | 7390                                      | 4035      | 2750                           |

| Type   | Body width, exterior | Total length without ladder <sup>1)</sup> | Wheelbase | Overall height without antenna |
|--------|----------------------|---|-----------|--------------------------------|
| IT 740 | 2300                 | 7390                                      | 4035      | 2750                           |
| IT 745 | 2300                 | 7390                                      | 4035      | 2750                           |
| IT 875 | 2300                 | 8760                                      | 4600      | 2850                           |

1) With ladder: + 70 mm

2) Ixeo Plus

### 16.3 Power supply

|   |  |                               |
|---|--|-------------------------------|
| Mains connection  | Protection class I   | 230 V (± 10 %),<br>47 - 63 Hz |
| Mains power rating                                      |  | 400 VA                        |
| Appropriate batteries                                   | 6-cell lead acid and lead acid gel batteries from 55 Ah                |                               |
| Charging characteristics                                | IUoU   |                               |
| Final charge voltage                                    |  | 14.3 V                        |
| Charging current  | 18 A throughout entire supply voltage range, electronically restricted | 18 A                          |
| Trickle charge voltage                                  | Automatic switching  | 13.8 V                        |
| Repeated charging cycle (switchover to "Main charging") | At < approx. 13.8 V battery voltage (with approx. 5 seconds delay)     |                               |
| Reflux (without mains and with connected battery)       | After approx. 3 minutes "Mains Off"                                    | < 0.3 mA                      |
| Guard circuits  | Short-circuit protection provided by built-in car fuse (FKS)           |                               |
|   | Safety fuse, 3.15 AT at power input                                    |                               |
|   | Overtemperature protection   |                               |
| Charging current distribution at mains connection       | Starter battery float charge with max. 2 A                             | Max. 2 A                      |
|   | Living area battery charge with max. 18 A                              | Max. 18 A                     |

|  |  |                |
|--|--|----------------|
| Charging current distribution during the journey | Simultaneous charging of starter and living area batteries by means of the alternator              | 50 A           |
|  | Parallel battery switching via disconnecter relay  |                |
|  | Maximum permitted alternator charging current to the living area battery: 50 A (see block diagram) |                |
| Battery monitor                                  | Disconnection  | 10.5 V ± 0.1 V |
| Battery monitor                                  | Minimum voltage for connection   | 11.0 V ± 0.1 V |

## Chapter overview

This chapter contains helpful tips for the journey.

The instructions address the following topics:

- road assistance in European countries
- traffic rules in European countries
- gas supply in European countries
- toll regulations in European countries
- safe ways to spend the night during travel
- camping in winter

At the end of the chapter there is a checklist containing the most important equipment for the journey.

### 17.1 Traffic rules in foreign countries



- ▷ The vehicle driver is required to inform himself as to the traffic rules of the countries in which he plans to travel before beginning the trip. Contact your automobile club or embassy for further information.
- ▷ In some European countries, warning vests must be worn when exiting the vehicle outside of towns in the case of vehicle failures or accidents.
- ▷ Depending on the country, different rules and regulations apply (e.g. different warning signs for rear carriers, obligation to carry breathalyzer kits, spare bulbs, high-visibility vests, size of reserve canister). The driver of the vehicle must familiarise him or herself with these rules before every journey.
- ▷ Up-to-date information can generally be found on the web pages of the national automobile associations.

Information about traffic regulations is especially important as state law applies in case of damage. For your own safety, always observe the following rules when travelling abroad:

- Carry your insurance certificate with you.
- Always register accidents with the police.
- Never sign documents that you have not read and understood completely.

### 17.2 Help on Europe's roads

| Country  | + Emergency services<br>★ Police                   | ☎ Breakdown service                  |
|----------|--|--------------------------------------|
| Belgium  | + 112<br>★ 112                                     | ☎ TCB Brussels 0 70 34 47 77         |
| Bulgaria | + 112/150<br>★ 112/166                             | ☎ UAB (02) 9 11 46/146 <sup>1)</sup> |
| Denmark  | + 112<br>free of charge<br>★ 112<br>free of charge | ☎ FDM 45 27 07 07                    |
| Germany  | + 112<br>★ 110                                     | ☎ ADAC 22 22 22 <sup>1)</sup>        |

| Country       | + Emergen-<br>cy services<br>★ Police              | ☎ Breakdown service  |
|---------------|--|--|
| Estonia       | + 112<br>★ 110/112                                 | ☎ EESTI (0) 6 97 91 88/18 88 <sup>1)</sup>                 |
| Finland       | + 112<br>★ 112                                     | ☎ Helsinki (09) 77 47 64 00                                |
| France        | + 15/112<br>★ 17                                   | ☎ Lyon (08) 25 80 08 22                                    |
| Greece        | + 112/166<br>★ 100/112                             | ☎ ELPA 104 00  |
| Great Britain | + 112<br>★ 112                                     | ☎ AA (08 00) 0 28 90 18                                    |
| Ireland       | + 112<br>★ 112                                     | ☎ AA Dublin 18 00 66 77 88                                 |
| Iceland       | + 112<br>★ 112                                     | ☎ F.I.B 5 11 21 12   |
| Italy         | + 118/112 <sup>1)</sup><br>★ 112                   | ☎ ACI 8 00 11 68 00  |
| Croatia       | + 112<br>★ 112                                     | ☎ HAK 9 87/ 0 19 87 <sup>1)</sup>                          |
| Latvia        | + 03/112 <sup>1)</sup><br>★ 02/112 <sup>1)</sup>   | ☎ LAMB 18 88   |
| Lithuania     | + 03/112 <sup>1)</sup><br>★ 02/112 <sup>1)</sup>   | ☎ LAS 8 80 00 00 00/18 88 <sup>1)</sup>                    |
| Luxembourg    | + 112<br>★ 113/112 <sup>1)</sup>                   | ☎ ACL 2 60 00  |
| Macedonia     | + 194<br>★ 192                                     | ☎ AMSM +389 2 31 81 196                                    |
| Montenegro    | + 94<br>★ 92                                       | ☎ AMSCG 19807  |
| Netherlands   | + 112<br>★ 112                                     | ☎ ANWB (088) 2 69 28 88                                    |
| Norway        | + 113<br>★ 112                                     | ☎ NAF 0 85 05  |
| Austria       | + 144/112 <sup>1)</sup><br>★ 133/112 <sup>1)</sup> | ☎ ÖAMTC 120  |
| Poland        | + 999/112 <sup>1)</sup><br>★ 997/112 <sup>1)</sup> | ☎ PZM 022 5 32 84 33                                       |
| Portugal      | + 112<br>★ 112                                     | ☎ ACP Lissab. (21) 9 42 91 03<br>ACP Porto (22) 8 34 00 01 |
| Romania       | + 961/112 <sup>1)</sup><br>★ 955/112 <sup>1)</sup> | ☎ ACR (021) 2 22 22 22                                     |

| Country        | + Emergency services<br>★ Police                   | ☎ Breakdown service                                  |
|----------------|--|--|
| Russia         | + 03<br>★ 02                                       | ☎ RAS 8- (4 95) 7 47 66 66                           |
| Sweden         | + 112<br>★ 112                                     | ☎ (08) 6 90 38 00                                    |
| Switzerland    | + 144<br>★ 117/112 <sup>1)</sup>                   | ☎ TCS 1 40/03 18 50 53 11 <sup>1)</sup>              |
| Serbia         | + 94<br>★ 92                                       | ☎ AMSS 987   |
| Slovakia       | + 112<br>★ 112                                     | ☎ SATC 1 81 24                                       |
| Slovenia       | + 112<br>★ 113                                     | ☎ AMZS (1) 9 87/<br>00386 1 5 30 53 53 <sup>1)</sup> |
| Spain          | + 061/112 <sup>1)</sup><br>★ 112                   | ☎ RACE 9 15 93 33 33                                 |
| Czech Republic | + 112<br>★ 112                                     | ☎ UAMK CR 12 30                                      |
| Turkey         | + 112<br>★ 155/112 <sup>1)</sup>                   | ☎ TTOK (02 12) 2 82 81 40                            |
| Ukraine        | + 03<br>★ 02                                       | ☎ 112 UA (8-032) 2 97 65 50                          |
| Hungary        | + 104/112 <sup>1)</sup><br>★ 107/112 <sup>1)</sup> | ☎ MAK<br>1 88/(06) 13 45 17 44 <sup>1)</sup>         |
| Cyprus         | + 112<br>★ 112                                     | ☎ AA (022) 31 31 31                                  |

<sup>1)</sup> In the mobile communication network

Date 07/2012

Specifications without guarantee

### 17.3 Traffic rules for motorhomes

For your information, the speed limits (in km/h), alcohol limits and daylight running light requirements in the most-visited countries are the following:

| Country                   | Speed limit in km/h            |                                 |                          |                          |                          | Alcohol limit | Day-time running lights compulsory |
|---------------------------|--------------------------------|---------------------------------|--------------------------|--------------------------|--------------------------|---------------|------------------------------------|
|                           | In built-up areas              | Out of town                     |                          | Motorway                 |                          |               |                                    |
|                           | Up to/over 3.5 t <sup>1)</sup> | Up to 3.5 t                     | Over 3.5 t <sup>1)</sup> | Up to 3.5 t              | Over 3.5 t <sup>1)</sup> |               |                                    |
| <b>Belgium</b>            | 50                             | 90                              | 90                       | 120                      | 90                       | 0.5           | No                                 |
| <b>Bosnia-Herzegovina</b> | 50                             | 80                              | 80                       | 130                      | 130                      | 0.3           | Yes                                |
| <b>Bulgaria</b>           | 50                             | 90                              | 70                       | 130                      | 130                      | 0.5           | Nov. to March                      |
| <b>Denmark</b>            | 50                             | 80                              | 70                       | 130                      | 80                       | 0.5           | Yes                                |
| <b>Germany</b>            | 50                             | 100                             | 80                       | 130 <sup>2)</sup>        | 100                      | 0.5           | No                                 |
| <b>Estonia</b>            | 50                             | 90                              | 70                       | 110                      | 90                       | 0.2           | Yes                                |
| <b>Finland</b>            | 50                             | 80/<br>100 <sup>3)</sup>        | 80/<br>100 <sup>3)</sup> | 80/<br>100 <sup>3)</sup> | 80/<br>100 <sup>3)</sup> | 0.5           | Yes                                |
| <b>France</b>             | 50                             | 90 <sup>4)</sup>                | 80                       | 130 <sup>4)</sup>        | 110                      | 0.5           | In wet conditions                  |
| <b>Greece</b>             | 50                             | 90-<br>110 <sup>5)</sup>        | 90-<br>110 <sup>5)</sup> | 130                      | 130                      | 0.5           | No                                 |
| <b>Great Britain</b>      | 48                             | 96-<br>112 <sup>5)</sup>        | 96-<br>112 <sup>5)</sup> | 112                      | 112                      | 0.8           | No                                 |
| <b>Ireland</b>            | 50                             | 80-<br>100 <sup>5)</sup>        | 80-<br>100 <sup>5)</sup> | 120                      | 80                       | 0.5           | No                                 |
| <b>Italy</b>              | 50                             | 90-<br>110 <sup>5)</sup><br>6)  | 80                       | 130 <sup>6)</sup>        | 100 <sup>7)</sup>        | 0.5           | Yes                                |
| <b>Croatia</b>            | 50                             | 90-<br>110 <sup>8)</sup>        | 90-<br>110 <sup>8)</sup> | 130                      | 130                      | 0.5           | Yes <sup>9)</sup>                  |
| <b>Latvia</b>             | 50                             | 90-<br>100 <sup>5)</sup>        | 90-<br>100 <sup>5)</sup> | 110 <sup>8)</sup>        | 110 <sup>8)</sup>        | 0.5           | Yes                                |
| <b>Lithuania</b>          | 50                             | 90-<br>110 <sup>5)</sup><br>10) | 80 <sup>10)</sup>        | 110                      | 90                       | 0.4           | Yes                                |
| <b>Luxembourg</b>         | 50                             | 90                              | 75                       | 130 <sup>11)</sup>       | 90                       | 0.5           | No                                 |
| <b>Macedonia</b>          | 40-<br>60 <sup>5)</sup>        | 80                              | 80                       | 80                       | 80                       | 0.5           | Yes                                |
| <b>Montenegro</b>         | 50                             | 80                              | 80                       | 100 <sup>8)</sup>        | 100 <sup>8)</sup>        | 0.5           | Yes                                |
| <b>Netherlands</b>        | 50                             | 80-<br>100 <sup>8)</sup>        | 80                       | 120                      | 80                       | 0.5           | No                                 |
| <b>Norway</b>             | 50                             | 80-<br>100 <sup>8)</sup>        | 80                       | 90-<br>100 <sup>5)</sup> | 80                       | 0.2           | Yes                                |

| Country               | Speed limit in km/h            |                      |                          |                    |                          | Alcohol limit | Day-time running lights compulsory |
|-----------------------|--------------------------------|----------------------|--------------------------|--------------------|--------------------------|---------------|------------------------------------|
|                       | In built-up areas              | Out of town          |                          | Motorway           |                          |               |                                    |
|                       | Up to/over 3.5 t <sup>1)</sup> | Up to 3.5 t          | Over 3.5 t <sup>1)</sup> | Up to 3.5 t        | Over 3.5 t <sup>1)</sup> |               |                                    |
| <b>Austria</b>        | 50                             | 100                  | 70                       | 130                | 80                       | 0.5           | No                                 |
| <b>Poland</b>         | 50 <sup>12)</sup>              | 90-100 <sup>8)</sup> | 70-80 <sup>8)</sup>      | 140                | 80                       | 0.2           | Yes                                |
| <b>Portugal</b>       | 50                             | 90-100 <sup>5)</sup> | 80-90 <sup>5)</sup>      | 120                | 110                      | 0.5           | No                                 |
| <b>Romania</b>        | 50                             | 80-90 <sup>8)</sup>  | 80-90 <sup>8)</sup>      | 120                | 110                      | 0.0           | Yes                                |
| <b>Sweden</b>         | _ 5)                           | _ 5)                 | _ 5)                     | _ 5)               | _ 5)                     | 0.2           | Yes                                |
| <b>Switzerland</b>    | 50                             | 80-100 <sup>8)</sup> | 80-100 <sup>8)</sup>     | 120                | 100                      | 0.5           | No                                 |
| <b>Serbia</b>         | 50                             | 80                   | 80                       | 80                 | 80                       | 0.3           | Yes                                |
| <b>Slovakia</b>       | 50                             | 90                   | 80                       | 130                | 90                       | 0.0           | Yes                                |
| <b>Slovenia</b>       | 50                             | 90-100 <sup>8)</sup> | 80                       | 130                | 80                       | 0.5           | Yes                                |
| <b>Spain</b>          | 50                             | 80-90 <sup>8)</sup>  | 80-90 <sup>8)</sup>      | 100 <sup>13)</sup> | 100 <sup>13)</sup>       | 0.5           | No                                 |
| <b>Czech Republic</b> | 50                             | 90-130 <sup>8)</sup> | 80                       | 130                | 80                       | 0.0           | Yes                                |
| <b>Hungary</b>        | 50                             | 90-110 <sup>8)</sup> | 70                       | 130                | 80                       | 0.0           | Out of town                        |

- 1) Motorhomes up to 7.5 t laden weight
- 2) Recommended speed
- 3) Vehicles registered after 01.01.1995 and unladen weight up to 1875 kg or after 01.01.1981 and unladen weight up to 1800 kg
- 4) In wet conditions in non-urban areas 80, on motorways 110 km/h
- 5) As signposted
- 6) When raining or snowing on dual carriageways 90 km/h, on motorways 110 km/h
- 7) On motorways with green signs
- 8) On expressways
- 9) From the last Sunday in October to the last Sunday in March
- 10) On non-asphalt roads 70 km/h
- 11) In wet conditions 110 km/h
- 12) Between 11 p.m. and 5 a.m. 60 km/h
- 13) On roads resembling motorways. In some countries, special rules apply for newly qualified drivers.

Date 2012  
 Source: ADAC  
 Specifications without guarantee

## 17.4 Sleeping in the vehicle away from camping areas

| Country              | Sleeping on roads and fields |    | Sleeping on privately owned lands |    | Comments   |
|----------------------|------------------------------|----|-----------------------------------|----|--|
|                      | Yes                          | No | Yes                               | No |  |
| <b>Belgium</b>       |                              | X  | X                                 |    | On highway rest areas max. 24 hours permitted  |
| <b>Bulgaria</b>      |                              | X  |                                   | X  |  |
| <b>Denmark</b>       |                              | X  | X                                 |    |  |
| <b>Germany</b>       | X                            |    | X                                 |    | Staying overnight for one night to restore driving ability is permitted. There may be regional and local limitations   |
| <b>Finland</b>       |                              | X  |                                   | X  | Possible with the permission of the land owner   |
| <b>France</b>        | (X)                          |    | X                                 |    | Permission from the local authorities or the owner of the land is required. Parking and staying overnight on free areas is prohibited                                      |
| <b>Greece</b>        |                              | X  |                                   | X  | One-off overnight stays in designated areas are permitted  |
| <b>Great Britain</b> |                              | X  | X                                 |    | Regulated by local rules   |
| <b>Ireland</b>       |                              | X  | X                                 |    | Regulated by local rules   |
| <b>Italy</b>         | X                            |    | X                                 |    | Staying overnight for one night at car parks and service stations is allowed. Observe the local regulations. Parking and staying overnight on free areas is prohibited     |
| <b>Croatia</b>       |                              | X  |                                   | X  |  |
| <b>Luxembourg</b>    |                              | X  |                                   | X  |  |
| <b>Macedonia</b>     |                              | X  |                                   | X  |  |
| <b>Netherlands</b>   |                              | X  |                                   | X  | Overnight stays on streets and squares is allowed in some boroughs   |
| <b>Norway</b>        | X                            |    | X                                 |    | Officially prohibited on rest areas and cultivated grounds. Driving on dirt tracks prohibited; observe local regulations   |
| <b>Austria</b>       |                              | X  |                                   | X  | Staying overnight for one night to restore driving ability is permitted, but not in nature reserves. Observe regional and local restrictions. Generally forbidden in Tyrol |
| <b>Poland</b>        |                              | X  | X                                 |    | Requires property owner's permission   |

| Country               | Sleeping on roads and fields |    | Sleeping on privately owned lands |    | Comments  |
|-----------------------|------------------------------|----|-----------------------------------|----|---|
|                       | Yes                          | No | Yes                               | No |   |
| Portugal              |                              | X  |                                   | X  | Staying overnight for one night on motorway service stations and car parks under 10 hours are tolerated               |
| Romania               |                              | X  |                                   | X  |   |
| Russia                |                              | X  |                                   | X  |   |
| Sweden                | X                            |    | X                                 |    | Not on agriculture areas or in the vicinity of houses. Driving on rough terrain prohibited; observe local regulations |
| Switzerland           |                              | X  | X                                 |    | One overnight stay at highway rest areas and in some cantons is tolerated   |
| Serbia and Montenegro |                              | X  |                                   | X  |   |
| Slovakia              |                              | X  | X                                 |    | Overnight stays on private land are only allowed if a toilet is present   |
| Slovenia              |                              | X  |                                   | X  |   |
| Spain                 | X                            |    | X                                 |    | Some regional prohibitions apply, especially on beaches   |
| Czech Republic        |                              | X  | X                                 |    | Overnight stays on private land are only allowed if a toilet is present   |
| Turkey                | X                            |    | X                                 |    |   |
| Ukraine               | X                            |    | X                                 |    |   |
| Hungary               |                              | X  | X                                 |    | Staying overnight on privately owned land is permitted only with police certification                                 |

Specifications without guarantee

## 17.5 Gas supply in European countries



- ▷ In Europe, there are several different connection systems for gas bottles. It is not always possible to fill or exchange your gas bottles in a foreign country. Get information about the connection system in the country you are travelling to before embarking on your journey, e.g. at a motoring club or in the trade press.

### General tips

Always observe the following instructions:

- Only go on vacation with completely filled gas bottles.
- Use all of the gas bottles' capacity.
- Take along adapter sets (available in camping supply stores) for filling gas bottles in foreign countries and for connecting the gas pressure regulator to foreign gas bottles.

- During the cold time of the year observe filling with propane gas component (butane does not gas below 0 °C).
- Use blue bottles from the firm Campingaz (distributed world-wide). Only use gas bottles with safety valves.
- When bottles from other countries are used, check the gas bottle compartments to see if the gas bottles fit into them. Gas bottles from other countries do not always display the same size as your own gas bottles.

## 17.6 Toll regulations in European countries

Many European countries have introduced a mandatory toll system. The toll regulations and how they are collected vary greatly from country to country. Nevertheless, ignorance is no excuse. Penalties can be quite severe.

As is the case with traffic regulations, the vehicle driver is required to be familiar with the toll formalities before starting out on a trip. For example, in Austria the vignette does not meet the toll requirements for vehicles that weigh more than 3.5 t. There, a so-called "Go-Box" must be obtained and charged.

Contact your automobile club or the Internet for further information.



- ▷ Windscreens with solar filters can affect the functioning of automatic toll collection systems (e.g. Go-Box). This must be taken into account when acquiring the appropriate device (e.g. Split-Go-Box).

## 17.7 Tips on staying overnight safely during travel

Prudent behaviour is the most important protective measure for insuring a safe night in the motorhome.

The risk of thievery is reduced to a minimum when the following basic rules are observed:

- Before commencing the journey, close and lock all windows, doors and skylights.
- During high season do not spend the night at highway rest stops or parking areas located along typical vacation routes.
- Several vehicles on one site at the same time do not necessarily decrease the chances of thievery occurring. Consult your own feelings about the parking site.
- Even if it is just for one night, go to a camping site.
- When parking on open space keep emergency routes clear. The way to the driver's seat should be clear. The ignition key should always be within reach.
- Only take with you those valuables which are absolutely necessary for the journey. If possible, store valuables in a small safe and not in the immediate vicinity of windows or doors.
- Always lock up the vehicle.

## 17.8 Tips for winter campers

The following tips will help make your winter camping experience as agreeable as possible.

- Reserve your parking place in good time. Good winter camping sites are often booked up early.
- Do not start your trip without winter tyres.
- Bring snow chains.

- Choose your parking place with care. Observe the ground beneath you. Snow and ice may melt.
- When the vehicle has been positioned, release the handbrake to prevent freezing.
- No snow walls should be allowed to cover the built-in forced ventilation.
- Keep the built-in forced ventilation free from snow and ice.
- Make sure the air circulation is good. Good air circulation prevents moisture from collecting and makes it easier to heat the living area.
- Cover the single-paned driver's cabin window with insulation mats to avoid thermal bridges.
- Follow the instructions in the section "Gas supply in European countries".
- Use a two-bottle system with automatic controller for the gas system, so that the supply does not run out during the night.
- Only operate the gas system using propane gas.
- Do not use the space behind the heater as a storage compartment.
- Never operate catalytic ovens or infra-red gas radiators in the interior of the vehicle, since they consume oxygen for burning.
- Lay the 230 V power cable in such a way that the cable cannot be frozen or be damaged (e.g. during snow removal).
- When it is snowing heavily, clear the roof of the vehicle of snow regularly. A few centimetres of powdery snow serves as insulation, but wet snow quickly becomes a heavy burden.
- Before embarking on the return journey, remove all the snow from the roof to avoid impeding vehicles behind you with a "snow flag".

### 17.9 Travel checklists

The following checklists will help that nothing important is left at home although not everything on the checklists might be necessary.



- ▷ Do not leave checking of documents (e.g. vehicle papers and information) as well as checking the condition of the vehicle until just before commencing the trip. Planning and checking documents well in advance will save unnecessary trouble.

#### Kitchen area

| ✓ | Object                  | ✓ | Object                               | ✓ | Object                   |
|---|-------------------------|---|--------------------------------------|---|--------------------------|
|   | Wiping cloth            |   | Cleansing agent (detergent)          |   | Salad servers            |
|   | Mug                     |   | Dishcloths                           |   | Chopping board           |
|   | Turnspit                |   | Set of knives and forks for grilling |   | Bowls                    |
|   | Can opener              |   | Coffeepot                            |   | Brush to wash the dishes |
|   | Egg-cup                 |   | Corkscrew                            |   | Cloth to wash the dishes |
|   | Ice cube tray           |   | Kitchen paper                        |   | Matches                  |
|   | Lighter                 |   | Spoons                               |   | Cups                     |
|   | Bottle opener           |   | Knives                               |   | Plates                   |
|   | Air-tight storage boxes |   | Garbage bags                         |   | Thermos jug              |
|   | Breakfast plate         |   | Frying pans                          |   | Pots                     |
|   | Forks                   |   | Stirring spoons                      |   | Glasses                  |

**Bathroom/sanitary items**

| ✓ | Object         | ✓ | Object       | ✓ | Object           |
|---|----------------|---|--------------|---|------------------|
|   | Towels         |   | Toilet brush |   | Toothbrush glass |
|   | Sanitary items |   | Toilet paper |   |                  |

**Living area**

|  |                   |  |                        |  |                             |
|--|-------------------|--|------------------------|--|-----------------------------|
|  | Dustbin           |  | Insect lamp            |  | Rain clothes                |
|  | Road atlas        |  | Insect repellent       |  | First aid kit               |
|  | Bath towels       |  | Deck of cards          |  | Travel guides/parking guide |
|  | Bath shoes        |  | Broom                  |  | Rucksack                    |
|  | Batteries         |  | Candles                |  | Sleeping bags               |
|  | Bed sheets        |  | Dust pan               |  | Pencils and paper           |
|  | Bed linen         |  | Coat-hangers           |  | Shoes                       |
|  | Laundry bag       |  | Clothes brush          |  | Shoe polish                 |
|  | Books             |  | Pillow                 |  | Vacuum cleaner              |
|  | Camping guide     |  | Map                    |  | Flash light                 |
|  | Spare bulbs       |  | Medicine               |  | Pocket knife                |
|  | Water bottle      |  | Music cassettes        |  | Table cloth                 |
|  | Binoculars        |  | Neck-supporting pillow |  | Clothes pins                |
|  | Fire extinguisher |  | Sewing kit             |  | Clothesline                 |
|  | Gas bottle        |  | Radio                  |  |                             |

**Vehicle/tools**

|  |                        |  |                                 |  |                               |
|--|------------------------|--|---------------------------------|--|-------------------------------|
|  | Waste water container  |  | Fabric tape                     |  | Screwdriver                   |
|  | Adapter socket         |  | Watering can for drinking water |  | Current-measuring instrument  |
|  | CEE adapter            |  | Cable reel                      |  | Step                          |
|  | Wire                   |  | V-belt                          |  | Wheel chocks                  |
|  | Spare wheel            |  | Glue                            |  | First-aid kit                 |
|  | Spare lamps            |  | Universal pliers                |  | Vehicle jack                  |
|  | Spare fuses            |  | Compressor                      |  | Hazard warning triangle       |
|  | Replacement water pump |  | Luster terminals                |  | Warning sign                  |
|  | Hammer                 |  | Loops                           |  | Warning vest(s)               |
|  | Flat wrench            |  | Tube adapter                    |  | Flashing hazard warning light |
|  | Gas filling adapter    |  | Hose clips                      |  |                               |
|  | Gas tube               |  | Snow chains (winter)            |  |                               |

**Outside**

|  |                |  |               |  |                            |
|--|----------------|--|---------------|--|----------------------------|
|  | Stay rope      |  | Camping table |  | Lock                       |
|  | Bellows        |  | Luggage racks |  | String                     |
|  | Camping chairs |  | Grill         |  | Tent pegs/tightening ropes |

**Documents**

| ✓ | Object                             | ✓ | Object                  | ✓ | Object             |
|---|------------------------------------|---|-------------------------|---|--------------------|
|   | List of addresses                  |   | Registration book       |   | Identity card      |
|   | Registration confirmation(s)       |   | Driving licence         |   | Passport           |
|   | Allergy certificate                |   | Green insurance card    |   | Writ of protection |
|   | Instruction manuals                |   | Vaccination certificate |   | Vignette/toll card |
|   | Instruction leaflets for medicines |   | Credit card             |   | Visa               |



| Pos. | Component  | Activity   | Interval        |
|------|--|--|-----------------|
| 1    | Auxiliary support  | Lubrication  | Annually        |
| 2    | Joints, hinges   | Lubrication  | Annually        |
| 3    | Refrigerator, heater, boiler, cooker, lighting, flap and door closures, toilet, seat belts | Function check   | Annually        |
| 4    | Windows, skylights   | Function check, water ingress test                     | Annually        |
| 5    | Upholstery, curtains, blinds   | Visual check   | Annually        |
| 6    | Sealing strips, edges, rubber  | Check for damage                                       | Annually        |
| 7    | Water supply   | Water ingress test                                     | Annually        |
| 8    | Hot-air system   | Function check, clean fan wheel as necessary           | Annually        |
| 9    | Underbody protection, floor skirt attachment   | Visual check   | Annually        |
| 10   | Pull-down bed suspension   | Function check   | Annually        |
| 11   | Electrical system  | Function check   | Annually        |
| 12   | Gas system   | Official gas inspection                                | Every two years |
| 13   | Connections between the chassis and body   | Check  | Every two years |
| 14   | Underbody  | Visual check, repair underbody protection as necessary | Every two years |



|                              |           |
|------------------------------|-----------|
| Delivery _____               | Pos. 1-11 |
| Stamp of the Bürstner dealer |           |
| Date                         | Signature |

|                              |           |
|------------------------------|-----------|
| 1st year _____               | Pos. 1-11 |
| Stamp of the Bürstner dealer |           |
| Date                         | Signature |

|                              |           |
|------------------------------|-----------|
| 2nd year _____               | Pos. 1-14 |
| Stamp of the Bürstner dealer |           |
| Date                         | Signature |

|                              |           |
|------------------------------|-----------|
| 3rd year _____               | Pos. 1-11 |
| Stamp of the Bürstner dealer |           |
| Date                         | Signature |

|                              |           |
|------------------------------|-----------|
| 4th year _____               | Pos. 1-14 |
| Stamp of the Bürstner dealer |           |
| Date                         | Signature |

|                              |           |
|------------------------------|-----------|
| 5th year _____               | Pos. 1-11 |
| Stamp of the Bürstner dealer |           |
| Date                         | Signature |

|                              |           |
|------------------------------|-----------|
| 6th year _____               | Pos. 1-14 |
| Stamp of the Bürstner dealer |           |
| Date                         | Signature |

|                              |           |
|------------------------------|-----------|
| 7th year _____               | Pos. 1-11 |
| Stamp of the Bürstner dealer |           |
| Date                         | Signature |

|                              |           |
|------------------------------|-----------|
| 8th year _____               | Pos. 1-14 |
| Stamp of the Bürstner dealer |           |
| Date                         | Signature |



|                                 |          |   |                    |
|---------------------------------|----------|---|--------------------|
| Summer operation                | 172, 175 | PVC-floor covering                      | 214                |
| Switching off                   | 173, 175 | Roman shade                             | 214                |
| Switching on                    | 172, 175 | Seat belt                               | 214                |
| Troubleshooting                 | 246, 247 | Sink                                    | 214                |
| Water, filling with             | 173, 175 | Synthetic parts, interior               | 213                |
| Winter operation                | 172, 175 | Temporary lay-up                        | 218                |
| Brakes                          | 42       | Underbody                               | 212                |
| Check                           | 43, 243  | Upholstery                              | 213                |
| Braking system, troubleshooting | 243      | Washing                                 | 212                |
| Breakdown services in Europe    | 271      | Waste water tank                        | 213                |
| Bulbs, changing                 | 227      | Water system                            | 214                |
| Exterior lighting               | 227      | Windows                                 | 212                |
| Garage light                    | 232      | Winter lay-up                           | 219                |
| Halogen spotlight               | 231, 232 | Carpet, cleaning                        | 214                |
| Interior lighting               | 229      | Central bench,                          |                    |
| Rear lights                     | 228      | sleeping conversion                     | 102, 103, 104, 105 |
| Recessed halogen light          | 230, 231 | Central locking system                  | 59                 |
| Side lights                     | 228      | Locking                                 | 59                 |
| Types of external bulbs         | 229      | Remote control                          | 59                 |
| Bunk bed                        | 92       | Unlocking                               | 59                 |
| Butane gas                      | 13, 116  | Central seating group,                  |                    |
|                                 |          | sleeping conversion                     | 100, 101           |
|                                 |          | Changing wheels                         | 237                |
|                                 |          | Tightening torque                       | 238                |
|                                 |          | Charging condition, displaying          |                    |
|                                 |          | Living area battery                     | 131                |
|                                 |          | Starter battery                         | 131                |
|                                 |          | Charging current                        | 137                |
|                                 |          | Chassis number                          | 234                |
|                                 |          | Checklist                               | 35, 218            |
|                                 |          | Before the journey                      | 35                 |
|                                 |          | For the journey                         | 279                |
|                                 |          | Initial start-up after temporary lay-up | 220                |
|                                 |          | Road safety                             | 35                 |
|                                 |          | Temporary lay-up                        | 218                |
|                                 |          | Winter lay-up                           | 219                |
|                                 |          | Child restraint systems                 | 43                 |
|                                 |          | Children's beds                         | 93, 95             |
|                                 |          | Circuit diagram                         |                    |
|                                 |          | Exterior                                | 153                |
|                                 |          | Interior                                | 150                |
|                                 |          | Circulating pump,                       |                    |
|                                 |          | setting the rotational speed            | 163                |
|                                 |          | Circulation fan                         | 156                |
|                                 |          | Cleaning                                |                    |
|                                 |          | Water pipes                             | 214                |
|                                 |          | Water tank                              | 214                |
|                                 |          | Cleaning see care                       | 211                |
|                                 |          | Closed circuit current                  | 124                |

## C

|  |         |
|--|---------|
| Cable reel                             | 143     |
| Camping gas bottles, use               | 14, 116 |
| Camping in winter                      | 278     |
| Cap for the drinking water filler neck | 64      |
| Capacity of the battery                | 124     |
| Caravan coupling                       | 31      |
| Care                                   | 211     |
| Air conditioning unit (Telair)         | 216     |
| Blind                                  | 214     |
| Carpet                                 | 214     |
| Curtains                               | 214     |
| Entrance step                          | 213     |
| External care                          | 211     |
| Extractor hood                         | 216     |
| Fuel cell                              | 214     |
| Furniture surfaces                     | 213     |
| Gas cooker                             | 214     |
| High-pressure cleaner, washing with    | 211     |
| Hot-water heater                       | 225     |
| In the winter                          | 217     |
| Insect screen                          | 214     |
| Interior care                          | 213     |
| Lamps                                  | 213     |
| Leather covers                         | 214     |
| Net curtains                           | 214     |

|   |          |  |          |
|---|----------|--|----------|
| Condensation .....                                | 71       | Maintenance work .....                       | 224      |
| On the double acrylic glass pane .....            | 72       | Troubleshooting .....                        | 255      |
| On the screwed connections                        |          | Drain cock, waste water tank .....           | 194      |
| in the floor .....                                | 71       | Position .....                               | 261      |
| Condensation water see condensation .....         | 72       | Drain cocks, position .....                  | 177, 261 |
| Connecting cable see 230 V power supply ...       | 143      | Drinking water filler neck .....             | 192      |
| Connection diagram, panel (IT 96) .....           | 151      | Closing .....                                | 192      |
| Conventional load .....                           | 19       | Opening .....                                | 192      |
| Conversion door .....                             | 59, 61   | Driver's seat .....                          | 44       |
| Roman shade, closing .....                        | 62       | Driving speed .....                          | 42       |
| Roman shade, opening .....                        | 62       | Driving the motorhome .....                  | 39       |
| Conversion door, inside                           |          | During the journey .....                     | 39       |
| Locking .....                                     | 60, 61   |  |          |
| Opening .....                                     | 60, 61   | <b>E</b>                                     |          |
| Conversion door, outside                          |          | Electrical steady legs                       |          |
| Locking .....                                     | 60, 61   | Remote control .....                         | 52       |
| Opening .....                                     | 60, 61   | Warning tone .....                           | 52       |
| Conversion to bed foundation (lift-off table) ... | 90       | Electrical system .....                      | 123      |
| Conversion to bed foundation                      |          | 230 V connection, troubleshooting .....      | 243      |
| (suspension table) .....                          | 89       | Entrance step, troubleshooting .....         | 243      |
| Converting seating group into bed .....           | 97       | Explanation of terms .....                   | 123      |
| Cooker .....                                      | 177      | Lighting, troubleshooting .....              | 243      |
| Troubleshooting .....                             | 250      | Safety instructions .....                    | 14       |
| Curtains, cleaning .....                          | 214      | Troubleshooting .....                        | 243      |
|   |          | Entrance step .....                          | 49       |
|   |          | Care .....                                   | 213      |
| <b>D</b>  |          | Electrically operated .....                  | 32       |
| Danger of suffocation .....                       | 10, 71   | Extending .....                              | 33       |
| Digital clock                                     |          | Indicator lamp .....                         | 32, 33   |
| Setting .....                                     | 136      | Retracting .....                             | 33       |
| Switching off .....                               | 136      | Troubleshooting .....                        | 243      |
| Switching on .....                                | 136      | Environmental tips .....                     | 8        |
| Dimensions see table of linear measures ...       | 268      | Exterior lighting                            |          |
| Dimensions, permissible .....                     | 273      | Bulbs, changing .....                        | 227      |
| Direction indicator .....                         | 228      | Checking .....                               | 35       |
| Discharging current .....                         | 137      | Troubleshooting .....                        | 243      |
| Displays  |          | External care .....                          | 211      |
| Battery voltage .....                             | 131, 134 | External connection see 230 V connection ... | 54       |
| Current .....                                     | 137      | External flaps .....                         | 62       |
| Digital clock .....                               | 136      | Flap lock .....                              | 62, 63   |
| Temperature .....                                 | 137      | External gas connection .....                | 118      |
| Waste water tank level .....                      | 132, 136 | External shower .....                        | 114      |
| Water tank level .....                            | 132, 136 | Connection .....                             | 114      |
| Disposal  |          | Emptying .....                               | 114      |
| Household waste .....                             | 8        | External socket .....                        | 149      |
| Sewage .....                                      | 8        | Extractor hood .....                         | 181      |
| Waste water .....                                 | 8        | Care .....                                   | 216      |
| Door lock .....                                   | 60, 61   | Filter, cleaning .....                       | 216      |
| Doors   |          |  |          |
| Conversion door .....                             | 59       |  |          |
| Lock .....  | 60, 61   |  |          |

| <b>F</b>   |              |
|--|--------------|
| Fault current protection switch                      | 143          |
| Check  | 149          |
| Filling level of the waste water tank,<br>displaying | 132          |
| Filling level of the water tank, displaying          | 132          |
| Filling the tank                                     | 47           |
| Fire   |              |
| Behaviour in the event of                            | 9            |
| Extinguishing  | 9            |
| Fire prevention                                      | 9            |
| Fire risks, avoidance                                | 9            |
| FI-switch see fault<br>current protection switch     | 148          |
| Fixed bed  | 90, 91       |
| Closing  | 90           |
| Head section, lowering                               | 91           |
| Head section, raising                                | 91           |
| Opening  | 90           |
| Fixed bed, electrically adjustable                   | 91           |
| Emergency operation                                  | 92           |
| Extending  | 92           |
| Head section, adjusting                              | 92           |
| Retracting   | 92           |
| Fixed table  |              |
| Extending  | 86           |
| Reducing size  | 86           |
| Table leg  | 85           |
| Table top  | 85           |
| Table-top, folding closed                            | 86           |
| Table-top, folding out                               | 86           |
| Table-top, moving                                    | 86           |
| Table-top, moving in<br>a crossways direction        | 87           |
| Table-top, moving in<br>a lengthways direction       | 87           |
| Table-top, rotating                                  | 87           |
| Flap lock  |              |
| Closing  | 63, 64       |
| Opening  | 63, 64       |
| Service flap   | 63           |
| With recessed handle                                 | 63           |
| Flat screen with holder                              | 68           |
| Positioning  | 69, 70       |
| Storing  | 69, 70       |
| Floor warming unit, electrical                       |              |
| Overload protection                                  | 167          |
| Switching off  | 167          |
| Switching on   | 167          |
| Forced ventilation                                   | 10, 71       |
| Front passenger's seat                               | 44           |
| Fuel cell  |              |
| Cleaning   | 214          |
| Components   | 139          |
| Function   | 139          |
| Instructions   | 138          |
| Maintenance  | 224          |
| Operating status, indication                         | 140          |
| Operating unit                                       | 140          |
| Position   | 139          |
| Process medium, refilling                            | 225          |
| Tank cartridge, replacing                            | 224          |
| Troubleshooting                                      | 245          |
| Fuel filler neck                                     | 47           |
| Furniture flaps                                      | 65           |
| Closing  | 65, 66       |
| Opening  | 65, 66       |
| Furniture flaps, troubleshooting                     | 255          |
| Furniture surfaces, cleaning                         | 213          |
| Fuse box   | 148          |
| Fuses  |              |
| 12 V fuses   | 144          |
| 230 V fuse   | 143, 148     |
| For the Thetford toilet                              | 146, 147     |
| For toilet   | 147          |
| On the living area battery                           | 145          |
| On the relay box AD01                                | 145          |
| On the solar charge regulator                        | 148          |
| On the starter battery                               | 145          |
| On the transformer/rectifier EBL 99                  | 146          |
| Fuses see 12 V fuses and 230 V fuse                  | 144          |
| <b>G</b>   |              |
| Garage light   | 232          |
| Gas bottle compartment                               | 13, 116      |
| Gas bottles  |              |
| Changing   | 117          |
| Safety instructions                                  | 14, 116      |
| Gas connection, external                             | 118          |
| Gas cooker   |              |
| Cleaning   | 214          |
| Switching off  | 178, 179     |
| Switching on   | 178          |
| Troubleshooting                                      | 250          |
| Gas isolator taps                                    | 118          |
| Symbols  | 118, 155     |
| Gas odour  | 13, 115, 246 |

|                                  |              |
|----------------------------------|--------------|
| Gas oven                         | 179          |
| Switching off                    | 180          |
| Switching on                     | 180          |
| Troubleshooting                  | 250          |
| Gas supply in European countries | 277          |
| Gas system                       | 115          |
| Defect                           | 13, 115, 246 |
| General instructions             | 12           |
| Safety instructions              | 12, 115      |
| Switching automatics             | 119          |
| Troubleshooting                  | 246          |
| Gas tube, check                  | 13, 116      |
| General instructions             | 7            |
| Ground plans                     | 261          |

## H

|                                      |              |
|--------------------------------------|--------------|
| Halogen spotlight                    | 231, 232     |
| Handbrake                            | 49           |
| Applying                             | 10           |
| Handling of tyres                    | 237          |
| Headrests                            | 45           |
| Heat exchanger                       |              |
| Switching off                        | 166          |
| Switching on                         | 166          |
| Heat exchanger (Alde)                |              |
| Position                             | 164          |
| Switching off                        | 164          |
| Switching on                         | 164          |
| Heat exchangers, heater, replacement | 155          |
| Heater                               | 156          |
| Air outlet nozzles, adjustment       | 156          |
| Circulation fan                      | 156          |
| Heat exchangers, replacement         | 155          |
| Hot air distribution                 | 156          |
| Initial start-up                     | 156          |
| Troubleshooting                      | 246          |
| Heki skylight                        | 80           |
| Closing                              | 80           |
| Insect screen                        | 81           |
| Opening                              | 80           |
| Roman shade                          | 80           |
| Ventilation position                 | 80           |
| Help on Europe's roads               | 271          |
| High rate of gas consumption         | 13, 115, 246 |
| High-pressure cleaner, washing with  | 211          |
| Hinged window                        |              |
| Blind                                | 76           |
| Closing                              | 72, 74       |
| Continuous ventilation               | 73, 75       |

|   |          |
|---|----------|
| Insect screen                                 | 76, 77   |
| Opening                                       | 72, 74   |
| Roman shade                                   | 77       |
| Hot air distribution                          | 156      |
| Hot-air heater                                |          |
| Circulation fan                               | 156      |
| Operating modes                               | 157, 159 |
| Position                                      | 261      |
| Switching off                                 | 158, 160 |
| Switching on                                  | 157, 159 |
| Troubleshooting                               | 246, 247 |
| Hot-water heater                              |          |
| 230 V electrical operation, selecting         | 162      |
| Adjustment menu                               | 161      |
| Auxiliary circulating pump                    | 165      |
| Care  | 225      |
| Fluid level, checking                         | 226      |
| Gas and 230 V electrical operation, selecting | 162      |
| Gas operation, selecting                      | 162      |
| Heat distribution                             | 163      |
| Heat exchanger                                | 164      |
| Heater, switching off                         | 162      |
| Heater, switching on                          | 162      |
| Heating fluid, topping up                     | 226      |
| Heating system, bleeding                      | 226      |
| Maintenance work                              | 225      |
| Operating modes                               | 162      |
| Operating unit                                | 160      |
| Rotational speed, circulating pump            | 163      |
| Safety instructions                           | 160      |
| Start screen                                  | 161      |
| Tool menus                                    | 161      |
| Troubleshooting                               | 248      |

## I

|                                    |          |
|------------------------------------|----------|
| Independent vehicle heater         |          |
| Maintenance                        | 227      |
| Programming                        | 168      |
| Switching off                      | 167      |
| Switching on                       | 167      |
| Indicator lamp, 12 V power supply  | 133, 138 |
| Indicator lamp, 230 V power supply | 133, 138 |
| Indicator lamp, entrance step      | 33       |
| Indicator lamp, toilet             | 209      |
| Information stickers               | 234      |
| Inner door, troubleshooting        | 255      |

## Index

|                                  |                              |  |
|----------------------------------|------------------------------|--|
| Insect screen door               |                              |  |
| Closing                          | 62                           |  |
| Opening                          | 62                           |  |
| Insect screen Omni-Vent skylight |                              |  |
| Closing                          | 82                           |  |
| Opening                          | 82                           |  |
| Insect screen, cleaning          | 214                          |  |
| Insect screen, Heki skylight     |                              |  |
| Closing                          | 81                           |  |
| Opening                          | 81                           |  |
| Insect screen, Skyroof skylight  |                              |  |
| Closing                          | 85                           |  |
| Opening                          | 85                           |  |
| Insect screen, windows           |                              |  |
| Closing                          | 76, 77                       |  |
| Opening                          | 76, 77                       |  |
| Insect screen, wind-up skylight  |                              |  |
| Closing                          | 81                           |  |
| Opening                          | 81                           |  |
| Inspection plan                  | 283                          |  |
| Inspection work                  | 223                          |  |
| Inspections                      | 223                          |  |
| Interior care                    | 213                          |  |
| Interior lighting                |                              |  |
| Bulbs, changing                  | 229                          |  |
| Troubleshooting                  | 243                          |  |
| <b>K</b>                         |                              |  |
| Keys                             | 17                           |  |
| <b>L</b>                         |                              |  |
| Ladder, rear                     | 23                           |  |
| Lamps                            | 229                          |  |
| Cleaning                         | 213                          |  |
| Lay-up                           |                              |  |
| Temporary                        | 218                          |  |
| Winter lay-up                    | 219                          |  |
| Leakage water inside the vehicle | 254                          |  |
| Leather covers, cleaning         | 214                          |  |
| Lift-off table                   |                              |  |
| Conversion to bed foundation     | 90                           |  |
| Moving in a crossways direction  | 89                           |  |
| Moving in a lengthways direction | 89                           |  |
| Table leg                        | 89                           |  |
| Table top                        | 89                           |  |
| Table-top, moving upwards        | 90                           |  |
| Table-top, rotating              | 89                           |  |
| Light switch                     |                              |  |
| Living area                      | 67                           |  |
| Toilet compartment               | 66                           |  |
| Lighting                         |                              |  |
| Front                            | 228                          |  |
| Lamps, cleaning                  | 213                          |  |
| Rear                             | 228                          |  |
| Side                             | 228                          |  |
| Troubleshooting                  | 243                          |  |
| Living area battery              | 127                          |  |
| Battery alarm                    | 133, 136                     |  |
| Charging                         | 128                          |  |
| Charging current, displaying     | 137                          |  |
| Discharging current, displaying  | 137                          |  |
| Fuses                            | 145                          |  |
| Instructions                     | 127                          |  |
| Maintenance work                 | 224                          |  |
| Position                         | 261                          |  |
| Troubleshooting                  | 244, 245                     |  |
| Voltage, displaying              | 131, 134                     |  |
| Load                             | 22                           |  |
| Bike rack                        | 25                           |  |
| Bike/e-bike bike rack            | 27                           |  |
| Rear garage                      | 24                           |  |
| Rear storage space               | 24                           |  |
| Roof rack                        | 23                           |  |
| Load rack                        | 29, 30                       |  |
| Load rack for roof loads         | 23                           |  |
| Load see also payload            | 22                           |  |
| Lock                             |                              |  |
| Conversion door                  | 60, 61                       |  |
| External flap                    | 63                           |  |
| Furniture flap                   | 65                           |  |
| Low beam                         | 228                          |  |
| L-shaped bench, sleeping         |                              |  |
| conversion                       | 107, 108, 109, 110, 111, 113 |  |
| <b>M</b>                         |                              |  |
| Main beam                        | 228                          |  |
| Maintenance                      | 223                          |  |
| Maintenance work                 | 223                          |  |
| Air conditioning unit (Dometic)  | 216                          |  |
| Air conditioning unit (Telair)   | 216                          |  |
| Doors                            | 224                          |  |
| Fuel cell                        | 224                          |  |
| Hot-water heater                 | 225                          |  |
| Independent vehicle heater       | 227                          |  |
| Living area battery              | 224                          |  |
| Marker light                     | 229                          |  |
| Mass in ready-to-drive condition | 19, 21                       |  |
| Maximum permissible gross weight | 18, 21                       |  |





|                                  |                              |  |  |
|----------------------------------|------------------------------|--|--|
| Sewage tank                      |                              |  |  |
| Emptying                         | 210                          |  |  |
| Removal                          | 210                          |  |  |
| Shade Omni-Vent skylight         |                              |  |  |
| Closing                          | 82                           |  |  |
| Opening                          | 82                           |  |  |
| Shower                           | 197                          |  |  |
| Shower connection point,         |                              |  |  |
| external shower                  | 114                          |  |  |
| Shower partition, securing       | 34                           |  |  |
| Side marker light                | 228                          |  |  |
| Sink, cleaning                   | 214                          |  |  |
| Skylight Omni-Vent               | 82                           |  |  |
| Closing                          | 82                           |  |  |
| Opening                          | 82                           |  |  |
| Skylights                        | 79                           |  |  |
| Troubleshooting                  | 255                          |  |  |
| Skyroof skylight                 | 83                           |  |  |
| Closing                          | 83                           |  |  |
| Continuous ventilation           | 84                           |  |  |
| Insect screen                    | 85                           |  |  |
| Opening                          | 83                           |  |  |
| Roman shade                      | 84                           |  |  |
| Sleeping conversion              |                              |  |  |
| Central bench                    | 102, 103, 104, 105           |  |  |
| Central seating group            | 101                          |  |  |
| L-shaped                         |                              |  |  |
| bench                            | 107, 108, 109, 110, 111, 113 |  |  |
| Sleeping conversion,             |                              |  |  |
| central seating group            | 100                          |  |  |
| Snow chains                      | 35                           |  |  |
| Sockets                          |                              |  |  |
| External socket                  | 149                          |  |  |
| SAT socket                       | 149                          |  |  |
| TV socket                        | 149                          |  |  |
| Solar charge regulator           | 141                          |  |  |
| Solar installation               | 141                          |  |  |
| Spare parts                      | 233                          |  |  |
| Spare wheel                      | 241                          |  |  |
| Spare wheel support              | 241                          |  |  |
| Special equipment                | 257                          |  |  |
| Description                      | 7                            |  |  |
| Marking                          | 7                            |  |  |
| Safety instructions              | 10                           |  |  |
| Weight details                   | 257                          |  |  |
| Speed limits                     | 273                          |  |  |
| Spotlight                        | 68, 231                      |  |  |
| Removing                         | 68                           |  |  |
| Shifting                         | 68                           |  |  |
| Turning                          | 68                           |  |  |
| Starter battery                  | 125                          |  |  |
| Charging                         | 126                          |  |  |
| Discharging                      | 125                          |  |  |
| Fuses                            | 145                          |  |  |
| Instructions                     | 125                          |  |  |
| Troubleshooting                  | 244                          |  |  |
| Voltage, displaying              | 131, 134                     |  |  |
| Start-up                         |                              |  |  |
| After temporary lay-up           | 220                          |  |  |
| After winter lay-up              | 220                          |  |  |
| Staying overnight                |                              |  |  |
| Away from camping areas          | 276                          |  |  |
| During travel                    | 278                          |  |  |
| Steady legs                      | 50, 51                       |  |  |
| Extending                        | 50, 51                       |  |  |
| Length, adjustment               | 50, 51                       |  |  |
| Retracting                       | 51                           |  |  |
| Stopcock, heating circuits       | 163                          |  |  |
| Supports see steady legs         | 50, 51                       |  |  |
| Suspension table                 |                              |  |  |
| Conversion to bed foundation     | 89                           |  |  |
| Extending                        | 88                           |  |  |
| Reducing size                    | 88                           |  |  |
| Table leg                        | 87                           |  |  |
| Table top                        | 87                           |  |  |
| Switching automatics, gas system | 119                          |  |  |
| Symbols                          |                              |  |  |
| For instructions                 | 7                            |  |  |
| Gas isolator taps                | 118, 155                     |  |  |
| Synthetic parts in the toilet    |                              |  |  |
| and living areas, cleaning       | 213                          |  |  |
| <b>T</b>                         |                              |  |  |
| Table of linear measures         | 268                          |  |  |
| Tables                           | 85                           |  |  |
| Tank lid see fuel filler neck    | 47                           |  |  |
| Technical data                   |                              |  |  |
| Dimensions                       | 268                          |  |  |
| Power supply                     | 269                          |  |  |
| Television                       | 33                           |  |  |
| Temperature display              | 137                          |  |  |
| Thetford cassette                | 198, 202, 204, 207           |  |  |
| Emptying                         | 202, 207                     |  |  |
| Removing                         | 204                          |  |  |
| Retaining clip                   | 198, 202, 204, 207           |  |  |
| Thetford toilet                  |                              |  |  |
| Emptying                         | 202, 207                     |  |  |
| Fuse                             | 146, 147                     |  |  |
| Preparing                        | 198, 204                     |  |  |

## Index

- Swiveling ..... 198  
 Using ..... 200, 206  
 With fixed seat ..... 204  
 Tightening torque, wheels ..... 238  
 Tips ..... 271  
 Toilet ..... 198  
   Fuse ..... 147  
   Troubleshooting ..... 254  
 Toilet (Dometic) ..... 208  
   Flushing ..... 209  
   Indicator lamp ..... 209  
   Preparing ..... 208  
 Toilet compartment ..... 197  
   Light switch ..... 66  
   Ventilation ..... 197  
 Toilet see Thetford toilet or toilet (Dometic) ... 198  
 Toll regulations in European countries ..... 278  
 Total discharge ..... 124  
 Towing ..... 12  
   General instructions ..... 31  
   Safety instructions ..... 12  
 Traffic rules in foreign countries ..... 271  
 Transformer/rectifier (EBL 99) ..... 128  
   Circuit diagram ..... 150  
   Functions ..... 129  
   Position ..... 129  
 Transformer/rectifier, position ..... 261  
 Travel checklists ..... 279  
 Travel cots suitable for children ..... 93, 95  
 Troubleshooting ..... 243  
   12 V power supply ..... 244  
   230 V connection ..... 243  
   Air conditioning unit (Dometic) ..... 249  
   Air conditioning unit (Telair) ..... 249  
   Battery ..... 244  
   Body ..... 255  
   Boiler (Alde) ..... 248  
   Boiler (Truma) ..... 246, 247  
   Braking system ..... 243  
   Cooker ..... 250  
   Electrical system ..... 243  
   Entrance step ..... 243  
   Extractor hood ..... 245  
   Fuel cell ..... 245  
   Furniture flaps ..... 255  
   Gas cooker ..... 250  
   Gas oven ..... 250  
   Gas system ..... 246  
   Heater ..... 246  
   Hot-air heater ..... 246, 247  
   Hot-water heater ..... 248  
   Inner door ..... 255  
   Lighting ..... 243  
   Living area battery ..... 244  
   Microwave oven ..... 250  
   Refrigerator ..... 250, 253  
   Starter battery ..... 244  
   Toilet ..... 254  
   Water supply ..... 254  
 TV socket ..... 149  
 Tyre change see changing wheels ..... 237  
 Tyre specifications ..... 237  
 Tyres ..... 235  
   Excessive wear ..... 11, 35, 235, 241  
   General instructions ..... 235  
   Handling ..... 237  
   Identification ..... 237  
   Load-carrying capacity ..... 238  
   Tyre pressure ..... 241  
   Tyre selection ..... 236
- U**
- Underbody, maintenance ..... 212  
 Unladen weight ..... 19  
 Upholstery, cleaning ..... 213
- V**
- Vehicle identification plate ..... 234  
 Vehicle lighting see exterior lighting ..... 227  
 Vehicle, washing ..... 212  
 Ventilation ..... 71  
   Toilet compartment ..... 197  
 Volume of waste water, displaying ..... 132, 136  
 Volume of water, displaying ..... 132, 136
- W**
- Wardrobe light ..... 67  
 Warning stickers ..... 234  
 Warning tone, electrical steady legs ..... 52  
 Warranty cards ..... 1  
 Washing with a high-pressure cleaner ..... 211  
 Waste gas vent on the right hand side  
 of the vehicle. .... 156, 171  
 Waste water hose ..... 194  
 Waste water tank ..... 194  
   Care ..... 213  
   Cleaning ..... 213

---

|                                      |          |                  |     |
|--------------------------------------|----------|------------------|-----|
| Cleaning opening                     | 194      | Wind-up skylight | 81  |
| Emptying                             | 194      | Closing          | 81  |
| Filling level, displaying            | 132, 136 | Insect screen    | 81  |
| Troubleshooting                      | 254      | Opening          | 81  |
| Waste water tank heater              | 195      | Roman shade      | 81  |
| Water pipes, cleaning                | 214      | Winter care      | 217 |
| Water pump                           | 191, 195 | Winter operation | 217 |
| Position                             | 261      |                  |     |
| Switch                               | 133, 138 |                  |     |
| Water supply                         |          |                  |     |
| General                              | 191      |                  |     |
| Troubleshooting                      | 254      |                  |     |
| Water system                         |          |                  |     |
| Care                                 | 214      |                  |     |
| Cleaning                             | 214      |                  |     |
| Disinfect                            | 215      |                  |     |
| Drinking water filler neck           | 192      |                  |     |
| Emptying                             | 196      |                  |     |
| Filling                              | 195      |                  |     |
| Safety instructions                  | 15       |                  |     |
| Water tank                           | 192      |                  |     |
| Cleaning                             | 214      |                  |     |
| Filling                              | 193      |                  |     |
| Filling level, displaying            | 132, 136 |                  |     |
| Overflow                             | 193      |                  |     |
| Position                             | 261      |                  |     |
| Volumes                              | 192      |                  |     |
| Water, draining                      | 193      |                  |     |
| Water, filling with                  | 193      |                  |     |
| Weight details for special equipment | 257      |                  |     |
| Wheel chocks                         | 49       |                  |     |
| Wheel rim size                       | 238      |                  |     |
| Wheel rim type                       | 235      |                  |     |
| Wheels                               | 235      |                  |     |
| Window, conversion door              |          |                  |     |
| Roman shade, closing                 | 62       |                  |     |
| Roman shade, opening                 | 62       |                  |     |
| Windows                              | 71       |                  |     |
| Blind                                | 76       |                  |     |
| Insect screen                        | 76       |                  |     |
| Roman shade                          | 76, 77   |                  |     |
| Shade                                | 77       |                  |     |
| Windows, cleaning                    | 212      |                  |     |

