

**Dear Reader ...**

We would like to congratulate you on the purchase of your new motorhome. You have selected a top-quality vehicle which will afford you many years of enjoyment.

To enable you to always use and operate your motorhome properly and easily, your Bürstner dealer will first provide you detailed instructions for all important functions when you take delivery.

This manual, the instruction manuals from the base vehicle manufacturer as well as the instruction manuals from the appliance manufacturer will always be at hand to answer any questions you may have regarding your motorhome.

**Before your first journey**

Please familiarise yourself with this manual rather than relying on it strictly for reference.

Fill in the warranty cards for the appliances and special equipment in the individual instructions and send these cards to the respective manufacturers. This ensures your warranty claim for each appliance.



<b>1</b>	<b>Introduction</b> .....	<b>7</b>	4.8	Pilot seats for the driver's and front passenger's seats .....	37
1.1	General .....	7	4.8.1	Seats (Aguti) .....	38
1.2	Environmental tips .....	8	4.8.2	Seats (Aguti-Liner) .....	38
<b>2</b>	<b>Safety</b> .....	<b>9</b>	4.9	Headrests .....	39
2.1	Fire prevention .....	9	4.10	Backrest adjustment mechanism for bench (partially special equipment) .....	40
2.1.1	Avoidance of fire risks .....	9	4.11	Seating arrangement .....	40
2.1.2	Fire-fighting .....	9	4.12	Electrical window winders (partially special equipment) .....	41
2.1.3	In case of fire .....	9	4.13	External mirrors .....	41
2.2	General .....	10	4.14	Roman shades for windscreen, driver's window and front passenger's window .....	42
2.3	Road safety .....	10	4.15	Bonnet .....	42
2.4	Towing .....	12	4.16	Washer nozzles .....	43
2.5	Gas system .....	12	4.17	Filling with washer fluid .....	44
2.5.1	General instructions .....	12	4.18	Filling up with diesel .....	44
2.5.2	Gas bottles .....	13	<b>5</b>	<b>Pitching the motorhome</b> .....	<b>47</b>
2.6	Electrical system .....	14	5.1	Handbrake .....	47
2.7	Water system .....	14	5.2	Entrance step .....	47
<b>3</b>	<b>Before the journey</b> .....	<b>15</b>	5.3	Wheel chocks .....	47
3.1	Keys .....	15	5.4	Supports .....	47
3.2	Registration .....	15	5.4.1	General instructions .....	47
3.3	Payload .....	16	5.4.2	Steady legs (SAWIKO) (special equipment) .....	48
3.3.1	Terms .....	16	5.4.3	Steady legs (AL-KO) (partially special equipment) .....	48
3.3.2	Calculating the payload .....	18	5.5	230 V connection .....	49
3.3.3	Loading the vehicle correctly .....	19	5.6	Refrigerator .....	49
3.3.4	Roof rail and ladder (special equipment) .....	21	5.7	Satellite unit (special equipment) .....	49
3.3.5	Rear garage/rear storage space .....	22	5.7.1	Equipment with automatic antenna alignment .....	50
3.3.6	Double floor .....	22	5.7.2	Equipment with semi-automatic antenna alignment .....	50
3.3.7	Extendable storage compartment .....	23	5.8	Awning (special equipment) .....	51
3.3.8	Bike rack (special equipment) .....	23	<b>6</b>	<b>Living</b> .....	<b>53</b>
3.3.9	Removable load rack AL-KO (special equipment) .....	24	6.1	Conversion door and driver's door .....	53
3.3.10	Load rack SAWIKO (special equipment) .....	25	6.1.1	Driver's door, outside (partially special equipment) .....	53
3.4	Towing .....	26	6.1.2	Driver's door, inside (partially special equipment) .....	54
3.5	Caravan coupling (special equipment) .....	26	6.1.3	Conversion door, outside (Hartal M1) .....	54
3.6	Entrance step (partially special equipment) .....	27	6.1.4	Conversion door, inside (Hartal M1) .....	55
3.7	Television (special equipment) .....	28	6.1.5	Conversion door, outside (Hartal Premium) (partially special equipment) .....	55
3.8	Sink and drain basin covers .....	29	6.1.6	Conversion door, inside (Hartal Premium) (partially special equipment) .....	56
3.9	Securing add-on parts .....	29			
3.10	Snow chains (special equipment) .....	30			
3.11	Road safety .....	30			
<b>4</b>	<b>During the journey</b> .....	<b>33</b>			
4.1	Driving the motorhome .....	33			
4.2	Parking distance control (special equipment) .....	34			
4.3	Reversing camera (partially special equipment) .....	35			
4.4	Driving speed .....	35			
4.5	Brakes .....	36			
4.6	Seat belts .....	36			
4.6.1	Fastening the seat belt correctly .....	37			
4.7	Child restraint systems .....	37			

6.1.7	Window of conversion door (Hartal Premium) (partially special equipment) . . . . .	56	6.14	Converting seating groups for sleeping . . . . .	85
6.1.8	Folding insect screen on the conversion door (partially special equipment) . . . . .	56	6.14.1	Central bench with divan (narrow) (special equipment) . . . . .	85
6.2	External flaps . . . . .	57	<b>7</b>	<b>Gas system . . . . .</b>	<b>87</b>
6.2.1	Flap lock with recessed handle . . . . .	57	7.1	General . . . . .	87
6.2.2	Flap lock, elliptical-shaped . . . . .	58	7.2	Gas bottles . . . . .	88
6.2.3	Flap lock with push button . . . . .	59	7.3	Changing gas bottles . . . . .	89
6.2.4	Flap for the 230 V connection, square . . . . .	59	7.4	Gas isolator taps . . . . .	90
6.2.5	Cap for the drinking water filler neck . . . . .	60	7.5	External gas connection (special equipment) . . . . .	90
6.3	Furniture flaps . . . . .	60	7.6	Crash-Protection-Unit switching facility (special equipment) . . . . .	91
6.3.1	Furniture flaps with push button . . . . .	61	7.7	DuoControl switching facility (special equipment) . . . . .	93
6.3.2	Furniture flaps with handle and push button . . . . .	61	7.8	Gas alarm system (special equipment) . . . . .	94
6.4	Light switch . . . . .	62	<b>8</b>	<b>Electrical system . . . . .</b>	<b>97</b>
6.4.1	Entrance area . . . . .	62	8.1	General safety instructions . . . . .	97
6.4.2	Interior . . . . .	62	8.2	Terms . . . . .	97
6.5	Light control . . . . .	63	8.3	12 V power supply . . . . .	98
6.6	Spotlight . . . . .	64	8.3.1	Starter battery . . . . .	98
6.7	Holder for flat screen . . . . .	65	8.3.2	Living area battery . . . . .	99
6.7.1	Holder on the column . . . . .	65	8.4	Transformer/rectifier (EBL 99) . . . . .	100
6.7.2	Holder in the TV cabinet . . . . .	66	8.4.1	Battery cut-off switch . . . . .	102
6.7.3	Holder with jointed arm . . . . .	66	8.4.2	Battery selector switch . . . . .	102
6.8	Ventilation . . . . .	67	8.4.3	Battery monitor . . . . .	102
6.9	Windows . . . . .	67	8.4.4	Charging the battery . . . . .	103
6.9.1	Hinged window with rotary hinges . . . . .	68	8.5	Transformer/rectifier (EBL 220) . . . . .	103
6.9.2	Hinged window with automatic hinges . . . . .	69	8.5.1	Battery separation . . . . .	105
6.9.3	Sliding window without lock . . . . .	71	8.5.2	Battery selector switch . . . . .	105
6.9.4	Blind and insect screen . . . . .	72	8.5.3	Battery monitor . . . . .	105
6.9.5	Roman shade and insect screen . . . . .	73	8.5.4	Charging the battery . . . . .	106
6.9.6	Roman shades for windscreen, driver's window and front passenger's window . . . . .	74	8.6	Panel IT 96-2 . . . . .	106
6.10	Skylights . . . . .	74	8.6.1	12 V main switch . . . . .	106
6.10.1	Heki skylight (mini and midi) . . . . .	75	8.6.2	V/tank gauge for battery voltage and water or waste water levels . . . . .	107
6.10.2	Wind-up skylight (partially special equipment) . . . . .	76	8.6.3	Switch for water pump . . . . .	108
6.11	Tables . . . . .	77	8.6.4	Battery alarm for the living area battery . . . . .	108
6.11.1	Fixed table (extendable table-top) . . . . .	77	8.6.5	12 V indicator lamp . . . . .	109
6.11.2	Fixed table (movable table-top) . . . . .	77	8.6.6	230 V indicator lamp . . . . .	109
6.11.3	Lift-off table . . . . .	78	8.7	Panel IT 994 . . . . .	109
6.12	Divan adjustment mechanism (partially special equipment) . . . . .	78	8.7.1	V/tank gauge for battery voltage and water or waste water levels . . . . .	109
6.13	Beds . . . . .	79	8.7.2	Battery alarm for the living area battery . . . . .	111
6.13.1	Pull-down bed (with lock) . . . . .	79	8.7.3	Digital clock/temperature gauge . . . . .	111
6.13.2	Pull-down bed, electrically operated . . . . .	81	8.7.4	Current gauge for charging/ discharging the living area battery . . . . .	112
6.13.3	Fixed bed (gas-pressure springs) . . . . .	82	8.7.5	12 V main switch . . . . .	112
6.13.4	Fixed bed (adjustable head section) . . . . .	83	8.7.6	12 V indicator lamp . . . . .	113
6.13.5	Fixed bed, electrically adjustable . . . . .	83	8.7.7	230 V indicator lamp . . . . .	113
			8.7.8	Switch for water pump . . . . .	113

8.8	Panel LT 510 . . . . .	113	9.6	Refrigerator . . . . .	159
8.8.1	230 V indicator lamp . . . . .	114	9.6.1	Refrigerator ventilation grill . . . . .	159
8.8.2	12 V main switch . . . . .	114	9.6.2	Operation (Dometic 7 series, automatic ignition) . . . . .	159
8.8.3	Batteries gauge . . . . .	115	9.6.3	Operation (Dometic 7 series with automatic power selection and frame heater) . . . . .	161
8.8.4	Tank gauge . . . . .	117	9.6.4	Operation (Dometic 8 series with automatic power selection) . . . . .	163
8.8.5	Alarms . . . . .	117	9.6.5	Refrigerator door locking mechanism . . . . .	165
8.8.6	Temperature display . . . . .	118			
8.8.7	Switch for tank heater . . . . .	118	<b>10</b>	<b>Sanitary fittings . . . . .</b>	<b>169</b>
8.8.8	Switch for water pump . . . . .	119	10.1	Water supply, general . . . . .	169
8.9	Solar installation (special equipment) . . . . .	119	10.2	Water tank . . . . .	170
8.10	230 V power supply . . . . .	120	10.2.1	Volumes . . . . .	170
8.10.1	230 V connection . . . . .	120	10.2.2	Drinking water filler neck with cap . . . . .	170
8.10.2	Power cable for external 230 V connection . . . . .	120	10.2.3	Filling with water . . . . .	170
8.11	Fuses . . . . .	121	10.2.4	Draining water (handle with overflow) . . . . .	171
8.11.1	12 V fuses . . . . .	122	10.3	Waste water tank . . . . .	171
8.11.2	230 V fuse . . . . .	126	10.3.1	Models without double floor . . . . .	171
8.12	External socket (special equipment) . . . . .	126	10.3.2	Models with double floor . . . . .	172
8.13	Circuit diagrams . . . . .	128	10.3.3	Waste water tank heater (special equipment) . . . . .	173
8.13.1	Circuit diagrams, interior . . . . .	128	10.4	Filling the water system . . . . .	173
8.13.2	Circuit diagram, exterior . . . . .	134	10.5	Emptying the water system . . . . .	174
<b>9</b>	<b>Appliances . . . . .</b>	<b>135</b>	10.6	Toilet compartment . . . . .	175
9.1	General . . . . .	135	10.7	Toilet . . . . .	176
9.2	Heater . . . . .	136	10.7.1	Swivel toilet (Thetford C-200) . . . . .	176
9.2.1	Models with waste gas vent on the right-hand side of the vehicle . . . . .	136	10.7.2	Toilet with fixed seat (Thetford C-402) . . . . .	182
9.2.2	To heat properly . . . . .	136	10.7.3	Toilet (Dometic) . . . . .	186
9.2.3	Truma Combi hot-air heater . . . . .	137			
9.2.4	Alde hot-water heater (partially special equipment) . . . . .	139	<b>11</b>	<b>Care . . . . .</b>	<b>189</b>
9.2.5	Auxiliary heat exchanger (partially special equipment) . . . . .	142	11.1	External care . . . . .	189
9.2.6	Electrical floor warming unit (special equipment) . . . . .	143	11.1.1	Washing with a high-pressure cleaner . . . . .	189
9.2.7	Independent vehicle heater (special equipment) . . . . .	144	11.1.2	Washing the vehicle . . . . .	189
9.3	Air conditioning unit (special equipment) . . . . .	145	11.1.3	Windows of acrylic glass . . . . .	190
9.3.1	Dometic . . . . .	145	11.1.4	Underbody . . . . .	190
9.3.2	Telair . . . . .	147	11.1.5	Waste water tank . . . . .	190
9.4	Boiler . . . . .	148	11.1.6	Entrance step . . . . .	191
9.4.1	Models with waste gas vent on the right-hand side of the vehicle . . . . .	149	11.2	Interior care . . . . .	191
9.4.2	Truma Combi boiler . . . . .	149	11.3	Water system . . . . .	192
9.4.3	Alde boiler (partially special equipment) . . . . .	152	11.3.1	Cleaning the water tank . . . . .	192
9.5	Cooker . . . . .	154	11.3.2	Cleaning the water pipes . . . . .	192
9.5.1	Gas cooker . . . . .	154	11.3.3	Disinfecting the water system . . . . .	193
9.5.2	Gas oven (Dometic) (special equipment) . . . . .	156	11.4	Extractor hood . . . . .	193
9.5.3	Microwave oven (special equipment) . . . . .	157	11.5	Air conditioning unit . . . . .	194
9.5.4	Extractor hood (special equipment) . . . . .	158	11.5.1	Dometic . . . . .	194
			11.5.2	Telair . . . . .	194
			11.6	Winter care . . . . .	194
			11.6.1	Preparations . . . . .	195
			11.6.2	Winter operation . . . . .	195
			11.6.3	At the end of the winter season . . . . .	195
			11.7	Lay-up . . . . .	196

11.7.1	Temporary lay-up . . . . .	196	<b>14</b>	<b>Troubleshooting . . . . .</b>	<b>225</b>
11.7.2	Winter lay-up . . . . .	197	14.1	Braking system . . . . .	225
11.7.3	Starting up the vehicle after a temporary lay-up or after lay-up over winter . . . . .	198	14.2	Electrical system . . . . .	225
<b>12</b>	<b>Maintenance . . . . .</b>	<b>201</b>	14.3	Gas system . . . . .	227
12.1	Inspection work . . . . .	201	14.4	Heater/boiler . . . . .	228
12.2	Maintenance work . . . . .	201	14.4.1	Heater/boiler Truma . . . . .	228
12.3	Doors . . . . .	201	14.4.2	Alde heater/boiler . . . . .	229
12.4	Living area battery . . . . .	202	14.5	Air conditioning unit . . . . .	230
12.5	Alde hot-water heater . . . . .	202	14.5.1	Dometic . . . . .	230
12.5.1	Checking the fluid level . . . . .	203	14.5.2	Telair . . . . .	230
12.5.2	Topping up heating fluid . . . . .	203	14.6	Cooker . . . . .	231
12.5.3	Bleeding the heating system . . . . .	203	14.6.1	Gas cooker/gas oven . . . . .	231
12.5.4	Position of the bleeding valves . . . . .	204	14.6.2	Microwave oven . . . . .	231
12.6	Independent vehicle heater . . . . .	204	14.7	Refrigerator . . . . .	231
12.7	Replacing bulbs, external . . . . .	204	14.7.1	Dometic 7 series . . . . .	231
12.7.1	Front lights . . . . .	205	14.7.2	Dometic 7 series with AES . . . . .	232
12.7.2	Front lights (variant) . . . . .	206	14.7.3	Dometic 8 series with AES . . . . .	233
12.7.3	Rear lights . . . . .	208	14.8	Water supply . . . . .	234
12.7.4	Side lights . . . . .	209	14.9	Body . . . . .	236
12.7.5	Types of bulbs for exterior lighting . . . . .	209	<b>15</b>	<b>Special equipment . . . . .</b>	<b>237</b>
12.8	Replacing bulbs, internal . . . . .	210	15.1	Weight details for special equipment . . . . .	237
12.8.1	Ceiling lamp . . . . .	210	<b>16</b>	<b>Technical data . . . . .</b>	<b>241</b>
12.8.2	Recessed halogen light . . . . .	211	16.1	View of ground plans . . . . .	241
12.8.3	Recessed halogen light (flat) . . . . .	211	16.2	Table of linear measures . . . . .	246
12.8.4	Halogen spotlight (movable) . . . . .	212	16.3	Power supply . . . . .	246
12.8.5	Halogen spotlight (movable) . . . . .	212	<b>17</b>	<b>Helpful notes . . . . .</b>	<b>249</b>
12.8.6	Halogen spotlight (movable) . . . . .	213	17.1	Traffic rules in foreign countries . . . . .	249
12.8.7	Halogen spotlight (gooseneck) . . . . .	213	17.2	Help on Europe's roads . . . . .	249
12.8.8	Bathroom lamp . . . . .	214	17.3	Speed limits and permissible dimensions . . . . .	251
12.8.9	Wardrobe light . . . . .	214	17.4	Driving with low beam in European countries . . . . .	254
12.8.10	Garage light . . . . .	215	17.5	Sleeping in the vehicle away from camping areas . . . . .	254
12.9	Spare parts . . . . .	215	17.6	Gas supply in European countries . . . . .	256
12.10	Vehicle identification plate . . . . .	216	17.7	Toll regulations in European countries . . . . .	256
12.11	Warning and information stickers . . . . .	216	17.8	Tips on staying overnight safely during travel . . . . .	256
<b>13</b>	<b>Wheels and tyres . . . . .</b>	<b>217</b>	17.9	Tips for winter campers . . . . .	257
13.1	General . . . . .	217	17.10	Travel checklists . . . . .	257
13.2	Tyre selection . . . . .	218	<b>18</b>	<b>Inspection plan . . . . .</b>	<b>261</b>
13.3	Tyre specifications . . . . .	219			
13.4	Handling of tyres . . . . .	219			
13.5	Changing wheels . . . . .	219			
13.5.1	General instructions . . . . .	219			
13.5.2	Tightening torque . . . . .	220			
13.5.3	Changing a wheel . . . . .	221			
13.5.4	Changing a wheel at alloy wheel rims . . . . .	222			
13.6	Spare wheel support (special equipment) . . . . .	222			
13.6.1	Spare wheel support under the vehicle . . . . .	222			
13.6.2	Spare wheel support in the rear garage . . . . .	222			
13.7	Tyre pressure . . . . .	223			

## Please read this instruction manual completely before using the vehicle for the first time!

Always keep this instruction manual in the vehicle. Also inform all other users of the safety regulations.



- ▶ The non-observance of this symbol can lead to personal injury.



- ▷ The non-observance of this symbol can lead to damage being caused to, or inside the vehicle.



- ▷ This symbol indicates recommendations or special aspects.



- ▷ This symbol indicates actions which lead to environmental awareness.

**This instruction manual contains sections which describe model-specific equipment or special equipment. These sections are specially marked. It may be that your vehicle has not been fitted with this special equipment. In some cases, the actual equipment of your vehicle may therefore be different from that shown in some illustrations and descriptions.**

However, your vehicle may be fitted with other special equipment not described in this instruction manual.

Special equipment is described when an explanation is required.

Adhere to the instruction manuals which are separately enclosed.



- ▷ The details "right", "left", "front" and "rear" always refer to the vehicle in direction of travel.
- ▷ All dimensions and weight details are "approximate".

Should the vehicle be subjected to damage due to a failure to follow the instructions in this instruction manual, then the guarantee claim is deemed invalid.

Our vehicles are subjected to continuous development. Please understand that we reserve the right to alter the form, equipment and technology. Therefore, no claims can be made against the manufacturer as a result of the contents of this instruction manual. The equipment which was known and included at the time of going to press is described.

The reprinting, translation and copying, including extracts is not permitted without prior written authorisation from the manufacturer.

### 1.1 General

The vehicle is constructed in accordance with the latest technology and the recognised safety regulations. Nevertheless, personal injury may result and the vehicle may be damaged if the safety instructions in this instruction manual are not followed.

Only use the vehicle in a technically impeccable condition. Follow the instructions in the instruction manual.

Malfunctions which impair the safety of persons or the vehicle should be immediately remedied by qualified personnel. To avoid further damages, observe the duty to avert, minimize or mitigate loss for the user during faults.

Have the vehicle's braking and gas systems inspected and repaired by an authorised specialist workshop only.

Alterations to the body are only to be carried out with the authorisation of the manufacturer.

The vehicle is designed for the exclusive transport of persons. Luggage and accessories may only be transported up to the maximum permissible gross weight.

Observe the test and inspection periods stipulated by the manufacturer.

## 1.2 Environmental tips



- ▷ Be considerate of the environment.
- ▷ Remember that: All kinds of waste water and household waste are not to be disposed of in drains or in the open countryside.
- ▷ On board, collect waste water only in the waste water tank or – if necessary – in other containers designed for that purpose.
- ▷ Only empty the waste water tank and toilet cassette or sewage tank at disposal stations at the camping or caravan sites, which are especially provided for this purpose. When stopping in towns and communities, observe the instructions at caravan sites or ask where there are disposal stations.
- ▷ Empty waste water tank as often as possible, even when it is not completely full (hygiene).  
If possible, flush out waste water tank and, if necessary, drainage pipe with fresh water every time it is emptied.
- ▷ Never allow the toilet cassette or sewage tank to become too full. Empty the toilet cassette or sewage tank frequently, at the latest as soon as the level indicator lights up.
- ▷ Separate household waste according to glass, tin cans, plastic and wet waste also when on a journey. Enquire at the town or community authority about disposal points. Household waste is not to be disposed of in waste paper baskets which are situated at car parks.
- ▷ Empty waste bins as often as possible into the containers provided for this purpose. This helps to avoid unpleasant smells and an accumulation of rubbish on board.
- ▷ When parked, do not allow the engine to run more than necessary. When running idle, a cold engine releases more contaminants than usual. The running temperature of the engine is achieved more quickly whilst the vehicle is in motion.
- ▷ Use an environmentally-friendly WC chemical agent for the WC which can also be biologically degraded and only use small doses.
- ▷ When staying in towns and communities for long periods, search for parking areas which are specially reserved for motorhomes. Enquire at the town or community authority about parking spaces.
- ▷ Always leave the parking places in a clean condition.



## Chapter overview

This chapter contains important safety instructions. The safety instructions are for the protection of persons and property.

The instructions address the following topics:

- fire prevention and what to do in case of fire
- general care of the vehicle
- road safety of the vehicle
- towing
- gas system of the vehicle
- electrical system of the vehicle
- water system of the vehicle

## 2.1 Fire prevention

### 2.1.1 Avoidance of fire risks



- ▶ Never leave children in the vehicle unattended.
- ▶ Keep flammable materials clear of heating and cooking appliances.
- ▶ Lights can get very hot. When the light is switched on, there must always be a safety distance of 30 cm between light and flammable objects. Fire hazard!
- ▶ Never use portable heating or cooking appliances.
- ▶ Only authorised qualified personnel may make changes to the electrical system, gas system or appliances.

### 2.1.2 Fire-fighting



- ▶ Always carry a dry powder fire extinguisher in the vehicle. The fire extinguisher must be approved, tested and close at hand.
- ▶ Have the fire extinguisher tested at regular intervals by authorised qualified personnel. Observe the date of testing.
- ▶ Depending on the equipment, the fire extinguisher is included in the scope of delivery.
- ▶ Always keep a fire blanket near the cooker.

### 2.1.3 In case of fire



- ▶ Evacuate all passengers.
- ▶ Cut off the electrical power supply and disconnect from the mains.
- ▶ Close regulator tap on the gas bottle.
- ▶ Sound the alarm and call the fire brigade.
- ▶ Fight the fire if this is possible without risk.



- ▷ Acquaint yourself with the position and operation of the emergency exits.
- ▷ Keep escape routes clear.
- ▷ Observe the fire extinguisher instructions for use.

All windows and doors which meet the following requirements are considered as emergency exits:

- Open to the outside or can be shifted in horizontal direction
- Opening angle at least 70°
- Minimum diameter of clearance = 450 mm
- Maximum distance from the vehicle floor = 950 mm

## 2.2 General



- ▶ The oxygen in the vehicle interior is used up by breathing and the use of gas operated appliances. That is why the oxygen needs to be replaced on a constant basis. For this purpose, forced ventilation options (e.g. skylights with forced ventilation, mushroom-shaped vents or floor vents) are fitted to the vehicle. Never cover or block forced ventilations from the inside or outside with objects such as e.g. a winter mat. Keep forced ventilations clear of snow and leaves. There is a danger of suffocation due to increased CO<sub>2</sub> levels.
- ▶ Observe the headroom of the doors.



- ▷ As far as the fitted appliances (heater, cooker, refrigerator, etc.) and the base vehicle (engine, brakes, etc.) are concerned, the instruction manuals are authoritative. It is imperative that they be observed.
- ▷ Fitting accessories or special equipment can alter the dimensions, weight and road behaviour of the vehicle. Some of the parts must be entered in the vehicle papers.
- ▷ Only use wheel rims and tyres which are approved for the vehicle. Information concerning the size of the approved wheel rims and tyres is included in the vehicle documents or can be obtained from authorised dealers and service centres.
- ▷ Firmly apply the handbrake when parking the vehicle.
- ▷ If the maximum permissible gross weight of the vehicle exceeds 4 tonnes, wheel chocks must be used when parking on gradients. The wheel chocks are provided as standard for vehicles with a maximum permissible gross weight exceeding 4 tonnes.



- ▷ When leaving the vehicle, it is imperative that all doors, external flaps and windows are closed.
- ▷ Carry a hazard warning triangle and a first-aid kit and/or flashing hazard warning light when this is required by law.
- ▷ The vehicle may only be driven by drivers who hold a driving licence which is valid for the respective vehicle class.
- ▷ When selling the vehicle, hand over all instruction manuals for the vehicle and the fitted appliances.

## 2.3 Road safety



- ▶ Before commencing the journey, carry out a functional check of indicating and lighting equipment, the steering and the brakes.
- ▶ If the vehicle has been stationary for a long period (approx. 10 months) have the braking and gas systems checked by an authorised specialist workshop.
- ▶ Before commencing the journey and after short interruptions of the journey, ensure that the entrance step is completely retracted.



- ▶ Before commencing the journey, secure the hinged pull-down bed.
- ▶ Before commencing the journey, open and secure the shades on the windscreen and on the driver's and front passenger's windows.
- ▶ Before commencing the journey, remove the television from the support and store it securely.
- ▶ Before commencing the journey, place and secure the flat screen and screen support in the initial position. If the screen holder is installed in a TV cabinet: Close TV cabinet.
- ▶ Before commencing the journey, take off the loose sink and drain basin covers and store them securely in the kitchen unit or the wardrobe.
- ▶ Before commencing the journey, fix adjustable tables.
- ▶ Before commencing the journey, rotate all swivel seats in the direction of travel and lock in position. During the journey, the swivel seats must remain locked in place in the direction of travel.
- ▶ During the journey, persons are only to sit on the permitted seats (see chapter 4). The authorised number of seats is stipulated in the vehicle documents.
- ▶ Seat belts must be worn by all passengers.
- ▶ Fasten your seat belts before the beginning of the journey and keep them fastened during the journey.
- ▶ Always secure children with the children safety equipment prescribed for the respective height and weight.
- ▶ Factory-set three-point safety belts must be used when attaching child restraint systems.
- ▶ The base vehicle is a commercial vehicle (small truck). Adjust your driving technique accordingly.
- ▶ In case of underpasses, tunnels or similar obstacles, note the total height of the vehicle (including the roof load).
- ▶ In winter, the roof must be free of snow and ice before commencing the journey.
- ▶ Check tyre pressure before a journey or every 2 weeks. Wrong tyre pressure causes excessive wear and can lead to damage or even to tyre burst. You can lose control of the vehicle.
- ▶ Do not operate the independent vehicle heater at petrol stations. Danger of explosion!
- ▶ Do not operate the independent vehicle heater in closed spaces. Danger of suffocation!



- ▷ Before commencing the journey, distribute the payload evenly within the vehicle (see chapter 3).
- ▷ When loading the vehicle and when taking a rest from driving, in order to load luggage or food, for example, observe the maximum permissible gross weight and axle loads (refer to vehicle documents).
- ▷ Before commencing the journey, ensure that all cupboard doors, the toilet compartment door and all drawers and flaps are secure. Engage the refrigerator door securing device.
- ▷ Before commencing the journey, close windows and skylights.
- ▷ Before commencing the journey, close all external flaps and lock them.



- ▷ Before commencing the journey, remove the external supports and retract the corner steadies or steady legs, which are fitted to the vehicle.
- ▷ Before commencing the journey, put the antenna in park position.
- ▷ During the initial journey and each time after changing a wheel, re-tighten the wheel bolts/wheel nuts after 50 km (30 miles). Subsequently inspect them at regular intervals in order to ensure that they are firmly seated. See chapter 13 for tightening torque.
- ▷ Tyres may not be older than 6 years as the material becomes brittle over time (see chapter 13).
- ▷ When using snow chains, the tyres, wheel suspension and steering are subjected to an additional load. When using snow chains, drive slowly (maximum speed 50 km/h) and only on streets which are completely covered with snow. Otherwise the vehicle could be damaged.

## 2.4 Towing



- ▶ Care is to be taken when connecting and detaching a trailer. Risk of accident and injury!
- ▶ No persons are to be between the towing vehicle and the trailer during positioning for connecting and detaching.

## 2.5 Gas system

### 2.5.1 General instructions



- ▶ Before commencing the journey, when leaving the vehicle or when gas equipment is not in use, close all gas isolator taps and the main isolator tap on the gas bottle.
- ▶ No appliance operated by a naked flame (e.g. heater or refrigerator) may be in operation when filling the tank, on ferries or in the garage. Danger of explosion!
- ▶ Do not use appliances operated with a naked flame in closed spaces (e.g. garages). Danger of poisoning and suffocation!
- ▶ Only have the gas system maintained, repaired or altered by an authorised specialist workshop.
- ▶ Have the gas system checked by an authorised specialist workshop according to the national regulations before commissioning. This also applies for not registered vehicles. For modifications to the gas system have the gas system immediately checked by an authorised specialist workshop.
- ▶ The gas pressure regulator and exhaust gas pipes must also be inspected. The gas pressure regulator has to be replaced after 10 years at the latest. The vehicle owner is responsible for seeing that this is carried out.
- ▶ In case of a defect of the gas system (gas odour, high gas consumption) there is danger of explosion! Close regulator tap on the gas bottle immediately. Open doors and windows and ventilate well.
- ▶ If the gas system is defective: Do not smoke; do not ignite any open flames, and do not operate electric switches (light switches etc.).
- ▶ Before using the cooker make sure that there is sufficient ventilation. Open windows or the skylight.



- ▶ Do not use the gas cooker or gas oven for heating purposes.
- ▶ If there are several gas devices, each gas device must have its own gas isolator tap. If individual gas devices are not in use, close the respective gas isolator tap.
- ▶ Ignition safety valves must close within 1 minute after the gas flame has extinguished. A clicking sound is audible. Check function from time to time.
- ▶ The built-in gas devices are exclusively meant for use with propane or butane gas or a mixture of both. The gas pressure regulator as well as all built-in gas devices are designed for a gas pressure of 30 mbar.
- ▶ Propane gas is capable of gasification up to -42 °C, whereas butane gas gasifies at 0 °C. Below these temperatures no gas pressure is available. Butane gas is unsuitable for use in winter.
- ▶ Regularly inspect the gas tube fitted to the gas bottle connection for tightness. The gas tube must not have any tears and must not be porous. Have the gas tube replaced by an authorised specialist workshop no later than ten years after the manufacturing date. The operator of the gas system must see to it that the parts are replaced.
- ▶ Due to its function and construction, the gas bottle compartment is a space which is open to the exterior. Never cover or block up the standard forced ventilations. Otherwise gas that is emitted can not be diverted to the outside.
- ▶ Do not use the gas bottle compartment as storage space as it is not moisture-proof.
- ▶ Secure the gas bottle compartment against unauthorised access. To do this, lock the compartment.
- ▶ The regulator tap on the gas bottle must be accessible.
- ▶ Only connect gas-operated devices (e.g. gas grill) which have been designed for a gas pressure of 30 mbar.
- ▶ The exhaust gas pipe must be fitted tightly to the heating system and to the vent and must be sealed. The exhaust gas pipe must not show any evidence of damage.
- ▶ Exhaust fumes must be able to escape into the atmosphere unhindered and fresh air must be able to enter unhindered. For this reason, keep the exhaust pipe and intake openings clean and unobstructed (e.g. free from snow and ice). For this reason, no snow walls or aprons may lie against the vehicle.

### 2.5.2 Gas bottles



- ▶ Gas bottles are only to be transported within the designated gas bottle compartment.
- ▶ Place the gas bottles in vertical position in the gas bottle compartment.
- ▶ Fasten the gas bottles so that they are unable to turn or tilt.
- ▶ If the gas bottles are not connected to the gas tube, always place the protective cap on top.
- ▶ Close the regulator tap on the gas bottle before the gas pressure regulator or gas tube are removed from the gas bottle.
- ▶ Use your hands only to connect the gas pressure regulator or the gas tube to the gas bottles. Do not use any tools.



- ▶ Only use special gas pressure regulators with a safety valve designed for vehicle use. Other gas pressure regulators are not permitted and cannot meet the demanding requirements.
- ▶ Use the gas pressure regulator defroster if the temperature falls below 5 °C.
- ▶ Use only 11 kg or 5 kg gas bottles. Camping gas bottles with built-in check valve (blue bottle with max. 2.5 or 3 kg content) are can be used in exceptional cases with a safety valve.
- ▶ Use the shortest possible tube lengths (150 cm max.) for external gas bottles.
- ▶ Never block the floor ventilation openings below the gas bottles.

## 2.6 Electrical system



- ▶ Only allow qualified personnel to work on the electrical system.
- ▶ Prior to carrying out work on the electrical system, switch off all devices and lights, disconnect the battery and disconnect the vehicle from the mains.
- ▶ Only use original fuses with the stipulated values.
- ▶ Only replace defective fuses when the cause of the defect is known and has been remedied.
- ▶ Never bridge or repair fuses.

## 2.7 Water system



- ▶ Water left standing in the water tank or in the water pipes becomes undrinkable after a short period. Therefore, before each use of the vehicle, thoroughly clean the water pipes and the water tank. After each use of the vehicle completely empty the water tank and the water pipes.
- ▶ In the case of lay-ups lasting more than a week disinfect the water system before using the vehicle.



- ▷ If the vehicle is not used for several days or if it is not heated when there is a risk of frost, empty the entire water system. Leave the water taps on in central position. Leave the safety/drainage valve (if there is one) and all drain cocks open. Frost damage to appliances, frost damage to the vehicle and deposits in water-carrying components can be avoided in this way.

## Chapter overview

This chapter contains important information which has to be noted before commencing your journey or carrying out any tasks before the journey.

The instructions address the following topics:

- keys
- registration
- calculating the payload
- correct loading of the vehicle and bike rack
- load rack
- towing
- retracting and extending the entrance step
- storing the television
- storing the sink cover
- securing add-on parts
- using snow chains

At the end of the chapter there is a checklist which once again summarises the most important points.

### 3.1 Keys

The following keys are included with your vehicle:

Two keys for

- ignition lock
- fuel tank

Two keys for

- driver's door
- conversion door of the body
- drinking water filler neck
- external flaps

Always deposit a replacement key outside the vehicle. Make a note of the key number. Our authorised dealers and workshops can offer assistance in case of loss.

### 3.2 Registration

Your motorhome is a vehicle which must be registered. Observe national regulations on registration.

Please remember that certain countries require a separate national code sticker in addition to the EU plate.

### 3.3 Payload



- ▶ Overloading the vehicle and wrong tyre pressure can cause tyres to burst. You can lose control of the vehicle.
- ▶ Only the maximum permissible gross weight and the mass in a ready-to-drive condition, not the actual weight of the vehicle, is stated in the vehicle documents. For your own safety, we recommend that you have your loaded vehicle (with all passengers, luggage and personal objects) weighed on a public weighbridge before you set out on your journey.
- ▶ Adapt the speed to the payload. The stopping distance is increased if the payload is high.



- ▷ Do not exceed the maximum permissible gross weight stated in the vehicle documents by the payload.
- ▷ Built-in accessories and special equipment reduce the payload.
- ▷ Adhere to the axle load stated in the vehicle documents.

On loading, make sure that the payload's centre of gravity is as low as possible (directly above the floor of the vehicle). Otherwise this may affect the driving characteristics of the vehicle.

#### Maximum permitted payloads

Description	Load (kg)
Pull-down bed	200
Bunk bed	100
Roof load	200
Rear garage and rear storage space	200
Storage compartment, extendable	40
Bike rack	Double Triple
	60 60
Load rack (AL-KO)	150
Load rack (SAWIKO)	130

#### 3.3.1 Terms



- ▷ Technically speaking, the term "mass" has now replaced the term "weight". However, "weight" is still the term more frequent in common use. For better understanding, "mass" is therefore only used in the following sections for fixed formulations.
- ▷ All specifications according to EU norm DIN EN 1646-2.

#### Maximum permissible gross weight in a laden condition

The maximum permissible gross weight in a laden condition is the weight that a vehicle may never exceed.

The maximum permissible overall weight in laden condition consists of the **mass in ready-to-drive condition** and of the **payload**.

In the vehicle documents, the manufacturer has specified the maximum permissible gross weight in a laden condition.

#### Permitted mass

The permitted mass is the weight specified by the manufacturer for issuing the type approval. The permitted mass must never exceed the maximum permissible gross weight of the loaded vehicle.



## Mass in ready-to-drive condition

The mass in ready-to-drive condition is the weight of the ready-to-drive standard vehicle.

The mass in ready-to-drive condition is made up as follows:

- Unladen weight (mass of the empty vehicle) with factory-installed standard equipment
- Driver's weight
- Basic equipment weight

Unladen weight includes lubricants such as oils and coolants which have been filled, the on-board tool set, the spare wheel and a fuel tank which has been filled up to 90 %.

75 kg are calculated for the weight of the driver, regardless of how much the driver really weighs.

Basic equipment includes all equipment and fluids required for safe and proper vehicle use. The weight of the basic equipment includes:

- Water system filled up to 90 % (water tank and pipes)
- Gas bottles filled up to 90 %
- A full heating system
- A full toilet flushing system
- The power cables for the 230 V power supply
- The installation kit for an auxiliary battery if an auxiliary battery can be used

The waste water and sewage tanks are empty.

## Example for calculating the basic equipment

Water tank with 120 l	120 kg
Gas bottles (2 x 11 kg <sub>gas</sub> + 2 x 14 kg <sub>bottle</sub> )	+ 50 kg
Boiler with 12 l	+ 12 kg
230 V power cable	+ 4 kg
Installation kit for auxiliary battery	+ 20 kg
<b>Total</b>	<b>= 206 kg</b>

In the vehicle documents, the manufacturer specifies the mass in ready-to-drive conditions.

## Payload

The payload is made up as follows:

- Conventional load
- Additional equipment
- Personal equipment



- ▷ The vehicle's payload can be increased by reducing the weight in a ready-to-drive condition. To do this, it is allowed for example to empty the fluid containers or to remove the gas bottles.

You will find explanations on the individual components of the payload in the following text.

## Conventional load

The conventional load is the weight specified by the manufacturer for the passengers.

Conventional load means: 75 kg are calculated for every seat specified by the manufacturer, regardless of how much the passengers actually weigh. The driver's seat is already included as part of the mass in ready-to-drive condition and must **not** be calculated as part of the conventional load.

In the vehicle documents, the manufacturer specifies the number of seats.

**Additional equipment** Additional equipment includes accessories and special equipment. Examples of additional equipment include:

- Caravan coupling
- Roof rail
- Awning
- Bike or motorcycle rack
- Satellite unit
- Microwave oven

Chapter 15 lists the weights of the various items of special equipment; they may also be obtained from the manufacturer.

**Personal equipment** Personal equipment includes all items in the vehicle that are not included in the conventional load or in the additional equipment. For example, personal equipment can include the following:

- Foodstuffs
- Crockery
- Television
- Radio
- Clothes
- Bedding
- Toys
- Books
- Toiletries

No matter where kept, personal equipment also includes:

- Animals
- Bikes
- Boats
- Surfboards
- Sports equipment

For the personal equipment, according to the applicable regulations, the manufacturer must use a minimum weight that is determined according to the following formula:

**Formula** Minimum weight  $M$  (kg) =  $10 \times N + 10 \times L$

**Explanation**  $N$  = maximum number of people including the driver, as stated by the manufacturer  
 $L$  = total length of the vehicle in metres

### 3.3.2 Calculating the payload



- ▶ The payload calculation at the factory is partly based on all-inclusive weights. For safety reasons, the maximum permissible gross weight in a laden condition must not be exceeded.
- ▶ Only the maximum permissible gross weight and the mass in a ready-to-drive condition, not the actual weight of the vehicle, is stated in the vehicle documents. For your own safety, we recommend that you have your loaded vehicle (with all passengers, luggage and personal objects) weighed on a public weighbridge before you set out on your journey.

The payload (see section 3.3.1) is the difference in weight between

- Maximum permissible gross weight in a laden condition and
- Vehicle mass complete in a ready-to-drive condition.

**Example for calculating the payload**

	Mass in kg to be calculated	Calculation
Maximum permissible gross weight according to vehicle documents	3500	
Vehicle mass in a ready-to-drive condition, including basic equipment according to vehicle documents	- 3070	
<b>This results in a permissible payload of</b>	<b>430</b>	
Conventional load e.g.: 3 persons each weighing 75 kg	- 225	
Additional equipment	- 40	
<b>For the personal equipment this results in</b>	<b>= 165</b>	

The calculation of the payload from the difference between the maximum permissible gross weight in laden condition and the mass specified by the manufacturer in ready-to-drive condition is however only a theoretical value.

Only if the vehicle is weighed with full tanks (fuel and water), full gas bottles and complete additional equipment on a public weighbridge, can the actual payload be determined.

To do this, proceed as follows:

- First only drive the vehicle on to the weighbridge with the front wheels and have it weighed.
- Then drive the vehicle on to the weighbridge with the back wheels and have it weighed.

The individual values give the current axle loads. These are important for the correct loading of the vehicle (see section 3.3.3). The sum of these values is the current weight of the vehicle.

The actual payload is the difference between the maximum permissible gross weight in laden condition and the weighed vehicle weight.

This can be used to determine the weight that remains for the personal equipment:

- Determine the weight of the passengers and subtract it from the value for the actual payload.


The result is the weight that is permitted for the actual load of the personal equipment.

### 3.3.3 Loading the vehicle correctly



- ▶ For safety reasons, never exceed the maximum permissible gross weight in a laden condition.
- ▶ Distribute the load evenly on the left and right sides of the vehicle.



- ▶ Distribute the load evenly on both axles. In doing so, observe the axle loads specified in the vehicle documents. Observe the permissible load-carrying capacity of the tyres (see chapter 13).
- ▶ Heavy loads behind the rear axle can reduce the load on the front axle due to the leverage effect (). This applies especially to long rear extensions, if a motorbike is transported on the rear carrier or if there is a heavy load in the rear storage space. The release of the front axle negatively affects the driving quality, especially for front-driven vehicles.
- ▶ Store all objects in such a way that they cannot slip.
- ▶ Store heavy objects (awning, tin cans, etc.) close to the axles. Low-lying storage compartments whose doors do not open in the direction of travel are particularly suited for storing heavy objects.
- ▶ Stack light objects (laundry) in the roof storage cabinets.
- ▶ Load the bike rack with bicycles only (max. three units).

Large storage spaces, such as the rear garage, also have room for heavy objects (e.g. motorcycle). This might mean that the axle load on the rear axle is exceeded.

However, the individual axles may not be overloaded under any circumstances. That is why it is important, at which distance to the axles the load is stored.

To distribute the load correctly, you will need a scale, a tape measure, a calculator and some time.

Two simple formulas are needed to calculate the effect of the weight of the load on the axles:

#### Formulas

$A \times G : R = \text{weight on the rear axle}$

Weight on the rear axle – G = weight on the front axle

#### Explanation

A = distance between storage compartment and front axle in cm

G = weight of the load in the storage compartment in kg

R = wheelbase of the vehicle (distance between axles) in cm



- ▷ Measure the external distances horizontally from the centre of the front wheel to the centre of the storage compartment or to the centre of the back wheel.

#### Calculating axle loads:

- Multiply the distance between storage compartment and front axle (A) with the weight of the load in the storage compartment (G) and divide the result by the wheelbase (R). The result is the weight of the load in the storage compartment on the rear axle. Make a note of this weight and of the storage compartment.
- In a second step, subtract the weight in the storage compartment (G) from the weight calculated beforehand. If the result is a **positive** value (example 1), this means that the load on the front axle is **reduced** by this value. If the result is a **negative** value (example 2), this means that the load on the front axle is **increased**. Make a note of this value, too.
- Calculate all storage compartments of the vehicle in the same way.
- In a last step, add all weights calculated for the rear axle to the rear axle load and add (or subtract) all weights calculated for the front axle to (from) the front axle load.

How to determine rear axle load and front axle load is described in section 3.3.2.

If the calculated value exceeds the permissible axle load, the load must be distributed in a different way.

If the load on the front axle is too low, the grip of the tyres on the road is reduced (traction). This applies in particular to vehicles with front wheel drive. In this case, the load must be redistributed, too.

**Example calculation**

		<b>Example 1</b>	<b>Example 2</b>
Distance to the front axle	A	(A1) 450 (cm)	(A2) 250 (cm)
Weight in the storage compartment	G	x 100 (kg)	x 50 (kg)
Wheelbase of the vehicle	R	÷ 325 (cm)	÷ 325 (cm)
<b>Load on the rear axle (add to the axle load)</b>		<b>138.5 (kg)</b>	<b>38.5 (kg)</b>
Weight in the storage compartment		- 100 (kg)	- 50 (kg)
<b>Load relief to the front axle (subtract from the axle load)</b>		<b>38.5 (kg)</b>	
<b>Load on the front axle (add to the axle load)</b>			<b>-11.5 (kg)</b>

**3.3.4 Roof rail and ladder (special equipment)**



- ▶ Access the roof only when a roof rail has been fitted.
- ▶ Take care when stepping onto the ladder. There is danger of slipping when the ladder is moist or icy.
- ▶ Take care when stepping onto the roof. There is danger of slipping when the roof is moist or icy.
- ▶ Do not overload the roof. Road behaviour and brake reaction deteriorate as the roof load increases.



- ▷ If the vehicle is equipped with a roof rail, load racks can be mounted on the roof rail for roof loads (e.g. for surfboards, rubber boats or light canoes). Special girder systems are available as accessory. The authorised dealer or service centre will be happy to advise you.
- ▷ The maximum permissible roof load is 200 kg.
- ▷ The maximum localised load is 90 kg/100 cm<sup>2</sup>.
- ▷ Before stepping on to the roof, extensively cover the area you will be treading on. Materials with a smooth or soft surface are suitable, for example, a thick polystyrene panel.
- ▷ Secure roof loads with tension belts. Do not use rubber expanders.
- ▷ Observe the overall height of the vehicle when the roof rack is loaded.



- ▷ The driver's cabin should have a clearly visible notice stating the overall height. This eliminates the need for calculations at bridges and thoroughfares.




Fig. 1 Rear ladder

*Climbing on to the roof (rear ladder):*

- Hook the lower part of the ladder (Fig. 1,1) in the part of the ladder (Fig. 1,2) which is fastened to the rear, and place it on the ground.
- Carefully climb the ladder.

*Climbing on to the roof (telescopic ladder):*

- Carefully place the telescopic ladder (special equipment) against the side of the vehicle.
- Carefully climb the ladder.

### 3.3.5 Rear garage/rear storage space



- ▶ Observe the permissible axle loads and maximum permissible gross weight when loading the rear garage/the rear storage space.
- ▶ The maximum permitted load of the rear garage/the rear storage space is 200 kg. Do not exceed the permissible rear axle load.
- ▶ Observe: If the rear garage or (depending on the model) the rear storage space is **loaded** to its maximum capacity, this will **reduce the load** on the front axle due to the levering action. The driving quality is impaired.



- ▷ Depending on the vehicle equipment, clamping rails with clamping eyelets are mounted in the rear garage or in the rear storage space. Always secure loads onto the clamping eyelets. Always use tightening straps or lashing nets for securing the load, never rubber expanders.
- ▷ When clamping loads, always check that the clamping eyelets are placed tightly in the clamping rails. If the clamping eyelet is not anchored tightly in the clamping rail, the load may slide or loosen during forcible movements of the steering wheel or when braking.
- ▷ Distribute the load evenly. Excessive spot loads can lead to damages of the floor covering.
- ▷ Use the supporting system offered by your dealer if two-wheelers are transported in the rear garage.

### 3.3.6 Double floor



- ▶ Observe the permissible axle loads and maximum permissible gross weight when loading the double floor.



- ▷ Distribute the load evenly. Excessive spot loads can lead to damages of the floor covering.

### 3.3.7 Extendable storage compartment



- ▷ The maximum permitted extendable storage compartment load is 40 kg.

### 3.3.8 Bike rack (special equipment)



- ▶ Observe the permissible axle loads and maximum permissible gross weight when loading the bike rack.
- ▶ Bicycles may not jut out beyond the maximum width of the vehicle. Adjust the attachments for the bikes accordingly.
- ▶ Load the bike rack with bicycles only (max. three units).
- ▶ Fasten bicycles using the straps provided and check to see that they are secure after you have driven a few kilometres.
- ▶ Check the secure attachment of the bicycles on the bike rack after the first 10 km and then at each break in the journey.
- ▶ Do not use the bike rack as luggage rack or ladder.



- ▷ The bike rack is only to be used for transporting bicycles.
- ▷ The gross weight specified by the manufacturer must not be exceeded.
- ▷ The identification plate and rear lights must not be covered.
- ▷ The maximum permissible payload of the bike rack is 60 kg.
- ▷ When loading the bike rack, observe the centre of gravity. If the bike rack is only loaded with **one** bicycle, position the bicycle as closely as possible to the vehicle wall.
- ▷ Driving with a folded out bike rack without bicycles is not permitted.
- ▷ Before every journey, check:
  - Is the bike rack without bicycles folded in correctly?
  - Are the bicycles securely fastened to the bike rack using the bike rack belts?

#### Loading the bike rack with bicycles

When loading the bike rack, observe the centre of gravity. The centre of gravity of the bicycles must be as close as possible to the rear wall of the vehicle. The bike rack should always be loaded from the inside to the outside.

Loading the bike rack correctly:

- Depending on the model, fold the bike rack down or pull it out.
- Place the heaviest bicycle directly against the rear wall.
- Place the lightest bicycles in the centre or on the outside of the bike rack.

- Secure the front and rear wheels of each bicycle with the retaining straps on the bike rack.
- In addition, fasten the outermost bicycle depending on the model of the bike rack on the retaining clip or the retaining bracket and to the spacer respectively.

If the bike rack is only loaded with **one** bicycle, position the bicycle as closely as possible to the rear wall.

#### Bike rack, not lowerable



- ▷ Also read the manufacturer's instruction manual.



Fig. 2 Bike rack, not lowerable

The bike rack (Fig. 2) permits to easily transport 2 bicycles. Expansion for 3 bicycles is possible.

#### Loading the bicycles:

- Fold the swivel clip down.
- Place the bicycles on top and secure them with quick straps.
- Fasten the spacer to the frame of the outermost bicycle.

### 3.3.9 Removable load rack AL-KO (special equipment)



- ▶ Do not exceed the rear axle load.
- ▶ Heavy loads behind the rear axle can reduce the load on the front axle due to the leverage effect ( $\frac{1}{2}$ ). This applies especially to long rear extensions, if a motorbike is transported on the rear carrier or if there is a heavy load in the rear storage space. The release of the front axle negatively affects the driving quality, especially for front-driven vehicles.
- ▶ Always make sure to store the load roadworthy and secure it against falling.
- ▶ The load may not jut out beyond the maximum width of the vehicle. The lighting and the official licence plate on the load rack may not be covered by the load.



- ▷ The load rack and caravan coupling may not be used simultaneously.





- ▷ The load rack has a EG type approval number.
- ▷ Have your dealer or service centre install the load rack.
- ▷ Observe the country-specific regulations.
- ▷ Also read the manufacturer's instruction manual.

The load rack permits transport of a load (e.g. a motorcycle or a motor scooter) weighing up to 150 kg. Always remove the load rack after use.




Fig. 3 Quick closure

*Installation:*

- Apply the handbrake.
- Insert the supports on the left and on the right into the holders on the frame and secure them with a quick closure (Fig. 3,1).
- Connect the electrics between the load rack and the vehicle.

*Removal:*

- Apply the handbrake.
- Disconnect the electrics between the load rack and the vehicle.
- Open the quick closure (Fig. 3,1) and pull the support from the holders on the frame.

### 3.3.10 Load rack SAWIKO (special equipment)



- ▶ Do not exceed the rear axle load.
- ▶ Heavy loads behind the rear axle can reduce the load on the front axle due to the leverage effect ( $\frac{L}{L_0} \cdot \frac{L_1}{L_0}$ ). This applies especially to long rear extensions, if a motorbike is transported on the rear carrier or if there is a heavy load in the rear storage space. The release of the front axle negatively affects the driving quality, especially for front-driven vehicles.
- ▶ Always make sure to store the load roadworthy and secure it against falling.
- ▶ The load may not jut out beyond the maximum width of the vehicle. The lighting and the official licence plate on the load rack may not be covered by the load.



- ▷ The load rack and caravan coupling may not be used simultaneously.



- ▷ The load rack has a EG type approval number.
- ▷ Have your dealer or service centre install the load rack.



- ▷ Observe the country-specific regulations.
- ▷ Also read the manufacturer's instruction manual.

The load rack permits transport of a load weighing up to 130 kg. For the transport of the load different attachments are available. They are e.g. motorcycle rack, bike rack or a transport box. Our authorised dealers and service centres will be happy to advise you.

### 3.4 Towing



- ▶ Care is to be taken when connecting and detaching a trailer. Risk of accident and injury!
- ▶ No persons are to be between the towing vehicle and the trailer during positioning for connecting and detaching.
- ▶ Observe the permissible nose weight and rear axle load of the towing vehicle. Nose weight and rear axle load must not be exceeded. The values of the nose weight and rear axle load are included in the documents of the vehicle and the caravan coupling.



- ▷ Trailer with an overrun brake: Do not connect or detach trailer with the overrun brake on.
- ▷ Caravan coupling with detachable ball neck: If the ball neck is mounted incorrectly, there is the danger of the trailer breaking away. Observe the instruction manual for the caravan coupling.

### 3.5 Caravan coupling (special equipment)



- ▶ When mounting a caravan coupling, see the vehicle documents for information on maximum nose weight and caravan load.
- ▶ Retighten the caravan coupling fixing screws after 1000 operating hours.



- ▷ The load rack and caravan coupling may not be used simultaneously.



- ▷ An entry must be made in the vehicle documents in order to attach a caravan coupling. The required documents are enclosed with the caravan coupling.
- ▷ Also read the manufacturer's instruction manual.



Fig. 4 Caravan coupling

**Entry in the vehicle documents**

Have your dealer or service centre install the add-on parts. They will also take care of all the formalities for you.

### 3.6 Entrance step (partially special equipment)



- ▶ Before commencing the journey and after short interruptions of the journey, ensure that the entrance step is completely retracted.
- ▶ Do not stand in the direct range of the entrance step while it is being retracted or extended.
- ▶ Do not step on the entrance step until it has extended completely. There is a risk of injury.
- ▶ Do not under any circumstances raise or lower persons or loads with the entrance step.



- ▷ Take note of the different step heights and make certain that the ground is firm and even when exiting.
- ▷ Do not grease or lubricate the pivot bearing and joints of the entrance step (see chapter 11).



- ▷ The switch to operate the entrance step is located on the inside of the vehicle in the area of the conversion door.
- ▷ If the entrance step is not retracted and locked in place correctly, a red indicator lamp lights up on the dashboard when the ignition is switched on.
- ▷ Follow the warning notice on the entrance step.

The vehicles have an electrically extendable entrance step.




Fig. 5 Warning notice for entrance step




Fig. 6 Operating switch entrance step

Before stepping on the entrance step, fully extend it (Fig. 5).

- Extending:* ■ Press the rocker switch (Fig. 6,1) down and hold it pressed (at least 3 seconds) until the entrance step has extended completely.
- Retracting:* ■ Press the rocker switch (Fig. 6,1) up until the entrance step has retracted completely.



Fig. 7 Indicator lamp

When the ignition is switched on and the entrance step is extended, an indicator lamp (Fig. 7,1) is illuminated on the dashboard.

### 3.7 Television (special equipment)



- ▶ Before commencing the journey, remove the television from the support and store it securely.
- ▶ Before commencing the journey, place and secure the flat screen and screen support in the initial position. If the screen holder is installed in a TV cabinet: Close TV cabinet.
- ▶ Before commencing the journey, ensure that the antenna is in park position. Danger of accidents! Park position means: The antenna points towards the back, is fully lowered and is locked in this position.



- ▷ If there is a risk of frost, do not leave the flat screen television in the vehicle.



- ▷ Further information on positioning the flat screen can be obtained from chapter 6.

### 3.8 Sink and drain basin covers



- ▶ In the event of an accident or emergency braking, the loose sink (Fig. 8,1) and drain basin covers could injure the occupants of the vehicle. Before commencing the journey, take the loose covers off and store them securely in the kitchen unit or wardrobe.



Fig. 8 Sink cover

### 3.9 Securing add-on parts



- ▶ In the event of an accident or emergency braking, loose add-on parts could injure the occupants of the vehicle. Before setting off, secure loose add-on parts in the holders provided or stow them in a secure place inside the vehicle.



- ▷ Unsecured flaps and doors can spring open during the journey and damage parts of the interior. Secure all flaps and doors before setting off.

Add-on parts are, for example, inner doors or partition walls. See section 6.3 for furniture flaps.



Fig. 9 Shower partition

*Securing add-on parts:*

- Secure doors or partition walls (Fig. 9,1) with the locks or means of securing provided.

### 3.10 Snow chains (special equipment)



- ▷ Only mount snow chains if there is a clearance of at least 50 mm between the tyres and the vehicle body.
- ▷ When using snow chains, the tyres, wheel suspension and steering are subjected to an additional load. When using snow chains, drive slowly (maximum speed 50 km/h) and only on streets which are completely covered with snow. Otherwise the vehicle could be damaged.
- ▷ Observe the fitting instructions issued by the manufacturer of the snow chains.
- ▷ Do not fit snow chains on alloy wheel rims.



- ▷ If the drive axle of the vehicle has twin tyres (2 tyres next to each other), mount the the snow chains to the outer tyres.

The use of snow chains is subject to the legal regulations of the individual countries.

- Always mount snow chains to the drive wheels.
- After a few metres, check the tension of the snow chains.

### 3.11 Road safety



- ▶ Check tyre pressure before a journey or every 2 weeks. Wrong tyre pressure causes excessive wear and can lead to damage or even to tyre burst. You can lose control of the vehicle.

Before commencing the journey, work through the checklist:

#### Base vehicle

No.	Checks	Checked
1	All vehicle documents are on board	
2	Tyres in proper condition	
3	Vehicle lighting, brake lights and reversing lights function	
4	Oil levels for engine, gearbox and power steering controlled	
5	Coolant and fluid for windscreen washers filled up	
6	Brakes function	
7	Brakes react evenly	
8	When braking, the vehicle remains in the lane	

#### Housing body, outside

9	Awning completely retracted	
10	Roof free of snow and ice (in winter)	
11	External connections and lines disconnected and stored away	
12	External supports removed	
13	Fitted supports retracted and fixed in place	
14	Wheel chocks removed and stored away	

No.	Checks	Checked
15	Entrance step retracted (observe indicator lamp)	
16	External flaps closed and locked	
17	Rear conversion door closed	
18	Overall height of the vehicle including roof rack when loaded measured and noted. Keep the height information close at hand in the driver's cabin	


## Housing body, inside

19	Windows and skylights closed and locked	
20	Television removed from the support and securely stored	
21	Flat screen secured	
22	Television antenna retracted (if one is built in)	
23	Loose parts and add-on parts stored away or fixed in position	
24	Open storage spaces empty	
25	No gas cartridges or other easily flammable materials stored in the roof cupboard of the awning light	
26	Store sink and drain basin covers securely	
27	Refrigerator door secured	
28	Refrigerator set to 12 V operation	
29	All drawers and flaps closed	
30	All doors secured	
31	Pull-down bed secured	
32	Children's seats mounted to seats with three-point safety belts	
33	Swivel seat locking device for driver's seat and front passenger's seat locked	
34	Shades in the driver's cabin opened and secured	

## Gas system

35	Gas bottles firmly fixed in the gas bottle compartment so that they are unable to turn	
36	Protective cap set on top of the gas bottle	
37	Regulator tap on the gas bottle and gas isolator taps are closed	

## Electrical system

38	<p>Check the battery voltage of the starter and living area battery (see chapter 8). If the panel indicates that the battery voltage is too low, the respective battery will need to be recharged. Observe the notes and instructions in chapter 8</p> <p> ▷ Commence journey with fully charged starter and living area batteries.</p>	
----	--	--





## Chapter overview

This chapter contains instructions on how to drive the motorhome.

The instructions address the following topics:

- the parking distance control
- reversing camera with LCD monitor
- driving speed
- brakes
- seat belts
- child restraint system
- seats and headrests
- the backrest adjustment mechanism for the bench
- seating arrangement
- electrical window winders
- electrically adjustable external mirrors
- Roman shades in the driver's cabin
- bonnet
- washer nozzles
- windscreen washer fluid container
- filling the tank

### 4.1 Driving the motorhome



- ▶ The base vehicle is a commercial vehicle (small truck). Adjust your driving technique accordingly.
- ▶ Before commencing the journey and after short interruptions of the journey, ensure that the entrance step is completely retracted.
- ▶ During the journey, seat belts should always be worn at the seats that have seat belts mounted.
- ▶ Never open your seat belts when travelling.
- ▶ Passengers must remain in the seats provided.
- ▶ The doors must remain locked.
- ▶ Avoid braking with a jerk.
- ▶ If a navigation system is used, only change the destination when the vehicle is stationary. Drive to a car park or stop in a safe area when changing the destination.
- ▶ Do not play DVDs using the monitor of the navigation system during the journey.



- ▷ Drive slowly on poor roads.
- ▷ Take extreme care when driving onto ferries, crossing uneven roads and driving in reverse. Because of the relatively large overhang, larger vehicles might swing out and "touch ground" in unfavourable conditions. This can cause damage to the underbody or to parts fitted there.



- ▷ If an accident occurs as a result of these instructions not being observed, the manufacturer will not be responsible for damages caused.
- ▷ The safety measures stipulated in chapter 2 have to be observed.



- ▶ If a reversing camera is installed in the vehicle, the camera is automatically switched on when driving in reverse gear.
- ▶ If the vehicle is equipped with the automatic transmission Comfort-Matic from Fiat, please note the following: The acoustic signal described in the instruction manual for Comfort-Matic is not active in our vehicles. No warning tone will sound.

## 4.2 Parking distance control (special equipment)



- ▶ Be particularly careful when driving backwards. Risk of accident and injury.
- ▶ The parking distance control is only an auxiliary appliance and may not necessarily recognise all obstacles. The driver of the vehicle is responsible for safety. If the device fails or there is a malfunction and damage occurs, then claims cannot be asserted against the vehicle manufacturer.




Fig. 10 Parking distance control operating unit

- 1 Position LED
- 2 On/Off key
- 3 Distance display
- 4 Display

### Short description

The parking distance control serves as an aid for parking. The distance is measured by the ultrasonic echo sounder method. The distance is calculated during the runtime of a reflected ultrasonic signal.

In the passenger compartment, an operating unit with a display (Fig. 10) shows the distance to the obstacle. At the same time, an acute signal sounds as a warning.



- ▶ When you switch on the ignition, the parking distance control carries out the system check independently. During this, all LEDs and segments (bars on the display) light up briefly and a beep signal is heard. If, after the system check, the red LED of the distance display (Fig. 10,3) flashes and a fast repeating warning tone is heard, the system has recognised a sensor defect. The defective sensor is shown on the display (Fig. 10,4).

There are two ways to activate the parking distance control:

*Activating by going into reverse gear:*

- Switch on the ignition and start the engine.
- Go into reverse gear.  
The display illuminates and an "ON" appears in the display. The parking distance control is ready to measure.

*Activating by pressing the On/Off key on the operating unit:*

- Press On/Off key (Fig. 10,2).  
The display illuminates and an "ON" appears in the display. The parking distance control is ready to measure.

- Switching off:*
- The parking distance control can be switched off at all times independent of the selected switch-on method using the On/Off key (Fig. 10,2).

### Distance display

The distance between the vehicle and the obstacle is issued in three ways: The display (Fig. 10,4) shows the distance in steps of 5 cm. The lowest distance measured by a sensor is shown. What sensor delivers the measurement is shown by the illumination of the corresponding position LED (Fig. 10,1).

The three different-coloured LEDs (Fig. 10,3) are the second way of displaying. The change of the colours from green or yellow to red signals that an obstacle is coming nearer.

In addition to the optical displays, an acoustic signal (sequence of tones) is issued, which changes in relation to the distance. If the distance between the vehicle and obstacle is reduced, the time intervals between the tone impulses also become shorter until it is a continuous tone.



- ▷ Further information can be obtained in the device manufacturer's instruction manual.

## 4.3 Reversing camera (partially special equipment)



Fig. 11 Reversing camera



Fig. 12 LCD monitor for reversing camera

Depending on the model, a reversing camera (Fig. 11,1) with LCD monitor (Fig. 12,1) is installed in the vehicle.

The camera and the LCD monitor are switched on automatically when the ignition is switched on or if the vehicle's engine is running and you drive in reverse gear. The system is switched off using the "POWER" push button (Fig. 12,5) on the LCD monitor. It is also switched on manually here.

You can adjust the brightness using the "BRIGHT" control knob (Fig. 12,2) on the LCD monitor. You can adjust the colour using the "COLOR" control knob (Fig. 12,3) on the LCD monitor.

A recorder or a receiver can also be connected to the LCD monitor. The volume of the audio signals can be adjusted using the "VOLUME" control knob (Fig. 12,4).

## 4.4 Driving speed



- ▶ The vehicle is equipped with a powerful engine. This means there are sufficient reserves in difficult traffic situations. This high power enables a high maximum speed and requires above-average driving ability.
- ▶ The vehicle provides a large contact surface for wind. A sudden cross-wind can be especially dangerous.



- ▶ Uneven or one-sided loading affects road performance.
- ▶ Driving on unknown streets, you may encounter hazardous road conditions and unexpected driving situations. Therefore, in the interest of safety, make sure your driving speed is appropriate to any given driving situation and environment.
- ▶ Adhere to the national legal speed limits.

#### 4.5 Brakes



- ▶ Have defects on the braking system immediately remedied by an authorised specialist workshop.



- ▷ Avoid block brakings. Block braking gives the tyres "brake plates" of varying strength. This reduces driving comfort. It might even make the tyres unserviceable.

#### Before each journey

Before each journey, check by means of a braking test:

- Do the brakes function?
- Do the brakes react evenly?
- Does the vehicle remain in the lane when braking?

#### 4.6 Seat belts

The vehicle is equipped with automatic three-point safety belts in the living area on the seats for which seat belts are compulsory by law. National regulations apply seat-belt fastening.



- ▶ Fasten your seat belts before the beginning of the journey and keep them fastened during the journey.
- ▶ Do not damage or trap belts. Have damaged seat belts changed by an authorised specialist workshop.
- ▶ Do not alter the belt fixing devices, automatic seat belt winders and the belt clips.
- ▶ Inspect the screwed connections of the seat belts from time to time in order to ensure that they are correctly seated.
- ▶ Only use one seat belt for **one** adult person.
- ▶ Do not belt in objects together with persons.
- ▶ Seat belts are not sufficient for persons who are less than 150 cm tall. In these cases use additional restraining devices. Observe test certificate.
- ▶ Factory-set three-point safety belts must be used when attaching child restraint systems.
- ▶ After an accident, replace the seat belts.
- ▶ During the journey, do not tilt the backrest too far backwards. Otherwise the functionality of the seat belt is no longer guaranteed.

#### 4.6.1 Fastening the seat belt correctly



- ▶ Do not twist the belt. The belt must be positioned smoothly against the body.
- ▶ When fastening the seat belt, adopt the correct sitting position.

The seat belt is fastened correctly when a fist can be passed between the body and the seat belt.

#### 4.7 Child restraint systems



- ▶ When travelling, secure children under 13 years of age that are smaller than 150 cm, with a suitable and officially approved child restraint system.
- ▶ Factory-set three-point safety belts must be used when attaching child restraint systems.
- ▶ Fasten the childrens' seat belts before commencing the journey and make sure that their seat belts are kept fastened during the journey.
- ▶ If a front passenger airbag is fitted in the vehicle, do not use a child restraint system (Reboard systems) that faces the back of the front passenger's seat. Follow warning notices in the vehicle.

Child restraint systems are divided into five classes:


Class	Body weight	Approximate age
0	Up to 10 kg	Up to 9 months
0+	Up to 13 kg	Up to 18 months
I	9 kg to 18 kg	9 months to 4 years
II	15 kg to 25 kg	3 years to 7 ½ years
III	22 kg to 36 kg	6 years to 12 years

#### 4.8 Pilot seats for the driver's and front passenger's seats



- ▶ Before commencing the journey, rotate all swivel seats in the direction of travel and lock in position.
- ▶ The seats must remain fixed in position during the journey and are not to be rotated.

### 4.8.1 Seats (Aguti)



- 1 Lengthways adjustment
- 2 Armrest adjustment
- 3 Rotating
- 4 Backrest adjustment

Fig. 13 Driver's seat and front passenger's seat

#### Rotating seats

The seats can be rotated in any direction. The seats can only be locked in position in the direction of travel.

- Push both armrests upward.
- Push the driver's seat/front passenger's seat backwards or into the central position.
- Operate the release lever (Fig. 13,3). The latch is released.
- Rotate the seat.

#### Adjusting the armrest

The height of the armrests is infinitely adjustable.

- Turn the knurled wheel (Fig. 13,2) upwards or downwards.

#### Adjusting an appropriate seating position

The position of the driver's and front passenger's seats can be adjusted. The handles which are required for this purpose are positioned to the front, right or left of the seat.

- Pull the handle (Fig. 13,1). The seat can be moved forward or backward.
- Release handle. The seat runner automatically locks into the desired position.
- Turn the knurled knob (Fig. 13,4). The angle of the backrest can be adjusted.

### 4.8.2 Seats (Aguti-Liner)



Fig. 14 Seat adjustment



Fig. 15 Armrest adjustment

#### Rotating the seat

The seats can be rotated in any direction. The seats can only be locked in position in the direction of travel.

### Moving seat in lengthways direction

- Push both armrests upward.
- Push the seat backwards or into the central position.
- Operate the release lever (Fig. 14,3). The latch is released.
- Rotate the seat.

Adjust the driver's seat so that the driver can depress the pedals comfortably.

- Pull the bar (Fig. 14,1) upwards.
- Push the seat forwards or backwards.
- Release the bar. The seat must audibly lock into place.

### Setting the seat inclination

Adjust the seat inclination so that the thighs rest on the seat surface without any pressure.

- Pull the lever (Fig. 14,2) upwards.
- Bring the seat into the desired inclination position by applying or relieving pressure.
- Release the lever. The seat must audibly lock into place.

### Adjusting the backrest

Adjust the angle of the backrest so that the steering wheel can be held with the arms slightly bent.

- Turn the knurled knob (Fig. 14,4). The backrest inclines forwards or backwards, depending on the rotation direction.

### Adjusting the armrest

The height of the armrests can be steplessly adjusted.

- Turn the knurled wheel (Fig. 15,1). The armrest inclines upwards or downwards, depending on the rotation direction.

## 4.9 Headrests



- ▷ The headrests are not adjustable for all models.




Fig. 16 Bench headrest

Before commencing the journey, adjust the headrests (Fig. 16,1) so that the back of the head is supported at approximately ear height. Push the headrests upwards or downwards by hand.

#### 4.10 Backrest adjustment mechanism for bench (partially special equipment)



- ▷ If the vehicle is equipped with the backrest adjustment, the bench cannot be converted into a bed.

The inclination of the backrest can be adjusted with the backrest adjustment mechanism "Travel Lounge".




Fig. 17 Backrest adjustment mechanism for bench

- Pull or press the bar (Fig. 17,1) under the seat (Fig. 17,3) upwards and hold it in this position.
- Push the seat on the rails (Fig. 17,2) to the desired position or carefully pull it forwards as far as it will go.
- Let go of the bar and move the seat forwards or backwards slightly until the seat can be heard to lock into place.

#### 4.11 Seating arrangement



- ▶ During the journey, persons are only to sit on the permitted seats. The authorised number of seats is stipulated in the vehicle documents.
- ▶ During the journey sitting on the divans is not permitted.
- ▶ Seat belts must be worn by all passengers.



Fig. 18 "Seat" symbol

Seats which may be used during travel are equipped with a sticker (Fig. 18).



## 4.12 Electrical window winders (partially special equipment)



- ▶ Remove hands and other objects from the window before closing.
- ▶ Even if you leave your vehicle just briefly, remove the ignition key from the steering lock. Otherwise children may be able to operate the window winder and injure themselves.

There is an electrical window winder on the driver's side of the vehicle.



Fig. 19 Switch for electrical window winders

- Opening:* ■ Press lower part of the switch (Fig. 19,2).
- Closing:* ■ Press upper part of the switch (Fig. 19,1).

## 4.13 External mirrors



Fig. 20 External mirrors

Depending on the model or equipment, the vehicle is equipped with two electrically adjustable and heated external mirrors (Fig. 20,1).

The switch used to adjust the external mirrors is located on the driver's door or on the left of the dashboard.




Fig. 21 External mirror adjustment and heater switch




Fig. 22 External mirror adjustment switch

#### Adjusting the external mirrors:

- Select the external mirror to be adjusted. To do so, turn the rotary switch (Fig. 21,2 or Fig. 22,1) to the left or right.
- Press the switch (Fig. 21,2 or Fig. 22,1) in the appropriate direction.

#### Switching on the external mirror heater:

- Press the switch (Fig. 21,1) on the dashboard. The switch indicator lamp shows it is in operation.

### 4.14 Roman shades for windscreen, driver's window and front passenger's window



- ▶ While travelling, the Roman shades for the windscreen, driver's window and front passenger's window must be open, in a fixed position and secured.



Fig. 23 Roman shade




Fig. 24 Lock for Roman shade

#### Opening and closing:

- Grasp the handle (Fig. 23,1) of the Roman shade and slide to the left or the right.

#### Securing:

- Push the handle (Fig. 24,1) onto the cap. The Roman shade is secured.

### 4.15 Bonnet



- ▶ When the bonnet is open, there is a risk of injury in the engine compartment.
- ▶ Even if the engine was switched off some time ago, it might still be hot. Danger of burns!



- ▶ Do not work in the engine compartment while the engine is running.
- ▶ The bonnet must be kept firmly closed and locked during the journey. After closing, check whether the lock has engaged. In order to carry this out, pull on the bonnet.




Fig. 25 Release lever for the bonnet (inside the vehicle)



Fig. 26 Release lever for the bonnet (outside)

- Opening:*
- Pull the lever (Fig. 25,1) on the left under the dashboard.
  - Place one hand on the top of the bonnet and one on the bottom and pull it forward as far as the safety hook allows.
  - Release the safety hook (Fig. 26,1). Do this by pulling the lever (Fig. 26,2) forward. The bonnet is unlocked.
  - Move the bonnet in an arch forwards and upwards.
- Closing:*
- Move the bonnet in an arch downwards and backwards until the latch locks audibly in place.
  - Check whether the bonnet is locked correctly. In order to carry this out, pull on the bonnet.

## 4.16 Washer nozzles




Fig. 27 Washer nozzle

The vehicle has washer nozzles with an adjustable angle of spray.

- Adjusting:*
- Use a suitable screwdriver to turn the adjusting screw (Fig. 27,1) until you reach the desired position.

#### 4.17 Filling with washer fluid




Fig. 28 Washer fluid container filler neck



Fig. 29 Filler neck in filling position

- Unlock and open the bonnet.
- Push the handle (Fig. 28,2) down and keep it pressed.
- Pull the flexible hose (Fig. 28,4) to the front and out of the holder (Fig. 28,3).
- Remove the lid (Fig. 28,1) from the filler neck of the washer fluid container.
- Twist the flexible hose in a way so that the filling hole points upwards (Fig. 29).
- Slowly fill in washer fluid.
- Push the lid onto the filler neck of the washer fluid container.
- Push the flexible hose back into the holder and lock it into place.

#### 4.18 Filling up with diesel



- ▶ No appliance operated by a naked flame (e.g. heater or refrigerator) may be in operation when filling the tank, on ferries or in the garage. Danger of explosion!
- ▶ The cap for the fuel filler neck and for the drinking water filler neck are very similar. Before filling the tank, always check the label.



- ▷ The fuel filler neck is labelled with the word "Diesel".

The fuel filler neck is situated on the exterior of the vehicle, at the front left.



Fig. 30 Cap for the fuel filler neck

- Opening:*
- Insert the key in the locking cylinder (Fig. 30,1) and turn it in an anticlockwise direction.
  - Remove cap.
- Closing:*
- Place the cap on the fuel filler neck.
  - Turn key in a clockwise direction.
  - Remove the key.
  - Check that the cap is fastened securely on the fuel filler neck.



## Chapter overview

This chapter contains instructions on how to pitch the vehicle.

The instructions address the following topics:

- handbrake
- entrance step
- wheel chocks
- operation of the supports
- 230 V connection
- refrigerator
- aligning the antenna
- retracting and extending the awning



- ▷ Pitch the vehicle so that it is as horizontal as possible. Secure the vehicle to prevent it from rolling.
- ▷ Animals (especially mice) can cause great damage to the interior of the vehicle. To prevent this from happening, regularly check the vehicle for damages or animal traces after pitching.

### 5.1 Handbrake

Firmly apply the handbrake when parking the vehicle.

### 5.2 Entrance step

In order to exit the vehicle, first fully extend the entrance step. Observe the indicator lamp on the dashboard.

For operating the entrance step, see section 3.6.

### 5.3 Wheel chocks

When parking the vehicle on slopes or inclines use the wheel chocks.

If the maximum permissible gross weight of the vehicle exceeds 4 tonnes, wheel chocks must be used when parking on gradients. The wheel chocks are provided as standard for vehicles with a maximum permissible gross weight exceeding 4 tonnes.

### 5.4 Supports

#### 5.4.1 General instructions



- ▷ Do not use the fitted supports as a vehicle jack. They supports are only for stabilising the parked vehicle to prevent the rear axle from bottoming out.
- ▷ When pitching the vehicle, ensure that the supports are evenly loaded.
- ▷ Before driving away, wind up the supports as far as they can go, fully retract and secure them.



- ▷ When the ground is soft, place a pad or block under the supports in order to prevent the vehicle from sinking into the ground.

### 5.4.2 Steady legs (SAWIKO) (special equipment)



- ▷ Depending on the model, the hexagonal nut has a joint, which can be used to bring the attached socket spanner into a more convenient position for turning.

In order to ensure their correct function, clean and grease the interior tubes of the steady legs regularly.

The length of the steady legs can be adjusted according to the model.




Fig. 31 Steady leg

#### Extending:

- Place the socket spanner on the hexagon nut (Fig. 31,1) and rotate until the steady leg is in a perpendicular downward position.
- If the length of the steady leg can be adjusted, remove the splint (Fig. 31,4) out of the support foot extension (Fig. 31,5).
- Pull out the support foot extension until it has reached the required length.
- Insert the splint in the support foot extension.
- Rotate the hexagonal nut until the steady leg rests completely on the ground and the vehicle is in a horizontal position.

#### Retracting:

- Place the socket spanner on the hexagon nut (Fig. 31,1) and rotate until the steady leg is clear of the ground.
- If the length of the steady leg can be adjusted, remove the splint (Fig. 31,4) out of the support foot extension (Fig. 31,5).
- Push in the support foot extension (Fig. 31,5) and insert the splint (Fig. 31,4) in the drilled hole in the support foot extension.
- Rotate the hexagonal nut (Fig. 31,1) until the steady leg has swung upwards and the guide (Fig. 31,2) has reached the very end of the slot (Fig. 31,3).



- ▷ Before commencing the journey, observe the following: Are all steady legs and support foot extensions retracted completely and secured with the splint?

### 5.4.3 Steady legs (AL-KO) (partially special equipment)



- ▷ Depending on the model, the hexagonal nut has a joint, which can be used to bring the attached socket spanner into a more convenient position for turning.

In order to ensure their correct function, clean and grease the interior tubes of the steady legs regularly.

The length of the steady legs can be adjusted according to the model.






Fig. 32 Steady leg

*Extending:*

- Place the socket spanner on the hexagon nut (Fig. 32,1) and rotate until the steady leg is in a perpendicular downward position.
- Remove the splint (Fig. 32,4) out of the support foot extension (Fig. 32,5).
- Extend the support foot extension until it has reached the required length.
- Insert the splint in the support foot extension.
- Rotate the hexagonal nut until the steady leg rests completely on the ground and the vehicle is in a horizontal position.

*Retracting:*

- Place the socket spanner on the hexagon nut (Fig. 32,1) and rotate until the steady leg is clear of the ground.
- Remove the splint (Fig. 32,4) out of the support foot extension (Fig. 32,5).
- Push in the support foot extension (Fig. 32,5) and insert the splint (Fig. 32,4) in the drilled hole in the support foot extension.
- Rotate the hexagonal nut (Fig. 32,1) with the socket spanner until the steady leg has swung upwards and the guide disc (Fig. 32,3) has completely retracted into the notch (Fig. 32,2).



- ▷ Before commencing the journey, observe the following: Are all steady legs and support foot extensions retracted completely and secured with the splint?

## 5.5 230 V connection

The vehicle can be connected to a 230 V power supply (see chapter 8).

## 5.6 Refrigerator

The 12 V operation of the refrigerator is only possible when the vehicle engine is running. When the vehicle engine is switched off, switch the refrigerator to 230 V operation or gas operation.

## 5.7 Satellite unit (special equipment)



- ▶ Before commencing the journey, ensure that the antenna is in park position. Danger of accidents!



- ▷ The vehicle must be still during the satellite search. Do not walk through the vehicle.
- ▷ Satellite reception is only possible, when the antenna is positioned in direct line of sight of the chosen satellite and the view is not blocked in any way.
- ▷ Further information can be obtained in the device manufacturer's instruction manual.

### 5.7.1 Equipment with automatic antenna alignment

The satellite unit is equipped with an automatic positioning unit. This automatic positioning unit ensures that the antennas are precisely aligned to the desired satellites.

Operation is menu-controlled (TV screen) using the remote control.

*Setting up the unit:*

- Switch on the television.
- Switch on the receiver on the appliance and via the remote control.
- Use the remote control to select the last selected setting (key "SEARCH"), the required program (key "OK") or the required satellite (key "SAT"). The satellite antenna repositions itself out of the park position and into search mode.

Depending on the selection the last selected TV program, the new selected TV program or the program selection of the satellite will be displayed when the system has found the satellite.

### 5.7.2 Equipment with semi-automatic antenna alignment

*Switching on the satellite unit:*

- Switch on the television and the receiver.
- On the electrical counter, press the "↑" key longer than three seconds. The satellite antenna lifts out of the park position and moves to the last position entered.

*Setting up the antenna:*

- Correct the angle of the antenna with the keys "↑" or "↓" according to the enclosed cards.
- Loosen the antenna mast clamp.
- Turn the antenna slowly. When the antenna finds the satellite, you will hear a signal tone.
- Optimise the reception by turning and tilting the antenna.
- Slightly retighten the antenna mast clamp.

*Lowering the antenna for driving:*

- Loosen the antenna mast clamp.
- Turn the antenna until the slot in the clamp and in the antenna mast are exactly over each other.
- On the electrical counter, press the "↓" button until "FE" appears in the display.
- Check whether the antenna is fully lowered and points to the rear of the vehicle.
- Slightly retighten the antenna mast clamp.
- Switch off the television and the receiver.

## 5.8 Awning (special equipment)



- ▷ Retract the awning in strong wind, rain or snow.
- ▷ In the case of light rain, shorten one of the support legs so that water can run off.
- ▷ Only retract the awning when the fabric is dry. When the awning must be retracted while the fabric is still wet: Extend the awning as soon as possible, in order to dry out the fabric.
- ▷ Before retracting, remove leaves and coarse dirt from the awning.



- ▷ Only use the awning for protection against the sun.
- ▷ Also read the manufacturer's instruction manual.

### Advantages of the awning

The advantages of an awning are:

- The awning provides shade.
- The awning creates a covered vestibule and thus expands the space.
- The vehicle thus becomes more homelike.



Fig. 33 Awning

### Putting up the awning:

- Use the manual crank to open up the awning (Fig. 33,1).
- Set up the brackets (Fig. 33,2) when the awning is open.



## Chapter overview

This chapter contains instructions about living in the vehicle.

The instructions address the following topics:

- opening and closing the doors and flaps
- light switches
- light control
- adjusting the halogen spotlights
- positioning the television
- ventilation of the vehicle
- opening and closing the windows and blinds
- opening and closing the Roman shades in the driver's cabin
- opening and closing the skylights
- modifying the table surfaces
- converting tables
- the adjustment mechanism of the divan
- use of the beds

### 6.1 Conversion door and driver's door



▶ Only drive with locked doors.



- ▷ Locking the doors can prevent them from opening of their own accord, e.g. during an accident.
- ▷ Locked doors also prevent forced entry, e.g. when waiting at traffic lights. However, in an emergency, locked doors make it more difficult for helpers to enter the vehicle.
- ▷ When leaving the vehicle, always lock the doors.

#### 6.1.1 Driver's door, outside (partially special equipment)




Fig. 34 Door lock of driver's door, outside

*Opening:*

- Insert the key into locking cylinder (Fig. 34,1) and turn until the door lock is unlatched.
- Return the key to the central position and remove it.
- Pull on the handle (Fig. 34,2). The door is open.

- Locking:*
- Insert the key into locking cylinder (Fig. 34,1) and turn until the door lock is engaged.
  - Return the key to the central position and remove it.

### 6.1.2 Driver's door, inside (partially special equipment)



Fig. 35 Door lock of driver's door, inside

- Opening:*
- Pull the door opening lever (Fig. 35,1). When this is done, the safety knob (Fig. 35,2) is automatically pressed upwards and the door lock is unlatched.
- Locking:*
- Close the door.
  - Push the safety knob down (Fig. 35,2).

### 6.1.3 Conversion door, outside (Hartal M1)



Fig. 36 Door lock of conversion door, outside

- Opening:*
- Insert the key into locking cylinder (Fig. 36,1) and turn until the door lock is unlatched.
  - Return the key to the central position and remove it.
  - Pull on the handle (Fig. 36,2). The door is open.
- Locking:*
- Insert the key into locking cylinder (Fig. 36,1) and turn until the door lock is engaged.
  - Return the key to the central position and remove it.

### 6.1.4 Conversion door, inside (Hartal M1)



Fig. 37 Door lock of conversion door, inside, locked

*Opening:* ■ Press lever (Fig. 37,2).

*Locking:* ■ Push the sliding trap (Fig. 37,1) down.

### 6.1.5 Conversion door, outside (Hartal Premium) (partially special equipment)




Fig. 38 Door lock of conversion door, outside

*Opening:* ■ Insert the key into locking cylinder (Fig. 38,2) and turn until the door lock is unlatched.  
 ■ Return the key to the central position and remove it.  
 ■ Pull on the handle (Fig. 38,1). The door is open.

*Locking:* ■ Insert the key into locking cylinder (Fig. 38,2) and turn until the door lock is engaged.  
 ■ Return the key to the central position and remove it.

### 6.1.6 Conversion door, inside (Hartal Premium) (partially special equipment)




Fig. 39 Door lock of conversion door, inside

- Opening:* ■ Pull on the handle (Fig. 39,2). The door lock is unlatched.
- Locking:* ■ Press the locking lever (Fig. 39,1).

### 6.1.7 Window of conversion door (Hartal Premium) (partially special equipment)

The conversion door window is fitted with a Roman shade.



Fig. 40 Roman shade

- Closing:* ■ Grip the Roman shade (Fig. 40,2) in the middle of the holding bar (Fig. 40,1), pull it upwards and then release it at the desired height. The Roman shade will stay at this height.
- Opening:* ■ Grip the Roman shade in the middle of the holding bar and push it down.

### 6.1.8 Folding insect screen on the conversion door (partially special equipment)



- ▷ Open the insect screen completely before closing the conversion door.





Fig. 41 Insect screen

*Closing:* ■ Pull out the insect screen completely by the bar (Fig. 41,1).

*Opening:* ■ Push the insect screen into its initial position by the bar (Fig. 41,1).

## 6.2 External flaps



- ▷ Before commencing the journey, close all external flaps and lock them.
- ▷ To open and close the external flap, open or close all locks that are fitted to the external flap.



- ▷ When leaving the vehicle, close all external flaps.

The external flaps fitted to the vehicle are all fitted with identical locking cylinders. Therefore, all locks can be opened with a single key.

### 6.2.1 Flap lock with recessed handle



- ▷ To open the external flap, pull all the lock handles fitted to that particular external flap at the same time.




Fig. 42 Flap lock with recessed handle

- Opening:*
- Insert key into locking cylinder (Fig. 42,1) and turn a quarter turn. The flap lock is unlatched.
  - Remove the key.
  - Pull on the lock handle (Fig. 42,2). The external flap is open.

- Closing:*
- Firmly close the external flap.
  - Insert key into locking cylinder and turn a quarter turn. The flap lock is locked.
  - Remove the key.

### 6.2.2 Flap lock, elliptical-shaped



- ▷ During rain, water can penetrate the opened flap lock. Therefore close the lock handle.




Fig. 43 Flap lock, elliptical-shaped, closed

- Opening:*
- Insert key into locking cylinder (Fig. 43,1) and turn a quarter turn in an anti-clockwise direction. The lock handle (Fig. 43,2) snaps out.
  - Remove the key.
  - Turn lock handle one quarter turn in an anticlockwise direction. The flap lock is open.
- Closing:*
- Firmly close the external flap.
  - Turn lock handle in a clockwise direction until it is horizontal. The flap lock is now engaged but not locked.
  - Insert key into locking cylinder.
  - Press down lock handle with key inserted and turn key a quarter turn in a clockwise direction. The lock handle will stay bolted.
  - Remove the key.

### 6.2.3 Flap lock with push button

Depending on the flap size the service flap is equipped with one or two lockable push-button locks.



Fig. 44 Push-button lock service flap

#### Opening:

- Insert the key into locking cylinder of the lockable push-button lock (Fig. 44,1) and turn a quarter turn. The push-button lock is unlatched.
- Remove the key.
- If equipped, unlock the second lockable push-button lock as well.
- Press the two push buttons of the push-button locks simultaneously with the thumb and open the service flap.

#### Closing:

- Close the service flap and press it shut. The push-button locks are now engaged but not locked.
- Insert the key into locking cylinder of the lockable push-button lock (Fig. 44,1) and turn a quarter turn. The push-button lock is locked.
- Remove the key.
- If equipped, lock the second lockable push-button lock as well.

### 6.2.4 Flap for the 230 V connection, square



- 1 Recessed grip
- 2 External flap

Fig. 45 Flap for the 230 V connection

#### Opening:

- Reach into the recessed grip (Fig. 45,1) on the external flap (Fig. 45,2) and swing the external flap upward.

#### Closing:

- Swivel the external flap downwards and press it shut.

### 6.2.5 Cap for the drinking water filler neck




Fig. 46 Cap for the drinking water filler neck




Fig. 47 Cap for the drinking water filler neck (alternative)



- ▶ The cap for the drinking water filler neck and for the fuel filler neck are very similar. Before filling the tank, always check the label.



- ▷ The drinking water filler neck is labelled by the word "WASSER" (water) (Fig. 46,1) or marked by the symbol  (Fig. 47,1).

#### Opening:

- Insert the key in the locking cylinder (Fig. 46,2 or Fig. 47,2) and turn it in an anticlockwise direction.
- Remove cap.

#### Closing:

- Insert the cap in the drinking water filler neck.
- Turn key in a clockwise direction.
- Remove the key.

### 6.3 Furniture flaps



- ▷ Before commencing the journey, close all furniture flaps and inner doors and lock them.
- ▷ The furniture flaps shown in this section are examples. Depending on the model, the locks and handles on the furniture flaps may differ to those displayed here.


### 6.3.1 Furniture flaps with push button



Fig. 48 Furniture flap with push button

- Opening:*
- Press inner part of the lock. The push button jumps out (Fig. 48).
  - Hold push button and open furniture flap.
- Closing:*
- Press furniture flap shut.
  - Press push button in until it locks. The furniture flap is closed correctly when the fastener locks into place.

### 6.3.2 Furniture flaps with handle and push button



- 1 Release knob
- 2 Handle

Fig. 49 Furniture flap with handle (example)

- Opening:*
- Press the release knob (Fig. 49,1) on the handle (Fig. 49,2) and hold it down.
  - Pull handle until furniture flap is open.
- Closing:*
- Press the furniture flap down until you can feel the flap hinge close and hear the lock snap into place.

## 6.4 Light switch

### 6.4.1 Entrance area



▷ The light switches shown in this section are examples. Depending on the model, the type and allocation of the light switches may differ to those displayed here.




Fig. 50 Light switch



Fig. 51 Awning light (partially special equipment)

The entrance area has light switches for the following lamps:

- Seating group lights (Fig. 50,1)
- Entrance lights (Fig. 50,2)
- Awning lights (Fig. 50,3)
- Living area lights (Fig. 50,4)

For models without awning light (Fig. 51) or night light in the entrance area the light switches are only used with one rocker switch.

### 6.4.2 Interior



▷ The lamps shown in this section are examples. Not all lamps used in the vehicle are shown. The examples are intended to clarify the possible positions for the light switches. The type and appearance of the light switches can deviate from those shown here.



Fig. 52 Toilet compartment lighting, light switch directly on the lamp



Fig. 53 Toilet compartment lighting, light switch separate from the lamp

Depending on the model, the light switches for the toilet compartment lighting are fitted at various points: Directly on the corresponding lamp (Fig. 52,1) or separate from the lamp below the toilet cabinet, underneath the wash basin or next to the entrance door (Fig. 53,1).



Fig. 54 Halogen lamp




Fig. 55 Recessed halogen light

The light switches in the living area are located directly on the corresponding lamp (Fig. 54,1) or next to the lamp (Fig. 55,1).

## 6.5 Light control

### Functions

Depending on the model, the vehicle is fitted with a central lighting system. This lighting system operates and dims single lamps or lamp groups that form part of the lighting system.

Furthermore, scene functions are integrated into the lighting system. These scene functions enable the user to save and automatically recall the desired brightness of all lamp groups.



- ▷ The lights that are not integrated into the lighting system (e.g. kitchen light, bathroom light or reading spotlights) are switched on and off via separate light switches.

### Light switch

The lights that are integrated into the lighting system are controlled via buttons on the panel (Fig. 56) or via buttons on two switches (Fig. 57 and Fig. 58). The switches are installed at various points in the vehicle.

### Buttons on the panel

All light control functions are available on the panel.



Fig. 56 Panel

**Buttons on the switch** Not all light control functions are available on the two switches.









Fig. 57 Buttons in the living area



Fig. 58 Buttons in the sleeping area

**Symbols** The symbols listed in the following table always have the same meaning.

Symbol	Signification
<b>M</b>	Light scene
	Main light, living area
	Indirect lighting, living area
	Main light, sleeping area
	Indirect lighting, sleeping area
	Night light
	All lamps "OFF"

**Operation** Each key has different functions:

Button	Press shortly	Keep pressed
Scene	Switch the preset scene on/off	Save the current scene setting (> 3 seconds)
Light	Switch the appropriate lamp on/off	Dim the appropriate lamp (> 1 second)

## 6.6 Spotlight



- ▶ Bulbs and light fittings can be extremely hot.
- ▶ Allow the light bulbs and lamp holders to cool down before touching them.
- ▶ If the light is switched on or still hot, there must always be a safety distance of at least 30 cm between stores or curtains and flammable objects. Fire hazard!






Fig. 59 Spotlight

**Turning:**

- Grasp the housing (Fig. 59,1) and turn it.

The housing can be turned in different directions:

- To the left and to the right
- Up and down

**Shifting:**

- Grasp the holder (Fig. 59,2).
- Push spotlight along the rail system to desired position.

## 6.7 Holder for flat screen



- ▶ Before commencing the journey, place and secure the flat screen and screen support in the initial position. If the screen holder is installed in a TV cabinet: Close TV cabinet.



- ▷ If there is a risk of frost, do not leave the flat screen television in the vehicle.

### 6.7.1 Holder on the column

The holder for the flat screen is attached to a column.




Fig. 60 Holder on the column

**Positioning:**

- Push the release lever (Fig. 60,2) to the side and turn the holder (Fig. 60,3) with the flat screen to the desired position.
- Press flat screen slightly upward and swivel it to the desired position. Three different inclination angles may be used.

- Storing away:*
- Turn flat screen back until the holder (Fig. 60,3) engages in the lock (Fig. 60,1).

### 6.7.2 Holder in the TV cabinet

The flat screen is attached to a console in the TV cabinet.



Fig. 61 Holder in the TV cabinet

- Positioning:*
- Push the unlocking bar (Fig. 61,1) in.
  - Pull out the extension (Fig. 61,2) as far as possible.
  - Swivel flat screen into the desired position.

- Storing away:*
- Swing back flat screen into its original position.
  - Push in the extension (Fig. 61,2) until the unlocking bar (Fig. 61,1) engages.

### 6.7.3 Holder with jointed arm

The flat screen is fastened to a jointed arm.




Fig. 62 Holder with jointed arm

- Positioning:*
- Pull the release knob (Fig. 62,3). The jointed arm (Fig. 62,4) is unlocked.
  - Swivel flat screen into the desired position.
  - Take hold of the flat screen at the top and bottom edge with both hands and set the desired angle of inclination.

- Storing away:*
- Turn the flat screen back into the original position until the holder (Fig. 62,1) engages in the lock (Fig. 62,2).

## 6.8 Ventilation



- ▶ The oxygen in the vehicle interior is used up by breathing and the use of gas operated appliances. That is why the oxygen needs to be replaced on a constant basis. For this purpose, forced ventilation options (e.g. skylights with forced ventilation, mushroom-shaped vents or floor vents) are fitted to the vehicle. Never cover or block forced ventilations from the inside or outside with objects such as e.g. a winter mat. Keep forced ventilations clear of snow and leaves. There is a danger of suffocation due to increased CO<sub>2</sub> levels.



- ▷ Although sufficient ventilation is provided, in certain weather conditions, condensation can form on metal objects (e.g. screwed connections in the floor).
- ▷ Additional cold spots can occur at thermal "bridges" (e.g. mushroom-shaped vents, skylight edges, sockets, filler necks, flaps, etc.).

### Condensation

Ensure that there is a continuous exchange of air by providing frequent and efficient ventilation. This is the only method for ensuring that condensation and resulting mould is not formed during cool weather. During the colder season, a pleasant living climate is created if heating output, air distribution and ventilation are synchronized. To avoid draft close the air outlet nozzles on the dashboard and set the air distribution of the base vehicle to air circulation.

If the vehicle is laid up for a longer period, occasionally ventilate it well, especially in summer as heat accumulation can occur. Do not only air the interior, but also the storage compartments which are accessible from the outside. Air the parking place as well if the vehicle is parked in a closed space (e.g. garage). The occurrence of condensation could lead to the formation of mould.

## 6.9 Windows



- ▷ The windows are fitted with a blind or Roman shade and with an insect screen or folding insect screen. After the latch has been released, the blind and insect screen automatically spring back to the initial position by tensile force. In order not to damage the tension mechanics, hold onto the blind or insect screen and allow it to slowly return to the initial position. The Roman shade and folding insect screen are made of thin woven fabric. In order not to damage the Roman shade or the insect screen, grasp the respective handle and carefully return it to the initial position.
- ▷ Do not keep blinds closed over a longer period of time as that can cause increased material wear.
- ▷ If the blind or the Roman shade is completely closed, exposure to direct sunlight can cause heat to accumulate between the blind/the Roman shade and the window. The window could be damaged. Therefore, if the shade is installed in the bottom blind box, close the shade only 2/3 when sunlight is intense. This allows the heat to escape between the window and the shade. If the shade is installed in the top blind box, close the shade fully and open it regularly. Also move the window into the "continuous ventilation" position.
- ▷ Before commencing the journey, close the windows.



- ▷ Depending on the weather, close the windows far enough to prevent moisture from entering.
- ▷ To open and close the window, open or close all catch levers which are fitted to the window.



- ▷ When leaving the vehicle, always close the windows.
- ▷ In extreme weather conditions or if the temperature fluctuates strongly, a light condensation film can form on the double-glazed acrylic glass. The glass is designed in such a way that condensation can evaporate when the external temperature increases. There is no danger of the double-glazed acrylic glass being damaged by condensation.

### 6.9.1 Hinged window with rotary hinges



- ▷ When opening the hinged windows, ensure that there are no torsional forces. Open and close the hinged windows evenly.




Fig. 63 Catch lever in "closed" position



Fig. 64 Hinged window with rotary hinges, open

- Opening:*
- Turn the catch lever (Fig. 63,3) a quarter turn towards the centre of the window.
  - Open the hinged window until the required position has been reached and use knurled knob (Fig. 64,1) to secure in position.

The hinged window remains locked in the required position.

- Closing:*
- Turn knurled knob (Fig. 64,1) until the latch is released.
  - Close the hinged window.
  - Turn the catch lever (Fig. 63,3) a quarter turn towards the window frame. The locking catch (Fig. 63,2) is located on the inside of the window catch (Fig. 63,1).




Fig. 65 Catch lever in the "continuous ventilation" position

### Continuous ventilation

With the catch lever, the hinged window can be placed in 2 positions:

- "Continuous ventilation" (Fig. 65)
- Firmly closed (Fig. 63)

To place the hinged window into the "continuous ventilation" position:

- Turn the catch lever (Fig. 65,3) a quarter turn towards the centre of the window.
- Lightly open the hinged window outwards.
- Return the catch lever to its initial position. The locking catch (Fig. 65,2) has to be moved into the recess of window catch (Fig. 65,1).

During the journey, the hinged window may not be in "continuous ventilation" position.

If it rains, the "continuous ventilation" hinged window position could lead to splashing water penetrating the living area. Therefore, close the hinged windows completely.

### 6.9.2 Hinged window with automatic hinges



- ▷ Open the window completely, to release the lock. If the locking device is not released and the window is closed nevertheless, there is the danger of the window breaking due to the massive counter-pressure.
- ▷ When opening the hinged windows, ensure that there are no torsional forces. Open and close the hinged windows evenly.
- ▷ If the catch lever is equipped with a safety knob, press the safety knob when operating the catch lever.




Fig. 66 Catch lever with safety knob in "closed" position



Fig. 67 Hinged window with automatic hinges

- Opening:*
- If necessary, press the safety knob (Fig. 66,3) down and hold it.
  - Turn the catch lever (Fig. 66,4) a quarter turn towards the centre of the window.
  - Open the hinged window until the required locking position is reached; the automatic hinge (Fig. 67,1) automatically locks in place.

The hinged window remains locked in the required position.




Fig. 68 Catch lever without safety knob in "closed" position



Fig. 69 Catch lever with safety knob in "closed" position

- Closing:*
- Open the hinged window as wide as necessary until the latch releases.
  - Close the hinged window.
  - If necessary, press the safety knob (Fig. 69,3) down and hold it.
  - Turn the catch lever (Fig. 68,3 or Fig. 69,4) a quarter turn towards the window frame. The locking catch (Fig. 68,2) is on the inner side of the window catch (Fig. 68,1) or the fork (Fig. 69,2) on the catch lever is completely on the inner side of the window catch (Fig. 69,1).




Fig. 70 Catch lever without safety knob in "continuous ventilation" position



Fig. 71 Catch lever with safety knob in "continuous ventilation" position

### Continuous ventilation

With the catch lever, the hinged window can be placed in two positions:

- "Continuous ventilation" (Fig. 70 or Fig. 71)
- Firmly closed (Fig. 68 or Fig. 69)

To place the hinged window into the "continuous ventilation" position:

- If necessary, press the safety knob (Fig. 71,3) down and hold it.
- Turn the catch lever (Fig. 70,3 or Fig. 71,4) a quarter turn towards the centre of the window.
- Lightly open the hinged window outwards.
- If necessary, press the safety knob (Fig. 71,3) down and hold it.
- Return catch lever to its initial position. Move the locking catch (Fig. 70,2) into the recess of the window catch (Fig. 70,1) or move the fork (Fig. 71,2) on the catch lever into the window catch (Fig. 71,1).
- If necessary, ensure that the safety knob is not pushed in but rather that it secures the catch lever.

During the journey, the hinged window may not be in "continuous ventilation" position.

If it rains, the "continuous ventilation" hinged window position could lead to splashing water penetrating the living area. Therefore, close the hinged windows completely.

### 6.9.3 Sliding window without lock



Fig. 72 Sliding window

- Opening:*
- Press handle (Fig. 72,1) and push or pull it forward or backward at the same time.
  - Open window half up to the required position.

*Closing:* ■ Close the window as far as possible and let the handle lock in place.

#### 6.9.4 Blind and insect screen



▷ Open blinds before commencing the journey. When the blinds are closed, vibrations can damage the spring shaft.

The windows are fitted with a blind and an insect screen. The blind and insect screen are adjusted separately.




Fig. 73 Hinged window

**Blind** The blind is located in the upper blind box.

*Closing:* ■ Pull blind at the handle (Fig. 73,2) downwards. If the blind is to be completely closed, it is suspended into the locking devices (Fig. 73,3) situated on both sides of the window frame.

*Opening:* ■ If the blind is completely closed: Press handle (Fig. 73,2) downwards and, at the same time, tilt it slightly inward. The blind can be taken out of the locking devices situated on both sides of the window frame.  
 ■ If the blind is in an intermediate position: Pull the handle (Fig. 73,2) slightly downwards until the locking device releases.  
 ■ Use handle to return blind slowly to its initial position.

**Insect screen** The insect screen is located in the upper blind box.

*Closing:* ■ Pull insect screen at the handle (Fig. 73,1) down and hang it into the locking devices (Fig. 73,3) situated on both sides of the window frame.

*Opening:* ■ Press handle (Fig. 73,1) downwards and, at the same time, tilt it slightly inward. The insect screen can be taken out of the locking devices situated on both sides of the window frame.  
 ■ Use handle to return the insect screen slowly to its initial position.



### 6.9.5 Roman shade and insect screen



Fig. 74 Hinged window

- Insect screen** Depending on the frame fitting, the insect screen is fitted into the window frame at the top or bottom.
- Closing:*
- Hold the bottom rod of the insect screen in the centre and pull it down carefully towards the bottom rod of the Roman shade.
  - Let the catch on the bottom rod of the insect screen snap into the Roman shade.
  - Continuous adjustment of the insect screen may be made by moving the bottom rods.
- Opening:*
- Push the bottom rods towards the Roman shade.
  - Hold the bottom rod of the insect screen in the middle and activate the catch.
  - Carefully return the bottom rod of the insect screen to the limit stop on the frame.
- Roman shade** Depending on the frame fitting, the Roman shade is fitted into the window frame at the top or bottom.
- Closing:*
- Hold the bottom rod of the Roman shade in the centre and pull it carefully towards the bottom rod of the insect screen.
  - Let the catch on the bottom rod of the Roman shade snap into the insect screen.
  - Continuous adjustment of the Roman shade may be made by moving the bottom rods.
- Opening:*
- Push the bottom rods towards the insect screen.
  - Hold the bottom rod of the Roman shade in the centre and activate the catch on the bottom rod of the insect screen.
  - Carefully return the bottom rod of the Roman shade to the limit stop on the frame.

### 6.9.6 Roman shades for windscreen, driver's window and front passenger's window




Fig. 75 Roman shade, driver's cabin window

- Closing:**
- Grasp the handle (Fig. 75,2) of the Roman shades and draw carefully until the magnetic catch keeps the Roman shades closed.
- Opening:**
- Using the handle, carefully push back the Roman shades.
  - Push the handle (Fig. 75,2) onto the cap (Fig. 75,1). The Roman shade is secured.

### 6.10 Skylights

Depending on the model, skylights with or without forced ventilation are fitted to the vehicle. If a skylight is fitted without forced ventilation, the forced ventilation is performed using mushroom-shaped vents.



- ▶ The apertures for forced ventilation must always be kept open. Never cover or block forced ventilations with objects such as e.g. a winter mat. Keep forced ventilations clear of snow and leaves.



- ▷ The skylights are fitted with a blind or Roman shade and with an insect screen or folding insect screen. After the latch has been released, the blind and insect screen automatically spring back to the initial position by tensile force. In order not to damage the tension mechanics, hold onto the blind or insect screen and allow it to slowly return to the initial position. The Roman shade and folding insect screen are made of thin woven fabric. In order not to damage the Roman shade or the insect screen, grasp the respective handle and carefully return it to the initial position.
- ▷ Do not keep blinds closed over a longer period of time as that can cause increased material wear.
- ▷ If the blind or the Roman shade is completely closed, exposure to direct sunlight can cause heat to accumulate between the blind/the Roman shade and the skylight. The skylight could be damaged. For that reason, close the blind/Roman shade only 2/3 of the way in direct sunlight. Open the skylight slightly or move it to ventilation position.
- ▷ Depending on the weather, close the skylights far enough to prevent moisture from entering.
- ▷ Do not climb on the skylights.
- ▷ Before commencing the journey, close the skylights.
- ▷ Before commencing the journey, check that the skylights are closed and locked.



▷ When leaving the vehicle, always close the skylights.

### 6.10.1 Heki skylight (mini and midi)




Fig. 76 Safety knob on the Heki skylight




Fig. 77 Heki skylight, guide

The Heki skylight is opened on one side only.

*Opening:*

- Press the safety knob (Fig. 76,2) and pull the bar (Fig. 76,1) down with both hands.
- Pull the bar (Fig. 77,1) in the guides (Fig. 77,2) to the rearmost position (Fig. 77,3).

*Closing:*

- Use both hands to push the bar (Fig. 77,1) slightly upwards.
- Push the bar back in the guides.
- Push the bar upwards with both hands until it is above the safety knob (Fig. 76,2).




Fig. 78 Heki skylight in ventilation position




Fig. 79 Ventilation position locking mechanism

#### Ventilation position

The Heki skylight can be put in two ventilation positions: Bad weather position (Fig. 78,1) and central position (Fig. 78,2). Depending on the model, the skylight can be locked in the central position with the latch (Fig. 79,1).

- Press the safety knob (Fig. 76,2) and pull the bar (Fig. 76,1) down with both hands.
- Pull the bar in the guides (Fig. 77,2) to the desired position.
- Push the bar slightly upwards and into the selected guide (Fig. 78,1 or 2) and lock if necessary.

**Roman shade** To close and open the Roman shade:

*Closing:* ■ Pull out Roman shade at the handle and release in the required position. The Roman shade will stay in that position.

*Opening:* ■ Slowly push the Roman shade at the handle to its initial position.

**Insect screen** To close and open the insect screen:

*Closing:* ■ Pull the insect screen by the handle to the opposite handle of the Roman shade.

*Opening:* ■ Press the rear part of the handle of the insect screen. The latch is released.  
■ Use handle to return the insect screen slowly to its initial position.

### 6.10.2 Wind-up skylight (partially special equipment)



Fig. 80 Wind-up skylight

The wind-up skylight can be opened using the manual crank.

*Opening:* ■ Rotate the hand crank (Fig. 80,2) until a resistance can be felt (max. opening angle 70°).

*Closing:* ■ Rotate the hand crank until the wind-up skylight is closed. The wind-up skylight can be locked after rotating two or three more times.  
■ Check the locking mechanism. To do so, press your hand against the acrylic glass.

**Roman shade** The Roman shade can be closed in any position, as desired. If the Roman shade is locked with the insect screen, the insect screen is also moved along on closing the Roman shade.

*Closing:* ■ Pull the handle of the Roman shade (Fig. 80,3) and release in the desired position. The Roman shade will stay in that position.

*Opening:* ■ Slowly push the Roman shade at the handle to its initial position.

**Insect screen** If the insect screen is locked with the Roman shade, the Roman shade is also moved along on closing the insect screen.

*Closing:* ■ Pull insect screen at the handle (Fig. 80,1) to the opposite handle of the Roman shade (Fig. 80,3) and allow to engage.

- Opening:*
- Press the handle of the insect screen (Fig. 80,1) at the back upwards and detach the insect screen from the Roman shade (Fig. 80,3).
  - Slowly push insect screen at the handle to its initial position.

## 6.11 Tables

### 6.11.1 Fixed table (extendable table-top)




Fig. 81 Fixed table

- Extending:*
- Pull the knob (Fig. 81,3) of the lock down and swing out the table-top extension (Fig. 81,2).

- Reducing size:*
- Swing the table-top extension (Fig. 81,2) under the table-top (Fig. 81,1) until the lock latches in place audibly.

The fixed table cannot be used as a bed foundation.

### 6.11.2 Fixed table (movable table-top)

The top of the fixed table can be moved both lengthways and crossways.




Fig. 82 Fixed table

- Moving in a lengthways direction:*
- Loosen knurled screw (Fig. 82,1).
  - Move table-top (Fig. 82,2) to the desired position.
  - Retighten the knurled screw.

- Moving in a crossways direction:*
- Loosen knurled screw (Fig. 82,3).
  - Move table-top (Fig. 82,2) to the desired position.
  - Retighten the knurled screw.

The fixed table cannot be used as a bed foundation.

### 6.11.3 Lift-off table



- ▶ Before commencing the journey, lower the table-top for safety reasons.



Fig. 83 Lift-off table

The top of the lift-off table can be moved both lengthways and crossways.

*Moving in a lengthways direction:*

- Undo the knurled screw (Fig. 83,5).
- Move the table-top (Fig. 83,1) to the desired position.
- Retighten the knurled screw.

*Moving in a crossways direction:*

- Undo the knurled screw (Fig. 83,3).
- Move the table-top (Fig. 83,1) to the desired position.
- Retighten the knurled screw.



- ▷ The table-top can only be completely lowered if the cushions have first been removed from the benches or if the table-top has been moved completely to the right and forward.

The lift-off table's lifting mechanism permits it to be used as a bed foundation.

*Conversion to bed foundation:*

- Swivel the lever (Fig. 83,2) under the table top (Fig. 83,1) by 180° to the left. The lifting mechanism in the table leg (Fig. 83,4) is unlocked.
- Press the table-top in the middle down to the stop limit and hold it down.
- Swivel back the lever by 180° to the right. The table-top remains in the lowest position.

*Move the table-top upwards:*

- Swivel the lever (Fig. 83,2) under the table top (Fig. 83,1) by 180° to the left. The table-top moves upwards to the limit stop.
- Swivel back the lever by 180° to the right. The table-top remains in the uppermost position.

## 6.12 Divan adjustment mechanism (partially special equipment)

The "Reliner<sup>®</sup>" mechanism allows you to adjust the seat, the neck cushion and the armrest of the divan.




Fig. 84 Adjusting the divan

*Adjusting the seat:*

- Pull up the loop (Fig. 84,2) and carefully pull the seat (Fig. 84,3) along the rails as far as it will go towards the middle.
- Let go of the loop and move the seat back and forth slightly until you hear it lock into place.

*Adjusting the neck cushion:*

- Hold the neck cushion (Fig. 84,4) in both hands and carefully move it up or down to the right position.

*Adjusting the armrest:*

- Hold the armrest (Fig. 84,1) in both hands and carefully move it up or down to the right position.

## 6.13 Beds

### 6.13.1 Pull-down bed (with lock)



- ▶ Switch off the reading lamps in the pull-down bed before the bed is pushed up. Fire hazard!
- ▶ Switch off the reading lamps on the underside of the pull-down bed when the bed is lowered. Fire hazard!
- ▶ The maximum permitted pull-down bed load is 200 kg.
- ▶ The pull-down bed is not to be used for the storage of luggage. When the bed is not being used, only place the bed linen which is required for two persons in it.
- ▶ Before commencing the journey, secure the pull-down bed. To do this, lock the pull-down bed.
- ▶ Never allow small children to remain in the pull-down bed without supervision.
- ▶ But in particular with regard to small children less than 6 years of age, users should ensure that they cannot fall out of the pull-down bed.
- ▶ Use separate children's beds or travel cots suitable for children.




Fig. 85 Lock




Fig. 86 Access ladder, catch

The pull-down bed is located in the driver's cabin above the seats.

#### Opening the pull-down bed:

- Rotate the driver's and front passenger's seats in the direction of travel, lock in position, push completely forwards and turn the backrest as far back as possible.
- Close the shade in the driver's cabin.
- Push the release knob (Fig. 85,1). The lock is released.
- With both hands, pull the pull-down bed down as far as it will go.



- ▷ When closing the pull-down bed, pull the side fabric panels inwards. This prevents the fabric from getting trapped in the lock of the pull-down bed.

#### Closing the pull-down bed:

- Use both hands to push pull-down bed upwards as far as it will go. When doing this, ensure that the snap latch engages audibly in the locking bracket.
- Check that the pull-down bed is locked correctly. To do this, pull down the pull-down bed firmly.

#### Access ladder

Always use the provided access ladder to climb up to the pull-down bed.

- Hang the access ladder (Fig. 86,4) with the two hooks (Fig. 86,1) on the rail (Fig. 86,2) of the frame of the pull-down bed.
- Push the two catches (Fig. 86,3) forward.

#### Roman shade

The Roman shade is fastened to the ceiling. Only let the Roman shade down if persons are already in the pull-down bed.



Fig. 87 Roman shade for pull-down bed

#### Closing:

- Unwind cord (Fig. 87,2) from of the button (Fig. 87,3).
- Carefully let down the Roman shade (Fig. 87,1) using the cord.



- Opening:*
- Using the cord (Fig. 87,2), carefully pull up the Roman shade (Fig. 87,1).
  - Wind cord several times around the button (Fig. 87,3).

### 6.13.2 Pull-down bed, electrically operated



- ▶ Switch off the reading lamps in the pull-down bed before the bed is pushed up. Fire hazard!
- ▶ Switch off the reading lamps on the underside of the pull-down bed when the bed is lowered. Fire hazard!
- ▶ The maximum permitted pull-down bed load is 200 kg.
- ▶ The pull-down bed is not to be used for the storage of luggage. When the bed is not being used, only place the bed linen which is required for two persons in it.
- ▶ Never allow small children to remain in the pull-down bed without supervision.
- ▶ But in particular with regard to small children less than 6 years of age, users should ensure that they cannot fall out of the pull-down bed.
- ▶ Use separate children's beds or travel cots suitable for children.
- ▶ Do not reach into the area between the bed and the side wall when lowering or raising. Danger of bruises!
- ▶ Only lower or raise the bed when there are no loads on it.
- ▶ Only lower the bed if the lowering area is clear.




Fig. 88 Manual control unit

#### Making ready for operation

After every power interruption (e.g. lay-up over winter), the electrical drive must be made ready for operation again. To do this, proceed as follows:

- On the manual control unit (Fig. 88,3) press both arrow keys (Fig. 88,1 and 2) simultaneously and keep them pressed until the pull-down bed has moved fully up or down and there is an audible beep tone.

#### Opening the pull-down bed:

- On the manual control unit (Fig. 88,3), press the bottom arrow key (Fig. 88,2) and keep it pressed until the pull-down bed has moved down into its end position.



- ▷ When closing the pull-down bed, pull the side fabric panels inwards. This prevents the fabric from getting trapped in the lock of the pull-down bed.

#### Closing the pull-down bed:

- On the manual control unit (Fig. 88,3), press the top arrow key (Fig. 88,1) and keep it pressed until the pull-down bed has moved up into its end position.

**Overload protection** If the pull-down bed meets an obstacle during opening or closing (e.g. a person or a headrest), the overload protection stops the movement. The pull-down bed cannot be moved further until after the overload protection has been reset.

*Performing a reset:*

- Switch off the 12 V power supply on the panel and then switch it back on.
- Use the arrow keys (Fig. 88,1 or 2) to move the pull-down bed in the opposite direction as far as the end position.




Fig. 89 Drive

**Emergency operation** If the pull-down bed can no longer be moved via the manual control unit (e.g. due to loss of the vehicle's power supply), it can also be operated manually. To do this, proceed as follows:

- Remove the connection (e.g. splint and pin) (Fig. 89,2) between the push rod (Fig. 89,1) and lever (Fig. 89,3).
- Open or close the pull-down bed manually.
- Contact customer service.

### 6.13.3 Fixed bed (gas-pressure springs)



Fig. 90 Fixed bed

A storage compartment is underneath the bed. Lift up the slatted frame to place items in the storage compartment or to empty it from the inside of the vehicle.

*Opening:*

- Lift the mattress forwards and set it down on the panel.
- Lift slatted frame. The gas-pressure springs (Fig. 90,1) hold the slatted frame open.

- Closing:*
- Press the slatted frame downwards against the resistance of the gas-pressure springs.
  - If necessary, push the mattress behind the panel.

### 6.13.4 Fixed bed (adjustable head section)



▶ Do not let the slatted frame fall down when closing the bed!



Fig. 91 Adjustable head section

Depending on the configuration, the head section of the slatted frame can be adjusted in several stages.

- Raising the head section:*
- Raise the head section (Fig. 91,2) of the slatted frame to the desired position. The support (Fig. 91,1) locks automatically into place.

The head section remains locked in the required position.

- Lowering the head section:*
- Raise the head section (Fig. 91,2) of the slatted frame until the lock is released.
  - Guide the head section downwards slowly.

### 6.13.5 Fixed bed, electrically adjustable



Fig. 92 Fixed bed, pulled out



Fig. 93 Fixed bed, retracted

The fixed bed (Fig. 92) can be adjusted in length via a manual control unit. This simplifies passage around the bed. When the foot section of the bed is shortened, the head sections are positioned at the same time (Fig. 93).



Fig. 94 Manual control unit

**Retracting:** ■ On the manual control unit (Fig. 94,2) push the "▼" button (Fig. 94,1) and keep it pressed. The foot section is retracted. The head sections are raised.

**Extending:** ■ On the manual control unit (Fig. 94,2) push the "▲" button (Fig. 94,3) and keep it pressed. The foot section is extended. The head sections are lowered.

**Adjusting the head sections:** ■ On the manual control unit (Fig. 94,2), press the "▼" button (Fig. 94,1) or "▲" button (Fig. 94,3) until the desired position is reached.

The head sections remain in the desired position.



Fig. 95 Drive

### Emergency operation

Proceed as follows if the bed can no longer be adjusted via the manual control unit:

- Release the connection (Fig. 95,2) between the push rod (Fig. 95,3) and slatted frame (Fig. 95,1).
- Slowly push the slatted frame all the way forward. When doing this, hold onto the head sections of the slatted frames.
- Contact customer service.

## 6.14 Converting seating groups for sleeping

### 6.14.1 Central bench with divan (narrow) (special equipment)




Fig. 96 Prior to conversion




Fig. 97 During conversion




Fig. 98 After conversion

- Convert the table (Fig. 96,3) to a bed foundation (see section 6.11).
- Lay the back cushion (Fig. 96,1) aside.
- Place the additional cushion (Fig. 97,7) on the table.
- Pull out the bedding box extension (Fig. 98,6).
- Place the seat cushion (Fig. 98,5) in the centre.
- Place the back cushion (Fig. 98,4) between the seat cushion and the wall.



## Chapter overview

This chapter contains instructions regarding the gas system of the vehicle. The instructions address the following topics:

- safety
- changing the gas bottles
- gas isolator taps
- external gas connection
- automatic switching facility
- the gas alarm system

The operation of the gas operation appliances of the vehicle is described in chapter 9.

### 7.1 General



- ▶ Before commencing the journey, when leaving the vehicle or when gas equipment is not in use, close all gas isolator taps and the main isolator tap on the gas bottle.
- ▶ No appliance operated by a naked flame (e.g. heater or refrigerator) may be in operation when filling the tank, on ferries or in the garage. Danger of explosion!
- ▶ Do not use appliances operated with a naked flame in closed spaces (e.g. garages). Danger of poisoning and suffocation!
- ▶ Only have the gas system maintained, repaired or altered by an authorised specialist workshop.
- ▶ Have the gas system checked by an authorised specialist workshop according to the national regulations before commissioning. This also applies for not registered vehicles. For modifications to the gas system have the gas system immediately checked by an authorised specialist workshop.
- ▶ The gas pressure regulator and exhaust gas pipes must also be inspected. The gas pressure regulator has to be replaced after 10 years at the latest. The vehicle owner is responsible for seeing that this is carried out.
- ▶ In case of a defect of the gas system (gas odour, high gas consumption) there is danger of explosion! Close regulator tap on the gas bottle immediately. Open doors and windows and ventilate well.
- ▶ If the gas system is defective: Do not smoke; do not ignite any open flames, and do not operate electric switches (light switches etc.).
- ▶ Before using the cooker make sure that there is sufficient ventilation. Open windows or the skylight.
- ▶ Do not use the gas cooker or gas oven for heating purposes.
- ▶ If there are several gas devices, each gas device must have its own gas isolator tap. If individual gas devices are not in use, close the respective gas isolator tap.
- ▶ Ignition safety valves must close within 1 minute after the gas flame has extinguished. A clicking sound is audible. Check function from time to time.
- ▶ The built-in gas devices are exclusively meant for use with propane or butane gas or a mixture of both. The gas pressure regulator as well as all built-in gas devices are designed for a gas pressure of 30 mbar.



- ▶ Propane gas is capable of gasification up to -42 °C, whereas butane gas gasifies at 0 °C. Below these temperatures no gas pressure is available. Butane gas is unsuitable for use in winter.
- ▶ Regularly inspect the gas tube fitted to the gas bottle connection for tightness. The gas tube must not have any tears and must not be porous. Have the gas tube replaced by an authorised specialist workshop no later than ten years after the manufacturing date. The operator of the gas system must see to it that the parts are replaced.
- ▶ Due to its function and construction, the gas bottle compartment is a space which is open to the exterior. Never cover or block up the standard forced ventilations. Otherwise gas that is emitted can not be diverted to the outside.
- ▶ Do not use the gas bottle compartment as storage space as it is not moisture-proof.
- ▶ Secure the gas bottle compartment against unauthorised access. To do this, lock the compartment.
- ▶ The regulator tap on the gas bottle must be accessible.
- ▶ Only connect gas-operated devices (e.g. gas grill) which have been designed for a gas pressure of 30 mbar.
- ▶ The exhaust gas pipe must be fitted tightly to the heating system and to the vent and must be sealed. The exhaust gas pipe must not show any evidence of damage.
- ▶ Exhaust fumes must be able to escape into the atmosphere unhindered and fresh air must be able to enter unhindered. For this reason, keep the exhaust pipe and intake openings clean and unobstructed (e.g. free from snow and ice). For this reason, no snow walls or aprons may lie against the vehicle.

## 7.2 Gas bottles



- ▶ Gas bottles are only to be transported within the designated gas bottle compartment.
- ▶ Place the gas bottles in vertical position in the gas bottle compartment.
- ▶ Fasten the gas bottles so that they are unable to turn or tilt.
- ▶ If the gas bottles are not connected to the gas tube, always place the protective cap on top.
- ▶ Close the regulator tap on the gas bottle before the gas pressure regulator or gas tube are removed from the gas bottle.
- ▶ Use your hands only to connect the gas pressure regulator or the gas tube to the gas bottles. Do not use any tools.
- ▶ Only use special gas pressure regulators with a safety valve designed for vehicle use. Other gas pressure regulators are not permitted and cannot meet the demanding requirements.
- ▶ Use the gas pressure regulator defroster if the temperature falls below 5 °C.
- ▶ Use only 11 kg or 5 kg gas bottles. Camping gas bottles with built-in check valve (blue bottle with max. 2.5 or 3 kg content) are can be used in exceptional cases with a safety valve.





- ▶ Use the shortest possible tube lengths (150 cm max.) for external gas bottles.
- ▶ Never block the floor ventilation openings below the gas bottles.



- ▷ With some models, the gas bottle compartment is located right next to the conversion door. With these models, only open the gas bottle compartment when the conversion door is closed. Danger from damages.



- ▷ For gas-operated units the gas pressure must be reduced to 30 mbar.
- ▷ Connect gas pressure regulator complete with safety valve directly to bottle valve.

The gas pressure regulator reduces the gas pressure in the gas bottle down to the operating pressure of the gas devices.

- ▷ For filling and connecting the gas bottles in Europe the accessories shops have corresponding Euro filling sets and Euro bottle sets.
- ▷ Information available at the dealers or service centre.
- ▷ For information on the gas supply in Europe see chapter 17.

### 7.3 Changing gas bottles



- ▶ When changing gas bottles, do not smoke or create any open fire.
- ▶ When you have changed the gas bottle, check whether gas escapes at the connection points and unions. Use a leakage search spray to spray the relevant connection point or union. These agents are available at the accessories shop.





Fig. 99 Gas bottle compartment

- Open external gas bottle compartment (see chapter 6).
- Close the regulator tap (Fig. 99,1) on the gas bottle (Fig. 99,2). Pay attention to the direction of the arrow.
- Unscrew the gas tube (Fig. 99,3) by hand from the gas bottle.
- Release the fixing belts and remove the gas bottle.
- Place a filled gas bottle in the gas bottle compartment.
- Fix gas bottle in place with the fixing belts.
- Screw gas tube on gas bottle by hand.

## 7.4 Gas isolator taps



- 1 Oven
- 2 Refrigerator
- 3 Heater/boiler
- 4 Cooker

Fig. 100 Symbols for the gas isolator taps

A gas isolator tap (Fig. 100) for every gas device is built into the vehicle. The gas isolator taps are located in the vehicle at different positions, and can also be fitted separately.

## 7.5 External gas connection (special equipment)



- ▶ If the external gas connection is not in use, always close the gas isolator tap.
- ▶ Only gas appliances with a suitable adapter should be connected to the external gas connection.
- ▶ Connect only external gas appliances which are designed for an operation pressure of 30 mbar.
- ▶ Once you have made the connection and opened the gas isolator tap, make sure that no gas is escaping at the connection point. If there is a leak in the external gas connection, gas will escape into the open air. Immediately close the gas isolator tap and the regulator tap on the gas bottle. Have the external gas connection checked by an authorised specialist workshop.
- ▶ When connecting an external gas appliance, make sure that there is nothing near the external gas connection that could cause a spark.
- ▶ Do not use the external gas connection to fill gas bottles. Observe the information stickers on the external gas connection.




Fig. 101 External gas connection, gas isolator tap closed

The external gas connection (Fig. 101) is located at the rear or to the left or right of the vehicle depending on the model.

- Connect the external gas device to the connection point (Fig. 101,1).
- Open the gas isolator tap (Fig. 101,2).

## 7.6 Crash-Protection-Unit switching facility (special equipment)



▶ Do not use the switching facility in closed spaces.



- ▷ When the vehicle is equipped with the Crash-Protection-Unit the living area heater may be operated during the journey.
- ▷ If the vehicle is equipped with a panel of the DT series and the switching facility is operated via this panel, the operating unit is redundant.
- ▷ Also read the manufacturer's instruction manual.

The Crash-Protection-Unit is an automatic switching facility with a control unit for a two-bottle gas system. The switching facility automatically switches gas supply from the primary bottle to the reserve bottle as soon as the primary bottle is either empty or no longer ready for operation. The gas appliances may still continue operation. The switching facility is suitable for all commercial gas bottles from 3 kg to 33 kg. In the event of an accident or a too high angle of the vehicle the gas supply will automatically be interrupted.




Fig. 102 Crash-Protection-Unit switching facility

### Construction of the unit

The Crash-Protection-Unit consists of two flow restrictors with manual release button (Fig. 102,6) a reversing valve (Fig. 102,4) with pressure regulator (Fig. 102,2), an electrovalve (Fig. 102,5) and the operating unit with tricoloured LED. The reversing valve is installed between the two gas tubes (Fig. 102,1).

Use the knob (Fig. 102,3) on the reversing valve to select which of the gas bottles is to be used as a primary bottle and which is to be used as a reserve bottle.



Fig. 103 Operating unit

Only the electrical functions can be switched at the operating unit (Fig. 103). The regulator taps on the gas bottles (Fig. 102,7) and the release buttons (Fig. 102,6) must be opened manually.

The reversing valve provides a constant gas pressure, regardless of which gas bottle is being drawn upon. The display in the reversing valve shows the filling level of the primary bottle. The gas supply comes from the primary bottle when the display is green. When the display is red the primary bottle is empty. In this case, the reserve bottle is used for the gas supply.

The indicator lamp on the operating unit shows the condition of the gas system. The system is okay when the indicator lamp (Fig. 103,1) lights up green. When the indicator lamp lights up or flashes red a fault has occurred. The gas supply is interrupted.

*Putting into operation:*

- Open the regulator taps of the gas bottles (Fig. 102,7).
- Press the release buttons (Fig. 102,6) successively for 10 seconds.
- Use the knob (Fig. 102,3) on the reversing valve (Fig. 102,4) to select the gas bottle which is to be the primary source of gas (primary bottle). Always turn the knob as far as it will go.
- Switch on the switching facility on the operating unit (Fig. 103). For this, set the rocker switch (Fig. 103,2) to "ON". The reversing valve is now deaerated. The indicator lamp (Fig. 103,1) flashes yellow (system test) and lights up green.

*Switching off:*

- Set the rocker switch (Fig. 103,2) to "OFF". The indicator lamp (Fig. 103,1) goes out.
- Close the regulator taps of the gas bottles (Fig. 102,7).



► When changing gas bottles, do not smoke or create any open fire.

*Changing gas bottles:*

- Turn the knob on the reversing valve. The display is green again. Should the display stay red the reserve bottle is also empty and has to be changed as well.
- Close regulator tap on the empty gas bottle.
- Unscrew the gas tube of the gas bottle.
- Release the fixing belts and remove the gas bottle.
- Place a new gas bottle in the gas bottle compartment.
- Fix gas bottle in place with the fixing belts.
- Connect the full gas bottle to the gas tube.

- Open regulator tap on the gas bottle.
- Press the release button for 10 seconds.
- Turn the knob on the reversing valve to the changed bottle. Open the release button when the display is green.
- Set the knob on the reversing valve with a half-turn, so that the newly replaced gas bottle will serve as a reserve bottle.

## 7.7 DuoControl switching facility (special equipment)



- ▶ Do not use the switching facility in closed spaces.



- ▷ Also read the manufacturer's instruction manual.

The DuoControl is an automatic switching facility with a remote display for a two-bottle gas system. The DuoControl switching facility automatically switches gas supply from the primary bottle to the reserve bottle as soon as the primary bottle is either empty or no longer ready for operation. The gas appliances may still continue operation. The DuoControl switching facility is suitable for all commercial gas bottles from 3 kg to 33 kg.




Fig. 104 DuoControl switching facility




Fig. 105 Operating unit

### Construction of the unit

The DuoControl switching facility consists of a reversing valve (Fig. 104,3) and an operating unit (Fig. 105). The reversing valve is installed between the gas tubes (Fig. 104,2 and 5). The knob (Fig. 104,4) on the reversing valve is used to select which of the gas bottles is to be used as a primary bottle and which is to be used as a reserve bottle.

The reversing valve is equipped with the regulator defroster Eis-Ex. This prevents damage to the gas system during the winter months.

Only the electrical functions can be switched at the operating unit (Fig. 105). The regulator taps on the gas bottles (Fig. 104,1 and 6) must be opened manually.

The reversing valve provides a constant gas pressure, regardless of which gas bottle is being drawn upon. The two indicator lamps on the operating unit indicate the level of the primary bottle. When the green indicator lamp (Fig. 105,6) illuminates, the primary bottle is full. When the red indicator lamp (Fig. 105,5) illuminates, the primary bottle is empty. In this case, the reserve bottle is used for the gas supply.

**Operating modes** The DuoControl switching facility has two operating modes:

- Winter operation "On and heating"
- Summer operation "On"

*Putting into operation:*

- Open the regulator taps on the gas bottles (Fig. 104,1 and 6).
- Use the knob (Fig. 104,4) on the reversing valve (Fig. 104,3) to select the gas bottle which is to be the primary source of gas (primary bottle). Always turn the knob as far as it will go.
- Switch on the DuoControl switching facility at the operating unit (Fig. 105). To do so, set the rocker switch (Fig. 105,7) to winter operation "On and heating" (Fig. 105,2) or to summer operation "On" (Fig. 105,4). The reversing valve is now deaerated. The yellow indicator lamp (Fig. 105,1) illuminates if the winter operation has been selected and the regulator defroster is activated.

*Switching off:*

- Set the rocker switch (Fig. 105,7) to "O" (Fig. 105,3). The yellow indicator lamp (Fig. 105,1) goes out.
- Close the regulator taps on the gas bottles (Fig. 104,1 and 6).

**Remote display**

The indicator lamps on the operating unit (Fig. 105,5 and 6) indicate in the vehicle interior whether the primary bottle is ready for operation.

**Changing gas bottles**

If the green indicator lamp (Fig. 105,6) stops illuminating during operation and the red indicator lamp (Fig. 105,5) illuminates, the gas bottle selected as primary bottle is empty and needs to be changed. The reserve bottle continues supplying the gas appliances with gas.



- ▶ When changing gas bottles, do not smoke or create any open fire.

*Changing gas bottles:*

- Close the regulator tap on the empty gas bottle.
- Unscrew the gas tube of the gas bottle.
- Connect the full gas bottle to the gas tube.
- Open the regulator tap on the gas bottle.
- Set the knob on the reversing valve with a half-turn, so that the newly replaced gas bottle will serve as a reserve bottle.

## 7.8 Gas alarm system (special equipment)



- ▷ If the gas sensor or a cable is defective, the buzzer sounds until the defect has been rectified.
- ▷ If a deodorant spray, hairspray or a powerful cleaning agent is used in the immediate vicinity of the gas sensor, a false alarm may be triggered. Extended time in a tunnel (traffic jam) may also trigger a false alarm.
- ▷ Also read the manufacturer's instruction manual.

The gas alarm system has two functions:

- Alarm in the case of an attack with narcotic gas
- Alarm if there is a leak in the gas system

The gas alarm system is ready for operation as soon as the 12 V power supply is supplied with power.



Fig. 106 Gas sensor

The flashing LED (Fig. 106,2) next to the terminal block of the gas sensor (Fig. 106,1) indicates readiness for operation.

*Switching off the buzzer:*

- Briefly switch off the 12 V power supply and switch it on again (e.g. on the safety cut-out in the power pack).





## Chapter overview

This chapter contains instructions regarding the electrical system of the vehicle.

The instructions address the following topics:

- safety
- explanations of terms relating to the battery
- 12 V power supply
- starter battery
- living area battery
- transformer/rectifier
- panel
- solar installation
- 230 V power supply
- connection to the 230 V power supply
- fuse rating
- external socket
- electrical wiring

The operation of the electrical appliances of the housing body is described in chapter 9.

### 8.1 General safety instructions



- ▶ Only allow qualified personnel to work on the electrical system.
- ▶ All electronic devices (e.g. mobile telephones, radios, televisions or DVD players) which have been retrofitted to the vehicle and are operated during the journey must have certain features: These are the CE certification, the EMC inspection (electromagnetic compatibility) and the "E1" inspection.

Only in this way can the functional reliability of the vehicle be ensured. Otherwise the airbag may be triggered or interference to the on-board electronics may result.

The vehicle is a safe place during a storm (Faraday cage). However, to protect the electrical devices, disconnect the 230 V connection and retract the antennae as a precaution.

### 8.2 Terms

#### Off-load voltage

The off-load voltage is the voltage of the battery in idle condition, i. e. no current is consumed and the battery is not being charged.

#### Closed circuit current

Some electrical appliances, such as the clock and the indicator lamps, require continuous electric current, for this reason they are referred to as inactive appliances. This closed circuit current flows even if the 12 V power supply has been switched off.

#### Total discharge

Total discharge of the battery is imminent, if a battery is completely discharged by an active appliance and by closed circuit current.



- ▷ Total discharge damages the battery.

**Capacity** Capacity refers to the amount of electricity which can be stored in a battery. The capacity of a battery is given in ampere hours (Ah). If a battery possesses a capacity of 80 Ah, then the battery can dispense a current of 1 A for 80 hours or a current of 2 A for 40 hours.

External influences such as temperature may alter the storage capacity of the battery.

## 8.3 12 V power supply

### 8.3.1 Starter battery

The starter battery serves for starting the engine and supplies the electrical appliances of the base vehicle as well as optional devices such as the radio, navigation system or central locking system with voltage. See the instruction manual of the base vehicle for the position of the starter battery.



- ▷ For models with a Fiat base vehicle, the radio in the driver's cabin is connected to the living area battery.

**Discharging** This section contains information regarding the discharge of the starter battery.



- ▷ Total discharge damages the battery.
- ▷ Recharge battery in good time.

A completely charged starter battery will be totally discharged via a closed circuit current (inactive appliances). Inactive appliances are optional devices such as a radio, alarm system, navigation system or a central locking system. Inactive appliances discharge the starter battery when the vehicle engine is switched off.

During periods of low external temperatures, the battery will lose part of its capacity.

**Charging** This section contains information regarding the charging of the starter battery.



- ▶ The acid in the battery is poisonous and corrosive. Any contact with the skin or the eyes is to be avoided.
- ▶ In the case of charging with an external charger there is danger of explosion. Only charge the battery in a well ventilated area and away from naked flames or possible sources of sparks.



- ▷ Charge the battery for at least 20 hours before laying up.
- ▷ Do not connect the battery cables to the wrong poles.
- ▷ If the starter battery or living area battery are disconnected, do not apply the ignition. Danger of short circuit!
- ▷ Before disconnecting or connecting the terminals of the battery, switch off the vehicle engine as well as the 230 V and 12 V power supplies and all appliances. Danger of short circuit!
- ▷ Observe the instruction manuals for the base vehicle and the charger.

The starter battery can only be fully charged with an external charger. When the vehicle is connected to the 230 V power supply, the transformer/rectifier charges the starter battery with a float charge only. Even in mobile operation, the vehicle engine alternator is not capable of completely charging the starter battery.

When charging the starter battery with an external charger, proceed as follows:

- Turn off the vehicle engine.
- Switch off the 12 V power supply on the panel. The indicator lamps or the displays on the panel go out.
- Disconnect the starter battery from the vehicle (e.g. pull the connector out).
- Switch off all gas appliances, all gas isolator taps and close the regulator tap on the gas bottle.
- There is a danger of short circuit when disconnecting the battery poles. For this reason, first disconnect the negative terminal on the starter battery and then the positive.
- Check that the external charger is turned off.
- Connect the external charger to the starter battery. Pay attention to the polarity: First connect the positive terminal "+" to the positive terminal of the starter battery, then connect the negative terminal "-" to the negative pole of the starter battery.
- Switch on the external charger.
- See the instructions for use of the connected charger for information concerning charge period required for the battery.
- See the specifications on the battery for information concerning its strength.
- Disconnect the charger in reverse order (the negative terminal first).

### 8.3.2 Living area battery



- ▷ Use only the built-in transformer/rectifier to load the living area battery.
- ▷ Prior to commencing a journey ensure the living area battery is fully charged. For this reason charge the living area battery for at least 20 hours before commencing the journey.
- ▷ During the trip, use every opportunity to charge the living area battery.
- ▷ Charge the living area battery for at least 20 hours after the journey.
- ▷ Charge the battery for at least 20 hours before laying up.
- ▷ When the living area battery is changed, only use batteries of the same type.
- ▷ When changing the living area battery, use only batteries which meet the minimum capacity of the charger. Observe the separate instruction manual for the charger. Lower-capacity batteries will generate a great deal of heat when they are charged. Danger of explosion!
- ▷ Before disconnecting or connecting the terminals of the battery, switch off the vehicle engine as well as the 230 V and 12 V power supplies and all appliances. Danger of short circuit!
- ▷ If the starter battery or living area battery are disconnected, do not apply the ignition. Danger of short circuit!
- ▷ Only connect devices with a maximum of 10 A to the sockets of the 12 V power supply.



- ▷ For models with a Fiat base vehicle, the radio in the driver's cabin is connected to the living area battery.

When the vehicle is not connected to the 230 V power supply or the 230 V power supply is switched off, the living area battery supplies the living area with 12 V DC. The living area battery has a limited power supply only. For this reason, electrical appliances such as the radio and the lights should not be operated for a long time without using the 230 V power supply.

**Position** See chapter 16.

**Discharging** The living area battery is discharged by the closed circuit current which some electrical appliances continuously require.



- ▷ Total discharge damages the battery.
- ▷ Recharge battery in good time.

A completely charged living area battery will be totally discharged via a closed circuit current (inactive appliances):

- After approximately 9 months with the safety/drainage valve switched off
- After approximately 1.5 months with the safety/drainage valve switched on

During periods of low external temperatures, the battery will lose part of its capacity.

The self-discharge rate of the battery is also dependant on temperature. At 20 to 25 °C the self-discharge rate is approx. 3 % of the capacity per month. The self-discharge rate will increase with rising temperatures: At 35 °C the self-discharge rate is approx. 20 % of the capacity per month.

An older battery no longer has the complete capacity available.

The higher the number of active electrical appliances, the faster the energy of the living area battery is consumed.

**Charging** Only use the transformer/rectifier to charge the living area battery. Therefore, connect the vehicle to a 230 V power supply system as often as possible.



- ▷ Charge the battery for at least 48 hours after a total discharge.



- ▷ Further information can be obtained in the separate documentation for the living area battery.

## 8.4 Transformer/rectifier (EBL 99)



- ▷ Do not cover the ventilation slots. Danger of overheating!



- ▷ Depending on the model, not all slots for the fuses are occupied.
- ▷ Further information can be obtained in the manufacturer's instruction manual.




Fig. 107 Transformer/rectifier (EBL 99)

- 1 Main supply socket 230 V~
- 2 Output: Block 1 - refrigerator
- 3 Input: Block 2 - control lines, alternator D+
- 4 Output: Block 4 - heater, safety/drainage valve, basic light (lighting in the entrance area), entrance step
- 5 Output: Block 3 - panel
- 6 Output: Block 5 - solar cell (if fitted), spare 2, spare 3, spare 4
- 7 Output: Block 6 - solar charge regulator (if fitted)
- 8 Output: Block 7 - auxiliary charging unit
- 9 Output: Block 8 - consumer circuit 1, consumer circuit 2, TV, water pump, spare 1, spare 5, spare 6
- 10 Battery selector switch ("Blei-Säure/Blei-Gel" (lead acid/dryfill))
- 11 Fuses (see table in section 8.11)
- 12 Battery cut-off switch ("Batterie Ein/Aus" (battery On/Off))

### Functions

The transformer/rectifier has the following functions:

- The transformer/rectifier charges the living area battery. The transformer/rectifier charges the starter battery with a float charge only.
- The transformer/rectifier monitors the voltage in the living area battery.
- The transformer/rectifier distributes the current to the 12 V circuits and secures them. Devices with a maximum of 10 A can be connected to the sockets.
- The transformer/rectifier contains connections for a solar charge regulator, an auxiliary charging unit as well as other control and monitoring functions.
- When the engine is turned off, the transformer/rectifier separates the starter battery electrically from the living area battery. This prevents the 12 V living area appliances from discharging the starter battery.

The transformer/rectifier only works in conjunction with a panel.

When the transformer/rectifier is subject to a heavy load, the fitted charger module reduces the charging current. This protects the charger from overheating. The transformer/rectifier is subject to a heavy load when e.g. an empty living area battery is being charged, additional electrical appliances are turned on and the ambient temperatures are high.

### Position

See chapter 16.

### 8.4.1 Battery cut-off switch



- ▷ When the battery cut-off switch is OFF, the safety/drainage valve opens. The water flows out of the boiler. When the battery cut-off switch is ON again, close the safety/drainage valve of the boiler by hand.
- ▷ Also switch off a refrigerator with automatic power selection system. The refrigerator will otherwise switch to gas operation.
- ▷ After switching the battery cut-off switch back on again: Put the basic light (lighting in the entrance area), entrance step, heater and spare 4 back into service (depending on the model). To do so, switch on the 12 V main switch briefly. This also applies if the living area battery was disconnected and then reconnected.

The battery cut-off switch disconnects all the living area 12 V appliances, even the safety/drainage valve. This prevents the living area battery from slowly discharging if the vehicle is not used for a longer period of time (e.g. temporary lay-up).

The batteries can still be charged by the transformer/rectifier when the battery cut-off switch is turned off.

Switching on/off:

- Press the battery cut-off switch up: Battery ON ("Batterie EIN").
- Press the battery cut-off switch down: Battery OFF ("Batterie AUS").

### 8.4.2 Battery selector switch



- ▶ If the battery selector switch is set incorrectly, there is the danger of the formation of detonating (oxy-hydrogen gas). Danger of explosion!



- ▷ Incorrect setting of the battery selector switch damages the living area battery.
- ▷ The factory settings of the battery selector switch must not be changed.

### 8.4.3 Battery monitor



- ▷ You must fully recharge a discharged living area battery as soon as possible.

The battery monitor in the transformer/rectifier monitors the voltage in the living area battery.

If the battery voltage falls below 10.5 V, the battery monitor in the transformer/rectifier switches off all of the 12 V appliances, excluding the safety/drainage valve.

A refrigerator with automatic power selection system switches to gas operation.

- Measures:*
- Switch off all electrical appliances that are not absolutely essential at the corresponding switch.
  - If necessary, use the 12 V main switch to switch the 12 V power supply back on for a short while. This is only possible, however, when the battery voltage is above 11 V. If the voltage is below this level, the 12 V power supply cannot be switched on again until the living area battery has been recharged.

#### 8.4.4 Charging the battery

When the vehicle engine is running, the vehicle alternator recharges the living area battery and the starter battery. When the vehicle engine is switched off, the batteries are automatically disconnected from one another by a relay in the transformer/rectifier. This prevents the starter battery from being run down by electrical appliances in the living area. The starting capability of the vehicle is thus preserved. The charging condition of the living area battery or the starter battery can be read on the panel.

If the vehicle is connected to the 230 V power supply, the living area battery and the starter battery are automatically charged by the charger module on the transformer/rectifier. The starter battery is only charged with a float charge. The charging current is adapted to suit the charging condition of the battery. This ensures that it is not possible to overload the battery.

To make use of the maximum output from the charger module on the transformer/rectifier, switch off all electrical appliances during charging.

#### 8.5 Transformer/rectifier (EBL 220)



- ▷ Do not cover the ventilation slots. Danger of overheating!



- ▷ Depending on the model, not all slots for the fuses are occupied.
- ▷ Further information can be obtained in the device manufacturer's instruction manual.




Fig. 108 Transformer/rectifier (EBL 220)

- 1 Connections BL 2 - auxiliary charging unit 1
- 2 Connections BL 1 - auxiliary charging unit 2
- 3 Flat fuses
- 4 Connections BL 9 - solar charge regulator
- 5 Mains connection 230 V
- 6 Connections BL 10 - panel
- 7 Battery selector switch, lead acid/dryfill option
- 8 Connections BL 13 - panel
- 9 Connections BL 12 - sensor for living area battery D+
- 10 Connections BL 11 - panel
- 11 Connections BL 8 - entrance step, TV, antenna
- 12 Connections BL 6 - heater, water pump, spare
- 13 Connections BL 7 - awning, tank heater, awning light
- 14 Selector switch for the number of auxiliary charging units
- 15 Connections BL 5 - solar charge regulator
- 16 Connections BL 4 - refrigerator from starter battery
- 17 Connections BL 3 - refrigerator

**Functions** The transformer/rectifier has the following functions:

- The transformer/rectifier charges the living area battery. The transformer/rectifier charges the starter battery with a float charge only.
- The transformer/rectifier monitors the voltage in the living area battery.
- The transformer/rectifier distributes the current to the 12 V circuits and secures them. Devices with a maximum of 10 A can be connected to the sockets.
- The transformer/rectifier contains connections for a solar charge regulator, an auxiliary charging unit as well as other control and monitoring functions.
- When the engine is turned off, the transformer/rectifier separates the starter battery electrically from the living area battery. This prevents the 12 V living area appliances from discharging the starter battery.

The transformer/rectifier only works in conjunction with a panel.

When the transformer/rectifier is subject to a heavy load, the fitted charger module reduces the charging current. This protects the charger from overheating. The transformer/rectifier is subject to a heavy load when e.g. an empty living area battery is being charged, additional electrical appliances are turned on and the ambient temperatures are high.

**Position** See chapter 16.



### 8.5.1 Battery separation



- ▷ The safety/drainage valve will open after the activation of the battery separation. The water flows out of the boiler. When the battery separation is deactivated again, close the safety/drainage valve of the boiler by hand.
- ▷ Also switch off a refrigerator with automatic power selection system. The refrigerator will otherwise switch to gas operation.
- ▷ After deactivation of the battery separation, it may be necessary to reset the date and time. The remaining settings will be saved at the activation of the battery separation and will be maintained.

The battery separation disconnects all the living area 12 V appliances, even the safety/drainage valve. This prevents the living area battery from slowly discharging if the vehicle is not used for a longer period of time (e.g. temporary lay-up).

The batteries can still be charged by the transformer/rectifier when the battery separation is activated.

#### Activating/deactivating

See section 8.8.2.

### 8.5.2 Battery selector switch



- ▶ If the battery selector switch is set incorrectly, there is the danger of the formation of detonating (oxy-hydrogen gas). Danger of explosion!



- ▷ Incorrect setting of the battery selector switch damages the living area battery.
- ▷ The factory settings of the battery selector switch must not be changed.

### 8.5.3 Battery monitor



- ▷ You must fully recharge a discharged living area battery as soon as possible.

The battery monitor in the transformer/rectifier monitors the voltage in the living area battery.

If the battery voltage falls below 10.5 V, the battery monitor in the transformer/rectifier switches off all of the 12 V appliances, excluding the safety/drainage valve.

A refrigerator with automatic power selection system switches to gas operation.

#### Measures:

- Switch off all electrical appliances that are not absolutely essential at the corresponding switch.
- If necessary, use the 12 V main switch to switch the 12 V power supply back on for a short while. This is only possible, however, when the battery voltage is above 11 V. If the voltage is below this level, the 12 V power supply cannot be switched on again until the living area battery has been recharged.

### 8.5.4 Charging the battery

When the vehicle engine is running, the vehicle alternator recharges the living area battery and the starter battery. When the vehicle engine is switched off, the batteries are automatically disconnected from one another by a relay in the transformer/rectifier. This prevents the starter battery from being run down by electrical appliances in the living area. The starting capability of the vehicle is thus preserved. The charging condition of the living area battery or the starter battery can be read on the panel.

If the vehicle is connected to the 230 V power supply, the living area battery and the starter battery are automatically charged by the charger module on the transformer/rectifier. The starter battery is only charged with a float charge. The charging current is adapted to suit the charging condition of the battery. This ensures that it is not possible to overload the battery.

To make use of the maximum output from the charger module on the transformer/rectifier, switch off all electrical appliances during charging.

## 8.6 Panel IT 96-2




Fig. 109 Panel IT 96-2

- 1 "ALARM" warning light for the living area battery
- 2 V/tank gauge
- 3 230 V indicator lamp
- 4 Rocker switch for water pump On/Off
- 5 Switch for reading the filling level in the water tank
- 6 Switch for reading the filling level in the waste water tank
- 7 12 V main switch "OFF"
- 8 12 V indicator lamp
- 9 12 V main switch "ON"
- 10 Switch for reading the battery voltage of the living area battery
- 11 Switch for reading the battery voltage of the starter battery

### 8.6.1 12 V main switch

The 12 V main switch (Fig. 109,7 and 9) switches the panel and the 12 V power supply to the living area on and off.

Exception: Depending on the model, safety/drainage valve, heater, basic light (lighting in the entrance area), entrance step, spare 4 and AES refrigerator remain ready to operate.

*Switching on:* ■ Press switch (Fig. 109,9) "12 V": The 12 V living area power supply is switched on. The indicator lamp (Fig. 109,8) lights up green.

*Switching off:* ■ Press switch (Fig. 109,7) "O": The 12 V living area power supply is switched off. The indicator lamp (Fig. 109,8) goes out.





- ▷ When leaving the vehicle, switch off the 12 V main switch. This prevents any unnecessary discharge of the living area battery.
- ▷ Appliances such as the safety/drainage valve, charger, solar charge regulator and panel consume approx. 20 mA to 65 mA of electricity from the battery capacity, even when the 12 V main switch is turned off. Therefore disconnect the living area battery from the 12 V power supply, if the vehicle will not be used for a long period of time.

## 8.6.2 V/tank gauge for battery voltage and water or waste water levels

**Battery voltage** The V/tank gauge is for the indication of the battery voltage of the starter battery or the living area battery.

With the V/tank gauge (Fig. 109,2), note the top scale. The gauge automatically lights up as soon as a switch is pressed.

*Displays:*

- Press switch (Fig. 109,11) "": The battery voltage of the starter battery is displayed.
- Press switch (Fig. 109,10) "": The battery voltage of the living area battery is displayed.

The following tables will help you correctly interpret the battery voltage of the living area battery displayed on the panel IT 96.

**Danger of total discharge (battery alarm)**

Battery voltage (values during operation)	Mobile operation (vehicle moving, no 230 V connection)	Battery operation (vehicle stationary, no 230 V connection)	Power operation (vehicle stationary, 230 V connection)
11 V or less <sup>1)</sup>	12 V power supply overload	If appliances are switched off: Battery flat	12 V power supply overload
	The battery is not charged by the alternator, the alternator's regulator is defective	If appliances are switched on: Battery overload	The battery is not charged by the transformer/rectifier, the transformer/rectifier is defective
11.5 V to 13.2 V	12 V power supply overload <sup>2)</sup>	Normal range	12 V power supply overload <sup>2)</sup>
	The battery is not charged by the alternator, the alternator's regulator is defective		The battery is not charged by the transformer/rectifier, the transformer/rectifier is defective
13.3 V to 13.7 V	Battery is being charged (main charge)	Occurs only briefly after charging	Battery is being charged (main charge)
13.8 V to 14.4 V	Battery being charged (float charge)	–	Battery being charged (float charge)
Over 14.5 V	Battery is overcharged, defective alternator control	–	Battery is overcharged, defective transformer/rectifier

<sup>1)</sup> The battery guard switches all the appliances off (at 10.5 V).

<sup>2)</sup> If the voltage does not exceed this range for several hours.

Values for off-load voltage	Charging condition of the battery
Less than 11 V	Totally discharged
12.0 V	0 %
12.2 V	25 %
12.3 V	50 %
12.5 V	75 %
More than 12.8 V	100 %





- ▷ Total discharge causes irreparable damage to the battery.

### Volume of water/waste water

The V/tank gauge is for the indication of the quantity of water or waste water. With the V/tank gauge (Fig. 109,2), use the bottom scale. The gauge automatically lights up as soon as a switch is pressed.

Displays:

- Press switch (Fig. 109,5) "": The volume of water is displayed.
- Press switch (Fig. 109,6) "": The volume of waste water is displayed.
- ▷ Only read the tank levels briefly. Keeping the reading option on for a long time can damage the transducers.



### 8.6.3 Switch for water pump

**Switching on:** ■ Press the upper part of the rocker switch (Fig. 109,4) "I": The water supply is ON.

**Switching off:** ■ Press the lower part of the rocker switch (Fig. 109,4) "O": The water supply is OFF.



- ▷ If the vehicle is not connected to the 230 V power supply and the water pump is not used for a longer period of time: Switch off the power supply for the water pump. The pump relay uses around 4 Ah current each day.

### 8.6.4 Battery alarm for the living area battery

The red "ALARM" warning light (Fig. 109,1) flashes as soon as the voltage of the living area battery falls below 11 V (measured under operation) and there is a risk of a total discharge.



- ▷ Total discharge damages the battery.



- ▷ If the battery voltage falls below 10.5 V, the battery monitor in the transformer/rectifier switches off all of the 12 V appliances, excluding the safety/drainage valve.

- Measures:*
- When the battery alarm comes on, switch off the appliances and charge the living area battery, either by mobile operation or by connection to a 230 V power supply.

### 8.6.5 12 V indicator lamp

The 12 V indicator lamp (Fig. 109,8) illuminates whenever the 12 V main switch (Fig. 109,9) is switched on.

### 8.6.6 230 V indicator lamp

The yellow 230 V indicator lamp (Fig. 109,3) illuminates whenever line voltage is available at the transformer/rectifier input.



- ▷ Further information can be obtained from the separate "Control panel" instruction manual.

## 8.7 Panel IT 994




Fig. 110 Panel IT 994

- 1 V/tank gauge
- 2 Digital clock/temperature gauge
- 3 230 V indicator lamp
- 4 Current gauge
- 5 12 V indicator lamp
- 6 12 V main switch
- 7 Rocker switch for water pump On/Off
- 8 Rocker switch °C for reading internal temperature or external temperature
- 9 Setting the digital clock - minutes
- 10 Setting the digital clock - hours
- 11 Rocker switch display On/Off
- 12 Rocker switch for reading the level in the water or waste water tanks
- 13 Rocker switch for reading the battery voltage of the starter and living area batteries
- 14 ALARM warning light for the living area battery

### 8.7.1 V/tank gauge for battery voltage and water or waste water levels

#### Battery voltage

The V/tank gauge is for the indication of the battery voltage of the starter battery or the living area battery.

With the V/tank gauge (Fig. 110,1), note the top scale. The gauge automatically lights up as soon as a switch is pressed.

#### *Displays:*

- Press the lower part of the rocker switch (Fig. 110,13): The battery voltage of the starter battery is displayed.
- Press the upper part of the rocker switch (Fig. 110,13): The battery voltage of the living area battery is displayed.

The following tables will help you correctly interpret the battery voltage of the living area battery displayed on the panel IT 994.

**Danger of total discharge (battery alarm)**

Battery voltage (values during operation)	Mobile operation (vehicle moving, no 230 V connection)	Battery operation (vehicle stationary, no 230 V connection)	Power operation (vehicle stationary, 230 V connection)
11 V or less <sup>1)</sup>	12 V power supply overload	If appliances are switched off: Battery flat	12 V power supply overload
	The battery is not charged by the alternator, the alternator's regulator is defective	If appliances are switched on: Battery overload	The battery is not charged by the transformer/rectifier, the transformer/rectifier is defective
11.5 V to 13.2 V	12 V power supply overload <sup>2)</sup>	Normal range	12 V power supply overload <sup>2)</sup>
	The battery is not charged by the alternator, the alternator's regulator is defective		The battery is not charged by the transformer/rectifier, the transformer/rectifier is defective
13.3 V to 13.7 V	Battery is being charged (main charge)	Occurs only briefly after charging	Battery is being charged (main charge)
13.8 V to 14.4 V	Battery being charged (float charge)	–	Battery being charged (float charge)
Over 14.5 V	Battery is overcharged, defective alternator control	–	Battery is overcharged, defective transformer/rectifier

<sup>1)</sup> The battery guard switches all the appliances off (at 10.5 V).

<sup>2)</sup> If the voltage does not exceed this range for several hours.

Values for off-load voltage	Charging condition of the battery
Less than 11 V	Totally discharged
12.0 V	0 %
12.3 V	50 %
12.5 V	75 %
More than 12.8 V	Full



▷ Total discharge causes irreparable damage to the battery.

**Volume of water/waste water**

The V/tank gauge is for the indication of the quantity of water or waste water. With the V/tank gauge (Fig. 110,1), use the bottom scale. The gauge automatically lights up as soon as a switch is pressed.

- Displays:*
- Press the upper part of the rocker switch (Fig. 110,12): The volume of water is displayed.
  - Press the lower part of the rocker switch (Fig. 110,12): The volume of waste water is displayed.
- ▷ Only read the tank levels briefly. Keeping the reading option on for a long time can damage the transducers.



### 8.7.2 Battery alarm for the living area battery

The red ALARM warning light (Fig. 110,14) flashes as soon as the voltage of the living area battery falls below 11 V (measured under operation) and there is a risk of a total discharge.



- ▷ When the battery alarm comes on, switch off the appliances and charge the living area battery, either by mobile operation or by connection to a 230 V power supply.
- ▷ Total discharge damages the battery.



- ▷ If the battery voltage falls below 10.5 V, the battery monitor in the transformer/rectifier switches off all of the 12 V appliances, excluding the safety/drainage valve.

### 8.7.3 Digital clock/temperature gauge

**Digital clock** The buttons under the gauge can be used to switch the digital clock on and off and to set it.

*Switching on:* ■ Press the upper part of the rocker switch (Fig. 110,11): Digital clock display is switched on. Temperature display is ready to operate.

*Switching off:* ■ Press the lower part of the rocker switch (Fig. 110,11): Digital clock display and temperature display are switched off.

*Adjusting:* ■ Press a thin device, such as a biro, into the opening for the hour display (Fig. 110,10) until the correct hours are displayed.  
 ■ Press a thin device, such as a biro, into the opening for the minute display (Fig. 110,9) until the correct minutes are displayed.



- ▷ The digital clock will go on running even when the digital clock display is switched off. The actual time can always be read.
- ▷ The digital clock loses the current time when the living area battery is disconnected. When the living area battery is reconnected, the display reads 00:00 and must be re-set.

#### Temperature display

The digital clock/temperature gauge is for the indication of the internal or external temperature.

The temperature display is only ready for operation if the digital clock display is switched on. After a reading, the respective temperature will be displayed for approx. 6 seconds.

- Displays:*
- Press the upper part of the rocker switch (Fig. 110,8): The internal temperature is displayed.
  - Press the lower part of the rocker switch (Fig. 110,8): The external temperature is displayed.

#### 8.7.4 Current gauge for charging/discharging the living area battery

The battery current actually flowing is permanently displayed on the current gauge (Fig. 110,4). The gauge automatically lights up as soon as a switch is pressed.

- Red "discharging" zone: Battery is being discharged at the discharging current indicated between 0 and 30 A.
- Indicator "0": Battery is neither being charged nor discharged.
- Green "charging" zone: Battery is being charged at the charging current indicated between 0 and 30 A.

#### Notes for charging/ discharge display

Display	Mobile operation (vehicle moving, no 230 V connection)	Battery operation (vehicle stationary, no 230 V connection)	Power operation (vehicle stationary, 230 V connection)
Red "discharging" zone (discharging current)	No charge! Too many appliances are switched on or the alternator is defective	Appliances are on Battery is being discharged	No charge! Too many appliances are switched on
0 A (there is no current)	Battery fully or virtually charged <sup>1)</sup>	Appliances are switched off	Battery fully or virtually charged <sup>2)</sup>
Green zone (charging current)	Battery is being charged (up to 30 A possible)	Battery is being charged (only possible with solar power)	Battery is being charged (up to max. 16 A possible; with 32 A auxiliary charging unit)

<sup>1)</sup> If the indicator falls from the green range to 0 and all appliances are switched off (apart from the refrigerator).

<sup>2)</sup> If the indicator falls from the green range to 0 and all appliances are switched off.

#### 8.7.5 12 V main switch

The 12 V main switch (Fig. 110,6) switches the panel and the 12 V power supply of the living area on and off.

Exception: Depending on the model, safety/drainage valve, heater, basic light (lighting in the entrance area), entrance step, spare 4 and AES refrigerator remain ready to operate.

- Switching on:*
- Press the upper part of the rocker switch (Fig. 110,6): The 12 V living area power supply is switched on. The indicator lamp (Fig. 110,5) lights up green.

- Switching off:*
- Press the lower part of the rocker switch (Fig. 110,6): The 12 V living area power supply is switched off. The indicator lamp (Fig. 110,5) goes out.





- ▷ When leaving the vehicle, switch off the 12 V main switch. This prevents any unnecessary discharge of the living area battery.
- ▷ Appliances such as the safety/drainage valve, charger, solar charge regulator and panel consume approx. 20 mA to 65 mA of electricity from the battery capacity, even when the 12 V main switch is turned off. Therefore disconnect the living area battery from the 12 V power supply, if the vehicle will not be used for a long period of time.

### 8.7.6 12 V indicator lamp

The 12 V indicator lamp (Fig. 110,5) illuminates whenever the 12 V main switch (Fig. 110,6) is switched on.

### 8.7.7 230 V indicator lamp

The yellow 230 V indicator lamp (Fig. 110,3) illuminates whenever line voltage is available at the transformer/rectifier input.

### 8.7.8 Switch for water pump

*Switching on:* ■ Press the upper part of the rocker switch (Fig. 110,7): The water supply is ON.

*Switching off:* ■ Press the lower part of the rocker switch (Fig. 110,7): The water supply is OFF.



- ▷ If the vehicle is not connected to the 230 V power supply and the water pump is not used for a longer period of time: Switch off the power supply for the water pump. The pump relay uses around 4 Ah current each day.

## 8.8 Panel LT 510



- ▷ The luminance of the LEDs and the symbols adapts automatically to the ambient light.
- ▷ The displays can only be called up if the 12 V power supply is switched on.
- ▷ As soon as a button is pressed, the gauge is automatically illuminated. The display goes out 20 seconds after the last key has been pressed.
- ▷ Further information can be obtained in the manufacturer's instruction manual.




Fig. 111 Panel LT 510

- 1 230 V indicator lamp
- 2 Batteries gauge
- 3 Volt symbol
- 4 Interior temperature button
- 5 External temperature button
- 6 Tank heater button
- 7 Water tank symbol
- 8 Tanks gauge
- 9 Light control button
- 10 Water pump button
- 11 Waste water tank symbol
- 12 Digital display, temperature
- 13 Tanks button
- 14 Starter battery button
- 15 Living area battery button
- 16 Symbol for starter battery and living area battery
- 17 Ampere symbol
- 18 Button for 12 V power supply (12 V main switch)

### 8.8.1 230 V indicator lamp

The 230 V indicator lamp (Fig. 111,1) illuminates whenever line voltage is available at the transformer/rectifier input.



- ▷ The 230 V indicator lamp also lights up whenever the 12 V main switch is switched off.

### 8.8.2 12 V main switch

The 12 V main switch (Fig. 111,18) switches the panel and the 12 V power supply of the living area on and off.

Exception: Heater, safety/drainage valve, basic light (lighting in the entrance area) and entrance step remain operational.

- Switching on:*
- Briefly press the 12 V power supply button (Fig. 111,18). The 12 V living area power supply is switched on. The "12 V" indicator lights up.



- ▷ If, after switching on, the "11.0" LED of the volt indicator and the "V" volt symbol (Fig. 111,3) in the batteries gauge (Fig. 111,2) flash, the voltage of the living area battery is too low. Charge battery.
- ▷ If, after switching on, the "12 V" indicator and the "V" volt symbol (Fig. 111,3) flash three times, battery separation is activated. Deactivate battery separation.

*Switching off:*

- Briefly press the 12 V power supply button (Fig. 111,18). The 12 V living area power supply is switched off. The "12 V power supply" indicator goes out.

*Activating battery disconnection (transformer/rectifier without battery cut-off switch):*

- Switch off 12 V power supply.
- Press button for living area battery (Fig. 111,15) and hold it down for approx. 10 seconds. The "V" volt symbol (Fig. 111,3) and the "12 V" indicator flash three times. The living area battery is disconnected from the 12 V power supply.

*Deactivating battery disconnection (transformer/rectifier without battery cut-off switch):*

- Press the 12 V power supply button (Fig. 111,18) and hold it down for approx. 5 seconds. The "V" volt symbol (Fig. 111,3) and the "12 V" indicator flash three times. The living area battery is connected to the 12 V power supply. The indicator lights up after approx. 5 seconds.



- ▷ When leaving the vehicle, switch off the 12 V main switch. This prevents any unnecessary discharge of the living area battery.
- ▷ Appliances such as the safety/drainage valve, charger, solar charge regulator and panel consume approx. 20 mA to 65 mA of electricity from the battery capacity, even when the 12 V main switch is turned off. Therefore disconnect the living area battery from the 12 V power supply, if the vehicle will not be used for a long period of time.

### 8.8.3 Batteries gauge

The voltage and charging/discharging of the living area battery or the starter battery voltage can be indicated using the batteries gauge.

*Displays:*

- Press button for living area battery (Fig. 111,15). The "V" volt symbol (Fig. 111,3) lights up. Depending on whether the battery is being charged or discharged, the "A" ampere symbol (Fig. 111,17) lights up white or red respectively. The battery voltage and current of the living area battery are displayed using the LEDs in the gauge.
- Press button for starter battery (Fig. 111,14). The "V" volt symbol (Fig. 111,3) lights up. The battery voltage of the starter battery is displayed using the LEDs in the gauge.

The tables below will help you interpret the statuses displayed on the panel.

**Volt indicator (blue)**

1 LED	2 LEDs	3 LEDs	4 LEDs	5 LEDs	6 LEDs	7 LEDs	8 LEDs
< 11.0 V	11.5 V	12.0 V	12.2 V	12.5 V	12.7 V	13.0 V	> 13.5 V

**Danger of total discharge (battery alarm)**

Battery voltage (values during operation)	Mobile operation (vehicle moving, no 230 V connection)	Battery operation (vehicle stationary, no 230 V connection)	Power operation (vehicle stationary, 230 V connection)
11 V or less <sup>1)</sup>	12 V power supply overload	If appliances are switched off: Battery flat	12 V power supply overload
	The battery is not charged by the alternator, the alternator's regulator is defective	If appliances are switched on: Battery overload	The battery is not charged by the transformer/rectifier, the transformer/rectifier is defective
11.5 V to 13 V	12 V power supply overload <sup>2)</sup>	Normal range	12 V power supply overload <sup>2)</sup>
	The battery is not charged by the alternator, the alternator's regulator is defective		The battery is not charged by the transformer/rectifier, the transformer/rectifier is defective
Over 13.5 V	Battery is being charged (main charge)	Occurs only briefly after charging	Battery is being charged (main charge)

1) The battery guard switches all the appliances off (at 10.5 V).

2) If the voltage does not exceed this range for several hours.

Values for off-load voltage	Charging condition of the battery
Less than 11 V	Totally discharged
12.0 V	0 % (discharged)
12.2 V	25 %
12.3 V	50 %
12.5 V	75 %
More than 12.8 V	Full



▷ Total discharge causes irreparable damage to the battery.

**Ampere indicator (blue)**

1 LED	2 LEDs	3 LEDs	4 LEDs	5 LEDs	2 LEDs	3 LEDs	4 LEDs
Discharging with:					Charging with:		
Ap-prox. 0 A	> 1 A	> 3 A	> 10 A	> 30 A	> 1 A	> 3 A	> 10 A

Current displayed	System status	"A" ampere symbol
-30 A to -10 A	Battery is being heavily discharged	Lights up red
-10 A to -1 A	Battery is being discharged	Lights up white
0 A	Battery current is low or 0 A	Lights up white
+1 A to +10 A	Battery being charged	Lights up white

### 8.8.4 Tank gauge

The water and waste water quantities can be indicated using the tank gauge.

*Displays:*

- Press tanks button (Fig. 111,13). The water tank (Fig. 111,7) and waste water tank (Fig. 111,11) symbols light up. The fill levels of the water tank (upper scale) and of the waste water tank (lower scale) are indicated using the LEDs in the gauge.

The table below will help you interpret the levels displayed on the panel.

**Level indicator (blue)**

1 LED	2 LEDs	3 LEDs	4 LEDs	5 LEDs	6 LEDs	7 LEDs	8 LEDs
25 %		50 %		75 %		100 %	

### 8.8.5 Alarms



- ▷ Perform display checks regularly.
- ▷ It is best to perform checks in the morning, before the 12 V appliances are switched on.

The table below will help you interpret the alarms displayed on the panel.



- ▷ Total discharge damages the battery.



- ▷ If the battery voltage falls below 10.5 V, the battery monitor in the transformer/rectifier switches off all of the 12 V appliances, excluding the safety/drainage valve.

Display	Signification	Remedy
The "V" volt symbol (Fig. 111,3) and the LED "11.0" flash when the values for the living area battery are called up	The battery voltage has fallen below 11 V. Danger of total discharge	Switch off all 12 V appliances and charge the battery either by mobile operation or by connection to a 230 V supply
The "V" volt symbol (Fig. 111,3) flashes when the 12 V power supply is switched off	The 12 V power supply can no longer be switched on	Switch off all 12 V appliances and charge the battery either by mobile operation or by connection to a 230 V supply
	Battery overvoltage	Contact customer service
The "V" volt symbol (Fig. 111,3) and the LEDs "11.0" and "12.0" flash when the values for the starter battery are called up	The battery voltage has fallen below 11 V. Danger of total discharge	Switch off all 12 V appliances and charge the battery either by mobile operation or by connection to a 230 V supply

**Tank alarm** The water tank symbol (Fig. 111,7) or waste water tank symbol (Fig. 111,11) flashes when the water tank is empty or the waste water tank is full.



- ▷ If, when the fill levels are called up, the LEDs in the scale flash in addition to the tank symbol, a sensor error has occurred. Clean tank sensors.

*Measures:* ■ Fill water tank or empty waste water tank.

### 8.8.6 Temperature display

The internal and external temperatures can be indicated using the digital display (Fig. 111,12).

- Displays:*
- Press the button for the internal temperature (Fig. 111,4). The internal temperature is displayed.
  - Press external temperature button (Fig. 111,5). The external temperature is displayed.

### 8.8.7 Switch for tank heater

The tank heater can be turned on and off using the tank heater button (Fig. 111,6).

*Switching on:* ■ Press the tank heater button (Fig. 111,6). The tank heater symbol lights up.

*Switching off:* ■ Press the tank heater button (Fig. 111,6). The tank heater symbol goes out.



- ▷ The tank heater is not switched off when the 12 V power supply is switched off. The tank heater must always be switched off separately. Although the tank heater can be switched off when the 12 V power supply is switched off, it cannot be switched on.

### 8.8.8 Switch for water pump

The water pump can be turned on and off using the water pump button (Fig. 111,10).

*Switching on:* ■ Press the water pump button (Fig. 111,10). The symbol lights up.

*Switching off:* ■ Press the water pump button (Fig. 111,10). The symbol goes out.



- ▷ The switch status of the water pump is saved when the 12 V power supply is switched off. This means: If the water pump was switched on when the 12 V power supply was switched off, it is also switched on after the 12 V power supply is switched back on.

### 8.9 Solar installation (special equipment)



- ▷ Protect the solar collectors (solar module) against mechanical overload.



- ▷ The solar installation supplies the most current under optimal sunlight conditions.
- ▷ Provide the solar collectors (solar module) open access to sunlight.
- ▷ Sunlight is greater in the open air than under trees and bridges.
- ▷ Tarpaulins block out sunlight.
- ▷ Always keep collector surfaces free of contamination.
- ▷ Also read the manufacturer's instruction manual.

The solar installation provides an environmentally compatible power supply independent of the mains. It converts energy from sunlight into electric current. The solar installation supplies additional current for the battery and appliances.

The solar charge regulator has an integrated overload protection and back flow valve. The charging current is automatically reduced or the solar collectors (solar modules) are switched off if the solar power is not sufficient (e.g. at night).



Fig. 112 Solar charge regulator

The operating display is by means of two LEDs (Fig. 112,1 and 2). The LEDs indicate the current operating status by means of different brightness. The higher the charge status of the battery, the brighter the LED lights "100 % ↑" (Fig. 112,1) and, the lower the charge status of the battery, the lower the LED lights "20 % ↓" (Fig. 112,2).

LED	Status	Signification
100 % ↑ 20 % ↓	Off	Solar power insufficient
100 % ↑ 20 % ↓	Lights	Battery being charged
100 % ↑ 20 % ↓	Lights brightly Glows weakly	Charging current limited to trickle charging current

## 8.10 230 V power supply



- ▶ Only allow qualified personnel to work on the electrical system.

The 230 V power supply provides electricity for:

- sockets with earth contact for appliances with maximum 16 A
- refrigerator
- transformer/rectifier
- air conditioning unit

The electrical appliances connected to the 12 V power supply of the living area are supplied with voltage by the living area battery.

Connect the vehicle to an external 230 V power supply system as often as possible. The charger module in the transformer/rectifier automatically charges the living area battery. In addition to this, the starter battery is charged with a float charge of 2 A.

The air conditioning unit and other optional devices are fuse-protected by their own two-pole automatic circuit breaker (16 A).

### 8.10.1 230 V connection



- ▶ The external 230 V power supply must be protected by fuse with a fault current protection switch (FI-switches, 30 mA).



- ▷ For the connection points on camp sites (camping distributors) highly sensitive fault current protection switches (FI-switches, 30 mA) are obligatory.
- ▷ Depending on the equipment, the vehicle is already equipped with a fault current protection switch (FI-switch).

The vehicle can be connected to an external 230 V power supply. The cable may have a length of maximum 25 m.

### 8.10.2 Power cable for external 230 V connection



- ▶ Completely unwind the cable on cable drums to prevent overheating.



**Power cable**

- Three-core (3 x 2.5 mm<sup>2</sup>) flexible rubber sheathed cable
- Maximum 25 m in length
- 1 plug with earth contact
- 1 socket with earth contact (plug-in devices according to EN 60309)

**Connection possibilities**

For your power cable, we recommend using a CEE connection cable with a CEE plug and coupling. If this type of connection is not feasible, we recommend the following combination with a safety plug:




Fig. 113 Connection possibilities 230 V connection




Fig. 114 Connecting an angled connector with socket

- Adapter cable:  
CEE 17 socket with earth contact (Fig. 113,1) – plug with earth contact (Fig. 113,2)
- Cable reel:  
Socket with earth contact (Fig. 113,3) – plug with earth contact (Fig. 113,4)
- Adapter cable:  
CEE 17 socket with earth contact (Fig. 113,5) – plug with earth contact (Fig. 113,6)



- ▶ When using a CEE 17 angled connector with rear socket (Fig. 114,1) only use a rubberised and sealed IP 44 socket with earth contact (Fig. 114,2). Do not use sockets without earth contact (Fig. 114,3). Danger of electrocution!

Depending on the design, the flap for the 230 V connection is designated with the symbol "⚡".

**Connecting the power cable:**

- Open external flap.
- Depending on the design, tilt the cover upwards.
- Insert connector.
- ▶ Depending on the design, disconnect the connector before removing it.




## 8.11 Fuses



- ▶ Only replace defective fuses when the cause of the defect is known and has been remedied.
- ▶ Replace defective fuses only after the power supply has been turned off.
- ▶ Never bridge or repair fuses.

### 8.11.1 12 V fuses

The appliances connected to the 12 V power supply in the living area are fused individually. The fuses are accessible in the driver's cabin, at the living area battery and on the transformer/rectifier.



- 1 Unbroken fuse element
- 2 Broken fuse element


Fig. 115 12 V fuse

An intact 12 V fuse can be detected by the unbroken fuse element (Fig. 115,1). If the fuse element is broken (Fig. 115,2), change the fuse.

Before changing fuses, take the function, value and colour of the relevant fuses from the following specifications. When changing fuses, only use flat fuses with the values shown below.

#### Fuses on the starter battery

The fuses are installed in the vicinity of the starter battery. The starter battery is on the floor between the seats in the driver's cabin and can be accessed under a cover.




- 1 Flat fuse 20 A/yellow  
(for the refrigerator)
- 2 Jumbo flat fuse 50 A/red

Fig. 116 Fuses on the starter battery

#### Fuses on the living area battery

The fuses are fitted next to the living area battery.



- 1 Jumbo flat fuse 50 A/red  
(for the transformer/rectifier)
- 2 Flat fuse 2 A/grey  
(for battery charger sensor)

Fig. 117 Fuses on the living area battery

**Fuses on the relay box  
AD01**

A relay box (AD01) is installed in one of the two seat consoles. The relay box helps generate the signals for the chassis lighting not provided by the base vehicle. The relay box can be used anywhere.

The circuit used by us can vary from the circuit provided by the manufacturer. Consequently, the circuit can also vary from the display on the relay box type plate, which the manufacturer affixed.

FuNo	Function	Value/colour
B2	Cl. 15 (Ignition On)	15 A blue
B3	Cl. 30 (constant position)	15 A blue
B5	D+ Signal	Internal polyswitch (2 A)
B6	Spare	15 A blue
B7	Front side marker lights (white/red)	5 A light brown

**Fuses on the  
transformer/rectifier  
(EBL 99)**

Function	Value/colour
Internal charger module	20 A yellow
Compressor/AES refrigerator	20 A yellow
Heater	10 A red
Basic light/electrically operated entrance step/radio	25 A white
Spare 4	25 A white
Spare 3	25 A white
Spare 2	15 A blue
Spare 1	15 A blue
Solar	15 A blue
Spare 5	15 A blue
Spare 6	15 A blue
Auxiliary charging unit	20 A yellow
Circuit 1	10 A red
Circuit 2	10 A red
TV	10 A red
Water pump	5 A light brown

**Fuses on the  
transformer/rectifier  
(EBL 220)**

Function	Value/colour
Auxiliary charging unit 2	25 A white
Auxiliary charging unit 1	25 A white
Internal charger module	20 A yellow
Spare 2	15 A blue
Pump (for water)	7.5 A brown
Circuit 3	10 A red
Circuit 2	15 A blue
Circuit 1	15 A blue
Spare 1	15 A blue

Function	Value/colour
Circuit 5	15 A blue
Refrigerator	15 A blue
Heater	10 A red
Circuit 4	15 A blue
Refrigerator control	2 A grey
Awning light	5 A light brown
Antenna	10 A red
TV	10 A red
Solar	15 A blue
Step	15 A blue
Awning	10 A red
Gas alarm	2 A grey
Pull-down bed	25 A white

#### Fuse for the Thetford toilet (swivel toilet)

The fuse is located in the locker wall of the Thetford cassette.



1 Flat fuse 3 A/purple

Fig. 118 Fuse for the Thetford toilet

#### Changing:

- Open the flap for the Thetford cassette on the outside of the vehicle.
- Pull out the Thetford cassette completely.
- Replace fuse (Fig. 118,1).

#### Fuse for the Thetford toilet (fixed seat)

The fuse is located in the locker wall of the Thetford cassette.




1 Flat fuse 3 A/purple

Fig. 119 Fuse for the Thetford toilet

- Changing:*
- Open the flap for the Thetford cassette on the outside of the vehicle.
  - Remove the Thetford cassette and swing out the flap in the housing panel.
  - Replace fuse (Fig. 119,1).

**Fuse for the Dometic toilet**

The fuse is located on the rear side of the control unit for the toilet.



- 1 Control unit
- 2 Flat fuse 10 A/red

Fig. 120 Fuse for toilet

- Changing:*
- Lift the control unit for the toilet (Fig. 120,1) with a suitable tool and pull it from the wall.
  - Replace fuse (Fig. 120,2).

**Fuse on the solar charge regulator (special equipment)**

The fuse is located on the solar charge regulator.



- 1 Flat fuse 5 A/light brown

Fig. 121 Solar charge regulator fuse

- Changing:*
- Disconnect all 12 V appliances.
  - Replace fuse (Fig. 121,1).

### 8.11.2 230 V fuse



Fig. 122 230 V fuse box with safety cut-out



Fig. 123 230 V fuse box with safety cut-out and fault current protection switch (FI)

Depending on the vehicle's equipment, either a two-pole safety cut-out (Fig. 122) or a safety cut-out with fault current protection switch (FI-switch) (Fig. 123) secures the 230 V power supply.

#### Checking fault current protection switch:

- When the vehicle is connected to the 230 V power supply, press the test button (Fig. 123,1). The safety cut-out must be activated.

**Position** See chapter 16.

### 8.12 External socket (special equipment)



Fig. 124 External socket

- 1 SAT socket
- 2 230 V socket
- 3 TV socket
- 4 12 V socket

The 230 V socket and the 12 V socket can be used to power electrical devices in the awning.

**Connection possibilities** TV socket and SAT socket offer various possibilities for TV operation:




Fig. 125 TV inside the vehicle




Fig. 126 TV in the awning

- TV inside the vehicle (Fig. 125,4): Connection to roof antenna (Fig. 125,1) with connection cable (Fig. 125,2)
- TV inside the vehicle (Fig. 125,4): Connection to external antenna (Fig. 125,3)
- TV inside the awning (Fig. 126,4): Connection to roof antenna (Fig. 126,1) with connection cable (Fig. 126,2)
- TV inside the awning (Fig. 126,4): Connection to external antenna (Fig. 126,3)

## 8.13 Circuit diagrams

### 8.13.1 Circuit diagrams, interior




Fig. 127 Circuit diagram, interior (EBL 99)






Fig. 128 Circuit diagram, interior (EBL 220)

BUE01013




Fig. 129 Block diagram for panel (IT 96-2)

<b>A</b>	<b>2 x AMP flat pins 4.8 x 0.8</b>
1	+ 12 V
2	Pump
<b>B</b>	<b>Lumberg MSFQ 5-pin</b>
1	Full
2	3/4
3	1/2
4	1/4
5	Base waste water tank
<b>C</b>	<b>Lumberg MSFQ 6-pin</b>
1	Full
2	3/4
3	1/2
4	1/4
5	Base water tank
6	n. c.
<b>D</b>	<b>Lumberg MSFQ 9-pin</b>
1	12 V indicator
2	12 V main switch off
3	12 V main switch on
4	+ Starter battery 12 V
5	+ Living area battery sensor
6	Negative living area battery sensor
7	230 V indicator
8	n. c.
9	n. c.




Fig. 130 Block diagram for panel (IT 994)

<b>A</b>	<b>2 x AMP flat pins 4.8 x 0.8</b>
1	+ 12 V
2	Pump
<b>B</b>	<b>Lumberg MSFQ 9-pin</b>
1	12 V indicator
2	12 V main switch off
3	12 V main switch on
4	+ Starter battery 12 V
5	+ Living area battery sensor
6	Negative living area battery sensor
7	230 V indicator
8	Shunt for appliances
9	Shunt battery
<b>C</b>	<b>Lumberg MSFQ 5-pin</b>
1	Full
2	3/4
3	1/2
4	1/4
5	Base waste water tank
<b>D</b>	<b>Lumberg MSFQ 6-pin</b>
1	Full
2	3/4
3	1/2
4	1/4
5	Base water tank
6	n. c.
<b>E</b>	<b>2 x Lumberg MSFQ 2-pin plugs</b>
<b>IN</b>	<b>External internal temperature sensor (optional)</b>
<b>OUT</b>	<b>External temperature sensor</b>
	▷ If an external internal temperature sensor is used, both gray stranded wires of the internal internal temperature sensor are separated.





Fig. 131 Block diagram, panel (LT 510)

<b>X1</b>	<b>Lumberg MSFQ 6-pin</b>
1	Full
2	3/4
3	1/2
4	1/4
5	Base water tank
6	n. c.
<b>X2</b>	<b>Lumberg MSFQ 5-pin</b>
1	Full
2	3/4
3	1/2
4	1/4
5	Base waste water tank
<b>X3</b>	<b>Lumberg MSFQ 12-pin</b>
1	Main switch relay 1 off
2	Main switch relay 1 on
3	Main switch relay 2 off
4	Main switch relay 2 on
5	Mains signal
6	Shunt for appliances
7	Shunt battery
8	Negative living area battery sensor
9	n. c.
10	+ Living area battery sensor
11	+ Starter battery 12 V
12	+ Lighting

<b>X6</b>	<b>Lumberg MSFQ 10-pin</b>
1	D+
2	Pump
3	Tank heater
4	Anti-freeze
5	n. c.
6	Solar starter battery
7	Solar living area battery
8	n. c.
9	n. c.
10	n. c.
<b>X7</b>	<b>Lumberg MSFQ 2-pin</b>
1	KTY Pin 1
2	KTY Pin 2
<b>X1</b>	<b>Lumberg MSFQ 4-pin</b>
1	ADI1
2	ADI2
3	+12 V
4	GND
<b>X2</b>	<b>Lumberg MSFQ 4-pin</b>
1	ADI1
2	ADI2
3	+12 V
4	GND

## 8.13.2 Circuit diagram, exterior

Fiat



BUE01014

Fig. 132 Circuit diagram, exterior

	Fiat colours	Bürstner colours	Connection
Left side	Pink-black contact 1	Grey	Left direction indicator
	Brown-black contact 2	Blue	Fog tail light
	Black contact 3	White	Earth return
	White-red contact 4	Green	Back-up light
	Green-black contact 5	Red	Brake light
	Yellow-green contact 6	Black	Left rear light
Right side	Pink contact 1	Grey	Right direction indicator
	Brown contact 2	Blue	Fog tail light
	Black contact 3	White	Earth return
	White-red contact 4	Green	Back-up light
	Green contact 5	Red	Brake light
	Yellow contact 6	Black	Right rear light

## Chapter overview

This chapter contains instructions regarding the appliances of the vehicle.

The instructions refer exclusively to the operation of the appliances.

Further information about the appliances can be found in the instruction manuals for the appliances, included separately with the vehicle.

The instructions address the following topics:

- heater
- air conditioning unit
- boiler
- gas cooker
- gas oven
- microwave oven
- extractor hood
- refrigerator

### 9.1 General



- ▷ The heat exchanger of the Truma hot-air heater has to be replaced after 30 years. The heat exchanger of the Alde hot-water heater has to be replaced after 10 years. Only the manufacturer of the heater or an authorised specialist workshop is allowed to replace the heat exchanger. The operator of the heater must see to it that the parts are replaced.
- ▷ For safety reasons, spare parts for pieces of heating appliances must correspond with manufacturer's instructions and be permitted by the manufacturer as a spare part. These spare parts may only be fitted by the manufacturer or an authorised specialist workshop.




- ▷ Further information can be obtained in the instruction manual for the respective appliance.

The heater, air conditioning unit, boiler, cooker and refrigerator are fitted depending on the model of the vehicle.

In this instruction manual a description is given only for the operation of the appliances and their particular features.

To operate gas appliances, first open the regulator tap on the gas bottle and the gas isolator tap corresponding to the appliance.



- 1 Oven
- 2 Refrigerator
- 3 Heater/boiler
- 4 Cooker

Fig. 133 Symbols for the gas isolator taps

## 9.2 Heater



- ▶ Never let gas escape unburned due to danger of explosion.
- ▶ Never run the heater in gas operation when refuelling, on ferries or in the garage. Danger of explosion!
- ▶ Never operate the heater in gas operation in closed spaces (e.g. garages). Danger of poisoning and suffocation!
- ▶ Do not use the space behind the heater as a storage compartment.



- ▷ The circulation fan of the hot-air heater automatically goes on when the hot-air heater is activated and is automatically switched off and on during operation by means of a thermostat control. This puts an immense strain on the living area battery, if the vehicle is connected to an external 230 V power supply. Take into consideration that the living area battery only has limited reserves of energy.

### Initial start-up

When lighting the heater for the first time a small amount of smoke and odour will occur. Immediately set the operating switch of the heater to its highest position. Open doors and windows and ventilate well. Smoke and odour will disappear by themselves after a while.

### 9.2.1 Models with waste gas vent on the right-hand side of the vehicle



- ▶ If the awning is put up and the heater is running in gas operation, exhaust gases from the heater can escape into the awning area. Danger of suffocation! Make sure the area is sufficiently ventilated.

### 9.2.2 To heat properly



Fig. 134 Air outlet nozzle

#### Hot air distribution

Several air outlet nozzles (Fig. 134) are built into the vehicle. Pipes conduct the warm air to the air outlet nozzles. Turn the air outlet nozzles in a suitable position so the air can escape as required. To avoid draft close the air outlet nozzles on the dashboard and set the air distribution of the base vehicle to air circulation.

#### Adjusting the air outlet nozzles

- Fully open: Full hot air stream
- Half or partially open: Reduced hot air stream

When five air outlet nozzles are completely opened, less warm air escapes through each nozzle. However, if only three air outlet nozzles are opened, more warm air flows out of each nozzle.




### 9.2.3 Truma Combi hot-air heater



- ▷ When there is a danger of frost the heater is not in operation, empty the heating system.
- ▷ Do not use the space above and behind the heater as a storage compartment.

Depending on the equipment, different heaters are installed in the vehicles. The heaters differ with regard to the energy type with which they can be operated.



- 1 Temperature control knob
- 2 Summer operation water temperature 40 °C or 60 °C
- 3 Rotary switch
- 4 Off
- 5 Winter operation "Heater without boiler"
- 6 Winter operation "Heater and boiler"
- 7 Green indicator lamp "Heating operation"
- 8 Red indicator lamp "Fault"
- 9 Yellow indicator lamp "Boiler heating-up phase"

Fig. 135 Operating unit for heater/boiler

#### Operating modes

All heaters have two operating modes:

- Winter operation
- Summer operation

It is only possible to heat the vehicle in the "Winter" operating mode. With the "Summer" operating mode only water in the boiler is heated. It is not possible to heat the vehicle in this operating mode.

#### Selecting operating mode:

- Set the operating mode using the rotary switch (Fig. 135,3).

The power supply of the heater cannot be interrupted by means of the 12 V main switch.

#### Variant: Heater with gas operation

The heater is operated exclusively with gas.

#### Winter operation

The heater selects the necessary burner setting according to the required room temperature. When the required room temperature is reached, the burner is switched off. In "Heater and boiler" operating mode (Fig. 135,6) water in the boiler is also heated. In the operating mode "Heater without boiler" (Fig. 135,5) the heater can be operated with an empty boiler.

#### Switching on:

- Open the regulator tap on the gas bottle and the gas isolator tap "Heater/boiler".
- Turn the temperature control knob (Fig. 135,1) on the operating unit to the desired heating level.
- Set rotary switch (Fig. 135,3) to winter operation "Heater without boiler" (Fig. 135,5) or to winter operation "Heater and boiler" (Fig. 135,6).

Green indicator lamp (Fig. 135,7) is on.

The circulation fan automatically switches on when the heater is activated.

- Switching off:*
- Turn the rotary switch (Fig. 135,3) to "O" (Fig. 135,4).
  - Close the gas isolator tap "Heater/boiler" and the regulator tap on the gas bottle.

After switching off the heater, the circulation fan may still run for a moment to use up the residual heat.

### Summer operation

It is not possible to heat the vehicle in "Summer" operating mode. In "Summer" operating mode, only the water in the boiler is heated.

### Variant: Heater with gas and 230 V electrical operation



- ▷ 230 V electrical operation is only possible when the vehicle is connected to the 230 V power supply.
- ▷ Select the output level for 230 V electrical operation so that it corresponds to the fuse protection of the 230 V connection (900 W for 3.9 A fuse, 1800 W for 7.8 A fuse).
- ▷ When the heater on the operating unit is set to summer operation and the energy selector switch is set to mixed operation, the heater still runs only in 230 V operation. The gas burner is not switched on.



- 1 230 V electrical operation (1800 W)
- 2 230 V electrical operation (900 W)
- 3 Gas operation
- 4 Gas and 230 V electrical operation (900 W)
- 5 Gas and 230 V electrical operation (1800 W)
- 6 Yellow indicator lamp "230 V electrical operation"

Fig. 136 Energy selector switch for heater/boiler

The heater can be operated with different types of energy:

- Gas operation (Fig. 136,3)
- 230 V electrical operation with the output levels 900 W (Fig. 136,2) or 1800 W (Fig. 136,1)
- Gas and 230 V electrical operation (mixed operation) with the output levels 900 W (Fig. 136,4) or 1800 W (Fig. 136,5)

The combination gas operation and 230 V electrical operation reduces the heating-up time (only possible when the heater on the operating unit (Fig. 135) is set to winter operation).

When 230 V electrical operation is selected, the yellow indicator lamp illuminates (Fig. 136,6).



- ▷ Further information can be obtained from the separate "Gas heater" instruction manual.
- ▷ For further information about the use of the boiler see section "Boiler".

### 9.2.4 Alde hot-water heater (partially special equipment)



- ▷ Never run hot-water heater without heating fluid. Observe notes in chapter 12.
- ▷ Never drill holes in the floor. This might damage the hot-water pipes.
- ▷ Do not use the space above and behind the heater as a storage compartment.



- ▷ The circulating pump must always be turned on when the hot-water heater is in operation.
- ▷ We recommend to bleed the heating system after the initial heater operation and to check the glycol content. Observe notes in chapter 12.
- ▷ When the heater is turned on, it starts with the last settings used.
- ▷ For further information, see the separate manufacturer's instruction manual and observe the maintenance instructions found in chapter 12.
- ▷ For further information about the use of the boiler see section "Boiler".

The hot-water heater is installed at the bottom of the wardrobe or under the beds.



- 1 Temperature control knob
- 2 Operating mode "Hot water"
- 3 Sliding switch for circulating pump
- 4 Operating mode "Heater and hot water"
- 5 Sliding switch for gas operation
- 6 Red indicator lamp "Fault"
- 7 Sliding switch for 230 V electrical operation

Fig. 137 Operating unit for hot-water heater

#### Operating modes

The hot-water heater has two operating modes:

- Heater and hot water (Fig. 137,4)
- Hot water (Fig. 137,2)

*Selecting operating mode:*

- Use the sliding switch (Fig. 137,3) to set the operating mode.

The hot-water heater can be operated with the following energy sources:

- Gas operation (Fig. 137,5)
- 230 V electrical operation (Fig. 137,7)
- Gas and 230 V electrical operation

#### Gas operation

*Switching on:*

- Open the regulator tap on the gas bottle and the gas isolator tap "Heater/boiler".
- Set sliding switch (Fig. 137,5) to gas operation.
- Turn the temperature control knob (Fig. 137,1) on the operating unit to the desired heating level.
- Set sliding switch (Fig. 137,3) to either "Heater and hot water" (Fig. 137,4) or to "Hot water" (Fig. 137,2).

The red indicator lamp (Fig. 137,6) goes on whenever a fault occurs.

- Switching off:*
- Set the sliding switches (Fig. 137,3 and 5) to "0".
  - Close the gas isolator tap "Heater/boiler" and the regulator tap on the gas bottle.

### 230 V electrical operation

- Switching on:*
- Set the sliding switch (Fig. 137,7) to the required output level.
  - Turn the temperature control knob (Fig. 137,1) on the operating unit to the desired heating level.
  - Set sliding switch (Fig. 137,3) to either "Heater and hot water" (Fig. 137,4) or to "Hot water" (Fig. 137,2).

- Switching off:*
- Set the sliding switches (Fig. 137,3 and 7) to "0".

### Gas and 230 V electrical operation



- ▷ If gas and 230 V electrical operation is selected and if the vehicle is connected to the 230 V power supply, then the hot-water heater at first only operates in 230 V electric operation. Only if the heat output is insufficient does the gas operation also automatically switch on.

- Switching on:*
- Open the regulator tap on the gas bottle and the gas isolator tap "Heater/boiler".
  - Set the sliding switch (Fig. 137,7) to the required output level.
  - Set sliding switch (Fig. 137,5) to gas operation.
  - Turn the temperature control knob (Fig. 137,1) on the operating unit to the desired heating level.
  - Set sliding switch (Fig. 137,3) to either "Heater and hot water" (Fig. 137,4) or to "Hot water" (Fig. 137,2).

The red indicator lamp (Fig. 137,6) goes on whenever a fault occurs.

- Switching off:*
- Set the sliding switches (Fig. 137,3, 5 and 7) to "0".
  - Close the gas isolator tap "Heater/boiler" and the regulator tap on the gas bottle.

### Setting the rotational speed of the circulating pump



- ▷ The hot-water heater is equipped with a very powerful pump. Only operate the pump for approx. 5 minutes on full output when the system is emptied or the pipes are bled. Otherwise, this will increase wear; loud operating noises are the result.



Fig. 138 Speed reduction

The rotational speed of the circulating pump can be set with the control knob (Fig. 138,2). At a lower rotary speed, the operating sounds of the pump are quieter.

The control knob is located on the circulating pump (Fig. 138,1).

*Setting the output:*

- Turn the control knob (Fig. 138,2) in an anticlockwise direction. The output is reduced.
- Rotate the control knob in a clockwise direction. The output is increased.

**3-way valve**

For models with a rear bed, a 3-way valve is connected to the hot water heater circulation. The 3-way valve is installed in the rear garage. The 3-way valve can be accessed via an external flap.



Fig. 139 3-way valve

*Opening the heat circulation in the rear area:*

- Set the lever (Fig. 139,2) of the 3-way valve (Fig. 139,1) parallel to the straight flow direction (Fig. 139).

*Locking the heat circulation in the rear area:*

- Set the lever (Fig. 139,2) of the 3-way valve (Fig. 139,1) transverse to the straight flow direction.

**Alde heat exchanger (special equipment)**



- ▷ The heat exchanger only works when the vehicle engine is running.
- ▷ If the heat exchanger is not being used (as in the summer), the heat exchanger on the stopcock should be shut off.

The heat exchanger can be used to heat the living area of the vehicle during travel without operating the hot-water heater in the living area.

The heat exchanger is connected to the vehicle engine's cooling circuit and thus has the same function as the vehicle heater.

Heat output is set with the living area's heating regulator.

The heat exchanger stopcock is located directly on the exchanger.



Fig. 140 Alde heat exchanger

- Turning on:* ■ Set stopcock handle (Fig. 140,1) parallel to the pipe.
- Shutting off:* ■ Set drain cock handle (Fig. 140,1) at a right angle to the pipe.

**Position** The heat exchanger is installed in the rear bench seat of the central seating group.

#### Alde auxiliary circulating pump (special equipment)



- ▷ The auxiliary circulating pump works only if the heat exchanger has been installed and started, and the hot-water heater is running.




Fig. 141 Auxiliary circulating pump




Fig. 142 Operating switch for auxiliary circulating pump

The auxiliary circulating pump (Fig. 141,1) can be used to heat the vehicle engine when parked.

The auxiliary circulating pump is connected to the vehicle engine's cooling circuit and thus functions as an engine heater.

The auxiliary circulating pump switch (Fig. 142,2) is located next to the hot-water heater operating unit. The yellow indicator lamp (Fig. 142,1) illuminates when the pump is operated.

#### 9.2.5 Auxiliary heat exchanger (partially special equipment)



- ▷ The fan on the auxiliary heat exchanger can be used for ventilation.
- ▷ The heat output is continuously adjusted.

The auxiliary heat exchanger is built into the bench seat.

The auxiliary heat exchanger may be used to provide the vehicle's living area with additional heat during the journey.

The auxiliary heat exchanger is integrated into the heat circulation of the base vehicle and is therefore only in operation when the vehicle engine is running.



Fig. 143 Operating controls for auxiliary heat exchanger

- Switching on:**
- Push the sliding regulator (Fig. 143,1) of the flow control downward to the desired position. The water circulation is open.
  - Turn the fan switch (Fig. 143,2) for the circulation fan in a clockwise direction.
- Switching off:**
- Turn the fan switch (Fig. 143,2) to "O".
  - Push the sliding regulator (Fig. 143,1) of the flow control upward as far as it goes.

### 9.2.6 Electrical floor warming unit (special equipment)



- ▶ On models with electrical floor warming unit, never drill holes in the floor or screw in any screws. Careful with sharp objects. There is danger of a power cut or a short circuit due to damage to a heater wire.



- ▷ Do not cover the transformer. Danger of overheating!



- ▷ The electrical floor warming unit only operates if the vehicle is connected to the 230 V power supply.
- ▷ The output of the electrical floor warming unit alone is not sufficient to heat the living area.





Fig. 144 Transformer for electrical floor warming unit




Fig. 145 Switch for electrical floor warming unit

The transformer (Fig. 144,1) for the electrical floor warming unit is installed either in the bench seat, in the bedding box or in the rear garage, depending on the model.

- Switching on:*
- Connect the vehicle to the 230 V power supply (see chapter 8).
  - Press the rocker switch (Fig. 145,2). The indicator lamp (Fig. 145,1) on the switch is illuminated.

- Switching off:*
- Press the rocker switch (Fig. 145,2). The indicator lamp (Fig. 145,1) on the switch goes off.

After switching off, the floor remains warm for a while, due to residual heat.

If the transformer is overloaded, the overload protection is actuated. The pin (Fig. 144,2) jumps out.

- Switching on overload protection:*
- Press the pin (Fig. 144,2) on the overload protection when the transformer is cooled.

### 9.2.7 Independent vehicle heater (special equipment)



- ▶ Do not operate the independent vehicle heater in closed spaces. Danger of suffocation!
- ▶ Do not operate the independent vehicle heater at petrol stations. Danger of explosion!

The inside and the engine can be heated with the independent vehicle heater. The heating of the engine can be switched off.

The independent vehicle heater can be turned on and off manually or with a timer. The time for the heating to start can be exactly preselected from 1 minute to 24 hours. It is possible to program three switching on times, of which only one can be activated. The maximum permitted operation time is 60 minutes.






Fig. 146 Operating unit for independent vehicle heater

*Switching on manually:* ■ Press the button (Fig. 146,7). The heating mode is displayed by the symbol (Fig. 146,9). The fan will only be switched on when there is a coolant temperature of 30 °C.

*Switching off manually:* ■ Press the button (Fig. 146,7). The symbol (Fig. 146,9) goes off.

*Switching on the engine heating:* ■ Press the lower part of the switch (Fig. 146,4). Engine is preheated. The fan is switched on immediately.

*Switching off the engine heating:* ■ Press the upper part of the switch (Fig. 146,4). Engine stays cold.

*Setting the time:* ■ Press the button (Fig. 146,2). The time setting is displayed by the symbol (Fig. 146,8).  
 ■ Set the time with the buttons (Fig. 146,3 and 6).

*Programming heating start:* ■ Press the button (Fig. 146,5).  
 ■ Set the switching on time within ten seconds, with the buttons (Fig. 146,3 and 6).

*Selecting programmed switching on time:* ■ Keep pressing button (Fig. 146,5) until the selected programme number (Fig. 146,1) appears in the display.

## 9.3 Air conditioning unit (special equipment)

### 9.3.1 Dometic



▷ If the unit is operating, always open at least one ventilation flap.



▷ In the winter, vehicle heating can be supported but not replaced by the air conditioning unit.

▷ Also read the manufacturer's instruction manual.




Fig. 147 Remote control

- 1 Symbol for automatic mode
- 2 Symbol for cold mode
- 3 Symbol for warm mode
- 4 Symbol for ventilation mode
- 5 Symbol for discharged batteries
- 6 Time
- 7 Temperature display
- 8 Fan speed display
- 9 ON/OFF button
- 10 Fan speed button
- 11 "MODE" button
- 12 "CLOCK" button
- 13 Reset key
- 14 Interior temperature display button "ROOM"
- 15 Store button "SET"
- 16 Light button "LIGHT"(optional)
- 17 Temperature unit change button "F/C"
- 18 Temperature decrease button "-"
- 19 Temperature increase button "+"
- 20 Display

To execute the individual switching commands, always point the remote control in the direction of the ceiling unit.

### Operating modes

The air conditioning unit has the following operating modes:

- Automatic
- Ventilation, manual
- Cooling, manual
- Heating, manual

#### Switching on:

- Press the ON/OFF button (Fig. 147,9).
- Press the "Mode" button (Fig. 147,11) as often as required until the required mode (Fig. 147,1, 2, 3 or 4) is indicated on the display (Fig. 147,20).
- Use the "+" (Fig. 147,19) and "-" (Fig. 147,18) buttons to set the desired temperature.
- Use the fan speed button (Fig. 147,10) to select the desired fan level.

#### Switching off:

- Press the ON/OFF button (Fig. 147,9).



Fig. 148 Air conditioning unit (Dometic)

### LED

The LED (Fig. 148,4) on the ceiling unit (Fig. 148,1) displays the operating status of the air conditioning unit:

Status LED	Signification
Off	Air conditioning unit off
Orange	Air conditioning unit ready to operate
Green	Air conditioning unit in operation
Red (continuous)	No 230 V power connection
Red (flashes once intermittently)	Fault in the interior temperature gauge
Red (flashes twice intermittently)	Fault in the exterior temperature gauge

**Air current**

The air current can be directed in different directions. The distribution of the air current toward the front or back is continuously adjustable.

*Adjusting air current:*


- Align the two deflectors (Fig. 148,3 and 5) in the desired position.
- Rotate knob (Fig. 148,2) on sliding regulator in an anticlockwise direction. The sliding regulator for air distribution is released.
- Slide the sliding regulator forwards or backwards to the desired position. The side on which the sliding regulator is located is closed.
- Turn the knob tight in the clockwise direction.

**9.3.2 Telair**


- ▷ Always wait at least 2 minutes between switching off and switching on again. Otherwise the compressor will be damaged.
- ▷ If the unit is operating, always open at least one ventilation flap.




- ▷ The air conditioning unit only runs if the vehicle is connected to a 230 V power supply.
- ▷ In the winter, vehicle heating can be supported but not replaced by the air conditioning unit.
- ▷ Following switch-on the air conditioning unit needs approx. 3 minutes until the compressor starts to run and cold air or hot air is output.
- ▷ Also read the manufacturer's instruction manual.



- 1 Symbol for automatic
- 2 Symbol for cooling
- 3 Symbol for heater
- 4 Temperature (set) display
- 5 Fan speed display
- 6 Temperature increase button
- 7 "ON/OFF" button
- 8 Temperature reduction button
- 9 Ventilation speed button
- 10 "Mode" button
- 11 Display

Fig. 149 Remote control



- 1 Mains connection indicator lamp
- 2 Temperature (current) display
- 3 Mode indicator lamp  
Green: Cooling  
Red: Heater

Fig. 150 Display on the diffuser

To execute the individual switching commands, always point the remote control in the direction of the receiver.

### Operating modes

- Automatic
- Cooling
- Heater

#### Switching on:

- Press the "ON/OFF" button (Fig. 149,7).
- Press the "Mode" button (Fig. 149,10) as often as required until the required mode (Fig. 149,1, 2 or 3) is indicated on the display. The corresponding indicator lamp on the diffuser display (Fig. 150,3) lights up.
- Use the temperature increase button (Fig. 149,6) or temperature reduction button (Fig. 149,8) to set the required temperature.
- Use the ventilation speed button (Fig. 149,9) to select the required ventilation level.

#### Switching off:

- Press the "ON/OFF" button (Fig. 149,7).
- ▷ If the air conditioning unit has run in heating mode, the blower will run on for some minutes in order to dissipate the heat completely.



## 9.4 Boiler



- ▶ Never let gas escape unburned due to danger of explosion.
- ▶ Never run the boiler in gas operation when refuelling, on ferries or in the garage. Danger of explosion!
- ▶ Never operate the boiler in gas operation in closed spaces (e.g. garages). Danger of poisoning and suffocation!
- ▶ The water in the boiler can be heated up to 65 °C. Risk of scalding!



- ▷ Never use boiler when empty.
- ▷ If the boiler is not being used, empty it if there is any risk of frost.
- ▷ Only operate the boiler with the maximum temperature setting if you require a large quantity of warm water. This protects the boiler against the build-up of limescale.




- ▷ Do not use the water from the boiler as drinking water.

### 9.4.1 Models with waste gas vent on the right-hand side of the vehicle



- ▶ If the awning is put up and the boiler is running in gas operation, exhaust gases from the boiler can escape into the awning area. Danger of suffocation! Make sure the area is sufficiently ventilated.

### 9.4.2 Truma Combi boiler



- 1 Summer operation water temperature 40 °C or 60 °C
- 2 Rotary switch
- 3 Winter operation "Heater and boiler"
- 4 Red indicator lamp "Fault"
- 5 Yellow indicator lamp "Boiler heating-up phase"

Fig. 151 Operating unit for heater/boiler

The boiler is integrated into the heater and is operated with gas (gas operation) or with gas and/or electricity (gas and 230 V electrical operation). The boiler is switched on by turning the rotary switch (Fig. 151,2) on the operating unit (Fig. 151). The type of energy is pre-selected (gas and 230 V electrical operation) with the energy selector switch (Fig. 153).

In winter operation "Heater and boiler" (Fig. 151,3) the water is automatically heated up when the heater is switched on. If the heater switches off after the required room temperature has been reached, the boiler will continue to heat up until the set water temperature has been reached.

In summer operation (Fig. 151,1) only the water in the boiler is heated up to either 40 °C or 60 °C. The water is heated to 60 °C in approx. 25 minutes. The yellow indicator lamp (Fig. 151,5) illuminates during the boiler heating-up period.

The power supply for the appliance cannot be interrupted by means of the 12 V main switch. When there is a fault, the red indicator lamp (Fig. 151,4) on the operating unit illuminates (see chapter 14).

#### Safety/drainage valve

The boiler is equipped with a safety/drainage valve (Fig. 152). The safety/drainage valve prevents water in the boiler from freezing, when there is frost and the heater is not switched on.



- ▷ When the vehicle is not used for a long period of time, open the safety/drainage valve and empty the boiler.
- ▷ At temperatures below 2 °C the safety/drainage valve opens automatically. Before filling the boiler, switch on the heater and wait until the temperature on the safety/drainage valve is above 6 °C. Only then can the safety/drainage valve be closed once again.
- ▷ The water pump and the water fittings are not protected against freezing by the safety/drainage valve.



- ▷ The drainage neck of the safety/drainage valve has to be free of dirt (e.g. leaves, ice) at all times.




Fig. 152 Safety/drainage valve of the boiler

#### Variant: Boiler with gas operation

The boiler is operated exclusively with gas.

##### Winter operation

In the "heater and boiler" switch setting in winter operation, the boiler is already switched on.

##### Summer operation

In summer operation the water can be heated up to 40 °C or 60 °C.

##### Switching on:

- Open the regulator tap on the gas bottle and the gas isolator tap "Heater/boiler".
- Set the rotary switch (Fig. 151,2) on the operating unit (Fig. 151) to "Summer operation" (Fig. 151,1).

The yellow indicator lamp (Fig. 151,5) is illuminated during the heating up period. When the set water temperature is reached, the period of heating up is finished and the yellow indicator lamp fades.


##### Switching off:

- Set the rotary switch (Fig. 151,2) on the operating unit (Fig. 151) to "O".
- Close the gas isolator tap "Heater/boiler" and the regulator tap on the gas bottle.

#### Variant: Boiler with gas and 230 V electrical operation



- ▷ 230 V electrical operation is only possible when the vehicle is connected to the 230 V power supply.
- ▷ Select the output level for 230 V electrical operation so that it corresponds to the fuse protection of the 230 V connection (900 W for 3.9 A fuse, 1800 W for 7.8 A fuse).
- ▷ When the boiler on the operating unit is set to summer operation and the energy selector switch is set to mixed operation, the boiler still runs only in 230 V operation. The gas burner is not switched on.



- 1 230 V electrical operation (1800 W)
- 2 230 V electrical operation (900 W)
- 3 Gas operation
- 4 Gas and 230 V electrical operation (900 W)
- 5 Gas and 230 V electrical operation (1800 W)
- 6 Yellow indicator lamp "230 V electrical operation"

Fig. 153 Energy selector switch for heater/boiler

The boiler can be operated with different types of energy:

- Gas operation (Fig. 153,3)
- 230 V electrical operation with the output levels 900 W (Fig. 153,2) or 1800 W (Fig. 153,1)
- Gas and 230 V electrical operation (mixed operation) with the output levels 900 W (Fig. 153,4) or 1800 W (Fig. 153,5)

The combination gas operation and 230 V electrical operation reduces the heating-up time (only possible when the boiler on the operating unit (Fig. 151) is set to winter operation).

When 230 V electrical operation is selected, the yellow indicator lamp illuminates (Fig. 153,6).

### Filling/emptying the boiler

The boiler can be supplied with water from the water tank.

#### *Filling the boiler with water:*

- Switch on 12 V power supply on the panel.
- Close the safety/drainage valve. Turn the knob (Fig. 152,1) perpendicular to the safety/drainage valve and press the button (Fig. 152,2) in.
- Set all the water taps to "Hot" and open them. The water pump is turned on. The warm water pipes are filled with water.
- Keep the taps open until the water flowing out of the taps has no bubbles in it. This is the only way to ensure that the boiler is full of water.
- Close all water taps.

#### *Emptying the boiler:*

- Set the rotary switch (Fig. 151,2) on the operating unit (Fig. 151) to "O".
- Open the safety/drainage valve. To do this turn the knob (Fig. 152,1) parallel to the safety/drainage valve. The snap fastener (Fig. 152,2) jumps out. The boiler is drained to the outside by the safety/drainage valve.
- Check whether the water has been drained completely from the boiler (approx. 10 litres).



- ▷ Further information can be obtained from the separate instruction manual "Boiler" or chapter 10.

### 9.4.3 Alde boiler (partially special equipment)



- 1 Temperature control knob
- 2 Operating mode "Hot water"
- 3 Sliding switch for circulating pump
- 4 Operating mode "Heater and hot water"
- 5 Sliding switch for gas operation
- 6 Red indicator lamp "Fault"
- 7 Sliding switch for 230 V electrical operation

Fig. 154 Operating unit for boiler

The boiler is integrated in the hot-water heater. Over a period of 30 minutes, the boiler heats approx. 12 l water to a temperature of approx. 40 °C.

**Operating modes** The boiler has two operating modes:

- Heater and hot water (Fig. 154,4)
- Hot water (Fig. 154,2)

*Selecting operating mode:* ■ Use the sliding switch (Fig. 154,3) to set the operating mode.

The boiler can be operated with the following energy sources:

- Gas operation (Fig. 154,5)
- 230 V electrical operation (Fig. 154,7)
- Gas and 230 V electrical operation

#### Gas operation

- Switching on:*
- Open the regulator tap on the gas bottle and the gas isolator tap "Heater/boiler".
  - Set sliding switch (Fig. 154,5) to gas operation.
  - Set sliding switch (Fig. 154,3) to either "Heater and hot water" (Fig. 154,4) or to "Hot water" (Fig. 154,2).

The red indicator lamp (Fig. 154,6) goes on whenever a fault occurs.

- Switching off:*
- Set the sliding switches (Fig. 154,3 and 5) to "0".
  - Close the gas isolator tap "Heater/boiler" and the regulator tap on the gas bottle.

#### 230 V electrical operation

- Switching on:*
- Set the sliding switch (Fig. 154,7) to the required output level.
  - Set sliding switch (Fig. 154,3) to either "Heater and hot water" (Fig. 154,4) or to "Hot water" (Fig. 154,2).

- Switching off:*
- Set the sliding switches (Fig. 154,3 and 7) to "0".



**Gas and 230 V electrical operation**


- ▷ If gas and 230 V electrical operation is selected and if the vehicle is connected to the 230 V power supply, then the boiler at first only operates in 230 V electric operation. Only if the heat output is insufficient does the gas operation also automatically switch on.

*Switching on:*

- Open the regulator tap on the gas bottle and the gas isolator tap "Heater/boiler".
- Set the sliding switch (Fig. 154,7) to the required output level.
- Set sliding switch (Fig. 154,5) to gas operation.
- Set sliding switch (Fig. 154,3) to either "Heater and hot water" (Fig. 154,4) or to "Hot water" (Fig. 154,2).

The red indicator lamp (Fig. 154,6) goes on whenever a fault occurs.

*Switching off:*

- Set the sliding switches (Fig. 154,3, 5 and 7) to "0".
- Close the gas isolator tap "Heater/boiler" and the regulator tap on the gas bottle.

**Filling/emptying the boiler**


The boiler can be supplied with water from the water tank.

- ▷ Depending on the model, the vehicle is fitted with one or two drain cocks.



Fig. 155 Drain cock

*Filling the boiler with water:*

- Close the drain cock(s). Position the rocking lever (Fig. 155,1) horizontally.
- Switch on 12 V power supply on the panel.
- Set all the water taps to "Hot" and open them. The water pump is turned on. The warm water pipes are filled with water.
- Keep the taps open until the water flowing out of the taps has no bubbles in it. This is the only way to ensure that the boiler is full of water.
- Close all water taps.

*Emptying the boiler:*

- Switch off boiler.
- Open all water taps and set to the central position.
- Open drain cock(s) (Fig. 155). To do so, set the rocking lever (Fig. 155,1) in a vertical position. The boiler is drained to the outside.
- Check whether the water has been drained completely from the boiler (approx. 12.5 litres).



- ▷ For further information, see the separate manufacturer's instruction manual and observe the maintenance instructions found in chapter 12.

**Position of the drain cock(s)**

See chapter 16.

## 9.5 Cooker



- ▶ Never let gas escape unburned due to danger of explosion.
- ▶ Before using the cooker make sure that there is sufficient ventilation. Open windows or the skylight.
- ▶ Do not use gas cooker or gas oven for heating.
- ▶ Do not fit any curtains in the immediate proximity of the cooker. Fire hazard!
- ▶ Always protect your hands with cooking gloves or potholders when handling hot pots, pans and similar items. There is a risk of injury.

### 9.5.1 Gas cooker



- ▶ During activation and operation of the gas cooker, no flammable objects or highly inflammable objects such as dishcloths, napkins etc. must be near the gas cooker. Fire hazard!
- ▶ The process of ignition must be visible from above and must not be covered by cooking pans placed on the cooker.
- ▶ If there is a flame protection, always put it up when using the gas cooker.
- ▶ Depending on the model, the gas cooker lid is held closed by a spring. When closing there is danger of getting injured!



- ▷ Do not place hot objects such as cooking pans on the sink cover. The plastic can become deformed.
- ▷ Do not use the glass gas cooker lid as a hob.
- ▷ Do not close the gas cooker lid while the gas cooker is in operation.
- ▷ Do not apply pressure on the gas cooker lid when it is closed.
- ▷ Do not place hot cooking pans on the gas cooker lid.
- ▷ Keep the gas cooker lid open after cooking until the burners are cool. Otherwise the glass plate could shatter.



- ▷ Only use pots and pans whose diameter is appropriate for the gas cooker burners.
- ▷ When the flame goes out, the thermocouple automatically cuts the gas supply.
- ▷ Further information can be obtained in the device manufacturer's instruction manual.

The vehicle kitchen unit is fitted with a three-burner gas cooker.

The operating controls for the gas cooker are located directly at the gas cooker.

**Manual ignition** The gas cooker must be lit manually.




Fig. 156 Gas cooker

- Switching on:*
- Open the regulator tap on the gas bottle and the gas isolator tap "Cooker".
  - Open the gas cooker lid (Fig. 156,3).
  - Fold out or set up the flame protection (Fig. 156,1), depending on the model.
  - Turn the control knob (Fig. 156,2) on the burner you wish to use to the ignition position (large flame).
  - Press the control knob down and hold it.
  - Light the burner with a gas lighter, a match or other suitable means of lighting.
  - Once the flame is burning, the control knob must be held down for 10 to 15 seconds, until the thermocouple automatically keeps the gas supply open.
  - Release the control knob and turn to the desired setting.
  - If ignition is unsuccessful, repeat the entire procedure.

- Switching off:*
- Turn the control knob to the 0-position. The flame fades.
  - Close the gas isolator tap "Cooker" and the regulator tap on the gas bottle.

**Automatic ignition (with rocker switch)**

The gas cooker is equipped with electronic ignition.



Fig. 157 Operating controls for gas cooker

- Switching on:*
- Open the regulator tap on the gas bottle and the gas isolator tap "Cooker".
  - Open the gas cooker lid.
  - Depending on the model, fold out and lock the flame protection.
  - Turn the control knob (Fig. 157,1) on the burner you wish to use to the ignition position (large flame).

- Press the control knob down and hold it.
- Press the rocker switch (Fig. 157,2). Ignition sparks are generated at the burner.
- Once the flame is burning, the control knob must be held down for 10 to 15 seconds, until the thermocouple automatically keeps the gas supply open.
- Release the control knob and turn to the desired setting.

*Switching off:*

- Turn the control knob to the 0-position. The flame fades.
- Close the gas isolator tap "Cooker" and the regulator tap on the gas bottle.

### Automatic ignition (without rocker switch)

The gas cooker is equipped with electronic ignition.



Fig. 158 Operating controls for gas cooker

*Switching on:*

- Open the regulator tap on the gas bottle and the gas isolator tap "Cooker".
- Open the gas cooker lid.
- Depending on the model, fold out and lock the flame protection.
- Turn the control knob (Fig. 158,1) on the burner you wish to use to the ignition position (large flame).
- Press the control knob down and hold it.  
The automatic ignition produces ignition sparks. A clicking noise can be heard.
- Once the flame is burning, the control knob must be held down for 10 to 15 seconds, until the thermocouple automatically keeps the gas supply open.
- Release the control knob and turn to the desired setting.

*Switching off:*

- Turn the control knob to the 0-position. The flame fades.
- Close the gas isolator tap "Cooker" and the regulator tap on the gas bottle.

### 9.5.2 Gas oven (Dometic) (special equipment)



- ▶ Keep the ventilation openings on the gas oven open at all times.
- ▶ There must be no flammable objects near the gas oven when it is being lit.
- ▶ If ignition has not taken place, repeat the entire procedure. If necessary, check if there is gas and/or current in the gas oven.



- ▶ If the gas oven still does not work, close the gas isolator tap and notify your service centre.
- ▶ If the burner flame is accidentally extinguished, turn the control knob to "O" and leave the burner off for at least 1 minute. Then ignite it again.



- ▷ Depending on the model the gas oven may come equipped with a grill.
- ▷ Before using the gas oven for the first time run it for 30 minutes at maximum temperature without any contents.
- ▷ When the flame goes out, the thermocouple automatically cuts the gas supply.
- ▷ Further information can be obtained from the separate instruction manual "Gas oven".

The oven is equipped with electronic ignition.



Fig. 159 Gas oven (Dometic)

*Switching on:*

- Open the regulator tap on the gas bottle and the gas isolator tap "Oven".
- Gently press the control knob (Fig. 159,1) and turn left to any position.
- Press the control knob and hold it down for 5 to 10 seconds. Ignition will take place automatically.
- Release the control knob and turn to the desired setting.

*Switching off:*

- Turn the control knob (Fig. 159,1) to "O". The flame fades.
- Close the gas isolator tap "Oven" and the regulator tap on the gas bottle.

### 9.5.3 Microwave oven (special equipment)



- ▶ Only qualified personnel may repair the microwave oven. Improper repairs can cause major risks to the user.
- ▶ The protection device against the escape of microwave energy should never be removed.
- ▶ Use the microwave oven only if it has been properly installed.
- ▶ Only use the microwave oven when the door seal is free of damage.
- ▶ Never leave the microwave oven unattended when it is in operation.
- ▶ If there is smoke, keep the microwave oven closed, switch it off and interrupt the power supply.



- ▷ Operate the microwave oven only with the rotary plate and the rotary cross in place.
- ▷ Use only crockery suitable for microwave use.



- ▷ The microwave oven only functions with correct 230 V power supply. In the case of fluctuations of the voltage or of voltage below 230 V, the microwave oven switches itself off completely. Therefore, do not switch on additional 230 V appliances when the microwave oven is in operation. Particularly in southern countries it happens that the line voltage is described as having 230 V but it really does not amount to this value. So it may happen that the microwave oven cannot be operated in these countries.
- ▷ Further information can be obtained in the manufacturer's instruction manual.



Fig. 160 Operating controls for microwave oven

- Switching on:*
- Press the key (Fig. 160,3) to open the door and place food into the cooking area.
  - Close the door. A clicking noise can be heard when it engages.
  - Select the output on the control knob (Fig. 160,1).
  - Select the cooking time with the control knob (Fig. 160,2). Cooking begins.

The end of the cooking process is signalled by a signal tone. The microwave oven will switch off automatically.

- Switching off:*
- Press the key (Fig. 160,3) to open the door and take out the food.

#### 9.5.4 Extractor hood (special equipment)



Fig. 161 Extractor hood

The cooking area is equipped with an extractor hood. The powerful fan blows the cooking steam directly outside. To switch on the extractor hood, press the right flip switch (Fig. 161,2).

Use the left flip switch (Fig. 161,1) to switch on the two lights in the extractor hood.

## 9.6 Refrigerator

During the journey, only operate the refrigerator via the 12 V power supply. At high ambient temperatures the refrigerator is unable to reach its full cooling power. At high external temperatures, the full cooling power of the cooling unit is only guaranteed if the refrigerator is ventilated sufficiently. In order to achieve a better ventilation the refrigerator ventilation grill can be removed.

### 9.6.1 Refrigerator ventilation grill




Fig. 162 Refrigerator ventilation grill (with sliding trap)

- Removal:*
- Push sliding trap (Fig. 162,1) upward.
  - Remove refrigerator ventilation grill.



Fig. 163 Refrigerator ventilation grill (with screw)

- Removal:*
- Turn screw (Fig. 163,1) one quarter turn using a coin.
  - Remove refrigerator ventilation grill.

### 9.6.2 Operation (Dometic 7 series, automatic ignition)

**Operating modes** The refrigerator has 2 operating modes:

- Gas operation
- Electrical operation (230 V AC or 12 V DC)

The operating mode is set with the operating controls on the refrigerator panel.




- ▷ Select only one energy source.
- ▷ Even when the 12 V power supply is switched off, a small electrical power flows which puts an extra load on the living area battery. Always switch off the refrigerator for a temporary lay-up.

### Gas operation



- ▶ Never let gas escape unburned due to danger of explosion.
- ▶ It is not permitted to operate the refrigerator with car gas.



- 1 Energy selector switch
- 2 "230 V" operating indicator
- 3 "GAS" operating indicator
- 4 "12 V" operating indicator
- 5 Control knob for setting the temperature

Fig. 164 Operating controls for the refrigerator (Dometic 7 series)

#### Switching on:

- Open the regulator tap on the gas bottle and the gas isolator tap "Refrigerator".
- Set the energy selector switch (Fig. 164,1) to "GAS".
- Set the control knob (Fig. 164,5) to maximum power. Gas supply is open. Ignition will take place automatically. A ticking sound can be heard until ignition has been completed successfully. The "GAS" operating indicator (Fig. 164,3) lights up yellow.
- Adjust the refrigerating temperature with the control knob.

#### Switching off:

- Set energy selector switch to "O". Refrigerator is switched off.
- Close the gas isolator tap "Refrigerator" and the regulator tap on the gas bottle.

### Electrical operation



- ▷ Close the gas isolator tap "Refrigerator" when the refrigerator is operated electrically.

The refrigerator can be operated with the following voltages:

- 230 V AC
- 12 V DC

#### Switching the 230 V operation on:

- Set energy selector switch (Fig. 164,1) to "230 V". The "230 V" operating indicator (Fig. 164,2) lights up green.
- Use the control knob (Fig. 164,5) to adjust the refrigerating temperature.

#### Switching the 230 V operation off:

- Set energy selector switch to "O". Refrigerator is switched off.

#### Switching the 12 V operation on:

- Set energy selector switch (Fig. 164,1) to "12 V". The "12 V" operating indicator (Fig. 164,4) lights up green.
- Use the control knob (Fig. 164,5) to adjust the refrigerating temperature.

#### Switching the 12 V operation off:

- Set energy selector switch to "O". Refrigerator is switched off.



When operated with 12 V, the refrigerator draws power only from the starter battery of the vehicle. The starter battery only supplies the refrigerator with 12 V when the vehicle engine is running. When the vehicle engine is not running, the refrigerator is cut off from the power supply in the living area. For this reason, change over to gas operation during prolonged driving breaks.



▷ Further information can be obtained from the separate instruction manual "Refrigerator".

### 9.6.3 Operation (Dometic 7 series with automatic power selection and frame heater)

#### Operating modes

The refrigerator is equipped with automatic power selection (AES). The AES automatically selects the optimal energy source and regulates the refrigerator operation. Manual intervention to select the type of power is possible but not required.


The AES selects from the following types of power:

- Solar installation 12 V
- 230 V AC
- 12 V DC
- Gas

Choosing the available energy source highest on the list.



▷ Even when the 12 V power supply is switched off, a small electrical power flows which puts an extra load on the living area battery. Always switch off the refrigerator for a temporary lay-up.



- 1 Frame heater (FH) button
- 2 Indicator lamp
- 3 Energy selector switch
- 4 Indicator lamps
- 5 Indicator lamps
- 6 Control knob for setting the temperature

Fig. 165 Operating controls for the refrigerator (Dometic 7 series with AES and FH)

#### 230 V operation

If the 230 V power supply is connected, this energy source is selected as the first priority by the AES.

#### 12 V operation

12 V operation is only selected by the AES if the vehicle's engine is running and the alternator supplies sufficient 12 V operating power.

#### Gas operation



- ▶ Never let gas escape unburned due to danger of explosion.
- ▶ It is not permitted to operate the refrigerator with car gas.



- ▷ Open the regulator tap on the gas bottle and the gas isolator tap "Refrigerator".

If the 230 V power supply is **not** connected and the vehicle's engine is **not running** the AES selects the gas supply. When selecting gas operation the ignition fuse is opened automatically so gas can get into the burner. At the same time the electronic ignition is activated. If the gas flame is extinguished, e.g. by blast of wind, the ignition is activated immediately and re-ignites the gas. When the gas operation is faulty, the "GAS" indicator lamp (Fig. 165,4) flashes red.

### Change-over between energy sources



- ▶ Open flames are prohibited at petrol stations. If the stop takes longer than 15 minutes, the refrigerator has to be turned off at the energy selector switch.

When changing over between the different power sources there are forced delays built in the AES. This means, that after a change-over to a new energy source the refrigerator can not be operated immediately. When changing over from 12 V operation to gas operation, a 15-minute delay is built in the AES. This prevents a change-over to gas operation when the vehicle is stopped briefly and the engine is switched off (e.g. stop to fill tank).

### Refrigerating temperature control

When turned on the first time the refrigerator automatically selects the middle thermostat position. This position can be adjusted manually by using the control knob (Fig. 165,6). The indicator lamps (Fig. 165,5) show the selected thermostat position. The refrigerating temperature for the three types of energy is set with the control knob. It takes a few hours till the refrigerator reaches its normal operating temperature. When changing over the operating mode the thermostat setting will be maintained. The refrigerating temperature is retained regardless of the type of power being used.

### Frame heater (FH)



- ▷ If the frame heater is switched on, it will always consume current. Therefore, switch off the frame heater if the vehicle engine is off and the vehicle is not connected to the 230 V power supply.

High external temperatures and high humidity can cause drops of water to form on the metal frame of the freezer compartment. This is why the refrigerator is equipped with a frame heater for the freezer compartment. If the temperature and humidity are high, switch on the frame heater by pressing the button (Fig. 165,1). This prevents corrosion. If the frame heater is switched on, the indicator lamp (Fig. 165,2) will be lit.

### Manual operation

#### Switching on:

- Open the regulator tap on the gas bottle and the gas isolator tap "Refrigerator".
- Select the energy type with the energy selector switch (Fig. 165,3). The respective indicator lamp (Fig. 165,4) lights up green.
- Adjust refrigerating temperature with the control knob (Fig. 165,6). The indicator lamps (Fig. 165,5) show the selected thermostat position.

When the gas operation is faulty, the "GAS" indicator lamp (Fig. 165,4) flashes red.



- ▷ If the refrigerator is manually set to "12 V", it will constantly consume current. Therefore, switch over to gas operation when the vehicle engine is **not** running, and the vehicle is **not** connected to the 230 V power supply.

Switching off:

- Turn the energy selector switch (Fig. 165,3) to "O". No indicator lamp (Fig. 165,4) is lit.
- Close the gas isolator tap "Refrigerator" and the regulator tap on the gas bottle.



- ▷ Further information can be obtained from the separate instruction manual "Refrigerator".

### 9.6.4 Operation (Dometic 8 series with automatic power selection)

#### Operating modes




Fig. 166 Operating controls for the refrigerator (Dometic 8 series with AES)

- 1 On/off switch/energy selector switch
- 2 Display-LED "open door" (only for central locking system of the refrigerator door)
- 3 Display-LED "fault"
- 4 Operating indicator
- 5 Display-LED "temperature range"
- 6 Switch for temperature setting
- 7 Door opener (only for refrigerator door central locking system)

The refrigerator is equipped with automatic power selection (AES). If automatic operation (AU) is selected, the AES automatically selects the optimum energy source and regulates the refrigerator operation. Manual intervention to select the type of power is possible but not required.

The AES selects from the following types of power:

- Solar installation 12 V
- 230 V AC
- 12 V DC
- Gas

Choosing the available energy source highest on the list.

In the case of a fault, the LED display fault will flash "▲!" (Fig. 166,3).



- ▷ Even when the 12 V power supply is switched off, a small electrical power flows which puts an extra load on the living area battery. Always switch off the refrigerator for a temporary lay-up.

**230 V operation** If the 230 V power supply is connected, this energy source is selected as the first priority by the AES.

**12 V operation** 12 V operation is only selected by the AES if the vehicle's engine is running and the alternator supplies sufficient 12 V operating power.

#### Gas operation



▶ Never let gas escape unburned due to danger of explosion.



▷ Open the regulator tap on the gas bottle and the gas isolator tap "Refrigerator".

If the 230 V power supply is **not** connected and the vehicle's engine is **not running** the AES selects the gas supply. When selecting gas operation the ignition fuse is opened automatically so gas can get into the burner. At the same time the electronic ignition is activated. If the gas flame is extinguished, e.g. by blast of wind, the ignition is activated immediately and re-ignites the gas. In the case of a fault in gas operation the text "GAS" flashes in the operating indicator (Fig. 166,4).

#### Change-over between energy sources



▶ Open flames are prohibited at petrol stations. If the stop takes longer than 15 minutes, the refrigerator has to be turned off at the energy selector switch.

When changing over between the different power sources there are forced delays built in the AES. This means, that after a change-over to a new energy source the refrigerator can not be operated immediately. When changing over from 12 V operation to gas operation, a 15-minute delay is built in the AES. This prevents a change-over to gas operation when the vehicle is stopped briefly and the engine is switched off (e.g. stop to fill tank).

#### Refrigerating temperature control

When turned on the first time the refrigerator automatically selects the middle thermostat position. This position can be adjusted manually by using the switch for temperature setting (Fig. 166,6). The indicator LEDs (Fig. 166,5) show the selected thermostat position. The refrigerating temperature for the three types of energy is set with the switch. It takes a few hours till the refrigerator reaches its normal operating temperature. When changing over the operating mode the thermostat setting will be maintained. The refrigerating temperature is retained regardless of the type of power being used.

#### Manual operation

##### Switching on:

- Open the regulator tap on the gas bottle and the gas isolator tap "Refrigerator".
- Press the on/off switch/energy selector switch (Fig. 166,1) down for 2 seconds in order to switch on the appliance. The operating mode selected most recently is shown in the operating indicator (Fig. 166,4).

- Select the energy type with the on/off switch/energy selector switch (Fig. 166,1).
- Set the refrigerating temperature on the switch for temperature setting (Fig. 166,6). The indicator LEDs (Fig. 166,5) show the selected thermostat position.

*Switching off:*

- Press down the on/off switch/energy selector switch (Fig. 166,1) for 2 seconds. All displays close.
- Close the gas isolator tap "Refrigerator" and the regulator tap on the gas bottle.



- ▷ Further information can be obtained from the separate instruction manual "Refrigerator".

### 9.6.5 Refrigerator door locking mechanism

With some models, the refrigerator has a separate freezer compartment. The specifications in this section correspondingly also apply to the door of the freezer compartment.



- ▷ During the journey the refrigerator door must always be closed and locked in the closed position.



- ▷ Lock the refrigerator door in ventilation position when the refrigerator is switched off. This prevents mould forming.

There are two positions for locking the refrigerator door in place:

- Closed refrigerator door during travel and when the refrigerator is in operation
- Slightly opened refrigerator door as a ventilation position when the refrigerator is switched off

#### Dometic 7 series




Fig. 167 Locking of the refrigerator door (Dometic 7 series)



Fig. 168 Refrigerator door in ventilation position (Dometic 7 series)

*Opening:*

- Push the lock (Fig. 167,1) to the left "🔓".
- Use recessed grip to open refrigerator door.

*Closing:*

- Fully close the refrigerator door.
- Push the lock (Fig. 167,1) completely to the right "🔒".

*Locking in the ventilation position:*

- Slightly open refrigerator door.
- Push the lock completely to the right. The door latch (Fig. 168,1) keeps the refrigerator door in a fixed position. The refrigerator door will then stay slightly open (Fig. 168).

### Dometic 7 series with separate freezer compartment




Fig. 169 Locking of the refrigerator door/freezer compartment door (Dometic 7 series with separate freezer compartment)




Fig. 170 Refrigerator door/freezer compartment door in ventilation position (Dometic 7 series with separate freezer compartment)

*Opening:*

- Push the lock (Fig. 169,1) to the side, so that the open lock "🔓" (Fig. 169,3) is completely visible.
- Use recessed grip to open refrigerator door/freezer compartment door.

*Closing:*

- Fully close the refrigerator door/freezer compartment door.
- Push the lock (Fig. 169,1) to the side, so that the closed lock "🔒" (Fig. 169,2) is completely visible.

*Locking in the ventilation position:*

- Slightly open refrigerator door/freezer compartment door.
- Push the lock completely to the right. The door latch (Fig. 170,1) keeps the refrigerator door/freezer compartment door in a fixed position. The refrigerator door/freezer compartment door will then stay slightly open (Fig. 170).

### Dometic 8 series



Fig. 171 Release button of the refrigerator door (Dometic 8 series)



Fig. 172 Lock hook fixture

*Opening:*

- Press the release button (Fig. 171,1) and open the refrigerator door.

*Closing:*

- Close the refrigerator door. The lock hook engages audibly.

When the vehicle has been positioned, the lock hook can be fixed. The refrigerator door can now be opened without having to press the release button.

*Fixing the lock hook:*

- Press the fixture (Fig. 172,1) upwards. The lock hook (Fig. 172,2) is pressed upwards and has no function.

*Unlocking the lock hook:*

- Push the lock hook (Fig. 172,2) down. The lock hook functions again.




Fig. 173 Locking device in normal position




Fig. 174 Locking device in ventilation position

*Locking in the ventilation position:*

- Open the refrigerator door.
- Press down the unlocking device (Fig. 173,2).
- Push locking device (Fig. 173,1) forwards (Fig. 174).

If the refrigerator door is closed now, a gap will remain between the refrigerator door and the refrigerator.





## Chapter overview

This chapter contains instructions regarding the sanitary fittings of the vehicle. The instructions address the following topics:

- water tank
- waste water tank
- waste water tank heater
- complete water system
- toilet compartment
- toilet

### 10.1 Water supply, general



- ▶ Fill water tank from supply systems that have been verified to provide drinking water quality.
- ▶ Only use such hoses or containers when filling that have been approved for use with drinking water.
- ▶ Thoroughly rinse filling hose or container with drinking water before use (2 to 3 times capacity).
- ▶ Empty filling hose or container completely after use and close openings of the filling hose or container.
- ▶ Water left standing in the water tank or in the water pipes becomes undrinkable after a short period. Therefore, before each use of the vehicle, thoroughly clean the water pipes and the water tank. After each use of the vehicle completely empty the water tank and the water pipes.
- ▶ In the case of lay-ups lasting more than a week disinfect the water system before using the vehicle.



- ▷ If the vehicle is not used for several days or if it is not heated when there is a risk of frost, empty the entire water system. Leave the water taps on in central position. Leave the safety/drainage valve (if there is one) and all drain cocks open. Frost damage to appliances, frost damage to the vehicle and deposits in water-carrying components can be avoided in this way.
- ▷ The water pump will overheat without water and can get damaged. Never operate water pump when the water tank is empty.

The vehicle is equipped with a fitted water tank. An electric water pump pumps the water to the individual water taps. Opening a water tap automatically switches on the water pump and pumps water to the tap.

The waste water tank collects the waste water. The water level in the water and waste water tanks can be checked on the panel.



- ▷ Before using the water fittings, the 12 V power supply and water pump on the panel must be turned on. Otherwise the water pump will not work.
- ▷ When the water tank is re-filled, an air bubble may form at the bottom of the pump. This air bubble will prevent water from being drawn in. Shake the water pump up and down energetically in the water.

## 10.2 Water tank

### 10.2.1 Volumes



- ▶ The water tank has a capacity of 120 l. However, the filling level is limited to 60 l for safety reasons (installed overflow). The panel has not been adjusted to this volume. The level indicator on the panel shows the actual amount of water in the tank.

If necessary or if there is a sufficiently large residual vehicle payload, the water tank can be filled up to its actual capacity. To do this, close drain cock. The drain cock is located on or at the side of the water tank.

### 10.2.2 Drinking water filler neck with cap



- ▶ The cap for the drinking water filler neck and for the fuel filler neck are very similar. Before filling the tank, always check the label.




Fig. 175 Cap for the drinking water filler neck



Fig. 176 Cap for the drinking water filler neck (alternative)

The drinking water filler neck is on the right or left side of the vehicle, depending on the model.

The drinking water filler neck is labelled by the word "WASSER" (water) (Fig. 175,1) or marked by the symbol "☕" (Fig. 176,1). The cap is open and closed using the key for the external flap locks.

- Opening:*
- Insert key into locking cylinder (Fig. 175,2 or Fig. 176,2) and turn a quarter turn in an anticlockwise direction.
  - Remove cap.
- Closing:*
- Place the cap on the drinking water filler neck.
  - Turn key one quarter turn in a clockwise direction.
  - Remove the key.
  - Check that the cap sits firmly on the drinking water filler neck.

### 10.2.3 Filling with water



- ▶ When filling the water tank, observe the maximum permissible gross weight of the vehicle. Luggage must be reduced accordingly when the water tank is full.

- Open drinking water filler neck.
- Fill the water tank with drinking water. Use a water hose, a water canister with a funnel or similar for filling.
- Close drinking water filler neck.

### 10.2.4 Draining water (handle with overflow)




Fig. 177 Water tank with handle

- Turn the handle (Fig. 177,1) on the water tank in an anticlockwise direction as far as possible beyond the resistance to fully open the drainage opening.

### 10.3 Waste water tank



- ▷ Never pour boiling water directly into the sink outlet. Boiling water could cause deformation and leaks in the waste water pipe system.



- ▷ Only empty the waste water tank at disposal stations, camping sites or caravan sites especially provided for this purpose.

#### 10.3.1 Models without double floor



- ▷ In case of frost add so much anti-freeze (such as kitchen salt) to the waste water tank so that the waste water cannot freeze.




Fig. 178 Drain cock

The waste water tank is in the rear area of the vehicle. It is located underneath the floor of the vehicle.

Waste water from the kitchen and washing unit flows through plastic pipes into the waste water tank.

The drain cock and the cleaning opening are located on the underside of the waste water tank.

The waste water tank holds 90 litres.

- Emptying:*
- Attach the waste water hose to the drain pipe.
  - Turn the handle (Fig. 178,1) of the drain cock in flow direction.
  - Completely empty waste water tank.
  - Turn the drain cock handle perpendicular to the flow direction.
  - Remove the waste water hose.

### 10.3.2 Models with double floor



- ▷ If the living area heater is out of order, the waste water tank no longer is sufficiently protected against frost. In case of frost add so much anti-freeze (such as kitchen salt) to the waste water tank so that the waste water cannot freeze.



Fig. 179 Drain cock

The waste water tank is in the double floor of the vehicle. The waste water tank can be accessed via an external flap.

Waste water from the kitchen and washing unit flows through plastic pipes into the waste water tank.

The drain cock and the cleaning opening are located on the underside of the waste water tank.

The waste water tank holds 100 litres.

The drain cock (Fig. 179,1) is accessible from the side storage flap.

- Emptying:*
- Attach the waste water hose to the drain pipe.
  - Turn the handle (Fig. 179,1) of the drain cock in flow direction. This drains the waste water through a spherical valve.
  - Completely empty waste water tank.
  - Close the drain cock handle at a right angle to the flow direction once all of the waste water has run out.
  - Remove the waste water hose.

### 10.3.3 Waste water tank heater (special equipment)



Fig. 180 Operating switch

The waste water tank may be heated and is insulated. The integrated frost guard prevents waste water from freezing.

A switch (Fig. 180,1) on the front of the bench seat or bed may be used to switch the frost guard on and off.

The frost guard begins to heat the waste water as soon as the water temperature drops to approx. 5 °C. The frost guard ends the heating process when the waste water reaches a temperature of approx. 10 °C.

### 10.4 Filling the water system



- ▶ When filling the water tank, observe the maximum permissible gross weight of the vehicle. Luggage must be reduced accordingly when the water tank is full.



- ▷ The water pump will overheat without water and can get damaged. Never operate water pump when the water tank is empty.



- ▷ The Truma system (heater/boiler) has an electric safety/drainage valve and, depending on the model, one or two drain cocks for emptying.
- ▷ Depending on the model, the Alde system (heater/boiler) has one or two drain cocks for emptying.
- ▷ The water quantity can be monitored on the panel while the water tank is filled.



Fig. 181 Drain cock (with rocking lever)




Fig. 182 Drain cock (with twist cap)

- Position the vehicle horizontally.
- Switch on 12 V power supply on the panel.

- If necessary, switch on the water pump on the panel.
- Clean or disinfect water system.
- Close the safety/drainage valve (Truma). Turn the knob perpendicular to the safety/drainage valve and press the push button in.  
If the temperature is below 6 °C, the safety/drainage valve cannot be closed. Therefore switch on the living area heater and wait until the temperature of the safety/drainage valve exceeds 6 °C.
- Close all drain cocks. To do this, position the drain cock's rocking lever (Fig. 181,1) horizontally or turn the drain cock's cap (Fig. 182,1) in a clockwise direction.
- Close the drainage opening of the water tank.
- Close all water taps.
- Open the drinking water filler neck on the outside of the vehicle.
- Fill the water tank with drinking water. Use a water hose, a water canister with a funnel or similar for filling.
- Set all the water taps to "Hot" and open them. The water pump is turned on. The warm water pipes are filled with water.
- Keep the taps open until the water flowing out of the taps has no bubbles in it. This is the only way to ensure that the boiler is full of water.
- Set all water taps to "Cold" and leave them open. This will fill the cold water pipes with water.
- Keep the taps open until the water flowing out of the taps has no bubbles in it.
- Close all water taps.
- Close drinking water filler neck.
- Check that the cap on the water tank is not leaking.

#### Position of the drain cocks and safety/drainage valve

See chapter 16.

### 10.5 Emptying the water system



- ▷ If the vehicle is not used for several days or if it is not heated when there is a risk of frost, empty the entire water system. Leave the water taps on in central position. Leave the safety/drainage valve (if there is one) and all drain cocks open. Frost damage to appliances, frost damage to the vehicle and deposits in water-carrying components can be avoided in this way.
- ▷ If the water pump can be turned off from the panel, always turn off the water pump from the panel before you empty the water system. Otherwise the water pump runs until it overheats or the battery is empty.



- ▷ The Truma system (heater/boiler) has an electric safety/drainage valve and, depending on the model, one or two drain cocks for emptying.
- ▷ Depending on the model, the Alde system (heater/boiler) has one or two drain cocks for emptying.



Fig. 183 Drain cock (with rocking lever)




Fig. 184 Drain cock (with twist cap)

To empty and ventilate the water system, proceed as follows. This will avoid frost damage:

- Position the vehicle horizontally.
- If necessary, switch off the water pump on the panel.
- Switch off the 12 V power supply on the panel.
- Shut off the boiler (see section 9.4).
- Open all drain cocks. To do this, position the drain cock's rocking lever (Fig. 183,1) vertically or turn the drain cock's cap (Fig. 184,1) in an anti-clockwise direction.
- Open the safety/drainage valve (Truma). To do this turn the knob parallel to the safety/drainage valve. The push button jumps out.
- Open the water tank drain.
- Open all water taps and set to the central position.
- Hang the shower handset up in the shower position.
- Hold the water pump up until the water pipes are completely empty.
- Check whether the water tank is completely empty.
- Blow out the remaining water in the water pipes (max. 0.5 bar). To do this, remove the pipe from the water pump and blow into the pipe.
- Empty the waste water tank. Take note of the environmental tips in this chapter.
- Empty toilet cassette or sewage tank. Take note of the environmental tips in this chapter.
- Clean the water tank and then rinse it out thoroughly.
- Let the water system dry for as long as possible.
- After emptying, leave all water taps on in the central position.
- Leave all drain cocks open.

**Position of the drain cocks and safety/drainage valve**

See chapter 16.

## 10.6 Toilet compartment



- ▷ Do not transport any loads in the shower tray. The shower tray or other items of equipment in the toilet compartment can be damaged.



- ▷ For ventilation purposes during or after a shower, and for drying wet clothing, close the toilet compartment door and open the window or the toilet compartment skylight. This improves the air circulation.
- ▷ Close the shower curtain completely when showering, so that no water is able to enter the area between the wash room wall and the shower tray.
- ▷ After taking a shower, rinse soap residue from the shower tray, otherwise cracks can appear in the shower tray over time.
- ▷ After using the shower, wipe it dry to prevent moisture from collecting.
- ▷ Further information about cleaning the toilet compartment can be found in the section 11.2.

## 10.7 Toilet



- ▷ If there is any risk of frost and the vehicle is not heated, empty the sewage tank (cassette).
- ▷ Do not sit on the lid of the toilet. The lid is not designed to bear the weight of a person and could break.
- ▷ Use a suitable chemical for this toilet. The ventilation will merely remove the odour but not germs and gases. Germs and gases will have a detrimental effect on the sealing rubbers.
- ▷ Never put the sanitary liquid directly in the toilet bowl.



- ▷ Further information can be obtained in the device manufacturer's instruction manual.



- ▷ Only empty the sewage tank (cassette) at disposal stations, at camping sites or caravan sites, that are especially provided for this purpose.

The flushing of the toilet is fed directly from the water system of the vehicle.

### 10.7.1 Swivel toilet (Thetford C-200)



- ▷ The Thetford cassette can only be taken out if the sliding trap is closed.




Fig. 185 Pulling the retaining clip

*Preparing toilet:*

- Open the flap for the Thetford cassette and pull the retaining clip upwards to remove the Thetford cassette.






Fig. 186 Removing the Thetford cassette

- Pull out the Thetford cassette as far as it can go.
- Tip the Thetford cassette slightly and then pull it out completely.




Fig. 187 Turning drainage neck

- Place the Thetford cassette upright.
- Turn the drainage neck upwards.
- Remove the cap of the drainage neck.
- ▷ Never put the sanitary liquid directly in the toilet bowl.




Fig. 188 Filling with sanitary liquid

- Fill the Thetford cassette with the specified quantity of sanitary liquid.
- Then add enough water to completely cover the bottom of the Thetford cassette.
- Close drainage neck with the cap.
- Return the drainage neck to its original position.



- ▷ When inserting, do not use force. The Thetford cassette can be damaged.




Fig. 189 Inserting the Thetford cassette

- Push the Thetford cassette back to its original position.




Fig. 190 Thetford cassette secured

- Ensure that the Thetford cassette is secured by the retaining clip.
- Lock the flap for the Thetford cassette.




Fig. 191 Rotating the toilet bowl

- Using the toilet:*
- Move the toilet bowl into a convenient position.




Fig. 192 Pre-flush

- Fill the toilet bowl with some water. Press the flush button. Flushing continues as long as the button is pressed.
- Use the toilet.

**C-200 S cassette**

With the C-200 S cassette, proceed as follows to flush the toilet:




Fig. 193 Operating the sliding trap

- Open the sliding trap. To do this, turn the slide lever in an anticlockwise direction.




Fig. 194 Operating the flush

- Flush the toilet. Press the flush button.
- After flushing close the sliding trap.

**C-200 E cassette** With the C-200 E cassette, proceed as follows to flush the toilet:




Fig. 195 Opening the sliding trap

- Open the sliding trap. To do this, press the left side of the sliding trap button.




Fig. 196 Closing the sliding trap

- Flush the toilet. Press the flush button.
- After flushing close the sliding trap. To do this, press the right side of the sliding trap button.



- ▷ The Thetford cassette can only be taken out if the sliding trap is closed.




Fig. 197 Removing the Thetford cassette

*Emptying the Thetford cassette:*

- Open the flap for the Thetford cassette and pull the retaining clip upwards to remove the Thetford cassette.
- Pull out the Thetford cassette as far as it can go.
- Tip the Thetford cassette slightly and then pull it out completely.




Fig. 198 Carrying the Thetford cassette

- Take the Thetford cassette to a proper disposal area. As you do this, point the drainage neck upwards.




Fig. 199 Emptying the Thetford cassette

- Turn the drainage neck upwards.
- Remove the cap of the drainage neck.
- Point the Thetford cassette with the drainage neck downwards.
- Activate the aeration knob with your thumb. The Thetford cassette empties.
- Rinse the Thetford cassette thoroughly with fresh water.
- Close drainage neck with the cap.
- Return the drainage neck to its original position.




Fig. 200 Inserting the Thetford cassette

- Prepare the Thetford toilet for use.
- Push the Thetford cassette back to its original position.
- Ensure that the Thetford cassette is secured by the retaining clip.
- Lock the flap for the Thetford cassette.

### 10.7.2 Toilet with fixed seat (Thetford C-402)



- ▷ The Thetford cassette can only be taken out if the sliding trap is closed.




Fig. 201 Pulling the retaining clip

*Preparing toilet:*

- Open the flap for the Thetford cassette and pull the retaining clip upwards to remove the Thetford cassette.




Fig. 202 Removing the Thetford cassette

- Pull out the Thetford cassette as far as it can go.
- Tip the Thetford cassette slightly and then pull it out completely.




Fig. 203 Turning drainage neck

- Place the Thetford cassette upright.
  - Turn the drainage neck upwards.
  - Remove the cap of the drainage neck.
- ▷ Never put the sanitary liquid directly in the toilet bowl.






Fig. 204 Filling with sanitary liquid

- Fill the Thetford cassette with the specified quantity of sanitary liquid.
  - Then add enough water to completely cover the bottom of the Thetford cassette.
  - Close drainage neck with the cap.
  - Return the drainage neck to its original position.
- ▷ When inserting, do not use force. The Thetford cassette can be damaged.




Fig. 205 Inserting the Thetford cassette

- Push the Thetford cassette back to its original position.




Fig. 206 Thetford cassette secured

- Ensure that the Thetford cassette is secured by the retaining clip.
- Lock the flap for the Thetford cassette.




Fig. 207 Pre-flush

*Using the toilet:*

- Fill the toilet bowl with some water. Press the flush button. Flushing continues as long as the button is pressed.
- Use the toilet.




Fig. 208 Operating the sliding trap

- Open the sliding trap. To do this, turn the slide lever in an anticlockwise direction.




Fig. 209 Operating the flush

- Flush the toilet. Press the flush button.
- After flushing close the sliding trap again. To do this turn the slide lever in a clockwise direction.



- ▷ The Thetford cassette can only be taken out if the sliding trap is closed.






Fig. 210 Removing the Thetford cassette

*Emptying the Thetford cassette:*

- Open the flap for the Thetford cassette and pull the retaining clip upwards to remove the Thetford cassette.
- Pull out the Thetford cassette as far as it can go.
- Tip the Thetford cassette slightly and then pull it out completely.



Fig. 211 Transporting the Thetford cassette

- Place the Thetford cassette upright on the wheels.
- Press down the handle of the draw bar and move away from the Thetford cassette. The lock of the draw bar releases itself.
- Pull the draw bar out completely by the handle.
- Take the Thetford cassette to a proper disposal area.
- Insert the draw bar completely using the handle.




Fig. 212 Emptying the Thetford cassette

- Turn the drainage neck upwards.
- Remove the cap of the drainage neck.
- Point the Thetford cassette with the drainage neck downwards.

- Activate the aeration knob with your thumb. The Thetford cassette empties.
- Rinse the Thetford cassette thoroughly with fresh water.
- Close drainage neck with the cap.
- Return the drainage neck to its original position.




Fig. 213 Inserting the Thetford cassette

- Prepare the Thetford toilet for use.
- Push the Thetford cassette back to its original position.
- Ensure that the Thetford cassette is secured by the retaining clip.
- Lock the flap for the Thetford cassette.

### 10.7.3 Toilet (Dometic)



- ▷ The sewage tank (cassette) can only be taken out if the sliding trap is closed.




Fig. 214 Flap for sewage tank



Fig. 215 Sewage tank

#### *Preparing toilet:*

- Open the flap for the sewage tank on the outside of the vehicle. Insert the key into the locking cylinder of the push-button lock (Fig. 214,1) and turn a quarter turn.
- Remove the key.
- Press both push-button locks (Fig. 214,2) simultaneously with your thumb and open the flap.
- Pull up the retaining clip (Fig. 215,3) and use the handle (Fig. 215,2) to lift the sewage tank (Fig. 215,1) straight up.
- Tilt the sewage tank slightly and remove fully.




Fig. 216 Turning drainage neck




Fig. 217 Filling with sanitary liquid

- Put the sewage tank down vertically.
- Turn the drainage neck upwards.
- Remove the cap of the drainage neck.
- Fill the stated amount of sanitary liquid into the sewage tank.
- Then add enough water to completely cover the bottom of the sewage tank.
- Close drainage neck with the cap.
- Return the drainage neck to its original position.
- Push the sewage tank back to its original position without applying any force.
- Ensure that the sewage tank is secured by the retaining clip.
- Lock the flap for the sewage tank.




Fig. 218 Toilet bowl with control and operating unit




Fig. 219 Control and operating unit toilet

Let some water run into the toilet bowl before using the toilet. In order to do so press the flush button (Fig. 219,3) on the control and operating unit (Fig. 218,2).

*Flushing:*

- Before flushing open the sliding trap of the toilet. For this pull out the slide lever (Fig. 218,1).
- For flushing, press the flush button (Fig. 219,3).
- After flushing close the sliding trap. To do so, push the slide lever back.

The indicator lamp (Fig. 219,2) goes on whenever the sewage tank is filled up to 3/4.

The indicator lamp (Fig. 219,1) goes on whenever the sewage tank has to be emptied.

- Removal of sewage tank:*
- Push the slide lever (Fig. 218,1) in. The sliding trap is closed. To empty, the sliding trap of the toilet **must** be closed.
  - Open the flap for the sewage tank on the outside of the vehicle.
  - Pull up the retaining clip (Fig. 215,3) and use the handle (Fig. 215,2) to lift the sewage tank (Fig. 215,1) straight up.
  - Tilt the sewage tank slightly and remove fully. The display "Sewage tank removed" (Fig. 219,4) lights up on the control and operating unit.




Fig. 220 Empty the sewage tank

- Emptying the sewage tank:*
- Take the sewage tank to a disposal point especially provided for this purpose.
  - Turn the drainage neck as far upwards as possible.
  - Remove the cap of the drainage neck.
  - Point the sewage tank with the drainage neck downwards.
  - Activate the aeration knob with your thumb. The sewage tank empties.
  - Flush the sewage tank with water.
  - Close drainage neck with the cap.
  - Return the drainage neck to its original position.
  - Push the sewage tank back to its original position without applying any force.
  - Ensure that the sewage tank is secured by the retaining clip.
  - Lock the flap for the sewage tank.

## Chapter overview

This chapter contains instructions regarding the care of the vehicle.

The instructions address the following topics:

- exterior of the vehicle
- interior
- water system
- extractor hood
- air conditioning unit
- winter operation

At the end of the chapter there is a checklist of measures you must carry out if you are not going to use the vehicle for an extended period of time.

The checklist address the following topics:

- temporary lay-up
- winter lay-up
- start-up after a lay-up

### 11.1 External care

#### 11.1.1 Washing with a high-pressure cleaner



- ▷ Do not clean the tyres with a high-pressure cleaner. The tyres might be damaged.
- ▷ Do not spray external applications (deco-films) directly with the high-pressure cleaner. The external applications could come off.

Before cleaning the vehicle with a high-pressure cleaner, observe the operating instructions of the high-pressure cleaner.

When cleaning with the nozzle for circular jet between the vehicle and the cleaning nozzle, maintain a minimum distance of approx. 700 mm.

Take into consideration that the jet of water comes out of the cleaning nozzle with pressure. The vehicle may be damaged by incorrect handling of the high-pressure cleaner. The temperature of the water should not be above 60 °C. Keep the jet of water in constant movement during the washing process. Do not direct the water jet at clearances, built-in electrical parts, plugs, seals, the ventilation grill or the skylights. The vehicle may be damaged or water may enter the interior.

#### 11.1.2 Washing the vehicle



- ▷ Never clean the vehicle in the car wash. Water can enter the refrigerator grills, the waste gas vents, the ventilation of the extractor hoods or the forced ventilations. The vehicle could be damaged.

- Wash the vehicle only on a washing site intended for this purpose. Avoid full sunshine. Observe environmental measures.
- Only clean external applications and synthetic parts with plenty of warm water, dish washing liquid and soft cloth.
- Wash down the vehicle with plenty of water, a clean sponge or a soft brush. In the case of stubborn dirt add dish washing liquid to the water.
- Painted exterior walls may also be cleaned with a caravan cleaner.

- Add-on parts made of glass-fibre reinforced plastic (GRP) require a regular follow-up treatment with a polisher. This way these parts will not turn yellow and the sealing of the surface remains intact.
- Treat rubber seals of doors and storage flaps with talc.
- Treat locking cylinder of doors and storage flaps with graphite dust.

### 11.1.3 Windows of acrylic glass

Acrylic glass windows are delicate and require very careful handling.



- ▷ Never rub acrylic glass windows dry as dust particles might damage the surface!
- ▷ Only clean acrylic glass windows with plenty of warm water, some dish washing liquid and a soft cloth.
- ▷ Never use glass cleaning agents with chemical, abrasive or alcohol-containing additives. Premature brittleness of the panes and associated cracks may result from their use.
- ▷ Avoid contact of cleansing agents used for the body (e.g. tar- or silicone-removing agents) with acrylic glass.
- ▷ Do not clean vehicle in car wash.
- ▷ Do not attach stickers to the acrylic glass windows.
- ▷ Having cleaned the vehicle rinse acrylic glass with sufficient clear water.
- ▷ Treat rubber seals with glycerin.



- ▷ An acrylic glass cleanser with antistatic effect is suitable for a follow-up treatment. Small scratches can be treated with an acrylic glass polish. These agents are available at the accessories shop.

### 11.1.4 Underbody

The underbody of the vehicle is partly coated with an age-resistant underbody protection. Should the underbody protection be damaged, repair immediately. Do not treat areas coated with underbody protection with spray oil.



- ▷ Only use products approved by the manufacturer. Our authorised dealers and service centres will be happy to advise you.

### 11.1.5 Waste water tank

Clean the waste water tank after every use.

*Cleaning:*

- Empty the waste water tank.
- Open the cleaning opening on the waste water tank and the drain cock.
- Thoroughly rinse out the waste water tank with fresh water.
- If possible, clean waste water sensors through the cleaning opening by hand.

### 11.1.6 Entrance step

If the entrance step is lubricated, coarse particles of dirt can settle on the lubricant during the journey and cause damage to the operating mechanism of the entrance step. Therefore, do not lubricate the moving parts of the entrance step.

## 11.2 Interior care



- ▷ If possible, treat stains immediately.
- ▷ Acrylic glass windows are delicate and require very careful handling (see section 11.1.3).
- ▷ Synthetic parts in the toilet and living area are very delicate and should be treated with care. Do not use solvents, alcohol-containing cleansers or scourers containing sand. This procedure will help you to avoid brittleness and formation of cracks.
- ▷ Do not pour any corrosive agents into the drain holes. Never pour boiling water directly into the drain holes. Corrosive agents and boiling water cause damage to drainage pipes and siphon traps.
- ▷ Do not use vinegar based products to clean the toilet and water system, or for decalcification of the water system. Vinegar-based products may cause damage to seals or parts of the installation. Use standard decalcifying products for decalcification.
- ▷ Save water. Mop up all remaining water.
- ▷ Vacuum off carpets and cushions with a suitable brush attachment.



- ▷ For information about the use of maintenance products, our representatives and service centres will be glad to advise.
- Surface and knobs of furniture, lamps and synthetic parts in the toilet and living area should be cleaned with water and a wool cloth. A mild cleanser may be added to the water. If required, use furniture polish for the painted surfaces.
- Clean upholstery with dry foam specially manufactured for the use on upholstery or with the foam of a mild detergent. Do not wash upholstery. Always have it cleaned. Protect upholstery from direct sunlight so that it does not lose its colour.
- Clean upholstery made of novalife® with clear water only.
- Leather covers should be cleaned with a cotton cloth and a mild soap (curd soap). Make sure that the leather is not soaked through and that no water seeps through the seams of the leather covers.
- Curtains and net curtains should be dry cleaned.
- Vacuum clean the carpet, if necessary clean with carpet shampoo.
- Clean PVC-floor covering with a mild, soapy cleanser for PVC floors. Do not place carpet on wet PVC-floor covering. The carpet and the PVC-floor covering may stick together.
- Never clean the sink or the gas cooker with a scourer. Avoid anything which may cause scratching or grooves.
- Clean gas cooker only with a moist cloth. Prevent any water from penetrating the gas cooker. Water may damage the gas cooker.

- Brush insect screens on doors, windows and skylights with a soft brush or vacuum with the brush attachment of the vacuum cleaner.
- Brush blinds with a soft brush or vacuum with the brush attachment of the vacuum cleaner. Grease or stubborn dirt may be removed with a mild soap at 30 °C (curd soap).
- Brush Roman shades with a soft brush or vacuum with the brush attachment of the vacuum cleaner. Grease or stubborn dirt may be removed with a mild soap at 30 °C (curd soap).
- Unrolled seat belts can be cleaned with warm soapsuds. The seat belt must be completely dry before being rolled up.

## 11.3 Water system

### 11.3.1 Cleaning the water tank

- Empty the water tank and close the drainage opening.
- Remove the cap of the water tank.
- Fill water tank with water and some washing-up liquid (do not use any scourers).
- Using a trade standard brush for washing dishes, scrub the water tank until there is no longer any visible deposit.
- Scrub also the pump housing.
- If possible, clean fresh water sensors through the cleaning openings by hand.
- Rinse water tank with copious amounts of drinking water.

### 11.3.2 Cleaning the water pipes



- ▷ Only use suitable cleaning agents as sold by the specialist trade.



- ▷ Collect any emerging mixture of water and cleaning agent for correct disposal.

- Empty the water system.
- Close all drain holes and drain cocks.
- Fill mixture of water and cleaning agent into the water tank. Observe the manufacturer's instructions regarding the mixing ratio.
- Open the drain cocks one by one.
- Leave the drain cocks open until the mixture of water and cleaning agent has reached the respective drain.
- Close the drain cocks.
- Set all the water taps to "Hot" and open them.
- Leave the drain cocks open until the mixture of water and cleaning agent has reached the drain.
- Set all water taps to "Cold" and open them.
- Leave the drain cocks open until the mixture of water and cleaning agent has reached the drain.



- Close all water taps.
- Flush the toilet several times.
- Allow the cleaning agent to act in accordance with the manufacturer's instructions.
- Empty the water system. Collect the mixture of water and cleaning agent for correct disposal.
- For rinsing fill the entire water system with drinking water and empty again several times over.

### 11.3.3 Disinfecting the water system



- ▷ Only use suitable disinfectants as sold by the specialist trade.



- ▷ Collect any emerging mixture of water and disinfectant for correct disposal.

- Empty the water system.
- Close all drain holes and drain cocks.
- Fill mixture of water and disinfectant into the water tank. Observe the manufacturer's instructions regarding the mixing ratio.
- Open the drain cocks one by one.
- Leave the drain cocks open until the mixture of water and disinfectant has reached the respective drain.
- Close the drain cocks.
- Set all the water taps to "Hot" and open them.
- Leave the drain cocks open until the mixture of water and disinfectant has reached the drain.
- Set all water taps to "Cold" and open them.
- Leave the drain cocks open until the mixture of water and disinfectant has reached the drain.
- Close all water taps.
- Flush the toilet several times.
- Allow the disinfectant to act in accordance with the manufacturer's instructions.
- Empty the water system. Collect the mixture of water and disinfectant for correct disposal.
- For rinsing fill the entire water system with drinking water and empty again several times over.

## 11.4 Extractor hood

Clean the extractor hood filter occasionally. How often cleaning is necessary depends on how often the extractor hood is used. Do not wait to clean the filter until the performance of the extractor hood has noticeably decreased.

*Cleaning the filter:*

- Wash the filter with warm water and some washing-up liquid.

## 11.5 Air conditioning unit

### 11.5.1 Dometic



Fig. 221 Air conditioning unit (Dometic)

A lint filter and an activated carbon filter are each located in the lower part of the air conditioning system ceiling unit (Fig. 221,2) behind the ventilation grilles (Fig. 221,1 and 3). The lint filters must be cleaned at regular intervals and replaced if necessary. The manufacturer recommends replacing the activated carbon filter yearly.

On the left side of the ceiling unit (outside of the vehicle) is located the drainage opening for the condensation. Keep the drain openings free from dirt, leaves or similar to allow the condensation to be drained.

### 11.5.2 Telair

Every now and then clean the filter and the ventilation grilles on the outside of the housing. How often cleaning is necessary depends on how often the air conditioning unit is used. Do not wait to clean the filter and the ventilation grill until the performance of the air conditioning unit has noticeably decreased.



- ▷ Only use mild cleaning solutions to clean the filter, never use benzene or solvents.

*Cleaning the filter:*

- Wash the filter with warm water and some washing-up liquid.
- Allow the filter to dry thoroughly before reassembly.

*Cleaning the ventilation grill:*

- Use a brush to remove coarse dirt or deposits from the external ventilation grilles. If a cleaning solution is used, ensure that no water ingresses into the inside of the housing.

## 11.6 Winter care

De-icing salt damages the underbody and the parts open to water spray. We recommend that you wash the vehicle more frequently during wintertime. Mechanical and surface treated parts and the underside are under particular strain, and should therefore be cleaned thoroughly.



- ▷ If there is any risk of frost, always run heater at a minimum of 15 °C. Switch the circulation fan (if there is one) to automatic. In the case of extreme external temperatures, the furniture flaps and doors should be left slightly open. The inflowing warm air can help prevent the freezing of water pipes, for example, and counteract the formation of condensation in the storage spaces.
- ▷ If there is any risk of frost, cover the outside surface of the windows with winter insulation mats.
- ▷ Keep waste gas vents and forced ventilations free of snow. Use a vent extension, if necessary.

### 11.6.1 Preparations

- Check the vehicle for paint and rust damage. Repair damage as necessary.
- Make certain that water cannot penetrate the automatic floor ventilation system and the heater.
- Use a wax-based rust inhibitor to protect the metal parts of the underbody.
- Use appropriate protection for external painted surfaces.

### 11.6.2 Winter operation

During winter operation, condensation develops when the vehicle is occupied under low-temperature conditions. To ensure good interior air quality and avoid vehicle damage from condensation, sufficient ventilation is essential.

- When heating the vehicle, the heater should be at the highest setting and roof storage cabinets, curtains and blinds should be opened. This ensures optimal ventilation.
- Only heat if the circulation system is switched on.
- In the morning, lift up all cushions, air out storage boxes and dry any damp areas.



- ▷ If condensation has still developed, just wipe it off.
- ▷ It is only possible to guarantee unrestricted operation during winter for models without double floor in connection with the "winter package" from the original equipment.

### 11.6.3 At the end of the winter season

- Thoroughly clean the underbody of the vehicle and the engine. When this is done, corrosion-inducing anti-freeze agents (salts, alkaline residues) are removed.
- Clean the exterior and use regular car wax to protect metal surfaces.


## 11.7 Lay-up



### 11.7.1 Temporary lay-up



- ▶ If the vehicle has been stationary for a long period (approx. 10 months) have the braking and gas systems checked by an authorised specialist workshop.
- ▶ Take into consideration that water is undrinkable after only a short time.
- ▶ Animal damage to cables can lead to short circuits. Fire hazard!

Before laying up the vehicle, go through the following checklist:

	Activities	Done
<b>Base vehicle</b>	Completely fill fuel tank. This prevents corrosion damage within the fuel tank system	
	Jack up vehicle so that the wheels do not bear any load, or move vehicle every 4 weeks. This prevents any pressure points from occurring on tyres and wheel bearings	
	Protect the tyres from direct exposure to the sun. Danger of formation of cracks!	
	Inflate tyres up to the recommended maximum pressure	
	Always provide for sufficient ventilation in the underbody area	
	 ▶ Humidity or lack of oxygen e.g. by covering with plastic film may cause optical irregularities to the underbody.	
	In addition observe the notes in the operating manual of the base vehicle	
<b>Body</b>	All vents should be sealed with the appropriate caps and all other openings (apart from forced ventilations) should also be sealed. This prevents animals (e.g. mice) from gaining entry	
	Air the interior, all storage compartments accessible from the outside, and the parking space (e.g. garage) every 3 weeks in order to prevent the occurrence of condensation and resulting mould formation	
<b>Interior</b>	Place upholstery in an upright position for ventilation, and cover	
	Clean refrigerator	
	Allow refrigerator and freezer compartment doors to remain slightly open	
	Search for traces of animals that have gained entry	
	Disconnect the flat screen from the mains and, if necessary, remove it from the vehicle	
<b>Gas system</b>	Close regulator tap on the gas bottle	
	Close all gas isolator taps	
	Always remove gas bottles from the gas bottle compartment, even if they are empty	

	Activities	Done
<b>Electrical system</b>	Fully charge living area and starter battery  ▷ Charge the battery for at least 20 hours before laying up.	
	Disconnect the living area battery from the 12 V power supply. In order to do this switch off the battery cut-off switch on the transformer/rectifier or activate the battery separation via the panel (see chapter 8)	
<b>Water system</b>	Empty the entire water system. Blow out the residual water from the water pipes (0.5 bar max.). Leave the water taps on in central position. Leave the safety/drainage valve and all drain cocks open. Observe the notes in chapter 10	
	Disconnect the safety/drainage valve (Truma) from the power supply. In order to do this switch off the battery cut-off switch on the transformer/rectifier or activate the battery separation via the panel (see chapter 8). Otherwise the battery will become discharged too quickly  ▷ If the safety/drainage valve is switched off, the water system is no longer sufficiently protected against frost.	

### 11.7.2 Winter lay-up


Additional measures are required if laying up the vehicle over winter:

	Activities	Done
<b>Base vehicle</b>	Clean body and underbody thoroughly and spray with hot wax or protect with varnish	
	Fill fuel tank with winter diesel	
	Check antifreeze in the cooling water	
	Rectify damage to the paintwork	
<b>Body</b>	Clean vehicle from outside thoroughly	
	Keep the forced ventilation open	
	Clean and grease installed supports	
	Clean and grease all door and flap hinges	
	Brush oil or glycerine on all locking mechanisms	
	Rub all rubber seals with talc	
	Use graphite dust to treat locking cylinders	
<b>Interior</b>	Position de-humidifiers	
	Remove upholstery from the vehicle and store in a dry place	
	Air the interior every 3 weeks	
	Empty all cabinets and storage compartments, open flaps, doors and drawers	
	Thoroughly clean the interior	
	If there is a risk of frost, do not leave the flat screen in the vehicle	

	Activities	Done
<b>Electrical system</b>	Remove the starter battery and the living area battery and store them in a place protected from frost (see chapter 8) or connect the vehicle to a 230 V supply	
<b>Water system</b>	Clean the water system using a cleaning agent from a specialised store	
<b>Complete vehicle</b>	Arrange the tarpaulins in such a way that the ventilation openings are not covered, or use porous tarpaulins	

### 11.7.3 Starting up the vehicle after a temporary lay-up or after lay-up over winter

Go through the following checklist before start-up:

	Activities	Done
<b>Base vehicle</b>	Check the tyre pressure on all tyres Check the tyre pressure of the spare wheel	
<b>Body</b>	Clean the pivot bearing of the entrance step Check the functioning of the fitted supports Check that the windows and skylights are working properly Check that all the external locks are working, such as the external flaps, the filler neck and the conversion door Remove the cover from the waste gas vent of the heater (if there is one) Remove the winter cover from the refrigerator grills (if there is one)	
<b>Gas system</b>	Put the gas bottles in the gas bottle compartment, tie down and connect to the gas pressure regulator	
<b>Electrical system</b>	Connect to 230 V power supply using the external socket Fully charge living area and starter battery  ▷ Charge the battery for at least 20 hours after lay-up. Connect the living area battery with the 12 V power supply. In order to do this switch on the battery cut-off switch on the transformer/rectifier or deactivate the battery separation via the panel (see chapter 8) Check that the electrical system are working, e.g. interior light, socket and all installed electrical appliances	
<b>Water system</b>	Disinfect water pipes and water tank Check the functionality of the operating lever for the waste water tank Close safety/drainage valve (if there is one), drain cocks and water taps Check the safety/drainage valve, water taps, drain cocks and water distributors for leaks	

**Appliances**

<b>Activities</b>	<b>Done</b>
Check the function of the appliances	
Change heating fluid of the hot-water heater every 2 years	





## Chapter overview

This chapter contains instructions about inspection and maintenance work concerning the vehicle.

The maintenance instructions address the following topics:

- doors
- living area battery
- Alde hot-water heater
- independent vehicle heater
- replacing light bulbs

At the end of the chapter you will find important instructions on how to obtain spare parts.

### 12.1 Inspection work

Like any technical appliance, the vehicle must be inspected at regular intervals.

This inspection work must be carried out by qualified personnel.

Special technical knowledge, which cannot be taught within the framework of this instruction manual, is required for these tasks. Personnel possessing this technical knowledge are available for assistance at all our service centres. Their experience and regular technical instruction by the factory as well as equipment and tools guarantee expert and up-to-date inspection of the vehicle.

Have the "First Programmed Inspection" carried out at one of our service centres 12 months after initial registration.

Further inspections should be carried out once a year.

The service centre in charge will confirm the work performed.

Have chassis inspections confirmed in the chassis manufacturer's customer service booklet.



- ▷ Observe the inspections indicated by the manufacturer and have them carried out at the specified intervals. The value of the vehicle is thus preserved.
- ▷ The confirmation of the inspection work carried out serves as valid proof in the event of damage and guarantee claims.

### 12.2 Maintenance work

As with every machine, this vehicle requires maintenance. The extent and frequency of the maintenance work required depend on conditions of operation and use. More difficult operating conditions make it necessary to service the vehicle more often.

Have the base vehicle and the appliances serviced at the intervals specified in the corresponding instruction manuals.

### 12.3 Doors

To maintain gliding capability between springs and hinges, grease the conversion door hinges occasionally.



- ▷ We recommend either Molykote PG 65 or Vaseline as lubricants.

## 12.4 Living area battery



- ▷ When replacing the battery, only use the same type of battery (same capacity and voltage, cycle stability).
- ▷ Never use conventional car batteries (starter batteries). A lead acid battery must not be replaced by a dryfill battery.
- ▷ Do not use so-called improvers.

Observe the following to extend battery life:

- Keep the battery surface clean and dry.
- Check the acid level periodically and top up with desalinated or distilled water as necessary. Never top up with acids.
- If water loss is considerable, have the controller voltage checked by an authorised specialist workshop.
- Use an acid density measurement to check the battery's charging condition.

### Acid density

- The battery must be recharged if the acid density falls below 1.21 kg/l. If battery acid with a density of 1.23 kg/l is used, the battery must be recharged when the acid density falls below 1.18 kg/l.
- With acid density of 1.21 kg/l, the battery is protected against freezing at temperatures up to -15 °C (at 1.28 kg/l up to -70 °C).

The battery has cycle stability and is thus particularly suited for vehicle power supply. Cycle stability means that several discharge/charging processes are possible.

## 12.5 Alde hot-water heater



- ▷ Check the level of the heating fluid regularly on the compensator reservoir.
- ▷ During or after the first operating hours of the hot-water heater, the filling level may fall below the minimum mark. If this is the case, top up the heating fluid.
- ▷ We recommend to bleed the heating system after the initial heater operation and to check the glycol content.
- ▷ Have heating fluid changed by an authorised dealer or a service centre at intervals of approximately two years as corrosion-protection wears off after some time.
- ▷ Top up heating system with a water-glycol mixture (60 : 40) only. This mixture offers frost protection up to approx. -25 °C. When topping up hot-water heaters that are connected to the engine's cooling circuit, please observe the instructions in the instruction manuals of the manufacturers.



- ▷ Further information can be obtained in the device manufacturer's instruction manual.

### 12.5.1 Checking the fluid level



Fig. 222 Compensator reservoir hot-water heater

- Switch off the hot-water heater and allow it to cool down.
- Check if the fluid level is between the marks "MIN" (Fig. 222,3) and "MAX" (Fig. 222,2) on the compensator reservoir (Fig. 222).

### 12.5.2 Topping up heating fluid

- Position the vehicle horizontally. This prevents the formation of bubbles.
- Switch off the hot-water heater and allow it to cool down.
- Unscrew or pull off the panel.
- Open the rotary lid (Fig. 222,1) on the compensator reservoir.
- Slowly remove cover with circulating pump upwards.
- Check anti-freeze with an anti-freeze hydrometer. The frost protection content must be 40 % or correspond to a frost protection of -25 °C.
- Fill water frost protection mixture slowly into the compensator reservoir.



- ▷ The optimum fluid level is reached when the fluid in the compensator reservoir is 1 cm above the "MIN" mark.

### 12.5.3 Bleeding the heating system



Fig. 223 Bleeding valve of hot-water heater

The bleeding valves are built in nearby the radiators.

For position of the bleeding valves, see also table "Position of the bleeding valves".

- Switch off the hot-water heater and allow it to cool down.
- Open bleeding valve (Fig. 223,1) and leave open until no more air escapes.
- Close bleeding valve.
- Repeat this procedure at all bleeding valves.
- Check to see if the hot-water heater warms up.

#### 12.5.4 Position of the bleeding valves

Position of the bleeding valves	
I 810	Status at the time of going to press not yet known
I 821	<p>The drain for complete emptying is in the double floor under the water tank (under the vehicle)</p> <p>Underneath the driver's and front passenger's seats</p> <p>In the front bench seat of the central seating group</p> <p>Above the divan behind the curtain</p> <p>In the furniture cabinet at the left access</p> <p>In the toilet compartment at the radiator</p> <p>On the rear bed, left and right</p> <p>On the heat exchanger</p> <p>In the kitchen to the side on the top drawer</p>

#### 12.6 Independent vehicle heater

Use the independent vehicle heater for 10 minutes at least once a month with a cold engine and smallest fan settings.

Before the heating season starts, have the independent vehicle heater checked by an authorised specialist workshop.

#### 12.7 Replacing bulbs, external



- ▶ Bulbs and light fittings can be extremely hot. Therefore, allow lights to cool down before changing bulbs.
- ▶ Store bulbs in a safe place inaccessible to children.
- ▶ Do not use any bulb that has been dropped or which shows scratches in its glass. The bulb might burst.



- ▷ A new bulb should not be touched with the fingers. Use a cloth when installing the new bulb.
- ▷ Use only bulbs of the same type and with the correct wattage (see table "Types of bulbs for exterior lighting").

#### Types of bulbs

Different types of bulbs are used in the vehicle. Below, we have described how to change the different types of bulbs.





Fig. 224 Types of bulbs

Pos. in Fig. 224	Fixture type/bulb type	Changing
1	Plug-in fixture	To remove, pull out the bulb
		To mount, push the bulb into the socket with gentle pressure
2	Bayonet socket	To remove, press the bulb down and turn in an anticlockwise direction
		To insert, place the bulb in the socket and turn in a clockwise direction
3	Cylindrical bulbs	To remove and to insert, carefully bend the contacts of the lamp holder outwards
4	Halogen bulb	To remove, release retaining springs
		After inserting, hook the retaining springs again

### 12.7.1 Front lights



- 1 Direction indicator
- 2 Parking light/main beam
- 3 Low beam
- 4 Fog light

Fig. 225 Front lights

#### Direction indicator

The bulbs are changed in the engine compartment.

- Open bonnet (see chapter 4).
- Unhook the direction indicator's tension spring.
- Remove lamp housing.
- Remove bulb.
- Put in a new bulb.
- Reassemble the direction indicator in the reverse order.

### Main beam/parking light/ low beam

The bulbs are changed in the engine compartment.




Fig. 226 Main beam/parking light/  
low beam

- Open bonnet (see chapter 4).
- Remove rubber cap (Fig. 226,1) from lamp housing.
- Press metal clip (Fig. 226,2) together and release from holder.
- Remove bulb (Fig. 226,3) with cable from lamp housing.
- Give parking light bulb one quarter turn in an anticlockwise direction and remove it.
- Put in a new bulb.
- Reassemble the lamp in the reverse order.

### Fog light

- Put your hand behind the fog light and remove rubber cap from lamp housing.
- Press metal clip together and release from holder.
- Remove bulb.
- Put in a new bulb.
- Reassemble the fog light in the reverse order.

## 12.7.2 Front lights (variant)



- 1 Fog light
- 2 Direction indicator
- 3 Parking light
- 4 Main beam/low beam

Fig. 227 Front lights

### Low beam/main beam

The bulbs are changed in the engine compartment.



Fig. 228 Low beam/main beam/parking light

- Open bonnet (see chapter 4).
- Put your hand behind the lamp holder (Fig. 228,1).
- Turn the lamp holder with the lamp in an anticlockwise direction and remove.
- Turn bulb in an anticlockwise direction and remove from the holder.
- Put in a new bulb.

#### **Parking light**

The bulbs are changed in the engine compartment.

- Open bonnet (see chapter 4).
- Turn the swivel nut on the lamp housing in an anticlockwise direction and remove.
- Remove the lamp housing with the lamp.
- Remove the bulb from the lamp housing.
- Put in a new bulb.

#### **Direction indicator**

The bulbs are changed in the engine compartment.




Fig. 229 Direction indicator

- Open bonnet (see chapter 4).
- Put your hand behind the lamp holder (Fig. 229,1).
- Turn the lamp holder with the lamp in an anticlockwise direction and remove.
- Remove bulb.
- Put in a new bulb.
- Reassemble the direction indicator in the reverse order.

- Fog light**
- Put your hand behind the lamp holder.
  - Turn the lamp holder with the lamp in an anticlockwise direction and remove.
  - Remove bulb.
  - Put in a new bulb.
  - Reassemble the fog light in the reverse order.

### 12.7.3 Rear lights

#### Elongated lamps



- 1 Housing screws
- 2 Rear light
- 3 Brake light
- 4 Direction indicator
- 5 Reverse light
- 6 Fog tail light

Fig. 230 Rear lights

- Undo the housing screws (Fig. 230,1).
- Remove housing.
- Remove bulb.
- Put in a new bulb.
- Reassemble the lamp in the reverse order.

#### Round lamps




- 1 Housing screws
- 2 Rear light/brake light
- 3 Direction indicator
- 4 Reverse light (right) and fog tail light (left)

Fig. 231 Rear lights

- Undo the housing screws (Fig. 231,1).
- Remove housing.
- Remove bulb.
- Put in a new bulb.
- Reassemble the lamp in the reverse order.



### 12.7.4 Side lights



- 1 Side marker light
- 2 Marker light
- 3 Direction indicator

Fig. 232 Side lights

#### Side marker light

The side marker light (Fig. 232,1) is fixed in the rear area at the top.



▷ Please have the LEDs of the side marker light replaced at a service centre.

#### Direction indicator

The lamp is glued in. If the bulb is faulty, contact an authorised dealer or service centre.

#### Marker lights

The marker lights (Fig. 232,2) are fitted in the lower part of the vehicle.

- Undo housing screws.
- Remove housing.
- Remove bulb.
- Put in a new bulb.
- Reassemble the lamp in the reverse order.

### 12.7.5 Types of bulbs for exterior lighting

	Exterior lighting	Type of bulb
<b>Front</b>	Main beam	H7 12 V 55 W
	Low beam	H7 12 V 55 W
	Parking light	T4W 12 V 4 W
		W5W 12 V 5 W (Viseo)
	Direction indicator	Bay 9s 12 V 21 W
		BAU 15s 12 V 21 W (Viseo)
Fog light	H3 12 V 55 W	
<b>Rear</b>	Rear light	Ba15s 12 V 5 W
	Brake light	Ba15s 12 V 21 W
	Direction indicator	Ba15s 12 V 21 W
	Fog tail light	Ba15s 12 V 21 W
	Reverse light	Ba15s 12 V 21 W
<b>Side</b>	Marker light	Ba15s 12 V 5 W

## 12.8 Replacing bulbs, internal




- ▶ Bulbs and light fittings can be extremely hot. Therefore, allow lights to cool down before changing bulbs.
- ▶ Shut off the power supply on the safety cut-out in the 230 V fuse box before changing bulbs.
- ▶ Store bulbs in a safe place inaccessible to children.
- ▶ Do not use any bulb that has been dropped or which shows scratches in its glass. The bulb might burst.
- ▶ Lights can get very hot. When the light is switched on, there must always be a safety distance of 30 cm between light and flammable objects. Fire hazard!



- ▷ A new bulb should not be touched with the fingers. Use a cloth when installing the new bulb.
- ▷ Only use bulbs of the same type and with the correct wattage.
- ▷ If LEDs in lights are defect, contact an authorised dealer or service centre.

### 12.8.1 Ceiling lamp



- 1 LED
- 2 Lamp shade
- 3 Halogen bulb

Fig. 233 Ceiling lamp

Halogen bulb H7 12 V/20 W

#### Changing bulbs:

- Pull the halogen bulb (Fig. 233,3) out of the fitting.
- Press the new halogen bulb into the fitting between the two spring tongues.



- ▷ The lamp shade does not have to be removed when changing the halogen bulb.
- ▷ The LEDs are integrated in the lamp shade. To change a LED, contact an authorised dealer or a service centre.

### 12.8.2 Recessed halogen light



Fig. 234 Recessed halogen light (flat)




Fig. 235 Changing the halogen bulb

Halogen bulb 12 V/10 W

The recessed halogen light (Fig. 234,1) is installed flush.

*Changing bulbs:*

- Use a screwdriver to remove the inner cover ring (Fig. 235,1) from the housing.
- Use a screwdriver to remove the cover ring with the glass (Fig. 235,2) from the lower section of the recessed halogen light.
- Remove halogen bulb (Fig. 235,3).
- Put in a new halogen bulb.
- Reassemble the lamp in the reverse order.

### 12.8.3 Recessed halogen light (flat)



Fig. 236 Recessed halogen light (flat)

Halogen bulb 12 V/10 W

The recessed halogen light (Fig. 236,2) is installed flush with the panel.

*Changing bulbs:*

- Use a suitable tool (e.g. a screwdriver) to lever out the internal cover ring with glass disk (Fig. 236,1) from the housing.
- Remove halogen bulb.
- Put in a new halogen bulb.
- Reassemble the lamp in the reverse order.

### 12.8.4 Halogen spotlight (movable)




Fig. 237 Halogen spotlight (movable)

Halogen bulb 12 V/10 W

- Changing bulbs:*
- Turn outer ring (Fig. 237,1) in an anticlockwise direction until it separates from the housing.
  - Remove retaining ring.
  - Remove halogen bulb.
  - Put in a new halogen bulb.
  - Reassemble the lamp in the reverse order.

### 12.8.5 Halogen spotlight (movable)




Fig. 238 Halogen spotlight (movable)

Halogen bulb 12 V/10 W

- Changing bulbs:*
- Loosen the fixing screw (Fig. 238,1).
  - Remove the lamp shade (Fig. 238,2).
  - Remove halogen bulb.
  - Put in a new halogen bulb.
  - Reassemble the lamp in the reverse order.

### 12.8.6 Halogen spotlight (movable)




Fig. 239 Halogen spotlight (movable)

Halogen bulb 12 V/10 W

*Changing bulbs:*

- Turn the halogen spotlight (Fig. 239,1) by 90° and remove from rail.
- Turn the lamp shade (Fig. 239,3) in an anticlockwise direction.
- Withdraw lamp shade complete with halogen bulb (Fig. 239,4) carefully from the holder (Fig. 239,2).
- Remove halogen bulb.
- Screw lamp shade onto holder.
- Insert new halogen spot light into the lamp shade and press into holder.
- Insert halogen lamp into the rail.

### 12.8.7 Halogen spotlight (gooseneck)



Fig. 240 Halogen spotlight (gooseneck)

Halogen bulb 12 V/10 W

*Changing bulbs:*

- Pull the halogen bulb (Fig. 240,1) out of the fitting.
- Put in a new halogen bulb.

### 12.8.8 Bathroom lamp



Fig. 241 Bathroom lamp

Halogen bulb 12 V/10 W

- Changing bulbs:*
- Turn the light covering (Fig. 241,1) a bit in an anticlockwise direction and remove it.
  - Remove halogen bulb.
  - Put in a new halogen bulb.
  - Reassemble the lamp in the reverse order.

### 12.8.9 Wardrobe light




Fig. 242 Wardrobe light

Halogen bulb 12 V/8 W

- Changing bulbs:*
- Press the light covering (Fig. 242,1) lightly together and remove it.
  - Remove halogen bulb.
  - Put in a new halogen bulb.
  - Reassemble the lamp in the reverse order.

### 12.8.10 Garage light



Fig. 243 Garage light

Halogen bulb 12 V/21 CP

*Changing bulbs:*

- Use a suitable tool (e.g. a screwdriver) to carefully lever out the cover (Fig. 243,2) at the notch (Fig. 243,1) and remove it.
- Remove halogen bulb.
- Put in a new halogen bulb.
- Reassemble the lamp in the reverse order.

### 12.9 Spare parts



- ▶ Every alteration of the original condition of the vehicle can alter road behaviour and jeopardize road safety.
- ▶ The special equipment and original spare parts recommended by us have been specially developed and supplied for your vehicle. These products are available at the authorised dealer or service centre. The authorised dealer or service centre is informed about admissible technical details and carries out the required work correctly.
- ▶ The use of accessories, parts and fittings not supplied by us may cause damage to the vehicle and jeopardize road safety. Even if an expert's report, a general type approval or a design certification exists, there is no guarantee for the proper quality of the product.
- ▶ No liability can be assumed for damage caused by products which have not been released by us. This also applies to impermissible alterations to the vehicle.

For safety reasons, spare parts for pieces of equipment must correspond with manufacturer's instructions and be permitted by the manufacturer as a spare part. These spare parts may only be fitted by the manufacturer or an authorised specialist workshop. The authorised dealers and service centres are available for any spare parts requirement.


Here are some suggestions of important spare parts:

- Fuses
- V-belt
- Windscreen blades
- Bulbs
- Water pump (submerged pump)

When ordering spare parts please indicate the chassis number and the vehicle type to the dealer.

The vehicle described in this instruction manual is built and equipped to factory standards. Special equipment is offered depending on its purpose or use. When fitting special equipment check if such equipment has to be entered in the vehicle documents. Observe the max. permissible gross weight. The authorised dealer or service centre will be happy to advise you.

## 12.10 Vehicle identification plate



1 Chassis number

Fig. 244 Vehicle identification plate

The vehicle identification plate (Fig. 244) with the chassis number is mounted on the right hand side on the front.

Do not remove the vehicle identification plate. The vehicle identification plate:

- Identifies the vehicle
- Helps with the procurement of spare parts
- Together with the vehicle documents identifies the vehicle owner



- ▷ Always include the **chassis number** with all inquiries for the customer service office.
- ▷ The chassis number of the base vehicle is located under a cover in the entrance at the passenger side for vehicle with passenger's door, for vehicles without passenger's door under a cover on the right hand side next to the front passenger's seat.

## 12.11 Warning and information stickers

There are warning and information stickers on and inside the vehicle. Warning and information stickers are for the sake of safety and must not be removed.



- ▷ Replacement stickers can be obtained from an authorised dealer or a service centre.



## Chapter overview

This chapter contains instructions regarding the tyres of the vehicle.

The instructions address the following topics:

- tyre selection
- handling of tyres
- changing wheels
- spare wheel support

At the end of the chapter there is a table you can use to find the correct tyre pressure for your vehicle.

### 13.1 General



- ▶ Check tyre pressure before a journey or every 2 weeks. Wrong tyre pressure causes excessive wear and can lead to damage or even to tyre burst. You can lose control of the vehicle.



- ▷ Only check the tyre pressure on cold tyres.
- ▷ Tubeless tyres have been installed on the vehicle. Never install tubes in these tyres.
- ▷ Read the instruction manual for the base vehicle.



- ▷ Depending on the base vehicle and model the vehicles are equipped with only one tyre repair kit as standard.
- ▷ In the case of a puncture, pull over to the side of the road. Make vehicle safe with a hazard warning triangle. Switch on the warning lights.
- ▷ Tyres on vehicles with tandem axles may wear faster.
- ▷ Tyres must not be older than 6 years as the material will become brittle over time. The four-digit DOT number on the tyre flank indicates the date of manufacture. The first two digits designate the week, the last two digits the year of manufacture.

Example: (1509) Week 15, year of manufacture 2009.

- Observe:**
- Check the tyres regularly (every 2 weeks) for equal tread wear, tread depth and external damage.
  - Replace tyres at the latest, when the minimum depth of tread stipulated by law is reached.
  - Always use tyres of the same model, same brand and same style (summer and winter tyres).
  - Only use tyres approved for the wheel rim type fitted. The permitted rim and tyre sizes are quoted in the vehicle documents and the authorised dealer or service centre will always be glad to give you advice.
  - Run-in new tyres for approx. 100 km (60 miles) at low speed since only then do they reach full strength.




Fig. 245 Tighten the wheel nuts or wheel bolts cross-wise

- Check regularly that the wheel nuts or wheel bolts are firmly seated. Retighten the wheel nuts or wheel bolts of a changed wheel cross-wise (Fig. 245) after 50 km (30 miles). See section 13.5.2 for tightening torque.
- When using new or newly painted rims, re-tighten the wheel nuts or wheel bolts once again after approx. 1,000 to 5,000 km (600 miles to 3,000 miles).
- For lay-ups or long periods of inactivity, keep the tyres and tyre bearings free from pressure points:  
Jack up the vehicle so that the wheels do not bear any load, or move the vehicle every 4 weeks in such a way that the position of the wheels is changed.

## 13.2 Tyre selection



- ▶ A wrong tyre can damage the tyres during the journey and even cause it to burst.



- ▷ If tyres that are not approved for the vehicle are used, then the type approval for the vehicle and subsequently the insurance coverage can lapse. Your dealer or service centre will be glad to advise you.

The tyre sizes approved for the vehicle are given in the vehicle documents or can be got from the dealers or service centres. Each tyre must fit the vehicle on which it will be driven. This applies to the external dimensions (diameter, width), which are indicated with the standardised size designations. In addition, the tyres must meet the requirements of the vehicle with regard to weight and speed.

Weight refers to the maximum permissible axle load which can be distributed on two tyres. The maximum load-carrying capacity of a tyre is indicated by its load index (= LI, load index code).

The axle geometry of a vehicle, such as wheel camber and track, is also important for tyre selection. The maximum permissible speed for a tyre (with full load-carrying capacity) is indicated by the speed index (= SI). Together, load index and speed index form the operating code of a tyre. This is an official component of the complete, standardised dimensions description which appears on every tyre. The information on the tyres must correspond to the specifications which appear in the vehicle papers.

### 13.3 Tyre specifications

215/70 R 15C 109/107 Q

Description	Explanation
215	Tyre width in mm
70	Height-to-width proportion in percent
R	Tyre design (R = radial)
15	Rim diameter in inches
C	Commercial (transporter)
109	Load index code for single tyres
107	Load index code for twin tyres
Q	Speed index (Q = 160 km/h)

### 13.4 Handling of tyres

- Drive over kerbs at an obtuse angle. Otherwise the flanks of the tyres may get pinched. Driving over a kerb at a sharp angle can damage the tyre and result in it getting ruptured.
- Drive over high manhole covers at a slow speed. Otherwise the tyres may get pinched. Driving over a high manhole cover at high speed can damage the tyre and result in it getting ruptured.
- Check the shock absorbers regularly. Driving with poor shock absorbers significantly increases wear.
- If the tread wear is uneven, have the toe-in and the wheel camber checked. Driving with an incorrectly set toe-in or a one-sided wheel camber leads to a significant increase in wear.
- Avoid block brakings. Block braking gives the tyres "brake plates" of varying strength. This reduces driving comfort. It might even make the tyres unserviceable.
- Do not clean the tyres with a high-pressure cleaner. The tyres can suffer serious damage within just a few seconds and rupture as a result.
- Drive in such a way as to protect your tyres. Avoid braking sharply, revving up too strongly and long journeys on poor roads.

### 13.5 Changing wheels

#### 13.5.1 General instructions



- ▶ The vehicle must be on level, firm ground, secure from slipping.
- ▶ Go into first gear. In the case of automatic transmission, change gear to "P" position.
- ▶ Before jacking up the vehicle firmly apply the handbrake.
- ▶ Prevent the vehicle from rolling away by blocking the opposite wheel with the wheel chocks.
- ▶ Under no circumstances jack the vehicle with the fitted supports.
- ▶ If a trailer is connected: Detach the trailer before lifting the vehicle.
- ▶ Position the vehicle jack underneath the axle, not under any circumstances on the bodywork.



- ▶ Never overload the vehicle jack. The maximum permissible load is specified on the vehicle jack's identification plate.
- ▶ Use the vehicle jack only for lifting the vehicle briefly while changing the tyre.
- ▶ No persons may be in the vehicle while it is raised.
- ▶ Do not start the motor while the vehicle is jacked up.
- ▶ Whilst the vehicle is in a jacked up position, persons must not lie down under it.



- ▷ Do not damage the thread of the thread bolts when changing the wheel.
- ▷ Tighten the wheel nuts or wheel bolts cross-wise (Fig. 245).
- ▷ When changing wheels (e.g. alloy wheel rims or wheels with winter tyres), use the correct wheel bolts of the correct length and shape. The firm seating of the wheels and the function of the braking system depend on this.
- ▷ Wheel rims and tyres not permitted for use with the vehicle can jeopardize road safety.
- ▷ Do not replace wheels cross-wise.



- ▷ Protect the vehicle according to the national regulations, e.g. with a hazard warning triangle.
- ▷ Before changing the wheel, check the wheel rim and tyre size, the max. tyre load and the speed index on the tyres. Only use the wheel rim and tyre sizes stated in the vehicle documents.
- ▷ The on-board tool set is adapted to the mounted wheel nuts or wheel bolts. When alloy wheel rims are mounted, carry an appropriate tool for the spare wheel (steel wheel rim) in the vehicle.
- ▷ When alloy wheel rims are mounted, the wheel nuts or wheel bolts for the spare wheel (steel wheel rim) are located in the drawer in the kitchen unit.
- ▷ Further information can be found in the instruction manual of the base vehicle.

### 13.5.2 Tightening torque



Fig. 246 Wheel bolts with on-board tool set

- 1 On-board tool set for steel wheel rim
- 2 Wheel bolt steel wheel rim
- 3 Wheel bolt alloy wheel rim
- 4 On-board tool set for alloy wheel rim

**Fiat base vehicle**

Wheel rim	Tightening torque
Steel wheel rim 15"	160 Nm
Steel wheel rim 16"	180 Nm
Alloy wheel rim 15"	140 Nm
Alloy wheel rim 16"	160 Nm

### 13.5.3 Changing a wheel



- ▶ The footplate of the vehicle jack must be levelly positioned on the ground.
- ▶ Do not tilt the vehicle jack.



- ▷ You should have a useable spare wheel available at all times. For this reason the wheel you have replaced should be repaired immediately.
- ▷ Take note of the general instructions in this chapter.



Fig. 247 Securing vehicle

- Park the vehicle on as even and stable a surface as possible.
- Go into first gear. In the case of automatic transmission, change gear to "P" position.
- Apply the handbrake.
- Place chocks or other appropriate objects beneath the opposite wheel of the vehicle to secure it (Fig. 247).
- Remove the spare wheel from the spare wheel support.
- If the ground is soft, place a stable support such as a wooden board beneath the vehicle jack.
- Position the vehicle jack at the designated mounting points.
- Turn the wheel bolts several times to loosen them, but do not remove them.
- Lift the vehicle until the wheel has been lifted 2 to 3 cm above the ground.
- Remove the wheel bolts and take off the wheel.
- Place the spare wheel on the wheel hub and adjust.
- Screw in the wheel bolts and slightly tighten them cross-wise.
- Crank down the vehicle jack and remove it.
- Using the wheelbrace, tighten the wheel bolts evenly (see section 13.5.2 for tightening torque).

### 13.5.4 Changing a wheel at alloy wheel rims



- ▶ Alloy wheel rims and steel wheel rims require different wheel bolts. When alloy wheel rims are mounted, the spare wheel (steel wheel rim) is accompanied by suitable wheel bolts.

Wheels with alloy wheel rims are changed in the same way as wheels with steel rims (see section 13.5.3).

## 13.6 Spare wheel support (special equipment)

Depending on the model, the spare wheel can be found under the vehicle or in the rear garage.

### 13.6.1 Spare wheel support under the vehicle

The spare wheel is fitted below the body between the frame parts of the chassis. The spare wheel can be lowered or lifted with a winch.



- ▷ Also read the separate instruction manual of the base vehicle.

*Removing the spare wheel:*

- Insert the crank from the on-board tool set into the holder on the winch.
- Turn crank in an anticlockwise direction until the retaining rope is released along the entire length.
- Pull the spare wheel out from under the vehicle as far as possible.
- Release the securing bracket and the wing nuts of the spare wheel support.
- Remove the spare wheel.



- ▷ When securing the spare wheel, the inside part of the rim must point upwards. Tighten wing nut and secure it with splint.
- ▷ Turn the crank until the retaining rope has been totally wound up, and the spare wheel fits tightly in the holder.

### 13.6.2 Spare wheel support in the rear garage



Fig. 248 Spare wheel support in the rear garage

*Removing the spare wheel:*

- Open external flap of the rear garage.
- Loosen and remove both fixing screws (Fig. 248,2) with the on-board tool set.
- Remove the spare wheel (Fig. 248,1) from the centring device (Fig. 248,3).

### 13.7 Tyre pressure




- ▶ Tyres overheat if the tyre pressure is too low. This can cause serious tyre damage.
- ▶ Check tyre pressure before a journey or every 2 weeks. Wrong tyre pressure causes excessive wear and can lead to damage or even to tyre burst. You can lose control of the vehicle.
- ▶ Use only valves that are approved for the specified tyre pressure.



- ▷ Only check the tyre pressure on cold tyres.

The payload and the durability of tyres is directly dependent on the tyre pressure. Air is a volatile medium. It is unavoidable that it will escape from tyres. As a rule of thumb it can be assumed that a filled tyre loses pressure at a rate of 0.1 bar every two months. To prevent the tyres becoming damaged or burst, check the tyre pressure regularly.

The contact surface of the tyre changes, depending on the tyre pressure.



- 1 Correct tyre pressure
- 2 Tyre pressure too low
- 3 Tyre pressure too high

Fig. 249 Contact surface of the tyre



- ▷ The information on pressure levels is valid for cold tyres and loaded vehicles.
- ▷ Pressure in hot tyres must be 0.3 bar higher than in cold tyres. Recheck the pressure when the tyres are cold.
- ▷ Tyre pressures in bar.
- ▷ Over 4.75 bar requires a metal valve.
- ▷ The tyre pressure tolerance is +/- 0.05 bar.

**Fiat**

Types	Tyre size	Front air pressure in bar	Rear air pressure in bar
All types	215/70 R 15 C (109/107) Q	4.1	4.5
All types with "Michelin Camping" tyres	215/70 R 15 C (109/107) Q	5.0	5.5
All types	225/75 R 16 C (116/114) R	4.5	5.0

Types	Tyre size	Front air pressure in bar	Rear air pressure in bar
All types with "Michelin Camping" tyres	225/75 R 16 C (116/114) R	5.5	5.5
All types	225/75 R 16 C (116/114) Q (tandem axle)	4.5	3.5
All types with "Michelin Camping" tyres	225/75 R 16 C (116/114) Q (tandem axle)	5.5	3.5

The vehicles are constantly brought up to the newest technical standards. It is possible that new tyre sizes are not yet included in this table. If this is the case, any dealer or service centre will be happy to provide the newest values.



## Chapter overview

This chapter contains instructions about possible faults in your vehicle. The faults are listed with their possible causes and corresponding remedies. The instructions address the following topics:

- braking system
- electrical system
- gas system
- heater
- boiler
- air conditioning unit
- gas cooker
- gas oven
- microwave oven
- refrigerator
- water supply
- body

The specified faults can be remedied with relative ease and without a great deal of specialised knowledge. In the event that the remedies detailed in this instruction manual should not be successful, an authorised specialist workshop must find and eliminate the cause of the fault.

### 14.1 Braking system



- ▶ Have defects on the braking system immediately remedied by an authorised specialist workshop.

### 14.2 Electrical system




- ▷ When the living area battery is changed, only use batteries of the same type.



- ▷ See chapter 8 for changing the fuses.

Fault	Cause	Remedy
Road light system does no longer work correctly	Bulb is defective	Replace bulb. Note volts and watts specifications
Interior lighting does no longer work correctly	Bulb is defective	Replace bulb. Note volts and watts specifications
	Fuse on the transformer/rectifier is defective	Replace fuse on the transformer/rectifier
The electrically operated entrance step cannot be moved in or out	Fuse on the transformer/rectifier is defective	Replace fuse on the transformer/rectifier

Fault	Cause	Remedy
No 230 V power supply despite connection	230 V automatic circuit breaker has triggered	Switch on the 230 V automatic circuit breaker
	The mains connection is de-energised	Check the mains connection
Starter or living area battery is not charged when operated in 230 V mode	Jumbo flat fuse (50 A) on the starter or living area battery is defective	Replace jumbo flat fuse (50 A) on the starter or living area battery
	Charger module in the transformer/rectifier is defective	Contact customer service
Living area battery is not charged during vehicle operation	Fuse on terminal D+ of the alternator is defective	Replace fuse
	Disconnecter relay in the transformer/rectifier is defective	Contact customer service
12 V power supply does not work	12 V power supply switched off	Switch 12 V power supply on
	Battery cut-off switch on the transformer/rectifier switched off or battery separation activated	Switch on battery cut-off switch or deactivate battery separation via the panel
	Living area battery is discharged	Charging the living area battery
	Jumbo flat fuse (50 A) on the living area battery is defective	Replace jumbo flat fuse (50 A) on the living area battery
	Disconnecter relay in the transformer/rectifier is defective	Contact customer service
12 V power supply does not work in 230 V operation	12 V power supply switched off	Switch 12 V power supply on
	Battery cut-off switch on the transformer/rectifier switched off or battery separation activated	Switch on battery cut-off switch or deactivate battery separation via the panel
	Charger module in the transformer/rectifier is defective	Contact customer service
	230 V automatic circuit breaker has triggered	Contact customer service
	Jumbo flat fuse (50 A) on the living area battery is defective	Replace jumbo flat fuse (50 A) on the living area battery
Starter battery is discharged in 12 V operation	Disconnecter relay in the transformer/rectifier is defective	Contact customer service
	Battery cut-off switch on the transformer/rectifier switched off or battery separation activated	Switch on battery cut-off switch or deactivate battery separation via the panel

Fault	Cause	Remedy
No voltage is supplied by the living area battery	Living area battery is discharged	Charge living area battery immediately   ▷ Total discharge damages the battery.  If the vehicle is to be laid up for a long period, fully charge the living area battery beforehand  Discharging is caused by inactive appliances (see chapter 8)
The 12 V indicator lamp does not light up or there is no display on the panel	12 V power supply switched off	Switch 12 V power supply on
	Battery cut-off switch on the transformer/rectifier switched off or battery separation activated	Switch on battery cut-off switch or deactivate battery separation via the panel
	Starter or living area battery is not charged	Charge the starter or living area battery
	Disconnecter relay in the transformer/rectifier is defective	Contact customer service
	Flat fuse (2 A) in the living area battery is defective	Replace flat fuse (2 A) in the living area battery
Extractor hood does not work	230 V automatic circuit breaker is switched off	Switch on the 230 V automatic circuit breaker
	Fuse (15 A) at the transformer/rectifier is defective	Replace fuse (15 A)
	Extractor hood defective	Contact customer service

### 14.3 Gas system



- ▶ In case of a defect of the gas system (gas odour, high gas consumption) there is danger of explosion! Close regulator tap on the gas bottle immediately. Open doors and windows and ventilate well.
- ▶ If the gas system is defective: Do not smoke; do not ignite any open flames, and do not operate electric switches (light switches etc.).
- ▶ Have the defective gas system repaired by an authorised specialist workshop.

Fault	Cause	Remedy
No gas	Gas bottle is empty	Change gas bottle
	Gas isolator tap closed	Open the gas isolator tap
	Regulator tap on the gas bottle is closed	Open regulator tap on the gas bottle
	External temperature is too low (-42 °C for propane gas, 0 °C for butane gas)	Wait for higher external temperatures
	Built-in appliance is defective	Contact customer service

## 14.4 Heater/boiler

In the event of a defect contact the nearest customer service workshop of the relevant appliance manufacturer. The list of addresses is enclosed with the accompanying appliance documentation. Only authorised qualified personnel may repair the appliance.

### 14.4.1 Heater/boiler Truma

Fault	Cause	Remedy
Heater does not ignite	Temperature sensor on operating unit or remote sensor defective	Pull out plug on operating unit. The heating then works without thermostat. Contact the customer service as soon as possible
Red indicator lamp "Fault" illuminates	Air in the gas pipe system	Switch off and on again. After two futile ignition attempts, wait for 10 minutes before trying again
	Lack of gas	Open regulator tap and gas isolator tap
		Connect a full gas bottle
Red indicator lamp "Fault" is flashing	Defect of a safety element	Contact customer service
	Operating voltage too low	Charge or replace the living area battery (or have it charged or replaced)
Green indicator lamp behind knob is not lit	Fuse on the transformer/rectifier is defective	Replace fuse on the transformer/rectifier
	Fuse in the electronic control unit has been triggered	Contact customer service
	Living area battery defective	Charge or replace the living area battery (or have it charged or replaced)

Fault	Cause	Remedy
Yellow indicator lamp on the energy selector switch does not illuminate	No supply voltage	Check 230 V connection and fuses
	Overheating switch was triggered	Press overheating switch
Boiler empties, safety/drainage valve has opened	Internal temperature below 8 °C	Heat inside
	Safety/drainage valve separated from battery supply	Cancel battery separation. In order to do this switch on the battery cut-off switch on the transformer/rectifier or deactivate the battery separation via the panel
	Operating voltage below 10.8 V	Charge or replace the living area battery (or have it charged or replaced)
	Fuse is defective	Replace fuse on the transformer/rectifier
Safety/drainage valve does not close when switching on	Safety/drainage valve separated from battery supply	Cancel battery separation. In order to do this switch on the battery cut-off switch on the transformer/rectifier or deactivate the battery separation via the panel
	Operating voltage below 10.8 V	Charge living area battery (or have it charged)
	Fuse is defective	Replace fuse on the transformer/rectifier
Red and green indicator lamps are not lit	Fuse is defective	Replace fuse on the transformer/rectifier
Fan wheel runs noisily or not steadily	Fan wheel is soiled	Contact Truma service department

#### 14.4.2 Alde heater/boiler

Fault	Cause	Remedy
Red indicator lamp "Fault" illuminates	Air in the gas pipe	Switch off and on again. After two futile ignition attempts, wait for 10 minutes before trying again
	Lack of gas	Open regulator tap and gas isolator tap
		Connect a full gas bottle
	Defect of a safety element	Contact customer service
Red indicator lamp is not lit	Fuse is defective	Replace fuse on the transformer/rectifier

## 14.5 Air conditioning unit

### 14.5.1 Dometic

Fault	Cause	Remedy
Air conditioning unit does not start up	No 230 V power supply	Connect the vehicle to the local power supply
	230 V automatic circuit breaker has triggered	Switch on the 230 V automatic circuit breaker
	Remote control batteries empty	Change remote control batteries
Air conditioning unit does not cool	Temperature below 16 °C	–
	Temperature has been set incorrectly	Adjust the temperature
	Thermostat defective	Contact customer service
Air conditioning unit does not warm up	Temperature above 30 °C	–
	Temperature has been set incorrectly	Adjust the temperature
	Thermostat defective	Contact customer service
Water is entering the vehicle	Drainage holes for condensation are clogged	Clean air conditioning unit
	Seal is defective	Contact customer service
No more air circulation	Air filter clogged	Clean air filter
	Fan wheel defective	Contact customer service

### 14.5.2 Telair

Fault	Cause	Remedy
Air conditioning unit does not start up	No 230 V power supply	Connect 230 V power supply
	230 V automatic circuit breaker has triggered	Switch on the 230 V automatic circuit breaker
	Remote control batteries empty	Change batteries (2 x AAA)
Air conditioning unit does not cool	Room temperature is lower than the preset temperature	Reset temperature
Air conditioning unit does not heat	Room temperature is higher than the preset temperature	Reset temperature
Insufficient ventilation rating	Ventilation flaps closed	Open at least one ventilation flap
	Filter dirty	Clean the filter
Water is entering the vehicle	Drainage holes for condensation are clogged	Clean air conditioning unit

## 14.6 Cooker

### 14.6.1 Gas cooker/gas oven

Fault	Cause	Remedy
Ignition fuse does not operate (flame does not burn after the control knobs are released)	Heat-up time is too short	Keep control knob pressed for approx. 15 to 20 seconds after ignition
	Ignition fuse is defective	Contact customer service
Flame extinguishes when being reduced to its minimum setting	Thermocouple sensor is incorrectly set	Correctly reset thermocouple sensor (do not bend). The sensor tip should protrude by 5 mm beyond the burner. The sensor neck should not be more than 3 mm away from the burner ring; if necessary, contact customer service

### 14.6.2 Microwave oven



► Only qualified personnel may repair the microwave oven. Improper repairs can cause major risks to the user.

Fault	Cause	Remedy
Microwave oven does not cut in	Fuse is defective	Replace fuse
	Door of the microwave oven is not properly closed	Remove foreign bodies stuck in the door of the microwave oven and close door properly

## 14.7 Refrigerator

In the event of a defect contact the nearest customer service workshop of the relevant appliance manufacturer. The list of addresses is enclosed with the accompanying appliance documentation. Only authorised qualified personnel may repair the appliance.

### 14.7.1 Dometic 7 series

Fault	Cause	Remedy
Refrigerator does not switch on when operating in 230 V mode	No 230 V power supply	Connect 230 V power supply
	230 V automatic circuit breaker has triggered	Switch on the 230 V automatic circuit breaker
	230 V operating voltage too low	Have the 230 V power supply checked by an authorised specialist workshop

Fault	Cause	Remedy
Refrigerator does not switch on when operating in 12 V mode	Jumbo flat fuse (50 A) in the starter battery is defective	Replace jumbo flat fuse (50 A) in the starter battery
	Flat fuse (20 A) in the starter battery is defective	Replace flat fuse (20 A) in the starter battery
	Disconnecter relay in the transformer/rectifier is defective	Contact customer service
	12 V operating voltage too low	Have the 12 V power supply checked by an authorised specialist workshop
Refrigerator does not switch on when operating in gas mode The "GAS" operating indicator flashes yellow	Lack of gas	Open regulator tap and gas isolator tap Connect a full gas bottle
	Air in the gas pipe	Repeat ignition 3 or 4 times
	Cobwebs or burnt residue in the burning chamber	Remove the ventilation grill on the outside of the vehicle and clean the burning chamber
The desired refrigerating temperature is not achieved	Incorrect setting	Set the temperature with the temperature controller
	Too much fresh food put into it	Set the temperature with the temperature controller

### 14.7.2 Dometic 7 series with AES

Fault	Cause	Remedy
Indicator lamps "230 V", "12 V" or "AUTO" are not lit green	Refrigerator is turned off	Switch on the refrigerator with energy selector switch
	No electrical operating voltage	Connect 230 V power supply
		Let the vehicle engine run
		Switch on or replace the fuse
Refrigerator does not switch to 12 V mode during the journey	Operating voltage of alternator is not present/too low	Contact a specialist workshop
		Contact a specialist workshop



Fault	Cause	Remedy
Refrigerator does not switch on in gas operation, "GAS" indicator lamp is not lit yellow	Lack of gas	Open regulator tap and gas isolator tap Connect a full gas bottle
	Cobwebs or burnt residue in the burning chamber	Remove the ventilation grill on the outside of the vehicle and clean the burning chamber
"GAS" indicator lamp flashes yellow, no gas	Air in the gas pipe	Switch off the refrigerator with energy selector switch
		Open regulator tap on the gas bottle and the gas isolator tap of the refrigerator
		Switch on the refrigerator with energy selector switch. After 10 seconds, the AES will attempt another ignition
		If the "GAS" indicator lamp flashes yellow again after approx. 30 seconds, the failure has not been remedied yet
		Repeat this process two to three times for ventilation. If the refrigerator cannot be operated, contact customer services

### 14.7.3 Dometic 8 series with AES



▷ In the case of a fault the LED display fault will always light up "⚠".

Fault	Cause	Remedy
Text "230 V" flashes	No 230 V power supply	Connect 230 V power supply
	230 V automatic circuit breaker has triggered	Switch on the 230 V automatic circuit breaker
	230 V operating voltage too low	Have the 230 V power supply checked by an authorised specialist workshop


Fault	Cause	Remedy
Text "12 V" flashes	Fuse on the transformer/rectifier is defective	Replace fuse on the transformer/rectifier
	Disconnecter relay in the transformer/rectifier is defective	Contact customer service
	12 V operating voltage too low	Have the 12 V power supply checked by an authorised specialist workshop
Text "GAS" flashes	Lack of gas	Open regulator tap and gas isolator tap
		Connect a full gas bottle
	Cobwebs or burnt residue in the burning chamber	Remove the ventilation grill on the outside of the vehicle and clean the burning chamber
LEDs for display of the temperature range flash	Temperature sensor defective	Contact customer service
Text "HE1" flashes	230 V heater element defective	Contact customer service
Text "HE2" flashes	12 V heater element defective	Contact customer service

## 14.8 Water supply

Fault	Cause	Remedy
Leakage water inside the vehicle	A leak has occurred	Identify leak, re-connect water pipes
No water	Water tank is empty	Replenish drinking water
	Drain cock not closed	Close drain cock
	12 V power supply switched off	Switch 12 V power supply on
	Fuse of the water pump is defective	Replace fuse on the transformer/rectifier
	Water pump defective	Exchange water pump (have it exchanged)
	Water pipe snapped off	Straighten water pipe or replace
	Transformer/rectifier defective	Contact customer service
	Water pump switched off on panel	Switch water pump on
Toilet has no flush water	Water tank is empty	Replenish drinking water
	Fuse for toilet is defective	Replace fuse
Display for water and waste water indicates a wrong value	Measuring probe in the waste water or water tank is soiled	Clean water/waste water tank
	Measuring probe is defective	Replace measuring probe

Fault	Cause	Remedy
Waste water tank cannot be emptied	Drain cock is clogged	Open the cleaning cap on the waste water tank and drain the waste water. Rinse the waste water tank well
Drain on the one-hand lever mixer is clogged	Perlator calcified	Unclip the perlator, de-calcify in vinegar water (only for products made from metal)
Water jets on the shower nozzle clogged	Water jets calcified	De-calcify shower nozzle in vinegar water (only for products made from metal) or rub off soft nozzle burling
Water drains from the shower tray slowly or does not drain at all	The vehicle is not in a horizontal position	Position the vehicle horizontally
Milkieness of the water	Tank filled with dirty water	Clean water tank mechanically and chemically; then disinfect and rinse copiously with drinking water
	Residues in the water tank or water system	Clean water system mechanically and chemically; then disinfect and rinse copiously with drinking water
Any change in the taste or odour of the water	Tank filled with dirty water	Clean water system mechanically and chemically; then disinfect and rinse copiously with drinking water
	Fuel filled into the water tank by mistake	Clean water system mechanically and chemically; then disinfect and rinse copiously with drinking water. If not successful: Contact a specialist workshop
	Microbiological deposits in the water system	Clean water system mechanically and chemically; then disinfect and rinse copiously with drinking water
Deposits in the water tank and/or water-carrying components	Water excessively long in the water tank and in water-carrying components	Clean water system mechanically and chemically; then disinfect and rinse copiously with drinking water

## 14.9 Body

Fault	Cause	Remedy
Flap hinges/door hinges are difficult to operate	Flap/door hinges are not sufficiently lubricated	Lubricate flap hinges/door hinges with acid-free and resin-free grease
Hinges/joints in the bathroom unit/toilet compartment are difficult to operate/make a grating noise	Hinges/joints are not sufficiently lubricated	Lubricate hinges/joints with solvent-free and acid-free grease  ▷ Spray cans often contain solvents
Storage compartment hinges are difficult to operate/make a grating noise	Storage compartment hinges are not sufficiently lubricated	Lubricate storage compartment hinges with acid-free and resin-free grease
Wind-up skylight is difficult to operate	Threaded spindle not lubricated	Lubricate threaded spindle
	Threaded spindle defective	Have threaded spindle replaced



- ▷ The authorised dealers and service centres are available for any spare parts requirement.

## 15.1 Weight details for special equipment



- ▶ The use of accessories, parts and fittings not supplied by us may cause damage to the vehicle and jeopardize road safety. Even if an expert's report, a general type approval or a design certification exists, there is no guarantee for the proper quality of the product.
- ▶ Every alteration of the original condition of the vehicle can alter road behaviour and jeopardize road safety.
- ▶ No liability can be assumed for damage caused by products which have not been released by us. This also applies to impermissible alterations to the vehicle.

Weight details for factory-provided special equipment are listed in the table below. If these objects are either carried in or on the vehicle and are not part of the standard equipment, they must be taken into consideration when calculating the payload.

All weight details are approximate.

Observe the max. permissible gross weight.

Item designation	Surplus weight (kg)
Waste water pipes, insulated and heated	2
Waste water tank, heated with heating coils	1
Airbag (driver/front passenger)	3
Alloy wheel rims	-15
Alloy wheel rims (tandem axle)	-20
Caravan coupling	40
Dashboard upgrade	2
Conversion door, single-section (with window)	30
External shower	1
External mirrors, electrically adjustable and heated	2
External socket	1
Automatic transmission	2
Car radio and CD	2
Front passenger's seat, variable height	2
Heki skylight midi	8
Skylight Heki 3	15
Roof rail	5
Extractor hood	1
Entrance step, electrical	5
Electrical stability program (ESP)	3
Spare wheel with 15" support	30
Spare wheel with 16" support	31
External gas connection	1
Driver's seat, variable height	2
Bike rack for 2 bicycles	10

Item designation	Surplus weight (kg)
Bike rack for 2 bicycles, lowerable	18
Bike rack for 3 bicycles	11
Bike rack for 3 bicycles, lowerable	20
Bike rack for 2 bicycles in rear garage	3
Bike rack for 2 bicycles on caravan coupling	18
Bike rack for 3 bicycles on caravan coupling	20
Driver's door	38
Floor warming unit	4
Garage door, left	3
Gas oven	17
Gas bottle (11 kg) made of aluminium	12
Gas switching facility, automatic	2
Gas alarm system	5
Rear ladder	10
Alde heater	30
Truma Combi 6 EH heater	3
Insect screen, door (full height)	4
Air conditioning unit (Dometic)	40
Driver's cabin air conditioning unit	18
Air conditioning unit (Telair)	34
Fuel tank 120 l	50
Refrigerator (150 l)	14
Refrigerator (Tec-Tower)	16
LCD television	7
Awning 350 cm	33
Awning 400 cm	38
Awning 450 cm	41
Awning 500 cm	46
Awning 600 cm	61
Microwave oven	14
Minisafe	12
Motorcycle rack	38
Motorcycle rack in the rear garage	12
Navigation system	2
Fog light	4
Receiver (satellite system)	1
Reversing camera	4
Diesel particulate filter	10
Satellite unit (automatic)	10

Item designation	Surplus weight (kg)
Satellite unit (semi-automatic)	9
SOG toilet ventilation	1
Solar installation 55 W	8
Solar installation 75 W	11
Independent vehicle heater	3
Rear steadies	5
Bedspread	2
Bag in the sleeping area	2
Telescopic ladder	10
Tempomat	3
Carpet in driver's cabin	2
Carpet in the living area	3
Adjustment mechanism bench (reliner)	14
Winter insulation mat, outside	3
Auxiliary battery	27
Auxiliary heat exchanger	3
Two cross beams and slip protection for roof racks	3






## 16.1 View of ground plans

### Explanations


- (1) 230 V fuse
- (2) Transformer/rectifier with 12 V fuses
- (3) Living area battery with main fuse
- (4) Water pump mounted in the tank area
- (5) Drain cock, waste water tank
- (6) Electric safety/drainage valve
- (7) Boiler/heater
- (8) Water drain cock - yellow
- (9) Water tank
- (10) Additional heater (partially special equipment)
- (11) Alde hot-water heater
- (12) Compensator reservoir for Alde hot-water heater
- (13) Alde auxiliary heat exchanger
- (14) Water drain cock - white
- \* Access via service flap
- \*\* Beneath the vehicle
- \*\*\* Access via kitchen floor cupboard

Specifications without guarantee



BUE01099

Fig. 250 Ground plan I 595 Viseo



BUE01100

Fig. 251 Ground plan I 620 Viseo




Fig. 252 Ground plan I 640 Visio




Fig. 253 Ground plan I 676 Visio




Fig. 254 Ground plan I 684 Aviano






Fig. 255 Ground plan I 694 Visio




BUE01209

Fig. 256 Ground plan I 694 Aviano




BUE01103

Fig. 257 Ground plan I 696 Visco




BUE01210

Fig. 258 Ground plan I 705 Elegance




BUE01104

Fig. 259 Ground plan I 715 Visco




BUE01211

Fig. 260 Ground plan I 725 Aviano




BUE01212

Fig. 261 Ground plan I 726 Visco




BUE01213

Fig. 262 Ground plan I 726 Elegance




BUE01214

Fig. 263 Ground plan I 727 Aviano




BUE01215

Fig. 264 Ground plan I 728 Aviano




BUE01216

Fig. 265 Ground plan I 729 Elegance



BUE01217

Fig. 266 Ground plan I 730 Elegance



BUE01218

Fig. 267 Ground plan I 810 Elegance




Fig. 268 Ground plan I 821 Elegance

## 16.2 Table of linear measures

Type	Body width, exterior	Total length without ladder	Wheelbase	Overall height without antenna
I 595	2300	5980	3000	2850
I 620	2300	6580	3800	2850
I 640	2300	6850	3800	2850
I 676	2300	6780	3800	2850
I 684	2300	6960	3800	2800
I 694 Aviano	2300	7010	4035	2800
I 694 Viseo	2300	6980	4035	2850
I 696	2300	6980	4035	2850
I 705	2300	7090	3850	2800
I 715	2300	7290	4035	2850
I 725	2300	7460	4035	2800
I 726 Elegance	2300	7590	4090	2800
I 726 Viseo	2300	7490	4035	2850
I 727	2300	7550	4035	2800
I 728	2300	7560	4035	2800
I 729	2300	7490	4090	2800
I 730	2300	7590	4090	2800
I 810	2300	9190	4500	2800
I 821	2300	8860	4500	2800

## 16.3 Power supply

Mains connection	Protection class I	230 V ( $\pm 10\%$ ), 47 - 63 Hz
Mains power rating		400 VA
Appropriate batteries	6-cell lead acid and lead acid gel batteries from 55 Ah	

Charging characteristics	IUoU	
Final charge voltage		14.3 V
Charging current	18 A throughout entire supply voltage range, electronically restricted	18 A
Trickle charge voltage	Automatic switching	13.8 V
Repeated charging cycle (switchover to "Main charging")	At < approx. 13.8 V battery voltage (with approx. 5 seconds delay)	
Reflux (without mains and with connected battery)	After approx. 3 minutes "Mains Off"	< 0.3 mA
Guard circuits	Short-circuit protection provided by built-in car fuse (FKS)	
	Safety fuse, 3.15 AT at power input	
	Overtemperature protection	
Charging current distribution at mains connection	Starter battery float charge with max. 2 A or 6 A	Max. 2 A (EBL 99) or max. 6 A (EBL 220)
	Living area battery charge with max. 18 A	Max. 18 A
Charging current distribution during the journey	Simultaneous charging of starter and living area batteries by means of the alternator	50 A
	Parallel battery switching via disconnecter relay	
	Maximum permitted alternator charging current to the living area battery: 50 A (see block diagram)	
Battery monitor	Disconnection	10.5 V ± 0.1 V
Battery monitor	Minimum voltage for connection	11.0 V ± 0.1 V





## Chapter overview

This chapter contains helpful tips for the journey.

The instructions address the following topics:

- road assistance in European countries
- traffic rules in European countries
- gas supply in European countries
- toll regulations in European countries
- safe ways to spend the night during travel
- camping in winter

At the end of the chapter there is a checklist containing the most important equipment for the journey.

### 17.1 Traffic rules in foreign countries



- ▷ The vehicle driver is required to inform himself as to the traffic rules of the countries in which he plans to travel before beginning the trip. Contact your automobile club or embassy for further information.
- ▷ In some European countries, warning vests must be worn when exiting the vehicle outside of towns in the case of vehicle failures or accidents.

Information about traffic regulations is especially important as state law applies in case of damage. For your own safety, always observe the following rules when travelling abroad:

- Take the green insurance card with you.
- Always register accidents with the police.
- Never sign documents that you have not read and understood completely.

### 17.2 Help on Europe's roads

Country	+ Emergency services ★ Police	☎ Breakdown service
Belgium	+ 112 ★ 112	☎ TCB Brussels 0 70 34 47 77
Bulgaria	+ 150 ★ 166	☎ UAB (02) 9 80 33 08/146 <sup>1)</sup>
Denmark	+ 112 free of charge ★ 112 free of charge	☎ Falck 79 42 42 42
Germany	+ 112 ★ 110	☎ ADAC 22 22 22 <sup>1)</sup>
Estonia	+ 112 ★ 110/112 <sup>1)</sup>	☎ EESTI (0) 6 97 91 88/18 88 <sup>1)</sup>
Finland	+ 112 ★ 112	☎ Helsinki (09) 77 47 64 00
France	+ 15/112 <sup>1)</sup> ★ 17/112 <sup>1)</sup>	☎ Lyon (08) 25 80 08 22 AIT-Assistance 0800 08 92 22

Country	+ Emergen- cy services ★ Police	☎ Breakdown service
Greece	+ 112 ★ 171/112 <sup>1)</sup>	☎ ELPA 104 00
Great Britain	+ 112 ★ 112	☎ AA (08 00) 0 28 90 18/ (08 00) 82 82 82 <sup>1)</sup>
Ireland	+ 999/112 <sup>1)</sup> ★ 999/112 <sup>1)</sup>	☎ AA Dublin 18 00 66 77 88
Iceland	+ 112 ★ 112	☎ F.I.B 5 11 21 12
Italy	+ 118/112 <sup>1)</sup> ★ 112	☎ ACI 803 116/8 00 11 68 00 <sup>1)</sup>
Croatia	+ 94/112 <sup>1)</sup> ★ 92/112 <sup>1)</sup>	☎ HAK 9 87/ 0 19 87 <sup>1)</sup>
Latvia	+ 03/112 <sup>1)</sup> ★ 02/112 <sup>1)</sup>	☎ LAMB 8 00 00 00
Lithuania	+ 03/112 <sup>1)</sup> ★ 02/112 <sup>1)</sup>	☎ LAS 8 80 00 00 00/18 88 <sup>1)</sup>
Luxembourg	+ 112 ★ 113/112 <sup>1)</sup>	☎ ACL 2 60 00
Macedonia	+ 194 ★ 192	☎ AMSM 196
Montenegro	+ 94 ★ 92	☎ AMSCG 9807
Netherlands	+ 112 ★ 112	☎ ANWB 08 82 69 28 88
Norway	+ 113 ★ 112	☎ NAF 81 00 05 05
Austria	+ 144/112 <sup>1)</sup> ★ 133/112 <sup>1)</sup>	☎ ÖAMTC 120
Poland	+ 999/112 <sup>1)</sup> ★ 997/112 <sup>1)</sup>	☎ PZM 022 5 32 84 33
Portugal	+ 112 ★ 112	☎ ACP Lissab. (21) 9 42 91 03 ACP Porto (22) 8 34 00 01
Romania	+ 961/112 <sup>1)</sup> ★ 955/112 <sup>1)</sup>	☎ ACR (021) 2 22 22 22/ (021) 2 22 15 53 <sup>1)</sup>
Russia	+ 03 ★ 02	☎ RAS (4 95) 7 47 66 66
Sweden	+ 112 ★ 112	☎ M 0 20 91 29 12

Country	+ Emergency services ★ Police	☎ Breakdown service
Switzerland	+ 144 ★ 117/112 <sup>1)</sup>	☎ TCS 1 40/03 18 50 53 11 <sup>1)</sup>
Serbia	+ 94 ★ 92	☎ AMSS (011) 19800
Slovakia	+ 155/112 <sup>1)</sup> ★ 158/112 <sup>1)</sup>	☎ SATC 1 81 24
Slovenia	+ 112 ★ 113	☎ AMZS (1) 9 87/ (003861) 5 30 53 53 <sup>1)</sup>
Spain	+ 061 ★ 112	☎ RACE 9 15 93 33 33
Czech Republic	+ 155/112 <sup>1)</sup> ★ 158/112 <sup>1)</sup>	☎ UAMK CR 12 30
Turkey	+ 112 ★ 155/112 <sup>1)</sup>	☎ TTOK (02 12) 2 82 81 40
Ukraine	+ 03 ★ 02	☎ 112 UA (8-032) 2 97 81 12
Hungary	+ 104/112 <sup>1)</sup> ★ 107/112 <sup>1)</sup>	☎ MAK 1 88/(0036-1) 13 45 17 44 <sup>1)</sup>
Cyprus	+ 112 ★ 112	☎ AA 02 22 31 31 31

<sup>1)</sup> In the mobile communication network

Date 03/2007

Specifications without guarantee

### 17.3 Speed limits and permissible dimensions



► Please always observe the speed limits in the individual countries.

For information, the speed limits (in km/h) and permissible dimensions (in m) of the countries visited most:

Country	Max. dimensions in meters		Gross weight	In built-up areas	Outside built-up areas	Motorway
	Width	Lgth.				
<b>Belgium</b>	2.55	12	Up to 7.5 t	50	90/120 <sup>1)</sup>	120
			Over 7.5 t	50	60/90 <sup>1)</sup>	90
<b>Bulgaria</b>	2.60	12	Up to 3.5 t	50	90	130
			Over 3.5 t	50	70	100
<b>Denmark</b>	2.55	12	Up to 3.5 t	50	80	130
			Over 3.5 t	50	70	80
<b>Germany</b>	2.55	12	Up to 3.5 t	50	100	130 <sup>3)</sup>
			3.5 t up to 7.5 t	50	80	100
			Over 7.5 t <sup>2)</sup>	50	80	80
<b>Estonia</b>	2.50	12	Up to 3.5 t	50	90	110
			Over 3.5 t	50	70	70
<b>Finland</b>	2.60	12		50	80 <sup>4)</sup>	80 <sup>4)</sup>
<b>France</b>	2.55	12	Up to 3.5 t	50	90 <sup>5)</sup> /-	130 <sup>5)</sup>
			Over 3.5 t	50	80 <sup>5)</sup> / 100 <sup>1) 5)</sup>	110 <sup>5)</sup>
<b>Greece</b>	2.50	12		50	90/110 <sup>11)</sup>	120
<b>Great Britain</b>	2.55	12		48	96/112 <sup>1)</sup>	112
<b>Ireland</b>	2.55	12		50	60/100 <sup>1)</sup>	120
<b>Iceland</b>	2.55	12		50	90 <sup>6)</sup>	-
<b>Italy</b>	2.50	12	Up to 3.5 t	50	90/110 <sup>1) 7)</sup>	130 <sup>7)</sup>
			Over 3.5 t	50	80	100
<b>Croatia</b>	2.55	12		50	90/110 <sup>1)</sup>	130
<b>Latvia</b>	2.50	12	Up to 7.5 t	50	90/100 <sup>11)</sup>	110
			Over 7.5 t	50	80	80
<b>Lithuania</b>	2.50	12	Up to 3.5 t	50	90	110
			Over 3.5 t	50	70	70
<b>Luxembourg</b>	2.55	12	Up to 3.5 t	50	90 <sup>8) 7)</sup>	130 <sup>8) 7)</sup>
			Over 3.5 t	50	75 <sup>7)</sup>	90 <sup>7)</sup>
<b>Macedonia</b>	2.50	12		40/60	80	80
<b>Montenegro</b>	2.50	12	Up to 3.5 t	50	80/100 <sup>1)</sup>	100
			Over 3.5 t	50	80	80
<b>Netherlands</b>	2.55 <sup>9)</sup>	12	Up to 3.5 t	50	80/100 <sup>1)</sup>	120
			Over 3.5 t	50	80	80
<b>Norway</b>	2.55	12.40	Up to 3.5 t	50	80/90 <sup>1)</sup>	90
			Over 3.5 t	50	80	80

Country	Max. dimensions in meters		Gross weight	In built-up areas	Outside built-up areas	Motorway
	Width	Lgth.				
Austria	2.55	12	Up to 3.5 t	50	100	130 <sup>10)</sup>
			Over 3.5 t	50	70	80
Poland	2.50	12	Up to 3.5 t	50	90/100 <sup>1)</sup>	130
			Over 3.5 t	50	70/80 <sup>1)</sup>	80
Portugal	2.50	12	Up to 3.5 t	50	90/100 <sup>11)</sup>	120 <sup>12)</sup>
			Over 3.5 t	50	80/90 <sup>11)</sup>	110 <sup>12)</sup>
Romania	2.50	12	Up to 3.5 t	50	80/90 <sup>1)</sup>	120
			Over 3.5 t	50	80/90 <sup>1)</sup>	110
Russia	2.50	12	Up to 3.5 t	60	90 <sup>13)</sup>	110 <sup>13)</sup>
			Over 3.5 t	60	70	90 <sup>13)</sup>
Sweden	2.60	24 <sup>14)</sup>	Up to 3.5 t	50	70-110 <sup>1) 11)</sup>	110
			Over 3.5 t	50	80/90 <sup>1)</sup>	90
Switzerland	2.55	12	Up to 3.5 t	50	80/100 <sup>1)</sup>	120
			Over 3.5 t <sup>15)</sup>	50	80/100 <sup>1)</sup>	100
Serbia and Montenegro	2.50	12	Up to 3.5 t	60	80/100 <sup>1)</sup>	100
			Over 3.5 t	60	80	80
Slovakia	2.50	12	Up to 3.5 t	60	90	130
			Over 3.5 t	60	80	80
Slovenia	2.55	12	Up to 3.5 t	50	80/100 <sup>1)</sup>	100
			Over 3.5 t	50	80	80
Spain	2.55	12		50	70/80 <sup>1)</sup>	90
Czech Republic	2.50	12	Up to 3.5 t	50	90	130
			Over 3.5 t	50	80	80
Turkey	2.50	10		50	80	90
Ukraine	2.50	12		60	90 <sup>13)</sup>	110 <sup>13)</sup>
Hungary	2.50	12	Up to 2.5 t	50	90/110 <sup>1)</sup>	130
			Over 2.5 t	50	70	80
Cyprus	2.55	12		50	80	100

- 1) On expressways, on roads with more than one lane in each direction
- 2) Vehicles over 7.5 tons max. permissible weight require a tachograph
- 3) Recommended speed: 130 km/h
- 4) Since 1995, for the first time, vehicles up to an unladen weight of 1875 kg and vehicles up to 3.5 t perm gross weight with appropriate equipment (ABS, driver airbag, seat belts on all seats) can drive max. 100 km/h
- 5) On wet roads, reduce speed by 10 km/h, on motorways by 20 km/h
- 6) On unmade roads (gravel): 80 km/h
- 7) In wet conditions, reduce speed by 20 km/h
- 8) Drivers who don't have their driver's licence for the full year, must not drive faster than max. 75 km/h when out of town or 90 km/h on motorways

- 9) On main roads 2.55 m, on roads marked "B" 2.20 m
- 10) Between 10 p.m. and 5 a.m. the speed limit on the following motorways is 100 km/h: A10 (Tauernautobahn), A12 (Inntalautobahn), A13 (Brennerautobahn), A14 (Rheintalautobahn)
- 11) According to traffic signs
- 12) Drivers who have had their driver's licence for less than one year must not drive faster than 90 km/h. Corresponding stickers (available from ACP offices) must be affixed in a clearly visible position on the rear of the vehicle
- 13) Drivers who have had their driver's licence for less than two years must not drive faster than 70 km/h
- 14) Swedish campsites often require the motorhome to have a closed waste water system
- 15) A heavy goods vehicle supplement must be paid on all roads for all vehicles exceeding 3.5 tons max. permissible weight

Date 06/2008

Source: ADAC

Specifications without guarantee

## 17.4 Driving with low beam in European countries



- ▷ In many European countries, it is compulsory to drive with the vehicle's lights on even during the day. Regulations vary between countries. Motoring organisations or consulates can provide you with the relevant information.

## 17.5 Sleeping in the vehicle away from camping areas

Country	Sleeping on roads and fields		Sleeping on privately owned lands		Comments
	Yes	No	Yes	No	
<b>Belgium</b>		X	X		On highway rest areas max. 24 hours permitted
<b>Bulgaria</b>		X		X	
<b>Denmark</b>	X		X		On streets and squares only up to 11 hours with a parking disc
<b>Germany</b>	X		X		Staying overnight for one night to restore driving ability is permitted. There may be regional and local limitations
<b>Finland</b>	X			X	Possible with the permission of the land owner
<b>France</b>	X		X		Permission from the local authorities or the owner of the land is required. Parking and staying overnight on free areas is prohibited
<b>Greece</b>		X		X	Staying overnight for one night at designated areas on the national route Patras-Athens-Thessaloniki is permitted
<b>Great Britain</b>		X	X		

Country	Sleeping on roads and fields		Sleeping on privately owned lands		Comments
	Yes	No	Yes	No	
Ireland		X	X		
Italy	X		X		Staying overnight for one night at car parks and service stations is allowed. Observe the local regulations. Parking and staying overnight on free areas is prohibited
Croatia		X		X	
Luxembourg		X	X		
Macedonia		X		X	
Netherlands		X	X		Overnight stays on streets and squares is allowed in some boroughs
Norway	X		X		Officially prohibited on rest areas and cultivated grounds. Travelling on dirt roads is prohibited
Austria	X		X		Staying overnight for one night to restore driving ability is permitted, but not in nature reserves. Observe regional and local restrictions. Generally forbidden in Tyrol
Poland		X	X		Requires property owner's permission
Portugal		X		X	Staying overnight for one night on motorway service stations and car parks under 10 hours are tolerated
Romania		X		X	
Russia		X		X	
Sweden	X		X		Not on agriculture areas or in the vicinity of houses. Driving on open fields is prohibited
Switzerland		X	X		One overnight stay at highway rest areas and in some cantons is tolerated
Serbia and Montenegro		X		X	
Slovakia	X		X		Overnight stays on private land are only allowed if a toilet is present
Slovenia		X		X	
Spain	X		X		Some regional prohibitions apply, especially on beaches
Czech Republic	X		X		Overnight stays on private land are only allowed if a toilet is present

Country	Sleeping on roads and fields		Sleeping on privately owned lands		Comments
	Yes	No	Yes	No	
Turkey	X		X		
Ukraine	X		X		
Hungary		X	X		Staying overnight on privately owned land is permitted only with police certification

Specifications without guarantee

## 17.6 Gas supply in European countries



- ▷ In Europe, there are several different connection systems for gas bottles. It is not always possible to fill or exchange your gas bottles in a foreign country. Get information about the connection system in the country you are travelling to before embarking on your journey, e.g. at a motoring club or in the trade press.

### General tips

Always observe the following instructions:

- Only go on vacation with completely filled gas bottles.
- Use all of the gas bottles' capacity.
- Take along adapter sets (available in camping supply stores) for filling gas bottles in foreign countries and for connecting the gas pressure regulator to foreign gas bottles.
- During the cold time of the year observe filling with propane gas component (butane does not gas below 0 °C).
- Use blue bottles from the firm Campingaz (distributed world-wide). Only use gas bottles with safety valves.
- When bottles from other countries are used, check the gas bottle compartments to see if the gas bottles fit into them. Gas bottles from other countries do not always display the same size as your own gas bottles.

## 17.7 Toll regulations in European countries

Many European countries have introduced a mandatory toll system. The toll regulations and how they are collected vary greatly from country to country. Nevertheless, ignorance is no excuse. Penalties can be quite severe.

As is the case with traffic regulations, the vehicle driver is required to be familiar with the toll formalities before starting out on a trip. For example, in Austria the vignette does not meet the toll requirements for vehicles that weigh more than 3.5 t. There, a so-called "Go-Box" must be obtained and charged.

Contact your automobile club or the Internet for further information.



- ▷ Windscreens with solar filters can affect the functioning of automatic toll collection systems (e.g. Go-Box). This must be taken into account when acquiring the appropriate device (e.g. Split-Go-Box).

## 17.8 Tips on staying overnight safely during travel

Prudent behaviour is the most important protective measure for insuring a safe night in the motorhome.



The risk of theft is reduced to a minimum when the following basic rules are observed:

- Before commencing the journey, close and lock all windows, doors and skylights.
- During high season do not spend the night at highway rest stops or parking areas located along typical vacation routes.
- Several vehicles on one site at the same time do not necessarily decrease the chances of theft occurring. Consult your own feelings about the parking site.
- Even if it is just for one night, go to a camping site.
- When parking on open space keep emergency routes clear. The way to the driver's seat should be clear. The ignition key should always be within reach.
- Only take with you those valuables which are absolutely necessary for the journey. If possible, store valuables in a small safe and not in the immediate vicinity of windows or doors.
- Always lock up the vehicle.

## 17.9 Tips for winter campers

The following tips will help make your winter camping experience as agreeable as possible.

- Reserve your parking place in good time. Good winter camping sites are often booked up early.
- Do not start your trip without winter tyres.
- Bring snow chains.
- Choose your parking place with care. Observe the ground beneath you. Snow and ice may melt.
- When the vehicle has been positioned, release the handbrake to prevent freezing.
- No snow walls should be allowed to cover the built-in forced ventilation.
- Keep the built-in forced ventilation free from snow and ice.
- Make sure the air circulation is good. Good air circulation prevents moisture from collecting and makes it easier to heat the living area.
- Cover the single-paned driver's cabin window with insulation mats to avoid thermal bridges.
- Follow the instructions in the section "Gas supply in European countries".
- Use a two-bottle system with automatic controller for the gas system, so that the supply does not run out during the night.
- Only operate the gas system using propane gas.
- Do not use the space behind the heater as a storage compartment.
- Never operate catalytic ovens or infra-red gas radiators in the interior of the vehicle, since they consume oxygen for burning.
- Lay the 230 V power cable in such a way that the cable cannot be frozen or be damaged (e.g. during snow removal).
- When it is snowing heavily, clear the roof of the vehicle of snow regularly. A few centimetres of powdery snow serves as insulation, but wet snow quickly becomes a heavy burden.
- Before embarking on the return journey, remove all the snow from the roof to avoid impeding vehicles behind you with a "snow flag".

## 17.10 Travel checklists

The following checklists will help that nothing important is left at home although not everything on the checklists might be necessary.



- ▷ Do not leave checking of documents (e.g. vehicle papers and information) as well as checking the condition of the vehicle until just before commencing the trip. Planning and checking documents well in advance will save unnecessary trouble.

### Kitchen area

✓	Object	✓	Object	✓	Object
	Wiping cloth		Cleansing agent (detergent)		Salad servers
	Mug		Dishcloths		Chopping board
	Turnspit		Set of knives and forks for grilling		Bowls
	Can opener		Coffeepot		Brush to wash the dishes
	Egg-cup		Corkscrew		Cloth to wash the dishes
	Ice cube tray		Kitchen paper		Matches
	Lighter		Spoons		Cups
	Bottle opener		Knives		Plates
	Air-tight storage boxes		Garbage bags		Thermos jug
	Breakfast plate		Frying pans		Pots
	Forks		Stirring spoons		Glasses

### Bathroom/sanitary items

	Towels		Toilet brush		Toothbrush glass
	Sanitary items		Toilet paper		

### Living area

	Dustbin		Insect lamp		Rain clothes
	Road atlas		Insect repellent		First aid kit
	Bath towels		Deck of cards		Travel guides/parking guide
	Bath shoes		Broom		Rucksack
	Batteries		Candles		Sleeping bags
	Bed sheets		Dust pan		Pencils and paper
	Bed linen		Coat-hangers		Shoes
	Laundry bag		Clothes brush		Shoe polish
	Books		Pillow		Vacuum cleaner
	Camping guide		Map		Flash light
	Spare bulbs		Medicine		Pocket knife
	Water bottle		Music cassettes		Table cloth
	Binoculars		Neck-supporting pillow		Clothes pins
	Fire extinguisher		Sewing kit		Clothesline
	Gas bottle		Radio		

**Vehicle/tools**

✓	Object	✓	Object	✓	Object
	Waste water container		Fabric tape		Screwdriver
	Adapter socket		Watering can for drinking water		Current-measuring instrument
	CEE adapter		Cable reel		Step
	Wire		V-belt		Wheel chocks
	Spare wheel		Glue		First-aid kit
	Spare lamps		Universal pliers		Vehicle jack
	Spare fuses		Compressor		Hazard warning triangle
	Replacement water pump		Luster terminals		Warning sign
	Hammer		Loops		Warning vest
	Flat wrench		Tube adapter		Flashing hazard warning light
	Gas filling adapter		Hose clips		
	Gas tube		Snow chains (winter)		

**Outside**

	Stay rope		Camping table		Lock
	Bellows		Luggage racks		String
	Camping chairs		Grill		Tent pegs/tightening ropes

**Documents**

	List of addresses		Registration book		Identity card
	Registration confirmation(s)		Driving licence		Passport
	Allergy certificate		Green insurance card		Writ of protection
	Instruction manuals		Vaccination certificate		Vignette/toll card
	Instruction leaflets for medicines		Credit card		Visa



Pos.	Component	Activity	Interval
1	Auxiliary support	Lubrication	Annually
2	Joints, hinges	Lubrication	Annually
3	Refrigerator, heater, boiler, cooker, lighting, flap and door closures, toilet, seat belts	Function check	Annually
4	Windows, skylights	Function check, water ingress test	Annually
5	Upholstery, curtains, blinds	Visual check	Annually
6	Sealing strips, edges, rubber	Check for damage	Annually
7	Water supply	Water ingress test	Annually
8	Hot-air system	Function check, clean fan wheel as necessary	Annually
9	Underbody protection, floor skirt attachment	Visual check	Annually
10	Pull-down bed suspension	Function check	Annually
11	Electrical system	Function check	Annually
12	Gas system	Official gas inspection	Every two years
13	Connections between the chassis and body	Check	Every two years
14	Underbody	Visual check, repair underbody protection as necessary	Every two years



Delivery _____	Pos. 1-11
Stamp of the Bürstner dealer	
Date	Signature

1st year _____	Pos. 1-11
Stamp of the Bürstner dealer	
Date	Signature

2nd year _____	Pos. 1-14
Stamp of the Bürstner dealer	
Date	Signature

3rd year _____	Pos. 1-11
Stamp of the Bürstner dealer	
Date	Signature

4th year _____	Pos. 1-14
Stamp of the Bürstner dealer	
Date	Signature

5th year _____	Pos. 1-11
Stamp of the Bürstner dealer	
Date	Signature

6th year _____	Pos. 1-14
Stamp of the Bürstner dealer	
Date	Signature

7th year _____	Pos. 1-11
Stamp of the Bürstner dealer	
Date	Signature

8th year _____	Pos. 1-14
Stamp of the Bürstner dealer	
Date	Signature

- 12 V fuses ..... 122  
    For Thetford toilet ..... 124  
    For toilet ..... 125  
    On the living area battery ..... 122  
    On the relay box AD01 ..... 123  
    On the starter battery ..... 122  
    On the transformer/rectifier ..... 123  
12 V indicator lamp ..... 109, 113  
12 V main switch ..... 106, 112, 114  
12 V power supply ..... 98  
    Switching on ..... 106, 112, 114  
    Troubleshooting ..... 226  
230 V connection ..... 49, 120  
    External flap ..... 59  
    Power cable ..... 120  
    Troubleshooting ..... 226  
230 V fuse ..... 126  
    Position ..... 241  
230 V fuse box ..... 126  
230 V indicator lamp ..... 109, 113, 114  
230 V power supply ..... 120  
3-way valve ..... 141
- A**
- Accessories, fitting ..... 10  
Adapter cable ..... 121  
Additional equipment ..... 18  
Add-on parts see special equipment ..... 10  
Add-on parts, securing ..... 29  
Adjustable head section, fixed bed ..... 83  
Adjustment mechanism, divan ..... 78  
Air conditioning unit (Dometic)  
    Air current, adjusting ..... 147  
    Care ..... 194  
    LED ..... 146  
    Maintenance ..... 194  
    Operating modes ..... 146  
    Switching off ..... 146  
    Switching on ..... 146  
    Troubleshooting ..... 230  
Air conditioning unit (Telair)  
    Care ..... 194  
    Filter, cleaning ..... 194  
    Operating modes ..... 148  
    Switching off ..... 148  
    Switching on ..... 148  
    Troubleshooting ..... 230  
    Ventilation grill, cleaning ..... 194  
Air outlet nozzles, adjustment ..... 136  
Alloy wheel rims ..... 222  
Antenna alignment ..... 50  
Antenna, lowering for driving ..... 50  
Appliances ..... 135  
    Manuals ..... 10  
    Warranty cards ..... 1  
Armrest, adjustment ..... 38, 39  
Automatic power selection (AES) ..... 161, 163  
Auxiliary heat exchanger  
    Switching off ..... 143  
    Switching on ..... 143  
Awning ..... 51
- B**
- Backrest adjustment mechanism ..... 40  
Basic equipment ..... 17  
Bathroom lamp ..... 214  
Battery alarm ..... 108, 111, 117  
Battery cut-off switch ..... 102  
Battery monitor ..... 102, 105  
Battery see starter battery  
or living area battery ..... 98, 99  
Battery selector switch ..... 102, 105  
Battery separation ..... 105  
Battery voltage, displaying ..... 107, 109, 115  
Bed extension, securing ..... 29  
Beds ..... 79  
Before the journey ..... 15  
Bike rack  
    Bicycles, loading ..... 24  
    Load ..... 23  
    Not lowerable ..... 24  
    Travelling with a loaded bike rack ..... 23  
Blind, cleaning ..... 192  
Blind, window  
    Closing ..... 72  
    Opening ..... 72  
Block diagram, panel (IT 96) ..... 130  
Block diagram, panel (IT 994) ..... 131  
Block diagram, panel (LT 510) ..... 132  
Boiler (Alde)  
    230 V electrical operation,  
    switching off ..... 152  
    230 V electrical operation,  
    switching on ..... 152  
    Emptying ..... 153  
    Gas and 230 V electrical operation,  
    switching off ..... 153  
    Gas and 230 V electrical operation,  
    switching on ..... 153

Gas operation, switching off . . . . .	152	Care . . . . .	189
Gas operation, switching on . . . . .	152	Air conditioning unit (Telair) . . . . .	194
Operating modes . . . . .	152	Blind . . . . .	192
Position . . . . .	241	Carpet . . . . .	191
Safety instructions . . . . .	152	Curtains . . . . .	191
Troubleshooting . . . . .	229	Entrance step . . . . .	191
Water, filling with . . . . .	153	External care . . . . .	189
Boiler (Truma) . . . . .	149	Extractor hood . . . . .	193
Emptying . . . . .	151	Furniture surfaces . . . . .	191
Operating modes . . . . .	149	Gas cooker . . . . .	191
Position . . . . .	241	High-pressure cleaner, washing with . . . . .	189
Safety/drainage valve . . . . .	149	Hot-water heater . . . . .	202
Summer operation . . . . .	150	In the winter . . . . .	194
Switching off . . . . .	150	Insect screen . . . . .	192
Switching on . . . . .	150	Interior care . . . . .	191
Troubleshooting . . . . .	228	Lamps . . . . .	191
Water, filling with . . . . .	151	Leather covers . . . . .	191
Winter operation . . . . .	150	Net curtains . . . . .	191
Bonnet . . . . .	42	PVC-floor covering . . . . .	191
Closing . . . . .	43	Roman shade . . . . .	192
Opening . . . . .	43	Seat belt . . . . .	192
Brakes . . . . .	36	Sink . . . . .	191
Check . . . . .	36, 225	Synthetic parts, interior . . . . .	191
Braking system, troubleshooting . . . . .	225	Temporary lay-up . . . . .	196
Breakdown services in Europe . . . . .	249	Underbody . . . . .	190
Bulbs, changing . . . . .	204	Upholstery . . . . .	191
Bathroom lamp . . . . .	214	Washing . . . . .	189
Ceiling lamp . . . . .	210	Waste water tank . . . . .	190
Exterior lighting . . . . .	204	Water system . . . . .	192
Front lights . . . . .	205, 206	Windows . . . . .	190
Garage light . . . . .	215	Winter lay-up . . . . .	197
Halogen spotlight . . . . .	212, 213	Carpet, cleaning . . . . .	191
Interior lighting . . . . .	210	Ceiling lamp . . . . .	210
Rear lights . . . . .	208	Central bench, sleeping conversion . . . . .	85
Recessed halogen light . . . . .	211	Changing wheels . . . . .	219
Side lights . . . . .	209	Tightening torque . . . . .	220
Types of external bulbs . . . . .	209	With alloy wheel rims . . . . .	222
Wardrobe light . . . . .	214	Charging condition, displaying	
Butane gas . . . . .	13, 88	Living area battery . . . . .	107
		Starter battery . . . . .	107
		Charging current . . . . .	112
		Chassis number . . . . .	216
		Checklist . . . . .	30, 196
		Before the journey . . . . .	30
		For the journey . . . . .	257
		Initial start-up after temporary lay-up . . . . .	198
		Road safety . . . . .	30
		Temporary lay-up . . . . .	196
		Winter lay-up . . . . .	197

## C

Cable reel . . . . .	120
Camping gas bottles, use . . . . .	14, 88
Camping in winter . . . . .	257
Cap for the drinking water filler neck . . . . .	60
Capacity of the battery . . . . .	98
Caravan coupling . . . . .	26



Child restraint systems	37
Children's beds	79, 81
Circuit diagram	
Exterior	134
Interior	128
Circulating pump, setting the rotational speed	140
Circulation fan	136
Cleaning	
Water pipes	192
Water tank	192
Cleaning see care	189
Closed circuit current	97
Condensation	67
On the double acrylic glass pane	68
On the screwed connections in the floor	67
Condensation water see condensation	68
Connecting cable see power cable	120
Conventional load	17
Conversion door	53, 56
Roman shade, closing	56
Roman shade, opening	56
Conversion door, inside	
Locking	55, 56
Opening	55, 56
Conversion door, outside	
Locking	54, 55
Opening	54, 55
Cooker	154
Troubleshooting	231
Curtains, cleaning	191
<b>D</b>	
Danger of suffocation	10, 67
Digital clock	
Setting	111
Switching off	111
Switching on	111
Dimensions see table of linear measures	246
Dimensions, permissible	251
Direction indicator	205, 207, 209
Discharging current	112
Displays	
Battery voltage	107, 109, 115
Current	112
Digital clock	111
Temperature	111, 118
Waste water tank level	108, 110, 117
Water tank level	108, 110, 117
Disposal	
Household waste	8
Sewage	8
Waste water	8
Divan adjustment mechanism	78
Door lock	53, 54, 55
Doors	
Conversion door	53
Driver's door	53
Lock	53, 54, 55
Maintenance work	201
Troubleshooting	236
Double floor, load	22
Drain cock, waste water tank	172
Position	241
Drain cocks, position	154, 241
Drinking water	14
Drinking water filler neck	170
Closing	170
Opening	170
Driver's door	53
Driver's door, inside	
Locking	54
Opening	54
Driver's door, outside	
Locking	54
Opening	53
Driver's seat	37
Adjusting an appropriate seating position	38
Armrest, adjustment	38, 39
Backrest, adjustment	39
Moving in lengthways direction	39
Seat inclination, adjustment	39
Seat, rotating	38
Driving speed	35
Driving the motorhome	33
DuoControl switching facility	93
During the journey	33
<b>E</b>	
Electrical system	97
230 V connection, troubleshooting	226
Entrance step, troubleshooting	225
Explanation of terms	97
Lighting, troubleshooting	225
Safety instructions	14
Troubleshooting	225

Entrance step	27, 47	Fixed table	77
Care	191	Extending	77
Extending	28	Moving in a crossways direction	77
Indicator lamp	27, 28	Moving in a lengthways direction	77
Retracting	28	Reducing size	77
Troubleshooting	225	Flap lock	
Environmental tips	8	Closing	58, 59, 60
Extendable storage compartment, loading	23	Elliptical-shaped	58
Exterior lighting		Opening	57, 58, 59, 60
Bulbs, changing	204	Service flap	59
Checking	30	With recessed handle	57
Troubleshooting	225	Flashing indicator see direction indicator	209
External care	189	Flat screen with holder	65
External connection see 230 V connection	49	Positioning	65, 66
External flaps	57	Storing	66
Flap lock	57, 58, 59	Floor warming unit, electrical	
External gas connection	90	Overload protection	144
External mirrors	41	Switching off	144
Adjusting	42	Switching on	144
Heater, switching on	42	Fog light	206, 208
External socket	126	Forced ventilation	10, 67
Extractor hood	158	Freezer compartment door locking mechanism	
Care	193	Closing	166
Filter, cleaning	193	Locking in the ventilation position	166
		Opening	166
<b>F</b>		Front passenger's seat	37
Fault current protection switch	120	Adjusting an appropriate seating position	38
Check	126	Armrest, adjustment	38, 39
Filling level of the waste water tank, displaying	108	Backrest, adjustment	39
Filling level of the water tank, displaying	108	Moving in lengthways direction	39
Filling the tank	44	Seat inclination, adjustment	39
Fire		Seat, rotating	38
Behaviour in the event of	9	Fuel filler neck	44
Extinguishing	9	Closing	45
Fire prevention	9	Opening	45
Fire risks, avoidance	9	Furniture flaps	
Fixed bed	82, 83	Closing	61
Closing	83	Opening	61
Head section, lowering	83	Furniture flaps, troubleshooting	236
Head section, raising	83	Furniture surfaces, cleaning	191
Opening	82	Fuses	
Fixed bed, electrically adjustable	83	12 V fuses	122
Emergency operation	84	230 V fuse	120, 126
Extending	84	For the Thetford toilet	124
Head section, adjusting	84	For toilet	125
Retracting	84	On the living area battery	122
		On the relay box AD01	123
		On the solar charge regulator	125

On the starter battery ..... 122  
 On the transformer/rectifier EBL 220 ..... 123  
 On the transformer/rectifier EBL 99 ..... 123  
 Fuses see 12 V fuses and 230 V fuse ..... 122

**G**

Garage light ..... 215  
 Gas alarm system ..... 94  
 Gas bottle compartment ..... 13, 88  
 Gas bottles  
   Changing ..... 89  
   Safety instructions ..... 13, 88  
 Gas connection, external ..... 90  
 Gas cooker  
   Cleaning ..... 191  
   Switching off ..... 155, 156  
   Switching on ..... 155, 156  
   Troubleshooting ..... 231  
 Gas isolator taps ..... 90  
   Symbols ..... 90, 135  
 Gas odour ..... 12, 87, 227  
 Gas oven ..... 156  
   Switching off ..... 157  
   Switching on ..... 157  
   Troubleshooting ..... 231  
 Gas supply in European countries ..... 256  
 Gas system ..... 87  
   Defect ..... 12, 87, 227  
   General instructions ..... 12  
   Safety instructions ..... 12, 87  
   Switching automatics ..... 91, 93  
   Troubleshooting ..... 227  
 Gas tube, check ..... 13, 88  
 General instructions ..... 7  
 Ground plans ..... 241

**H**

Halogen spotlight ..... 212, 213  
 Handbrake ..... 47  
   Applying ..... 10  
 Handling of tyres ..... 219  
 Headrests ..... 39  
 Heat exchanger  
   Switching off ..... 143  
   Switching on ..... 143  
 Heat exchanger (Alde)  
   Position ..... 142  
   Switching off ..... 142  
   Switching on ..... 142

Heat exchangers, heater, replacement ..... 135  
 Heater ..... 136  
   Air outlet nozzles, adjustment ..... 136  
   Circulation fan ..... 136  
   Heat circulation, regulating ..... 141  
   Heat exchangers, replacement ..... 135  
   Hot air distribution ..... 136  
   Initial start-up ..... 136  
   Troubleshooting ..... 228  
 Heki skylight ..... 75  
   Closing ..... 75  
   Insect screen ..... 76  
   Opening ..... 75  
   Roman shade ..... 76  
   Ventilation position ..... 75  
 Help on Europe's roads ..... 249  
 High rate of gas consumption ..... 12, 87, 227  
 High-pressure cleaner, washing with ..... 189  
 Hinged window  
   Blind ..... 72  
   Closing ..... 68, 70  
   Continuous ventilation ..... 69, 71  
   Insect screen ..... 72  
   Opening ..... 68, 70  
 Hot air distribution ..... 136  
 Hot-air heater  
   Circulation fan ..... 136  
   Operating modes ..... 137  
   Position ..... 241  
   Switching off ..... 138  
   Switching on ..... 137  
   Troubleshooting ..... 228  
 Hot-water heater  
   230 V electrical operation,  
   switching off ..... 140  
   230 V electrical operation,  
   switching on ..... 140  
   3-way valve ..... 141  
   Auxiliary circulating pump ..... 142  
   Care ..... 202  
   Fluid level, checking ..... 203  
   Gas and 230 V electrical operation,  
   switching off ..... 140  
   Gas and 230 V electrical operation,  
   switching on ..... 140  
   Gas operation, switching off ..... 140  
   Gas operation, switching on ..... 139  
   Heat exchanger ..... 141  
   Heating fluid, topping up ..... 203  
   Heating system, bleeding ..... 203

Maintenance work .....	202		
Operating modes .....	139		
Position .....	241		
Rotational speed, circulating pump .....	140		
Safety instructions .....	139		
Troubleshooting .....	229		
<b>I</b>			
Independent vehicle heater			
Maintenance .....	204		
Programming .....	145		
Switching off .....	145		
Switching on .....	145		
Indicator lamp,			
12 V power supply .....	109, 113		
Indicator lamp,			
230 V power supply .....	109, 113, 114		
Indicator lamp, entrance step .....	28		
Indicator lamp, toilet .....	187		
Information stickers .....	216		
Initial start-up			
After temporary lay-up .....	198		
After winter lay-up .....	198		
Inner door, troubleshooting .....	236		
Insect screen door			
Closing .....	57		
Opening .....	57		
Insect screen, cleaning .....	192		
Insect screen, Heki skylight			
Closing .....	76		
Opening .....	76		
Insect screen, windows			
Closing .....	72, 73		
Opening .....	72, 73		
Insect screen, wind-up skylight			
Closing .....	76		
Opening .....	77		
Inspection plan .....	261		
Inspection work .....	201		
Inspections .....	201		
Interior care .....	191		
Interior lighting			
Bulbs, changing .....	210		
Troubleshooting .....	225		
<b>K</b>			
Keys .....	15		
<b>L</b>			
Ladder, rear .....	21		
Lamps .....	210		
Cleaning .....	191		
Lay-up			
Temporary .....	196		
Winter lay-up .....	197		
Leakage water inside the vehicle .....	234		
Leather covers, cleaning .....	191		
Lift-off table			
Conversion to bed foundation .....	78		
Table-top, moving in a			
crossways direction .....	78		
Table-top, moving in a			
lengthways direction .....	78		
Table-top, moving upwards .....	78		
Light control .....	63		
Light metal wheel rims			
see alloy wheel rims .....	222		
Light switch .....	63		
Living area .....	63		
Toilet compartment .....	62		
Lighting			
Front .....	205, 206		
Lamps, cleaning .....	191		
Rear .....	208		
Side .....	209		
Troubleshooting .....	225		
Living area battery .....	99		
Battery alarm .....	108, 111, 117		
Charging .....	100		
Charging current, displaying .....	112		
Discharging current, displaying .....	112		
Fuses .....	122		
Instructions .....	99		
Maintenance work .....	202		
Position .....	241		
Troubleshooting .....	226, 227		
Voltage, displaying .....	107, 109, 115		
Load .....	19		
Bike rack .....	23		
Double floor .....	22		
Extendable storage compartment .....	23		
Rear garage .....	22		
Rear storage space .....	22		
Roof rack .....	21		
Load rack .....	24, 25		
Load rack for roof loads .....	21		
Load see also payload .....	19		

Lock		
Conversion door	54, 55	
Driver's door	53	
External flap	57, 58, 59	
Furniture flap	61	
Low beam	206, 254	
<b>M</b>		
Main beam	206	
Maintenance	201	
Maintenance work	201	
Air conditioning unit (Dometic)	194	
Air conditioning unit (Telair)	194	
Doors	201	
Hot-water heater	202	
Independent vehicle heater	204	
Living area battery	202	
Marker light	209	
Mass in ready-to-drive condition	17, 19	
Maximum permissible gross weight	16, 19	
Mechanical steady legs		
Extending	48, 49	
Length, adjustment	48, 49	
Retracting	48, 49	
Microwave oven		
Switching off	158	
Switching on	158	
Troubleshooting	231	
Monitor, reversing camera	35	
<b>N</b>		
Net curtains, cleaning	191	
No gas	228	
Nose weight	26	
<b>O</b>		
Off-load voltage	97	
Operating modes		
Air conditioning unit (Dometic)	146	
Air conditioning unit (Telair)	148	
Boiler (Alde)	152	
Boiler (Truma)	149	
Hot-air heater	137	
Hot-water heater	139	
Refrigerator	159, 161	
Switching automatics, gas system	94	
Oven see gas cooker or gas oven	154, 156	
Overloading	19	
<b>P</b>		
Panel (IT 96)	106	
12 V indicator lamp	109	
12 V main switch	106	
230 V indicator lamp	109	
Battery voltage, displaying	107	
Block diagram	130	
Filling level of the waste water tank, displaying	108	
Filling level of the water tank, displaying	108	
Switch for water pump	108	
Panel (IT 994)	109	
12 V indicator lamp	113	
12 V main switch	112	
230 V indicator lamp	113	
Battery voltage, displaying	109	
Block diagram	131	
Filling level of the waste water tank, displaying	110	
Filling level of the water tank, displaying	110	
Switch for water pump	113	
Panel (light control)	63	
Panel (LT 510)	113	
12 V main switch	114	
230 V indicator lamp	114	
Alarms	117	
Battery displays	115	
Block diagram	132	
Tank display	117	
Tank heater switch	118	
Temperature display	118	
Water pump switch	119	
Panel see also displays	106, 109	
Parking distance control	34	
Switching off	35	
Parking light	206, 207	
Payload	16	
Calculation	18	
Composition	17	
Example calculation	17, 19	
Payload see also load	16	
Permissible gross weight see maximum permissible gross weight	16	
Permitted mass	16	
Personal equipment	18	
Pilot seat see driver's seat and front passenger's seat	37	

---

Power cable for the 230 V connection	120	Road safety	30
Power supply	246	Checklist	30
Propane gas	13, 88	Notes for	10
Pull-down bed		Roman shade, cleaning	192
Access ladder	80	Roman shade, driver's cabin	42
Closing	80	Closing	74
Opening	80	Opening	74
Roman shade	80	Roman shade, Heki skylight	
Pull-down bed, electrically operated	81	Closing	76
Closing	81	Opening	76
Emergency operation	82	Roman shade, pull-down bed	
Making ready for operation	81	Closing	80
Opening	81	Opening	81
Overload protection	82	Roman shade, window of conversion door	
PVC-floor covering, cleaning	191	Closing	56
		Opening	56
		Roman shade, windows	
<b>R</b>		Closing	73
Rear axle load	26	Opening	73
Rear garage	22	Roman shade, wind-up skylight	
Rear ladder	21	Closing	76
Rear storage space	22	Opening	76
Recessed halogen light	211	Roof load	21
Refrigerator	49, 159	Roof rack, load	21
12 V operation, switching on/off	160	Roof rail	21
230 V operation, switching on/off	160		
Change-over between energy		<b>S</b>	
sources	162, 164	Safety cut-out	126
Door lock	165, 166	Safety instructions	9
Frame heater	162	Changing wheels	219
Gas operation	164	Cooker	154
Gas operation, switching off	160	Electrical system	14
Gas operation, switching on	160	Fire prevention	9
Operating modes	159, 161	Gas bottles	88
Operation	162, 164	Gas system	12, 87
Refrigerating temperature control	162, 164	Heater	139
Switching off	163	Road safety	10
Switching on	162	Towing	12
Troubleshooting	231, 232	Water system	14
Ventilation grill, removal	159	Safety knob, hinged window	69
Refrigerator door locking mechanism		Safety switch (FI)	126
Closing	165, 166	Safety/drainage valve boiler	149
Locking in the ventilation position	166, 167	Position	241
Opening	165, 166	Sanitary fittings	169
Refrigerator ventilation grill, removal	159	SAT socket	127
Registration	15	Satellite unit	49, 50
Reversing camera	35	With automatic antenna alignment	50
Risk of frost damage	14, 169, 174	With semi-automatic antenna	
		alignment	50



Total discharge	97	Tyres	217
Towing	12	Excessive wear	11, 30, 217, 223
General instructions	26	General instructions	217
Safety instructions	12	Handling	219
Traffic rules in foreign countries	249	Identification	219
Transformer/rectifier (EBL 220)	103	Load-carrying capacity	220
Circuit diagram	129	Tyre pressure	223
Functions	104	Tyre selection	218
Position	104		
Transformer/rectifier (EBL 99)	100	<b>U</b>	
Circuit diagram	128	Underbody, maintenance	190
Functions	101	Unladen weight	17
Position	101	Upholstery, cleaning	191
Transformer/rectifier, position	241		
Travel checklists	257	<b>V</b>	
Travel cots suitable for children	79, 81	Vehicle identification plate	216
Troubleshooting	225	Vehicle lighting see exterior lighting	204
12 V power supply	226	Vehicle, washing	189
230 V connection	226	Ventilation	67
Air conditioning unit (Dometic)	230	Toilet compartment	175
Air conditioning unit (Telair)	230	Volume of waste water,	
Battery	226	displaying	108, 110, 117
Body	236	Volume of water, displaying	108, 110, 117
Boiler (Alde)	229		
Boiler (Truma)	228	<b>W</b>	
Braking system	225	Wardrobe light	214
Cooker	231	Warning stickers	216
Electrical system	225	Warranty cards	1
Entrance step	225	Washer fluid, filling	44
Extractor hood	227	Washer nozzles, setting	43
Furniture flaps	236	Washing with a high-pressure cleaner	189
Gas cooker	231	Waste gas vent on the right hand side	
Gas oven	231	of the vehicle.	136, 149
Gas system	227	Waste water hose	172
Heater	228	Waste water tank	171, 172
Hot-air heater	228	Care	190
Hot-water heater	229	Cleaning	190
Inner door	236	Cleaning opening	172
Lighting	225	Emptying	172
Living area battery	226	Filling level, displaying	108, 110, 117
Microwave oven	231	Troubleshooting	235
Refrigerator	231, 232	Waste water tank heater	173
Starter battery	226	Water pipes, cleaning	192
Toilet	234	Water pump	169, 173
Water supply	234	Position	241
TV socket	127	Switch	108, 113
Tyre change see changing wheels	219	Switching on and off	119
Tyre specifications	219		



---

Water supply	
General	169
Troubleshooting	234
Water system	
Care	192
Cleaning	192
Disinfect	193
Drinking water filler neck	170
Emptying	174
Filling	173
Safety instructions	14
Water tank	170
Cleaning	192
Filling	170
Filling level, displaying	108, 110, 117
Position	241
Volumes	170
Water, draining	171
Water, filling with	170
Weight details for special equipment	237
Wheel chocks	47
Wheel rim size	220
Wheel rim type	217
Wheels	217
Window winders, electrical	41
Window, conversion door	
Roman shade, closing	56
Roman shade, opening	56
Windows	67
Blind	72
Cleaning	190
Insect screen	72, 73
Roman shade	73, 74
Wind-up skylight	76
Closing	76
Insect screen	76
Opening	76
Roman shade	76
Troubleshooting	236
Winter care	194
Winter operation	195

