

BÜRSTNER

---

# Instruction Manual



- ✓ Averso
- ✓ Averso Harmony Line

GB



**Travel in comfort and convenience -  
your home on four wheels**

**Welcome to the group of caravan owners!**

Congratulations on the purchase of your new BÜRSTNER caravan!

You have purchased a high-quality, reliable and elegant vehicle that offers special advantages and extraordinary comfort.

Our employees extend their best wishes for your satisfaction when travelling, on holiday, or in your free-time; we are confident that you will always enjoy pleasant hours in your new home on wheels.

© Bürstner GmbH  
Weststraße 33  
D-77694 Kehl

Tel.: +49 7851 85 - 0  
Fax: +49 7851 85 - 201

E-mail: [info@buerstner.com](mailto:info@buerstner.com)  
Internet: [www.buerstner.com](http://www.buerstner.com)

Version: 24.09.2019  
Art. No. 2843180  
Created by: gds GmbH  
global document solutions  
[www.gds.eu](http://www.gds.eu)

---

<b>1</b>	<b>Introduction.....</b>	<b>7</b>
1.1	Technical documentation .....	8
1.2	Explanation of symbols used .....	9
1.3	Vehicle registration.....	11
1.4	Keys .....	11
<b>2</b>	<b>Safety.....</b>	<b>12</b>
2.1	Intended use.....	12
2.2	Responsibility of the vehicle owner.....	13
2.3	General requirements .....	14
2.4	Fire safety.....	15
2.5	Traffic safety.....	16
2.5.1	Vehicle .....	16
2.5.2	Load .....	20
2.5.3	Driving.....	21
2.6	Operational reliability.....	23
2.6.1	Gas supply .....	23
2.6.2	Electrical system .....	26
2.6.3	Sanitary system .....	29
2.7	Environmental protection .....	31
<b>3</b>	<b>Technical data.....</b>	<b>32</b>
3.1	Caravan body .....	32
3.2	Built-in devices .....	32
3.3	Loads.....	33
3.4	Nameplate .....	33
<b>4</b>	<b>Driving .....</b>	<b>34</b>
4.1	Loading the vehicle .....	34
4.1.1	Terminology and specifications .....	34
4.1.2	Calculating the maximum load.....	35
4.1.3	Loading and stowing luggage .....	36
4.1.4	Reviewing the check list.....	37
4.2	Checking the vehicle .....	38
4.3	Coupling the caravan and the towing vehicle .....	39
4.3.1	Prerequisites for coupling .....	39
4.3.2	12 V power supply in towing operation .....	41
4.3.3	Coupling with "AL-KO" safety coupling.....	42
4.3.4	Uncoupling with "AL-KO" safety coupling .....	44
4.3.5	"AL-KO" ATC stabiliser system (optional).....	44
4.4	Travelling and parking.....	45
4.5	Parking the caravan at the destination.....	47
4.5.1	Parking the caravan .....	47
4.5.2	Extending and retracting the support elements .....	48

---



## Introduction

<b>5</b>	<b>Overview .....</b>	<b>50</b>
5.1	Caravan body .....	51
5.1.1	Keys .....	51
5.1.2	Entrance door .....	52
5.1.3	Door and hatch locks .....	54
5.1.4	Window .....	57
5.1.5	Air conditioning system (optional) .....	59
5.1.6	Skylights .....	59
5.1.7	Pop-up roof (optional) .....	61
5.1.8	Awning fastening .....	63
5.1.9	Multifunction light switch .....	64
5.1.10	Exhibition lighting system .....	64
5.1.11	Heating system function switch, floor heating and filling levels .....	64
5.1.12	Smoke alarm .....	65
5.2	Furnishings .....	66
5.2.1	Sitting area .....	66
5.2.2	Sleeping area .....	68
5.2.3	Bathroom .....	69
5.2.4	Kitchen area .....	72
5.3	Storage compartments .....	74
5.3.1	Closets and compartments .....	74
5.3.2	Waste container .....	78
5.3.3	TV bracket .....	78
5.4	Technical equipment .....	79
5.4.1	Electrical system .....	79
5.4.1.1	Supply battery .....	82
5.4.2	Gas supply .....	92
5.4.3	Heater .....	96
5.4.3.1	TRUMA heater 3004 S and 5004 S .....	96
5.4.3.2	TRUMA Combination heater (optional) .....	98
5.4.3.3	ALDE- heater (optional) .....	99
5.4.4	Fresh water and waste water system .....	103
5.4.5	Water heater .....	107
5.4.5.1	TRUMA heater and TRUMA water heater system .....	108
5.4.5.2	TRUMA Combination heater (optional) .....	109
5.4.5.3	With installed ALDE heater (optional) .....	109
<b>6</b>	<b>Camping .....</b>	<b>110</b>
6.1	Setting up the caravan .....	110
6.1.1	Establishing the power connection .....	110
6.1.2	Filling the fresh water tank .....	110
6.1.3	Draining fresh water .....	112
6.1.4	Draining the waste water .....	114

---

6.1.5	Changing the gas bottle (standard) .....	116
6.1.6	Replacing the gas bottle (DuoControl CS) (optional) .....	117
6.1.7	Gas supply maintenance (general).....	120
6.2	Airing .....	120
6.3	Heating and water heating .....	126
6.3.1	TRUMA heater .....	126
6.3.2	TRUMA Combination heater (optional).....	132
6.3.3	ALDE- heater (optional) .....	144
6.3.4	Water heater .....	151
6.3.4.1	TRUMA heater and TRUMA water heater system .....	152
6.3.4.2	Applicable if the TRUMA combination heater is installed...	153
6.3.4.3	With installed ALDE heater (optional) .....	154
6.4	Sitting and sleeping .....	155
6.4.1	Converting the sitting area .....	155
6.4.2	Folding console as bed extension .....	158
6.4.3	Sitting group conversion to a sleeping area.....	159
6.4.4	Setting up the lighting .....	161
6.4.5	Opening and closing the pop-up roof.....	163
6.5	Bathroom.....	167
6.5.1	Using the shower and washbasin .....	167
6.5.2	Flushing the toilet with fixed installed toilets (optional).....	167
6.5.3	Flushing the toilet with revolving toilets (optional) .....	169
6.6	Kitchen area .....	171
6.6.1	Using the gas hob .....	171
6.6.2	Using the combination ceramic hob.....	173
6.6.3	Folding console to extend the kitchen counter-top .....	175
6.6.4	Using the oven with grill function (optional) .....	175
6.6.5	Using the Thetford refrigerator (optional).....	177
6.6.6	Using the Domestic refrigerator (optional) .....	179
<b>7</b>	<b>Maintenance .....</b>	<b>183</b>
7.1	Exterior cleaning.....	183
7.2	Interior cleaning.....	184
7.3	Pop-up roof (optional) .....	184
7.4	Supply battery (optional) .....	185
7.5	Preparing the caravan for periods of non-use.....	186
<b>8</b>	<b>Maintenance and inspection .....</b>	<b>188</b>
8.1	Maintenance schedule .....	189
8.2	Inspection schedule .....	190
8.3	Wheels and tyres.....	191
8.3.1	Changing wheels .....	195
8.3.2	Tyre pressure table .....	199

---



## Introduction

8.4	ALDE heating maintenance overview .....	202
<b>9</b>	<b>Malfunctions.....</b>	<b>204</b>
9.1	Caravan body .....	204
9.2	Electrical system.....	205
9.2.1	Malfunctions in standard equipment .....	205
9.2.2	Faults of the stand-alone package (optional).....	206
9.2.3	Changing light bulbs.....	207
9.2.4	Changing the smoke detector battery .....	209
9.3	Gas supply.....	210
9.4	Hob .....	210
9.5	Heater and hot water .....	211
9.5.1	Malfunctions, TRUMA heater .....	211
9.5.2	Malfunctions, ALDE heater .....	212
9.6	Refrigerator.....	213
9.7	Fresh water and waste water system.....	214
<b>10</b>	<b>Tightness guarantee.....</b>	<b>215</b>
10.1	Guarantee certificate .....	215
10.2	Guarantee conditions and terms .....	215
10.3	Inspection schedule and inspection certificates .....	219
10.3.1	Vehicle data.....	219
10.3.2	Leak test after 12 months.....	220
10.3.3	Leak test after 24 months.....	222
10.3.4	Leak test after 36 months.....	224
10.3.5	Leak test after 48 months.....	226
10.3.6	Leak test after 60 months.....	228
10.3.7	Leak test after 72 months.....	230
10.3.8	Leak test after 84 months.....	232
10.3.9	Leak test after 96 months.....	234
10.3.10	Leak test after 108 months.....	236
<b>11</b>	<b>Index.....</b>	<b>238</b>

---

# 1 Introduction

**Before the first trip**

Your dealer will provide extensive instruction in all important functions when your vehicle is transferred to you so that you can properly operate and use your vehicle at any time.

In addition, this operating manual provides important information for using the vehicle and equipment. Carefully read this operating manual prior to using your caravan for the first time. Always comply with the instructions and safety instructions contained in this operating manual!

Strictly comply with the instructions in the accompanying operating manuals provided by the manufacturers of the built-in devices!

**In an emergency situation: Help...!**

If there are questions about operation, care, maintenance or repair, you can contact your nearest authorised dealer with confidence. Contact data is available in the dealer directory provided.

The dealers know your vehicle and are familiar with our latest innovations and they can provide prompt and expert assistance.

## Introduction

---

### 1.1 Technical documentation

The following vehicle documents are in the document case:

#### Manufacturer documentation

- Operating manual with inspection booklet for tightness guarantee
- Dealer directory

#### Supplemental documents

- Operating and installation instructions - refrigerator
- Guarantee and information documentation for heater and boiler
- Operating manual for the sanitary system
- Operating manual for the built-in liquefied petroleum gas (LPG) hob
- Test certificate for LPG systems with inspection tags
- Operating manual for the sanitary system

#### Topicality

We continuously work on further enhancing the performance characteristics of our caravans. Thus we reserve the right to make changes in shape, equipment and technology on the vehicle compared to the information provided in this operating manual. Descriptions are for the equipment known and installed at the time this manual went to press. Consequently, no claims against the manufacturer can be derived based on the content of this manual.

#### Retention

The operating manual and all accompanying documents concerning the vehicle and the installed devices are considered to be a fixed component of your vehicle. They must always be accessible to all users.

Keep this operating manual and associated documents on hand in the vehicle.

Transfer all documents to the next owner if the vehicle is sold. If loaning the vehicle to a third party provide the documents to the user.



## 1.2 Explanation of symbols used

### Safety and warning signs

Important instructions are especially marked by symbols and signal term. Comply exactly with the specified instructions to prevent personal injury, material damage and environmental damage.

#### **DANGER**



##### **Danger to life and/or severe damage to health**

This symbol combined with the "DANGER" signal term identifies an immediate hazard resulting in death or severe (irreversible) injuries.

#### **WARNING**



##### **Severe damage to health**

This symbol combined with the "WARNING" signal term identifies an imminent hazard potentially resulting in death or severe (irreversible) injuries.

#### **CAUTION**



##### **Damage to health**

This symbol combined with the "CAUTION" signal term identifies a hazard potentially resulting in slight (reversible) injuries.

#### **CAUTION**



##### **Damage to property**

This symbol combined with the "ATTENTION" signal term identifies a situation that may cause to damages to the product or objects in its vicinity.

## Introduction

---

### Tips and recommendations

#### NOTICE



*This symbol combined with the "NOTE" signal term identifies useful tips and recommendations for the efficient handling of the vehicle and its equipment.*

---

### Environmental protection

#### NOTICE



*This symbol combined with the "NOTE" signal term identifies important information regarding an environmentally conscious behaviour.*

---

### Directions

The "right", "left", "front", and "rear" directions always refer to the view in driving direction.

Dimensions and weights are rounded ("approximate" information).

Only a selection of special options ("optional") is listed. Always refer to the supplemental documents.

### Terms

#### **Caravan, vehicle**

Refers to the entire vehicle from the draw-bar to the rear lights, including chassis and caravan body.

#### **Caravan body**

Refers to the superstructure mounted on the chassis, including all systems and furnishings.

---

## 1.3 Vehicle registration

### Obligation to register

Pursuant to applicable national regulations, your vehicle must be registered with the relevant authority. Registration is issued by the vehicle licensing organization of your local government.

### Required documents

For registration you require:

- Registration certificate part I (vehicle registration certificate)
- Registration certificate part II (vehicle title document)
- COC document (European certificate of conformity)
- Insurance verification
- Verification of inspection (MOT certificate)
- ID card or passport
- Registration authority (if registered by a third party)
- Registration application if required

The registration certificate part II also serves as the holder's verification of ownership. Do not keep it in the vehicle!

The vehicle documents (registration certificate part I, insurance slip and MOT certificate) are considered to be the proof of authorisation for the use of the vehicle and must be carried during its use. Never store any vehicle documents in or at the vehicle!

### Vehicle license

Holders are provided at the rear for attachment of the license plate.

Note that in some countries, in addition to the country code shown on the license plate, a separate nationality tag is also prescribed.

## 1.4 Keys

When you pick up your vehicle, you are given three keys:

- Entry door to the caravan body
- Gas locker lid
- Intake port for the fresh water tank
- Sanitary system compartment
- Additional service hatch(es) (if present)



## Safety

---

## 2 Safety

This section lists all the important safety aspects for optimal protection of persons in the vehicle, and for safe and trouble-free use of the furnishings.

Moreover, the following sections include additional safety instructions for avoiding imminent dangers when using devices and equipment.

Always comply with the handling instructions specified and keep the pictograms, signs, and texts that are affixed to the built-in equipment in a legible condition.

### 2.1 Intended use

The caravan is designed exclusively for private habitation purposes and transport of travel luggage, and it can be used in public traffic in accordance with the provisions of the German Road Traffic Act and the German Road Traffic Registration Act.

The caravan must not be used for commercial transport of persons and/or goods.

Transporting unsecured loads and/or packed goods that are not used as travel luggage is not permitted.

Passengers are not allowed to be in the caravan when the vehicle is in motion. Every passenger must be seated in the towing vehicle with seat belts fastened during the trip.

The gross vehicle weight rating and the gross axle weight rating per axle should not be exceeded.

Any use of the caravan other than that described herein is prohibited and is considered to be improper use.

---

## 2.2 Responsibility of the vehicle owner

The vehicle has been designed and built in accordance with state of the art and in accordance with recognised safety-related rules.

Nevertheless if the instructions in the operating manual are not followed serious personal injury, significant material damage to or on the vehicle or environmental damage can occur.

Consequently the vehicle owner is obligated:

- To always keep the vehicle in technically faultless and road-safe condition.
- To exactly follow the instructions in the operating manual, and to ensure that all passengers comply with the instructions contained in the operating manual.
- To comply with the specified service intervals and to ensure that the legally prescribed tests and inspections are executed.
- To have the gas supply regularly inspected by an authorised service operation pursuant to applicable regulations.
- Not to make any unauthorised modifications to the vehicle or to the caravan body.
- To have technical problems that may adversely affect the safety of people and/or public road transport to be remedied immediately by specialist personnel.
- To always act in an environmentally responsible manner.
- To stay informed of current regulations and laws that can contain additional obligations.

## Safety

---

### 2.3 General requirements

For your own safety and the safety of your passengers always comply with the following instructions:

- People must travel in the towing vehicle, and never in the caravan body.
- Travel with the caravan only when it is technically sound and fully roadworthy.
  - Prior to every trip, ensure the technically sound condition of the vehicle.
  - Always comply with the operating instructions and traffic regulations.
- Always secure the vehicle when parking and leaving.
  - Engage the parking brake.
  - Lock all doors, hatches and windows.
- Always ensure adequate ventilation of the vehicle.
  - Always ensure clear air flow through the forced ventilation openings.
  - Thoroughly ventilate the living area when cooking or heating.
- Exercise caution when using doors and hatches. There is danger of crushing injuries.
- Pay attention to passage heights when entering and exiting, and performing cleaning and maintenance work. There is danger of crushing and impact injuries.
- Always be prepared to respond to accidents.

## 2.4 Fire safety

### Avoid fire and fire propagation!

- Always keep the smoke alarm, located in the ceiling of the caravan body, in functional condition.
  - Prior to using the vehicle for the first time, remove the protective foil from the block battery in the smoke alarm and connect the block battery to activate the smoke alarm.
  - Do not hook things into the openings on the smoke alarm housing, or cover the openings on the housing.
  - Replace the battery installed in the smoke alarm on a regular basis.
  - Replace the installed smoke alarm with a new smoke alarm every 10 years at the latest.
- Always carry an approved and tested dry-powder fire extinguisher (at least 1 kg) in the vehicle (not included in the scope of delivery).
- Always keep fire extinguisher in reach and have it tested regularly. Be aware of the test date.

### Avoid fire hazards!

- Never leave children alone in the vehicle.
- Keep flammable materials away from the heater and hob.
- Never use portable heating and cooking devices.
- Never cover electrical components that can develop heat during operation (e.g. charger, electric block, lights).
- Never modify the electrical equipment or to the liquid petroleum gas (LPG) system. Have all repairs performed by qualified personnel.

### Act appropriately if there is a fire!

If the smoke alarm trips or if you detect signs of a fire in the vehicle:

- Evacuate vehicle passengers without delay. If necessary provide first-aid.
- Switch off the power supply and disconnect it from the mains.
- Close the gas bottle valves.
- Secure the danger zone around the vehicle.
- Sound the alarm and call the fire department.
- Fight the fire, if this is possible without danger.

## Safety

---

### 2.5 Traffic safety

Driving in public traffic always demands special caution and attentiveness. Always comply with locally applicable traffic regulations, the operating guidelines for the vehicle and the following instructions!

#### 2.5.1 Vehicle

##### Dimensions and weight

Caravan and towing vehicle together comprise a rig with large dimensions and heavy weight. The driving and braking behaviour of the rig differ significantly from that of a single vehicle.

Inappropriate behaviour in road traffic - particularly by inexperienced rig drivers - can cause accidents resulting in serious or fatal injury.

Always adjust your manner of driving and comply with the following:

- Do not exceed the permissible gross vehicle weight and permissible axle load when loading the vehicle (→ nameplate)
- Compared to your car, the rig has a longer braking distance.
- If the automatic vehicle stabilization device - if present - responds, stay calm and slow down.
- Prior to driving into parking facilities, underpasses, bridges, tunnels, or vehicle decks of ferries, note the passage dimensions as well as height and width information.
- Comply with local driving restrictions or special driving instructions for caravans.
- Due to the load or attachment of accessories, dimensions, weight and driving behaviour of the caravan can change.
- When driving with the caravan attached, carry wheel chocks and use them when parking on inclines and slopes.

#### NOTE



*Dimensions, weight and permissible load are specified in the motor vehicle registration certificate part I.*

---



**Rig operation**

Risk of injury for people in the coupling area when the caravan is coupled.

Always ensure that:

- The towing vehicle has a functionally safe trailer pulling device and electrical connector coupling.
- The caravan is in an operationally safe condition, has a valid license, and is designed for the towing vehicle.. Do not exceed the permissible trailer load and maximum draw-bar load (→ registration certificate part I, operating manuals for the towing vehicle and the towing device).
- Do not couple or uncouple caravan if the overrun brake is activated.
- For couplings with removable towing ball ensure that the towing ball is properly fastened (→ operating manual provided with the towing device).
- Always proceed with caution when coupling or uncoupling the caravan.
- Ensure that a helper standing away from the towing vehicle assists the driver of the towing vehicle in approaching the caravan coupling.
- Ensure that no one is in the caravan and that no one is in the space between towing vehicle and caravan.
- Enter the danger zone between the towing vehicle and caravan only when the towing vehicle and caravan are at standstill and are both secured with parking brakes.
- Immediately after coupling always check the vehicle lighting equipment and brakes on the caravan for correct function.

## Safety

---

### Wheels and tyres

Worn tyres and incorrect tyre pressures adversely affect the driving and braking behaviour of the vehicle and can cause accidents.

Always ensure that:

- Rims and tyres must be approved for the vehicle (→ motor vehicle registration certificate part I).
- Regularly (during every refuelling stop, for example) check the proper condition and correct tyre pressure of the vehicle (→ Section "Tyre pressure table")
- Immediately replace worn tyres.
- For the first trip, after every wheel fitting, and after every wheel change, re-tighten the lug nuts after 50 km (30 miles).
- During longer trips, check the lug nuts for firm seat at regular intervals.
- Tyres must not be older than six years. The same applies for spare tyres - even if they have not been used.
- Use summer tyres or snow tyres in accordance with the outdoor temperatures in the country of travel.
- Depending on the tyres, comply with the specified tread regulations.
- Prior to a longer parking period, offload the tyres (e.g. jack up the vehicle, dismount the wheels, apply a preserving agent to the tyres and store them horizontally or on a wheel tree in a dry and frost-free location).

### Brakes

Defects in the braking system can cause serious accidents with fatal consequences.

Always ensure that:

- Prior to each trip check brakes for functional safety, uniform response, and directional stability. Have any defects repaired immediately by an authorised specialised workshop.
- Never make unauthorised changes to braking system components..
- Always firmly engage the parking brake when parking the vehicle.
- After a longer period of non-use ( $\geq 10$  months), have the braking system checked by an authorised workshop.
- When travelling with a loaded caravan, on slippery roads and on routes with gradients, always drive with utmost caution and bear in mind that driving stability and braking capacity of the rig are significantly impaired.

---

**Vehicle equipment****Mandatory equipment**

- 2 Wheel chocks

Depending on the local regulations in the country of initial registration, additional equipment may be pre-installed in the vehicle. For example, vehicles for initial registration in Germany contain:

- 1 Entry step
- 1 Gas pressure regulator, 30 mbar

**Recommended optional equipment**

- 2 Gas bottles, filled (11 kg or 5 kg)
- 1 Water canister with spout attachment or watering can
- CEE connector cable for external 230 V connection
- Adapter set for external power supply
- Cable drum (25 m)
- Fire extinguisher (minimum 1 kg content)

## Safety

### 2.5.2 Load

Excessive load and improper arrangement of the load adversely affect the driving characteristics and braking behaviour of the vehicle and can cause accidents.

Always ensure that you:

- Do not exceed the gross vehicle weight rating (→ motor vehicle registration certificate part I).
- Accessories and/or special equipment options reduce the possible load.
- Never exceed the maximum permissible axle loads (→ nameplate).
- Always evenly distribute the load in the entire vehicle. Avoid placing the load on one side.
- Never place heavy objects in the cabinets or compartments so that they may suddenly shift forward when braking, performing an emergency stop, or if there is collision in the direction of travel..
- Arrange the load so that its centre of gravity is as close as possible to the floor of the vehicle. Heavy and bulky objects should be placed beneath other items.
- Secure loose and movable objects, such as luggage, adjustable tables and adjustable beds against shifting.
- Prior to starting the trip, close cabinets and hatches and lock in place. Lock refrigerator door, sliding doors, and shower doors.
- When driving at night adjust the headlight levelling control to offset the load effect.

#### NOTE



*Information on calculating the possible load and proper arrangement of the load → Section "Loading the vehicle".*

#### ATTENTION



##### **Vehicle damage due to excessive roof load!**

The vehicle roof is not designed for heavy roof load and may collapse.

- Do not climb, step or walk on the roof; do not overload.
- Remove snow and ice from the vehicle's roof if parked outdoors during winter.

---

### 2.5.3 Driving

#### Before the trip

Unsecured load, a vehicle in a condition that is not ready to drive and/or technical defects can cause accidents with severe or fatal injuries.

Before starting your trip, always perform the following tasks:

- Remove any branches, twigs, leaves, snow or ice from the vehicle roof.
- Before starting your trip, ensure that the entry step is retracted.
- Check the functioning of signalling and lighting equipment.
- Ensure faultless functioning of brakes and steering gear.
- Check rims and tyre tread for proper condition. Ensure that the tyres are inflated to the proper pressure.
- Securely stow luggage and loose objects. Also ensure that the load is uniformly distributed in the vehicle.
- Close and secure all inner and outer doors, service hatches, windows and skylights.
- Close and secure the pop-up top, if available.
- In the living area, close and secure cabinets, refrigerator doors and cover plates for the hob and sink.
- Lock adjustable tables and beds.
- If available, push the TV drawer back and secure. Close the hatch of the TV compartment or secure the TV drawer so that it cannot twist.
- Switch the refrigerator to internal 12 V power supply.
- Close the quick-action valves and the gas bottle valve.
- Remove the wheel chocks and retract the vehicle support elements.



## Safety

---

### On the road

Failure to comply with local traffic regulations can cause accidents with serious or fatal injuries.

When driving the towing vehicle:

- Always comply with local traffic regulations.
- Always adjust your driving to current road and traffic conditions and the total weight and dimensions of your rig.
- Comply with driving restrictions for caravans.
- Always ensure that your rig does not exceed passage dimensions such as heights and widths when entering parking facilities, underpasses, bridges, tunnels or the vehicle decks of ferries.
- Never open door locks during driving.
- Avoid sudden and abrupt braking.
- Drive slowly and carefully on roads with damaged surfaces.
- Avoid bottoming out on ramps (when entering a ferry, for example), uneven surfaces, or when driving in reverse.

### After the road trip

Unsecured vehicles can roll way and cause serious injury and material damage.

Always ensure the following when stopping and parking the caravan:

- Never stop or park the caravan on steep slopes, embankments or gradients.
- Firmly engage the parking brake first when parking and stopping the caravan. Then place the wheel chocks.
- On slight embankments, inclines, or slopes, place wheel chocks in front of and behind one or more wheels. Secure the wheels through the curved stop surface of the wheel chock.
- Do not use wheel chocks to compensate for uneven terrain or roads.
- Extend the supports when parking the caravan for some time.
- In winter conditions, free the vehicle of the snow and ice load. Do not exceed the permissible roof load of 75 kg.

---

## 2.6 Operational reliability

### 2.6.1 Gas supply

#### General

The gas supply system was installed, inspected and accepted according to DIN EN 1949 and a pressure and tightness was completed according to the German Association for Gas and Water DVGW worksheet G 607. Any modification of the gas supply system after delivery of the vehicle invalidates the enclosed gas test certificate and the inspection tag at your vehicle.

- In addition to the following instructions, always comply with the instructions provided for the built-in gas devices.
- Always carry the operating manuals for the gas devices in the vehicle with easy access for all parties.

Defective gas devices and supply lines may catch fire or explode and cause severe injuries. Escaping gas is a suffocation hazard.

Always ensure that:

#### Test obligation

- Have the gas supply inspected by an authorised specialist workshop at the latest every two years. This also applies for non-licensed vehicles. Comply with local regulations.
- Do not modify the gas supply without proper authorisation. Only an authorised workshop may repair and replace gas devices.
- Regularly check the functioning of the safety pilots. Safety pilots must close the gas supply within one minute after the gas flame is extinguished (audible click).
- Check the gas hose at the pressure regulator whenever the gas bottle is exchanged. The hose should not be porous or scored.  
If required, have the gas hose replaced by an authorised workshop.

## Safety

### Using the gas devices

- Use only tested and intact gas devices and gas bottles (11 kg or 5 kg bottles).
- Open the quick-action valve of a gas device only if the device is to be operated. Valves must be closed when the unit is not in use.
- Open the skylight before using the gas hob.
- Do not use the hob as a space heater.
- If you smell gas or notice high levels of gas consumption, defects or other irregularities, immediately:
  - Switch off all gas devices
  - Close the main shut-off valve on the gas bottles
  - Do not smoke and do not ignite any flames
  - Do not switch on any lights or other electrical devices
  - Open windows and doors, thoroughly ventilate the interior
- Do not use butane gas for winter operation as it is only capable of gasification to 0 °C. Propane gasifies to minus 42 °C.

### Gas bottles, pressure regulators and gas bottle locker

- Only connect gas bottles that are filled with propane or butane, or with a mixture of the two gases.
- Transport gas bottles only in the gas bottle locker.
- Always set up gas bottle locker vertically and strap them securely in place.
- Use only pressure regulators that are permanently set to 30 mbar output pressure.
- Always carefully connect pressure regulators as prescribed:
  - If there is a direct connection without gas pressure regulator set (optional), connect the pressure regulator directly on the gas bottle valve.
  - If you use a gas pressure regulator set (e.g. DuoComfort or SecuMotion, both optional) the pressure regulator must be mounted on the rigid permanent line. In this case, connect the gas bottle valve to the gas pressure regulator using an approved high-pressure gas hose.
- Tighten the pressure regulator or high-pressure gas hose only manually (left-handed thread!). Do not use tools.
- Gas bottle valves must be accessible at any time.
- Do not use gas bottle locker as a storage compartment.
- Never cover the forced ventilation at the gas bottle locker.
- Always secure the gas bottle locker against unauthorised access.



---

**Driving and parking**

- Prior to starting the trip, close the glass bottle valve and the quick-action valves of the gas devices.
- Do not operate any gas devices when refuelling, on ferries, in garages or parking facilities. Danger of explosion!
- Prior to extended stand times, close the glass bottle valve and the quick-action valves of the gas devices.
- After a longer period of non-use ( $\geq 10$  months), have an authorised workshop check the gas supply system for tightness and functioning before prior to first use.

## Safety

### 2.6.2 Electrical system

#### General

The vehicle is equipped with a power supply system for:

- a. Combined operation, that is, the 230 V input via CEE-outlet and use of 230 V consumers and 12 V operators, thanks to the 12 V converted installed in the caravan.
- b. 12 V operation via the towing vehicle when the the caravan is coupled and the 13-pole outlet at the towing vehicle is fully assigned.

#### NOTICE



*The poles 10 to 13 are frequently not assigned when the coupling system with outlet is installed at a later time.*

All external lights required for road traffic are controlled as with the towing vehicle.

Emergency lighting in the caravan is also ensured (exception with stand-alone package (optional)). providing the following 12 V consumers:

- Ceiling light
- Water pump
- Toilet lighting
- Electric toilet

During driving, the system also feeds the refrigerator, starts the towing vehicle's engine and operates the generator.

#### NOTICE



*Refrigerator operation is not possible if the 13-pole outlet is not fully assigned.*

#### NOTICE



*In towing vehicles meeting the EURO 6 standard, it can happen that the on-board computer shuts down the charging cable for the refrigerator to reduce fuel consumption.*

If a stand-alone package (optional) is installed, the towing vehicle does not provide 12 V supply for the interior. In this case, the supply battery in the caravan ensures the entire supply. The entire 12 V network in the interior is available when the 12 V main switch is actuated.

During driving, the refrigerator and the supply battery are supplied with the generator's current. If the engine of the towing vehicle is shut down, you can control the refrigerator only via gas or an external 230 V supply. The refrigerator is not supplied with 12 V via the supply battery during standstill.

### NOTICE



*Before travelling to foreign countries, obtain information about the plug and connector systems used at your destination. Adapters are available from specialised dealers.*

Touching live components can cause serious or fatal injury. Improper connection or defective electrical devices can cause fires.

Always ensure that:

#### External power connection

- Prior to connecting, ensure that the external power supply matches the specifications of the vehicle's electrical system.
- The external power supply must be protected with a residual current circuit breaker (FI switch, 30 mA).
- Use only connection conduits with the following properties:
  - Flexible CEE rubber-sheathed cable for outdoor use
  - Cross-section 3 x 2.5 mm<sup>2</sup> minimum
  - Plug connector and coupling should each have earthing contact
- The point of connection must be in less than 25 m distance.
- When using cable drums, completely unroll the power cable; this prevents the cable from overheating.
- Lay the cable so that it does not cause a stumbling hazard, mark the cable routing, if necessary.



## Safety

---

### Electrical system and devices

- Connect only tested and intact devices.
- Any device exhibiting defects, faults or external damages must be immediately disconnected from the vehicle system.
- Periodic testing by an electrician.
  - Annually for frequent use
  - Every three years for occasional use
  - Half-yearly activation of the RCD test button
- Any work on the system, repairs or replacement of electrical devices must be performed by an authorised workshop only.
- Prior to starting any work on the system, switch off all electrical consumers, such as lights, TV, radio and other devices; disconnect the external power supply and disconnect the supply battery (if present).
- Check the function of the integrated residual current circuit breaker in the fuse box at regular intervals.
- Never bridge, manipulate or repair any miniature circuit breaker or safety fuse.
- Replace defective fuses only after the cause of the fault has been identified and rectified.
- Replace defective fuses only with new original fuses with prescribed ampere rating.

### 2.6.3 Sanitary system

The caravan is factory-equipped with a fresh water tank and a toilet. A 25 l waste water tank on rollers (optional) is available as option.

#### WARNING



##### Health hazards due to chemicals!

Harmful chemical cleaning agents are required for toilet hygiene.

- Comply with the manufacturer's instruction on the packaging and use with caution.

#### ATTENTION



##### Damages after extended stand time or frost!

If the vehicle is not used in winter, the sanitary system may be damaged due to frost.

Extended stand times can cause algae growth in the sanitary system.

- Ensure that the overflow valve is free from contamination and ice formation.
- In the event of frost or extended stand time, completely empty the water tanks, containers, hoses, and conduits. Dry-run the pump for approximately five minutes to avoid frost damage caused by residual water in the pump.

#### NOTE



*Waste water, solid waste and chemical substances can cause significant environmental damage.*

- *Drain the waste water and solid waste tank only at designated disposal points.*

## Safety

---

### Hygiene

#### WARNING



#### Health hazard due to germs and bacteria in the drinking water!

Contaminated drinking water can cause serious infections.

- Prior to the first use, disinfect the fresh water system of the vehicle, and thoroughly flush with drinking water.
  - Transfer water only from supply systems with proven drinking water quality.
  - Filling hose and container must be approved for drinking water.
- 

- Fresh water becomes undrinkable very quickly! Prior to every start-up, thoroughly flush the fresh water tank, the lines and water cocks with plenty of tap water.
- Regularly sterilise the fresh water tank. Special sterilizing agents are available from specialised dealers. Comply with the manufacturer's instructions specified on the packaging of the sterilising agent, and with local application guidelines and fresh water regulations.
- Wear hygiene gloves (from specialist suppliers) when handling the waste water tank and the solid waste container; and thoroughly cleanse any exposed skin.
- Drain waste water and solid waste tanks only at designated disposal points, never in nature. If needed, information about the nearest disposal station can be obtained from the municipal administration.

---

## 2.7 Environmental protection

### Cleanliness

Real camping enthusiasts always leave their stopover clean and tidy. Always behave in such a manner that you will be welcomed back!

Many towns and communities offer designated and well-equipped compounds with all necessary supply and disposal facilities for caravans.

### Waste

Separate glass, plastic, paper, and kitchen waste, and dispose of waste in the containers provided for the various recyclable materials. If necessary, contact municipal authorities for information on disposal possibilities.

Please note: Do not dispose of household waste in the waste containers provided at rest stops and parking facilities!

### Waste water

Do not dispose of waste water in street drains or in free nature!

Always empty waste water and solid waste containers in designated disposal points in camping grounds or specifically equipped communal compounds.

### Toilet chemistry

Use only environment-friendly and biodegradable WC chemicals.

## Technical data

### 3 Technical data

#### General

This section contains a selection of important technical data. A complete overview of all technical specifications is provided in the price list and the enclosed operating manuals of the devices installed.

#### 3.1 Caravan body

Specification	Value	Unit
Filling volume, fresh water tank	44	l
Intake volume, waste water tank <sup>1)</sup>	25	l
Capacity, supply battery <sup>1)</sup> , minimum	60	Ah

<sup>1)</sup> Special option (See also "Special options" in → chapter "Overview").

#### 3.2 Built-in devices

The technical data of the built-in devices are provided in the respective operating manuals. These are in the document case. Depending on the selected fittings, they include the documentation for:

- Kitchen appliances (e.g. refrigerator, oven, grill)
- Heater, boiler, sanitary system
- Electric control, storage battery, charger
- Special options (e.g. grill)



### 3.3 Loads

#### ATTENTION



##### Vehicle damage due to excessive roof load!

The vehicle roof is not designed for heavy roof load and may collapse.

- Do not climb, step or walk on the roof; do not overload.
- Remove snow and ice from the vehicle's roof if parked outdoors during winter.

Depending on the selected equipment your caravan is equipped with different load units.


The maximum permissible load of these components is:

Load unit	Max. weight
Gas locker	50 kg
Bunk beds	80 kg
Folding beds	50 kg

### 3.4 Nameplate

The nameplate is affixed in the front storage compartment. The chassis number has been also stamped into the right draw-bar strut below the superstructure.

The nameplate must be neither modified nor removed. It must always be in legible condition.



Bürstner GmbH	
WBU4911TLG1281117	
	1.500 kg
	100 kg
1-	1.500 kg
2-	kg
3-	kg

Fig. 1: Nameplate

The nameplate provides the following information:

- Manufacturer
- ETG No.
- BÜRSTNER Chassis No.
- Permissible total weight
- Permissible axle load, axle 1
- Permissible axle load, axle 2
- Permissible bearing load
- Type designation



## Driving

# 4 Driving

## Fundamentals

When driving your caravan, always comply with the regional traffic regulations and laws. Carefully plan your route in advance. Drive carefully and in an environmentally responsible manner.

Bear in mind that your rig has dimensions and weight that are significantly greater than those of a car. Always remember that towing a caravan is subject to additional regulations.

towing a caravan is described in the operating manuals of many towing vehicles. Always keep this operating manual on board for easy access for anyone driving the vehicle. Comply with the information and the handling instructions provided in the manual.

In addition, always comply with the instructions specified in the "Safety" section of this manual.

## 4.1 Loading the vehicle

### 4.1.1 Terminology and specifications

<b>Technically permissible total weight</b>	Total vehicle weight that must not be exceeded. Provided in → Registration certificate Part II
<b>Weight in ready-to-drive status</b>	Unloaded weight including weight of the basic equipment required for proper use and to drive the vehicle, (including fresh water, gas, wheel chocks, cable drum, etc., without optional equipment). Provided in → Registration certificate Part II
<b>Load</b>	Mass of all objects carried including luggage, personal items and properties, and the optional equipment.
<b>Optional equipment</b>	Accessories offered by the manufacturer beyond the standard equipment and that may be either ordered with the vehicle or installed at a later time, such as satellite dish, oven, air-conditioning.

**Personal items**

Weight of all items carried in the caravan not contained in the aforementioned list, such as foodstuff, crockery, radio, TV, clothing, bedding, toys, books, toiletry articles, bicycles, boats, surfboard, sport equipment. These objects must be taken into account in any event, regardless of where they are stored.

For personal items, you may use a ballpark figure of 20 kg per person plus 10 kg per metre of vehicle length, if the actual individual requirement does not significantly differ from this value.

**4.1.2 Calculating the maximum load**
**Sample calculation**

Specification	Value
Technically permissible total weight	1600 kg
of which the mass in ready-to-drive status (including basic equipment such as gas, fresh water)	- 1350 kg
<b>The maximum load is</b>	<b>= 250 kg</b>
Personal items (for four persons with 20 kg each)	+ 80 kg
General equipment (10 kg per metre caravan body)	+ 50 kg
Special options	+ 35 kg
<b>The general load is</b>	<b>= 165 kg</b>
<b>Remaining possible residual load</b>	<b>= 85 kg</b>

## Driving

### 4.1.3 Loading and stowing luggage

Prior to loading the vehicle, check the location and arrangement of storage spaces in the vehicle (→ section "Storage spaces"). Follow the instructions in the "Safety" section!

#### Distribute the luggage properly.

1. Ensure that all weights are correctly taken into account.

#### NOTE



*Do not forget to add all books, leisure and sport equipment, foodstuff, etc.*

2. Evenly distribute the luggage items according to their individual weights:
  - Taking the maximum axle loads into account, place heavy items (such as tent hardware and canned goods):
    - in lower placed storage lockers with doors not opening in driving direction, or
    - securely attached to the floor in the living area to prevent movement.
  - Store light objects (garments) in the built-in wardrobe and the hinged compartments.

#### 4.1.4 Reviewing the check list

Before the trip, review all required travel documents and equipment using the following list.

Amend this list to meet your specific requirements.

##### Checks

- All vehicle documents are on board (operating manuals for caravan, towing vehicle, installed equipment and devices)
- Motor vehicle registration certificate, part I carried by the driver
- Certificate of insurance on board
- Travel documents for all passengers on board
- Currencies of transit countries and destinations on board
- Trip route, road maps, country information on board
- Luggage completely and properly stored
- Veterinary certificates required for transit countries and destinations, for pets on board.
- Road regulations for caravans in the transit countries and destinations are known

## Driving

### 4.2 Checking the vehicle

#### WARNING



#### Danger of accident and injury due to vehicle defects!

Defects on and in the vehicle can cause accidents with severe to fatal injuries as the consequence.

- Prior to every start, check the vehicle and the load for condition and driving safety.

Copy (and amend, if necessary) the following list to meet your needs and tick each line when the respective list item has been completed, before starting your trip.

Tasks and checks that must be executed immediately before starting	✓
1. Free vehicle, particularly the roof, from deposits such as branches, twigs, leaves, snow, and ice.	
2. Check the functioning of signalling and lighting equipment.	
3. Ensure faultless functioning of brakes and steering gear.	
4. Check rims and tyre tread for proper condition. Ensure that the tyres are inflated to the proper pressure.	
5. Check load for proper distribution and fastening.	
6. Close and secure all inner and outer doors, service hatches, windows and skylights.	
7. Close and secure the pop-up top, if available.	
8. Close and secure cabinets, refrigerator doors and cover plates for hob and sink.	
9. Lock adjustable tables and beds.	
10. Push in and secure TV stand. Close the hatch or secure the stand against twisting.	
11. Switch the refrigerator to internal 12 V power supply.	
12. Disconnect the external 230 V power supply with CEE plug.	
13. Close gas bottle valves and quick-action valves.	
14. Remove the wheel chocks and retract the vehicle supports.	

## 4.3 Coupling the caravan and the towing vehicle

### 4.3.1 Prerequisites for coupling

#### Safety

#### WARNING



#### Risk of injury when moving or standing between caravan and towing vehicle!

If the towing vehicle is moved backward, persons positioned between the vehicles can be caught between the vehicles and severely injured.

- Never remain between the vehicles when the towing vehicle is reversed.
- Provide the driver with directions and signals during reversing. Be aware of persons in the vicinity or approaching the vehicles.
- Wait with establishing the connection between the two vehicles until the towing vehicles has closely approached the coupling system of the caravan, shut down the engine, and engaged the parking brake.
- You may optionally push the caravan toward the towing vehicle.

#### ATTENTION



#### Damage to property when permissible values are exceeded

The towing vehicle and/or the caravan may be damaged when permissible values are exceeded during coupling.

When coupling, ensure that the following values are not exceeded:

- Permissible axle load
- Permissible support load
- Permissible rear axle load of the towing vehicle
- Permissible total weight of towing vehicle plus caravan

Refer to the documentation of the towing vehicles and the caravan nameplate for the permissible values.



## Driving

---

The design of the coupling system depends on the caravan model and the selected equipment.

Additional information on handling the caravan coupling is supplied in the accompanying operating manual provided by the manufacturer.

- Before using the caravan coupling for the first time, note the instructions in the manufacturer's operating manual, particularly the safety instructions!

### Prerequisites

Coupling prerequisites:

- The support wheel must be lowered to the ground and secured so that it bears the draw-bar load.
- The parking brake of the caravan is engaged.



### 4.3.2 12 V power supply in towing operation




Fig. 2: 13-pole plug

#### 13-pole plug

The 12 V-power supply of the caravan in coupled condition is ensured only when the towing vehicle and the caravan are connected via a 13-pole plug.

Contact No.	Power circuit	Wire Ø in mm / colour
1 / L	Indicator left	1.5 / yellow
2 / 54 g	Rear fog lamp	1.5 / blue
3 / 31	Earth (for power circuit contacts 1-8)	1.5 / white
4 / R	Indicator right	1.5 / green
5 / 58 R	Right rear lamp, outline lamp, side light and license plate lamp	1.5 / brown
6 / 54	Brake lights	1.5 / red
7 / 58 L	Left rear lamp, outline lamp, side light and license plate lamp	1.5 / black
8	Reversing light	1.5 / pink
9	Power supply (steady plus)	2.5 / orange
10	Charge cable plus (refrigerator)	2.5 / grey
11	Earth (refrigerator)	2.5 / white/black
12	Coding for coupled caravan (free)	1.5 / white/blue
13	Earth (for power circuit contact 9)	2.5 / white/red

#### Information

#### NOTICE



*It must be ensured that the towing vehicle makes available sufficient power for the safe operation of 12 V consumers in caravans when driving. With some vehicles it is possible that the battery management of the towing vehicle switches off consumers to protect the battery. Contact your vehicle manufacturer for more information.*

## Driving

### 4.3.3 Coupling with "AL-KO" safety coupling



Fig. 3: Basic position




Fig. 4: Maximum swivel range of the ball coupling on the coupling ball of the towing vehicle.



Fig. 5: Tow-ball coupling open

- 1 Coupling handle, position open
- 2 Stabilising lever, open

#### WARNING



**Danger of accident and injury if the caravan becomes detached!**

If improperly coupled, the caravan can become detached from the towing vehicle and cause serious accidents with fatal consequences.

- The coupling ball on the towing vehicle must be free of grease and other residue.
- Immediately replace any friction linings that are fouled with grease; do not attempt to clean them.
- Do not exceed the maximum permissible swivel range of the tow bar coupling.
- After each coupling action, check the coupling for correct seat and solid, secure connection of the rig vehicles.

- Maximum permissible vertical swivel range:  $\pm 25^\circ$
- Maximum permissible horizontal swivel range:  $\pm 20^\circ$

#### Coupling process

1. Release the parking brake on the caravan and position the caravan with the tow-bar coupling precisely above the trailer ball of the towing vehicle.
2. Engage the parking brake.
3. Pull the coupling handle (1) upward.
4. Slowly crank down the support wheel, while placing the opened tow-ball coupling on the towing coupling of the towing vehicle.

#### NOTE



Due to the draw-bar load, the tow ball coupling engages automatically and audibly and the coupling handle returns to the initial position.

5. Use your hands to firmly press the coupling handle (1) downward.
6. Check the coupling for firm seating.  
The tow-ball coupling is correctly coupled if the green edge of the safety display (→ Fig. 6) is visible.
7. Place the brake away cable of the towing vehicle around the coupling of the towing vehicle and hook the cable's spring hook onto the cable itself.



Fig. 6: Safety display


8. Insert the electrical connector plug of the caravan into the towing outlet on the towing vehicle.
9. Check the lights (rear light, brake lights, blinkers, reverse light, clearance lights) on the caravan.
10. Release the parking brake before starting the trip.



Fig. 7: Wear indicator

**Wear indicator**

1. Couple the caravan to the towing vehicle.
2. Open the stabilising lever (1/2).
3. Close the stabilising lever until resistance is noticeable, (friction linings rest on the trailer ball of the towing vehicle, however, they are not yet tensioned.).


**Visible green mark:**

- Front and rear friction linings are okay.
- Coupling ball okay

**Green mark no longer visible:**

- Front and rear friction linings worn → Replace friction linings
- Coupling ball  $\varnothing < 49$  mm



Arrow position	Condition
Arrow below mark 1-green	New status
Arrow above mark 1-red	Left and right friction linings worn → Replace friction linings
Arrow at mark -2	AKS closed

## Driving

### 4.3.4 Uncoupling with "AL-KO" safety coupling

#### NOTE



When uncoupling the caravan, the overrun device must be relaxed and the bellows must be extended.



Fig. 8: "AL-KO" safety coupling

1. Engage the parking brake of the caravan.
2. Detach the contact breaking cable and remove from the towing vehicle.
3. Remove the electric connection plug from the towing vehicles and securely store in the plug receptacle in the caravan draw-bar to prevent moisture.
4. Lower the support wheel to the ground, secure and crank down until the caravan's draw-bar slightly lifts.
5. Pull up the stabilising lever (2) to the stop.
6. Pull the coupling handle (1) upward and hold.
7. Crank the support wheel further until the coupling bell fully lifts from the towing ball of the towing vehicle.
8. Reset coupling handle (1) and stabiliser lever (2) to their start positions.

### 4.3.5 "AL-KO" ATC stabiliser system (optional)



Fig. 9: ATC stabiliser system

The ATC stabiliser system by AL-KO continuously monitors the running behaviour of the caravans.

In driving conditions causing the caravan to swerve, the lateral acceleration, sensors of the ATC control electronic capture even minuscule lateral movements. The system immediately slows the caravan without driver intervention. Some few seconds of braking are sufficient to return the rig into a safe driving condition.

- Refer to the attached operating manual of the manufacturer.

---

## 4.4 Travelling and parking

### Travelling

#### WARNING



#### Risk of injury and accident due to incorrect behaviour!

The rig comprised of towing vehicle and caravan has large dimensions and a great weight. Incorrect behaviour can result in accidents with serious or fatal injury as the consequences.

- Remember changed driving properties, longer braking distance, higher total weight, and larger dimensions when driving the rig.
  - Always adjust your driving style to the current road and weather conditions.
  - Comply with local traffic regulations.
  - Comply with specific regulations for rigs in transit countries and destinations.
- 

### Parking

#### WARNING



#### Risk of injury due to an unsecured vehicle!

Unsecured vehicles can roll away and cause serious injury or material damage.

- Never stop or park the caravan on steep slopes, embankments or gradients.
  - When stopping or parking the vehicle, always secure with wheel chocks against uncontrolled rolling away.
-

## Driving

---

1. Turn off the engine of the towing vehicle.
2. Put the vehicle in gear. For a towing vehicle with automatic transmission, place the selection lever in park position "P".
3. Firmly engage the parking brake of the towing vehicle.

If the caravan is parked without towing vehicle:

1. Firmly engage the parking brake of the caravan.
2. On slight inclines, slopes, or embankments, place wheel chocks in front of and behind one or more wheels of the caravan.

### NOTE



*Do not use wheel chocks to compensate for uneven terrain.*

---

---

## 4.5 Parking the caravan at the destination

### 4.5.1 Parking the caravan

#### Selecting a parking place

For optimal and trouble-free use of all technical vehicle equipment, select the parking place in accordance with the following criteria:

- Stable, horizontal, level surface.
- Electrical mains connection in the immediate vicinity (maximum distance: 25 metres).
- Fresh water and waste water connections as well as approved disposal station in the immediate vicinity.
- Adequate parking space dimensions ensuring that all doors and maintenance hatches are accessible after parking the caravan.

#### Parking the caravan

1. Uncouple the caravan, push it to the parking space and align it in the desired position.
2. Firmly engage the parking brake.
3. Place wheel chocks, if necessary.

#### NOTE



*Do not use wheel chocks to compensate for uneven terrain.*

- 
4. Extend the corner support elements

## Driving

### 4.5.2 Extending and retracting the support elements

#### WARNING



#### Crushing hazard when extending or retracting the support elements!

Extending and retracting support elements can cause feet, hands, or other body parts to be crushed and injured.

- Do not position yourself in the swivel area of the supports.
- Do not tamper with support elements.

#### NOTE



*On soft, yielding surfaces, place large plates under the supporting elements before extending to prevent them from sinking into the ground.*

#### NOTE



*The supporting elements do not serve as vehicle jacks, rather they are used exclusively to stabilise the vehicle. When extending, load all supporting elements uniformly.*

*To compensate for inclines use special drive-on wedges that are commercially available!*



**Extending the prop**


Fig. 10: Hexagonal bolt (1) for socket wrench

1. Place the socket wrench from the gas bottle box on the hexagonal bolt (1) at the front right caravan corner.
2. Turn the socket wrench clockwise until the support element rests firmly on the ground.
3. Extend the support element on the left front side of the caravan in the same manner. Use the two front support elements to align the caravan horizontally and bring it into a stable position.
4. Extend the rear corner support elements. Align the vehicle as described for the forward support elements and bring the vehicle to a stable position.
5. Once all 4 support elements are correctly extended and the caravan is stabilised, return the socket wrench to its holder in the gas bottle box.

**Retracting the support element**
**WARNING**

**Danger of injury due to improperly retracted support elements!**

Support elements that are not properly retracted can cause accidents, severe injury and material damage. Therefore:

- Prior to starting each trip, ensure that all support elements are properly retracted.

1. Place the socket wrench from the gas locker in the hexagon of the threaded rod at the front right caravan corner.
2. Turn the socket wrench counter clockwise until the support element is completely retracted to the stop.
3. Repeat steps 1 and 2 with the other support elements.
4. Withdraw the socket wrench and store it in its holder in the gas locker.

## Overview

# 5 Overview

### General

This section provides an overview of the caravan body and its equipment. The arrangement and important control elements of the built-in devices are explained.

#### NOTE



*Some of the built-in items described here are only available on express special option, or as accessories. These equipment elements are only in your caravan body if they were specifically requested when the vehicle was ordered.*

Several equipment elements are presented as examples, or are presented in different model variants in the descriptions below. The variant actually installed the vehicle in these cases always depends on the model or price, and due to its design cannot always be replaced with a different variant. Claims to equip the vehicle with a specific variant cannot be derived from this operating manual.

#### ■ Special options

Special options (identified below by "(optional)") directly affect the design, manufacturing and price of a vehicle and, in most cases, they cannot be retrofitted or installed at a later time. Claims for special options that are not directly listed in the purchase contract cannot be derived from this operating manual.

#### ■ Accessories

Accessories are not components of the scope of delivery if they have not been specified in the vehicle purchase order and are not separately shown in the final price sheet for the vehicle.









Claims to accessories that were not agreed cannot be derived from this operating manual.

Accessory equipment can usually be retrofitted even at a later time, if requested by the customer.

A binding list of the factory-installed basic equipment in your vehicle is shown in the price list used when your vehicle was ordered.

**Explanation of symbols**

For the presentation of floor plan variants the following symbols are used in the drawings below:

Symbol	Meaning	Symbol	Meaning
	Sitting area		Round sitting area
	Cabinet		Wardrobe
	Single bed		Double bed
	Kitchen area		Bathroom

## 5.1 Caravan body

### General

This section introduces the caravan body and provides examples of the location and function of specific elements and built-in units.

#### 5.1.1 Keys

With your caravan you receive three copies of the same key. This key can open the following locks:

- Entrance door and intake port for drinking water
- Service and storage hatches on the outside of the caravan

## Overview

---

### 5.1.2 Entrance door



*Fig. 11: Entrance door without window (example)*

#### **Entrance door without window**

The entry to the living area is on the right side of the vehicle.

The entrance door can be locked from the outside with a safety lock that can also be locked and unlocked from the inside.

An awning light (optional) illuminates the entry area at night.



*Fig. 12: Entrance door with window (example)*

#### **Entrance door with window (optional)**

An entrance door with window and internal hinges can be ordered as special option.



Fig. 13: Closed but unsecured door lock

### Opening and closing the entrance door

To lock and secure the entrance door from inside:



Fig. 14: Lever in top position

1. Turn lever (1) to top position



Fig. 15: Door closed and secured

2. Rotate inner knob (2) upward until two pins (3) protrude to additionally secure the door.



Fig. 16: Door lock open

- To open the door, simply push the lever downward.

## Overview



Fig. 17: Door and hatch locks

Entrance door and large hatches can be locked in open condition. This prevents unintentional slamming of doors and hatches i.e. by the wind.

- To hold the door or hatch in place, carefully open the door until the stop and then press it lightly against the holder until the catch lock (1) engages in the receptacle (2).
- To release, pull the door or hatch out of the holder with a light jerk.

### 5.1.3 Door and hatch locks

Entrance door and service hatches are fitted with locks to prevent unauthorised access. All locks can be opened with the same caravan body key.

Locking door and hatches prevents unintended opening of the same during driving or in extraordinary situations, such as an accident.

#### ATTENTION



#### Property damage due to inserted keys!

Keys that are not removed can cause severe scratches in the outer shell of the caravan body. Keys can break off.

- Always remove the key immediately after opening or closing locks.

**Service compartment lock**

*Fig. 18: Service compartment lock*

The service locks can be operated with the entry door key. They are not operated via remote control.

**Opening the service compartment:**

- Use the key to unlock the lock and clockwise rotate the knob by 90°. At this position, the contact pressure abates but the service compartment cannot yet be opened.
- To open the service compartment, rotate the knob clockwise by another 90°.

**Closing the service compartment:**

You can re-engage the lock in opened conditions. After closing the hatch, you only need to counter-clockwise rotate the knob by 180° with some pressure until it latches.

**Door lock**

*Fig. 19: Door lock*

- To open the entry door, unlock the door lock with the key, reach into the recessed grip and pull the door to the outside.

## Overview

### Gas locker lock



Fig. 20: Gas locker lock

The front door key is also used to operate the gas locker lock.

#### Opening the gas locker:

- After closing the lock:
- After closing, the handle must be turned through 90 degrees to the right to unlock.
- Press the gas bottle locker lid up.

#### Closing the gas locker:

- Press the gas bottle locker lid down.
- To lock the gas bottle locker lid, press down and lock with the handle.

### Lock on the fresh water intake port



Fig. 21: Fresh water intake port

The lock for the fresh water fill intake port is located directly in the closure cap.

- To open, or close, hold the closure cap firmly and turn the lock 180°.



## 5.1.4 Window

### Hinged window



Fig. 22: Framed hinged window

The living and sleeping area features large hinged windows designed to provide superior ventilation.

- To open, turn the sash fastener fitted at the lower frame and slightly push the window to the outside until the support arms latch. Three positions can be selected for the width of the opening.
- To close the window, swing fully to the outside and then slowly pull downward. Finally, return the sash fastener to the locked position.

### ATTENTION



#### Open windows can cause material damage!

Projecting windows can hit signs, light poles, and other elements during driving, and cause severe damage to the vehicle and other property.

- Never drive with opened hinged windows!

### Kitchen window



Fig. 23: Sliding window (optional)

Depending on the selected model and fittings, the kitchen area features a sliding window (optional) or a hinged window that must be opened during cooking to ventilate the interior.

#### Opening and closing the sliding window

- To open, press the inner slide handle to the side and hold; at the same time slide the moveable part of the window to the side.
- When closing, ensure that the slide handle again engages.

## Overview

### Combination blind



Fig. 24: Combination blind

The hinged windows are fitted combination blinds consisting of a fly screen and a blackout blind. Both blind components are hung from the window top.

For both blinds:

- To close, use the handle to pull the fly screen fully downward and slightly push against the window until the lower strip latches.
- To open, push the handle downward and slightly pull toward yourself until the lower strip detaches. Due to the tension, the blind automatically rolls up – hold the handle during this action.

The blackout blind can be lowered in three different heights. It latches in one of three possible positions in the lateral guide rails.

### ATTENTION



#### Damage to the blinds if they fly up!

To avoid damage to the blind, ensure that the blind CANNOT fly up.


### NOTE



*Do not keep the blind closed during driving and over a longer period of time (several weeks).*

*Over time, the springs would suffer if the blinds are permanently lowered.*

### Re-tensioning the blinds



### Blind care

Use a screwdriver to re-tension the blind springs.

- Insert the screwdriver and turn once or twice clockwise.
- Check the tension and repeat the process, if required. Ensure that you don't over-tension the springs.

As a rule, never use aggressive cleaning agents (solvents or abrasives). Use a damp cloth and soapy water to clean the blinds and frame parts. Use a soft brush and/or damp cloth to clean the fly screen.

### 5.1.5 Air conditioning system (optional)



Fig. 25: Air conditioning system (optional)

As a special option, a special attachment air conditioner is available to regulate the room temperature of the interior.

In summer operation the air conditioner generates dehumidified cool air. In winter operation it generates supplemental warm air, without, however, replacing the heater of the vehicle.

The air conditioner is installed in the vehicle roof.

Operation, maintenance, and service of the air conditioner are described in detail in the corresponding operating manual.

### 5.1.6 Skylights

Different models of skylights are installed in the ceiling depending on the model and selected equipment. The skylights are opened and locked from inside.

The skylights have fly screens, blackout blinds, and forced ventilation slots.

Depending on the model, skylights can be opened upwards or placed in a diagonal open position.

#### ATTENTION



#### **Material damage due to open windows or skylights when driving!**

- Open windows or skylights can hit signs, light poles, and other elements and cause severe damage to the vehicle and other property.
- Never drive with opened windows or roof canopies!

## Overview

### Models

#### Model variants



*Fig. 26: Skylight (Heki 2)*



*Fig. 27: Skylight hood 400 x 400 mm*



*Fig. 28: Prop-up skylight*



*Fig. 29: Midi Heki / Mini Heki plus*

## 5.1.7 Pop-up roof (optional)

### Safety instructions

#### DANGER



##### Life-threatening danger due to lightning!

During a thunderstorm, any persons in the pop-up roof can suffer life-threatening injury.

- Never stay in the pop-up roof during thunderstorms.

#### WARNING



##### Danger of injury due to falling!

When sleeping, playing, or if they are in the pop-up roof unattended, small children can fall through the passage and suffer broken limbs and permanent bodily injury.

Persons with limited mobility can fall when climbing up and climbing down or can injure themselves in the hinged pop-up roof.

- The pop-up roof is not suited for unsupervised use by children under six years.
- Persons with limited mobility should avoid using the pop-up roof.

#### CAUTION



##### Health damages due to exhaust gases!

In adverse wind conditions, the heating system's exhaust gases may be drawn into the sleeping area.

- Close all tent windows when operating the heater.

#### ATTENTION



##### Risk of fire due to the ceiling light

The ceiling light may scorch the interior furnishings.

- Turn off ceiling light after every use.

## Overview



Fig. 30: Pop-up roof, opened

Upon request, a pop-up roof manufactured from fibre-glass reinforced plastics (GFRP) can be installed in the roof. In pop-up status, it offers two additional sleeping berths.

The pop-up roof features a large bed pad with slatted frame, a skylight, a fly-screened ventilation window with protective rain cover (lockable from the inside), two transparent sheet windows with black-out blind, one supplemental vent with closing mechanism, and a ceiling light with remote control.



Fig. 31: Pop-up roof, interior



Fig. 32: Vent window



Fig. 33: Passage

### ATTENTION



#### Material damage due to raised pop-up roof when driving!

- An open or unsecured pop-up roof can get caught on trees, signs, light poles, in entrances to parking garages, or other parts, it can tear off and cause severe damage to the vehicle and property owned by others.
  - Never drive with opened or unsecured pop-up roof!
  - Prior to driving, always check that the pop-up roof is properly folded and secured and latched against unintentional opening!

The pop-up roof can be easily opened by simply pushing the rod at the rope against the GFRP shell. It is then held in position by pneumatic springs. It can be quickly closed by pulling it down.

- Do not use the pull rope as a climbing or holding rope!

### NOTE



*Due pressure differences, the pneumatic springs may act with different force at different ambient temperatures.*

**Care tips****NOTE**

*Thoroughly vent the roof bellows several times during the season, to prevent stagnant moisture and musty odour.*

*Do not fold the pop-up roof in damp or wet condition immediately after rainfall, for example.*

*Prior to longer breaks in use, remove the bed pad from the pop-up roof to avoid stagnant moisture and mildew.*

**5.1.8 Awning fastening**

Fig. 34: Awning fastening

On the entry side of the caravan, on the outer edge, there is a circumferential profile strip (1) for fastening an awning.

The profile strip is widened somewhat on the rear of the vehicle.

- Start drawing the awning into the profile at this point.

## Overview

### 5.1.9 Multifunction light switch



Fig. 35: Multifunction switch (example)

Two multifunction switches are installed at convenient height in the entrance area. They control the various sources of light from inside and outside of the vehicle, permitting lighting the interior before entering the vehicle body.

### 5.1.10 Exhibition lighting system

The Caravan is equipped with the light function referred to as “Exhibition lighting”.

By pressing the button for the awning lighting 5 times in the entrance area, the exhibition lighting system is activated. This means that the base light (awning light, ceiling light, kitchen light, bathroom light) and the indirect lighting will automatically switch on again no later than 30 seconds after it has been switched off.

If it has been activated accidentally, it can be cancelled by pressing the awning lighting button 5 times again.

### 5.1.11 Heating system function switch, floor heating and filling levels



Fig. 36: Function switch (example)

The function switches for the heating system, the floor heating, or the check of filling levels of battery or fresh water tank are located above the entrance door.



### 5.1.12 Smoke alarm



*Fig. 37: Smoke detector*

A battery-operated smoke alarm is attached to the ceiling of the living area. If smoke develops in the vehicle, an acoustic alarm sounds warning the passengers of a possible fire.

The smoke alarm's integrated power supply via the installed 9V block battery ensures that the smoke alarm functions independently of the vehicle electrical system, and that it also operates when the vehicle's power supply is switched off.

- Prior to using the vehicle for the first time, remove the protective foil from the block battery to activate the smoke alarm.
- Regularly check the block battery and replace when necessary.

## Overview

### 5.2 Furnishings

#### 5.2.1 Sitting area



Fig. 38: Sitting area, example

The shape and arrangement of the sitting area and table installed in the caravan depend on the model. Lower the table top to provide additional sleeping spaces (→Section "Sitting and sleeping"). The following images represent currently available layout variants.

#### NOTE



*Fading of the upholstery can be effectively countered by always protecting the sitting area from direct sunlight.*

#### Round seating area (U-shape)

Characteristic	Model variants	
Convertible to double bed	<p>U-shape both arms equal in length</p>	<p>U-shape with one arm extended</p>

#### Seating area with individual benches Seating area in L-shape

Characteristic	Model variants	
Convertible to additional sleeping area	<p>Separate bench seats</p>	<p>L-shape</p>

**Table shapes**

**Model variants**



*Fig. 39: Hook-in table*



*Fig. 40: Folding table*

## Overview

### 5.2.2 Sleeping area



Fig. 41: Sleeping area, example

The furnishings of the sleeping area are based on the vehicle model and the selected equipment.

A skylight with fly screen, blackout blind or combination blind is arranged above the sleeping area. Hinged windows are on the sides.

The built-in beds can be folded upward. Storage space for larger pieces of luggage is provided under the slatted frames. The folding compartments above the beds are suitable for light luggage.

## WARNING






### Danger of injury due to falling!

There is a significant danger of injury due to falling out of the top bunk.

- Always use the bed ladder to climb up or down.
- When using the top bunk, always tension the safety net to safeguard against falling out.
- Never leave children in the top bunk unattended, and ensure that they cannot fall out.
- Use special travel beds designed for small children that are available from your dealer.

Model variants

Double bed	Characteristic
	<p>Large contiguous sleeping surface for 2 persons, permanently installed and arranged longitudinally or transversely, depending on the floor plan.</p>
Single beds	Characteristic
	<p>For single longitudinal or transverse arrangement; if arranged in pairs, single beds are installed longitudinally. The aisle between parallel beds can be bridged to set up a solid sleeping level.</p>
Bunk beds	Characteristic
	<p>The bunk beds consists of two single beds arranged one above the other. Always use the bed ladder for climbing up!</p>

5.2.3 Bathroom

NOTE



Waste water, solid waste and chemical substances can cause significant environmental damage.

- Drain the waste water and solid waste tank only at designated disposal points.



Fig. 42: Bathroom, example

Depending on the model and selected equipment, the bathroom is fitted with a washbasin and under-sink cabinet, shower stall, toilet, and either a skylight with fly screen and forced ventilation, or a side window.

Hot water is supplied via the mixer tap.

The waste water runs to the outside via the drain or into the waste water tank (optional), if ordered with configuration.

A large mirror is installed above the washbasin.

## Overview

### Shower stall



Fig. 43: Shower stall, example

Depending on the floor plan and selected equipment, the bathroom contains a shower. It is surrounded by a shower curtain or a shower door that keeps water inside the shower.

### ATTENTION



**Material damage if the splash protection door is not locked in place when the vehicle is in motion!**

If the splash protection door is not locked in place when the vehicle is in motion, it may swing open and destroy the bathroom fixtures.

- Prior to starting any trip and, ideally, immediately after each use, always secure the splash protection door with the provided fasteners!

The shower is supplied from the hot water boiler and features a mixer tap, storage shelf and towel holder.

### Removable slatted floor (optional)



Fig. 44: Slatted floor cover in solid wood

This visually appealing floor insert in solid wood protects the surface of the shower pan.

However, wood can suffer from excessive moisture and accumulate mildew. Remove the insert during showering or ensure to varnish the wood regularly (at least every six months) using linseed oil.

Linseed oil and similar products are available from specialist shops or DIY stores.

**Toilet**

*Fig. 45: Cassette toilet*

The cassette toilet is installed next to the washbasin or the shower. For all floor plan models, a separate flushing water tank is provided for the toilets.



*Fig. 46: Holding tank with flushing water intake port*

The waste water from the toilet is collected in the holding tank.

- To empty and clean, remove the holding tank from the outside via the sanitary compartment.

The flushing water intake pipe is also located here.

## Overview

### 5.2.4 Kitchen area



Fig. 47: Kitchen area, example

The kitchen area is designed for longer stays. The kitchen counter area features gas hob, sink and a small working surface. Gas hob and sink are covered with safety glass panels.

Cabinets for crockery are installed above this counter.

The window behind the hob ensures sufficient fresh air when preparing food.

Underneath the counter-top, additional kitchen cabinets are installed with drawer compartments for pots and pans, cutlery, and accessories. In some models, the refrigerator is also installed underneath the counter-top.

#### CAUTION



#### Risk of injury due to flying crockery and hot cooking appliances.

Flying dishes and hot cooking appliances can cause serious injury and material damage.

Before the trip:

- Turn off the gas hob and shut off the gas supply.
- Safely store crockery and kitchen appliances.
- Close the glass panels and kitchen window.
- Lock the cabinets and drawers.



## Refrigerator



Fig. 48: Refrigerator (example)

The refrigerator is in the kitchen area; it can be operated with 12 V, 230 V or gas. The model of refrigerator installed depends on the vehicle model. As a special option, a large refrigerator (optional) or a refrigerator/freezer combination (optional) can be installed.

### NOTE



*Gas ignition at altitudes higher than 1000 m above sea level may be disturbed - this is not a malfunction but a reaction to changed pressure levels.*

The refrigerator works trouble-free at inclines up to approximately 5°.

The refrigerator is designed to be flame-proof. The gas supply shuts off automatically if there is insufficient gas.

## Overview

### 5.3 Storage compartments

This section tells you how and where to best stow your luggage.

#### WARNING



#### **Danger of accident and injury due to unsecured packed goods!**

Unsecured luggage and excessive load adversely affect driving behaviour; luggage can slide and cause serious accidents.

- Comply with the specifications for maximum permissible load.
- Weigh luggage before loading and distribute weight uniformly.
- Secure all luggage so that it cannot slip.

#### 5.3.1 Closets and compartments

##### Wardrobe



Dresses, jackets, suits, and shirts are best kept in the spacious built-in wardrobe.

Fig. 49: Built-in wardrobe (middle of photo)

### Linen closet



*Fig. 50: Linen closet*

Linen closets for storing wrinkle-free apparel are arranged at various points in the vehicle and in different numbers, depending on the model and selected equipment.

### Overhead cabinets and lower cabinets



*Fig. 51: Lower cabinet, example*

Undergarments and clothing articles that do not need to be hung can be conveniently stored in the upper and lower cabinets.

In most of the floor plan models, an upper cabinet is located above the built-in wardrobe or above the large refrigerator.

Depending on model and selected equipment, lower cabinets, for example are located underneath the built-in wardrobe, the bed, under seats, or under steps.

### Wall cupboards in the living area



*Fig. 52: Wall cupboards above the sitting area*

Additional storage possibilities are offered by the hinged compartments and open storage units e.g. above the sitting area as shown in the illustration.

This is a good place to store items of common interest, such as games, maps, or magazines.

## Overview

---

### Wall cupboards in the sleeping area



*Fig. 53: Wall cupboards in the sleeping area*

Hinged compartments are also installed above the beds; these compartments are primarily designed to hold useful accessories that are used daily such as towels and casual clothing.

### Under-bed storage



*Fig. 54: Under-bed storage*

Storage compartments under the beds are available for medium-sized luggage. Under-bed compartments can be reached via a hatch or by lifting and unfolding the slatted frame under the mattress.

### Upper kitchen cabinet



*Fig. 55: Upper kitchen cabinet, example*

Small and medium-sized kitchen items such as crockery, plastic glasses, or cups are best stowed in the lockable storage units above the kitchen block.

### Lower kitchen cabinet



Fig. 56: Lower kitchen cabinet

Large kitchen items such as pots and pans have a secure place in the large drawers in the lower kitchen cabinet.

Depending on the vehicle's model, drawers or lattice-type trays provide quick access to the stored objects.

- Before starting the journey, always close all drawers and cupboard doors! Check the door locks.

### Storage areas in the bathroom



Fig. 57: Cabinet compartments in the bathroom, example

Cosmetics, toilet and hygiene articles can be stored in the storage shelves, and upper and lower cabinets in the bathroom.

Additional storage space is provided by, for example, a mirror cabinet, if supplied with the model and selected equipment.

#### ATTENTION



**Damage due to unintended opening of the mirror cabinet doors during the trip!**

Mirror cabinet doors can open on their own due to driving vibration and damage the fixtures in the bathroom.

- Prior to driving, lock the mirror cabinet door with the key and remove the key to avoid unintended opening of the locks and doors.

## Overview

---

### 5.3.2 Waste container



Fig. 58: Waste container

The waste container is conveniently installed in the lower portion of the entrance door.

### 5.3.3 TV bracket



Fig. 59: TV drawer compartment, example

Some vehicle models are designed with a TV drawer compartment or a TV bracket for the secure transport of a flat-screen TV. Depending on the arrangement, either a rigid or pivoting holding panel accommodates the TV set. With the pivoting version, the screen can be viewed from the sitting area and the sleeping area.

- Follow the manufacturer's instructions when mounting the TV to the retaining plate.
- Lock the pivoting TV bracket when the unit is not in use.
- In vehicles with drawer compartment, simply push the TV set into the drawer and close the sliding door.

## 5.4 Technical equipment

### General

Your caravan is equipped with modern and convenient technical systems. This section provides important information on the structure and function of the equipment and built-in devices.

### 5.4.1 Electrical system

#### General

The electrical system of the caravan is configured for 12 V and 230 V operation.

As soon as the 230V input of the caravan is connected to an external 230V supply network (e.g. via a camping site outlet), the dual devices are operated via the supplied power connection in conjunction with the power supply unit.

If the caravan is fitted with a stand-alone package (optional), a charger will charge the supply battery (optional). At full battery capacity, the charger ensures constant charge. In this case the 12V consumers (lighting, water pump, except for the refrigerator) are supplied with electricity from the supply battery.

When driving the rig, only some of the 12V consumers are supplied from the battery of the towing vehicle.

#### NOTICE



*During interruptions in travel (e.g. rest breaks), always switch off the 12V consumers to prevent the rechargeable starter battery from discharging unnecessarily!*

#### DANGER



#### Life-threatening danger due to electric shock!

Danger of electric shock potentially resulting in serious or fatal injury when working on electrical equipment.

- Any repair tasks on the electrical system must be performed by qualified personnel.
- Replace defective fuses only after the cause of the fault has been identified and rectified.

## Overview

### Power connection



Fig. 60: Power connection

The power connection (Fig. 60) is located under a protective cover (1) at the outside of the caravan.

Connect the CEE cable with the connection plug and secure with the stopping lever.

#### NOTE



*Before travelling to foreign countries, obtain information about the plug and connector systems used at your destination. Suitable adapters are commercially available.*

### Converter (power supply unit) and cut-outs




Fig. 61: Converter (power supply unit) (1) and cut-outs

The electric system is secured with miniature circuit breakers and a ELCB. The miniature circuit breakers also serve as main disconnect switches.

- 3 Light circuit
- 4 GFCI
- 5 Test switch for GFCI

The power supply is divided in separate circuits:

Power circuit	Assignment	Nominal current in [A]
Lighting circuit 1	Interior lighting and power outlets	10
Lighting circuit 2	230 V operation (incl. optional ALDE)	16

- Reserve fuses (2) at the converter housing (1).
- Shut the circuit breaker off if the vehicle is not in use (e.g. during the winter months). This disconnects all devices from the power supply.





Fig. 62: 12 V-Emergency lighting



Fig. 63: 12 V-Complete supply

### 12 V Emergency lighting

If the 15 A plug-in fuse (1) is in its outer position, the power supply uses the standard setting with emergency lighting.

### 12 V Complete supply

If the blind plug is removed and the 15 A plug-in fuse (1) is set to the left (3), the power supply uses the 12 V-complete supply setting.

The refrigerator is protected by the charge cable (pole 10). Hence, the refrigerator is supplied with 12 V from the generator only when the engine of the towing vehicle is running.

## CAUTION



### Material damage due to total discharge!

The starter battery of the towing vehicle may fully discharge when the power supply uses the 12 V-Complete supply setting.

This discharge would be caused by the 12 V lighting and other 12 V consumers.

- Always switch off all 12 V consumers in the caravan when it is not in use to prevent a total discharge of the starter battery during standstill.

## NOTE



*In towing vehicles meeting the EURO 6 standard, it can happen that the on-board computer shuts down the power supply for the refrigerator due to excessive current consumption.*

## NOTE



*Red LEDs are found next to the plug-in fuses. If an LED illuminates, it indicates that the corresponding fuse is defective.*



## Overview

---

### 5.4.1.1 Supply battery

#### General

You can use either a conventional lead/acid battery or a so-called AGM battery.

The supply battery supplies all activated 12V consumers when the system is not connected to an external power source. Thus, the supply battery is continuously discharging.

#### Lead-acid battery pack (optional)

The lead-acid battery pack is designed for cyclical loads in particular.

To maintain long-term functional operating condition it requires basic maintenance. The charger has been equipped with a battery monitor protecting the supply battery from total discharge during use.

However, irreparable damage can occur if the vehicle is parked for longer periods (e.g. in winter) without manual maintenance. For this reason, you must use the charger to recharge the supply battery at least once a month.

For an unused but not fully discharged supply battery, the charging process will be completed after ten to twelve hours.

**AGM battery (optional)**

The AGM battery (**absorbent glass mat**) is a state-of-the-art battery that absorbs the electrolyte in a special fibre-glass matting. Lead-mat battery packs do not have a free sulphuric acid and can be operated in any position. The acid cannot escape even if the AGM battery breaks. AGM batteries are ideally suited for the use in mobile homes and caravans.

**Benefits:**

- Low maintenance (closed system)
- High cycle stability, long service life
- Good total discharge properties
- Low spontaneous discharge, long storage life
- Escape proof, no gas formation, no corrosion, no drip tray
- High shock and vibration resistance
- Small footprint at comparable capacity

It is recommended to charge the AGM battery in the early times once a month for more than 24 hours. At low discharge, this interval can be extended, depending on external temperatures, once per quarter for example.

**NOTICE**

*You can switch in parallel only batteries of the same type and same capacity.*

## Overview

### Stand-alone package (optional)




Fig. 64: Stand-alone package

The stand-alone package comprises a supply battery (1) and a charger (2).

The supply battery supplies all 12 V consumers as soon as the 12 V main switch above the entrance door is switched on and the 12 V consumers are activated. Thus, the supply battery is continuously discharging.

**Exception:** 12 V operation of the refrigerator.

The refrigerator can be in 12 V mode during driving only via the charge cable. During standstill, you can operate the refrigerator only with gas or an external 230 V supply.

The charger recharges the supply battery as soon as you have connected to the 230 V power supply. The 12 V consumers are supplied only via the supply battery. As soon as the supply battery has reached its full capacity, the charger will provide sufficient trickle charge.

Comply with the safety instructions and operating instructions provided in the manufacturer's documentation for operation!

### CAUTION



#### Fire danger due to heat accumulation!

Supply battery and charger become hot during operation and can cause smouldering or fire if heat cannot be discharged properly.

- Never cover the supply battery and the charger.
- Do not misuse the storage space of the supply battery and the charger as the storage space for other objects.


**Charger display panel**


Fig. 65: Charger display panel

The charger optimally charges the supply battery. The input source with the highest input voltage supplies the charging current for the battery connected to the output.

- 1 12 V- touch button with LED  
Use the 12 V main switch to activate and deactivate the consumers connected to the charge controller.
- 2 LED status indicator
- 3 LED status indicator for autonomous supply

### NOTICE



- *The device must be installed and opened only by authorised specialist personnel!*
- *The device must be fully disconnected from the power source before the fuses are exchanged!*
- *Fuses must be replaced with fuses of the same fuse class and category!*
- *Prior to replacing a defective fuse, the cause of the fuse having tripped must be eliminated (short-circuit, overload)!*
- *Incorrect polarity of the connected battery or the input voltage can result in a defective control unit.*
- *Insufficient ventilation of the device causes a reduction in the charge current.*
- *The housing surface can become hot during operation!*

## Overview

### Battery charge status

### ATTENTION



#### Explosion hazard due to overcharging!

A defective charger can cause "boiling" and, consequently an explosion of the supply battery.

- Immediately switch off the charger when the battery is boiling.
- Have the defective charger repaired by an authorised specialist workshop or replace with a new unit.

The charge status can be read from the charger.  
The displayed voltage is interpreted as follows:

Voltage display	Battery charge status	Note
≤ 11 V	Total discharge	No charge, or 12 V system overloaded
11.1 – 13.2 V	Normal operating range	Voltage no longer increases
12.00 V	Empty	Charging process too weak or 12 V system overloaded
12.18 V	¼ full	
12.32 V	½ full	
12.55 V	¾ full	
12.80 V	Full	
12.8 – 14.4 V	Overfull	Only permissible for a brief period immediately after charging
> 14.4V	<b>Overcharged - battery may boil: Danger of explosion!</b>	Charger defective

## ATTENTION



### **Material damage due to improper maintenance!**

Improper maintenance of the battery will cause destruction and total failure of the unit!

- Comply with manufacturer instructions.
- Travel only with fully charged battery.
- After every trip, recharge the battery for 12 hours.
- Batteries subject to high ambient temperatures ( $\geq 30\text{ °C}$ ) require more frequent recharging.
- At shut-down times of more than four weeks, disconnect the batteries from the on-board system and recharge on a monthly basis.
- Check the acid condition at least once a year (only in lead-acid battery).

### **Battery charging process**

During the charging process of the battery (lead-acid only), a combustible hydrogen-air mixture may form which can escape via the venting hose into the atmosphere.

In the course of charging, the water in the battery is continuously consumed, yet the diluted sulphuric acid remains the same.

- To avoid an increase in acid concentration, check the acid level annually. Add distilled water if necessary!

## Overview

---

### WARNING



#### **Risk of injury due to improper handling of rechargeable batteries!**

Rechargeable batteries can release toxic acid, explode and cause severe injury if handled improperly.

- Do not expose rechargeable batteries to high temperatures. Do not bring the rechargeable battery in the vicinity of sparks, ignition sources, or fire. Do not smoke.
  - Do not remove the pole terminals during charging. Do not move the batteries.
  - Do not touch escaping fluids. In the event of skin contact, wash immediately and thoroughly with water.
  - Eye contact: Rinse out eyes immediately with plenty of water and seek medical attention.
  - Collect escaped fluid with suitable absorbent cloth and dispose of according to applicable environmental regulations. Wear protective gloves!
- 

#### **Charging via a 230 V power supply**

If an external 230 V power supply is connected, the rechargeable battery (optional) is recharged from the built-in charger (optional). The charging current is adjusted to the charge status in this process. Overcharging is not possible.

- To exploit the full capacity of the charger, switch off all electrical consumers during the charging process.




**LED battery lights**

In the interior, above the bench and in the sleeping area, there is a track light system with 12 V LED spotlights. Those can be rotated, pivoted and adjusted, allowing all areas to be well illuminated (for use see → "Arranging the lights" section).

Each spotlight has its own ON/OFF switch.

Charging of the replaceable Li-ion battery, type 18650, is performed only in the brackets above the sitting area.



*Fig. 66: LED battery lights*

## Overview

---

### Room spotlights



*Fig. 67: Canopy*

Depending on the model and the selected equipment, there are either room spotlights with multiple rotating and pivoting halogen lamps on a rail system, or permanently installed lights in the canopy. These are activated via a central ON/OFF switch. The light intensity can be regulated.

### Bathroom lighting



*Fig. 68: Bathroom lighting, example*

In the illustration on the left-hand side, the LED lights are installed in the bathroom above the mirror of the washbasin. These lights are also switched via lighting circuits 1 or 2. They can be operated if the lighting circuits are enabled.

**Kitchen light**

*Fig. 69: Typical LED light rail*

There is an LED light rail in the kitchen area below the top cabinet, which can be switched on and off via an ON/OFF switch.

**230V outlet**

*Fig. 70: 230 V outlet, example*

Outlets for the connection of small appliances when an external power supply is connected can be found at various locations in the vehicle interior, depending on the model and selected equipment (the picture shows an outlet in the support of the sitting area).

**Awning light (optional)**

*Fig. 71: Awning light with LEDs*

The awning light (optional) lights up the entrance area at night. It can be operated with the remote control unit (optional) or the corresponding button on the entry door.

The awning light must always be operated manually. For safety reasons, it does not switch off automatically and remains in operation until it is switched off.

## Overview

### Remote control unit (optional)



Fig. 72: Remote control

Use the remote control to operate the awning light and the ceiling light.

The buttons on the remote control unit have the following functions:

- 1 Awning light ON/OFF
- 2 Ceiling light ON/OFF

The light intensity can be regulated by keeping the ceiling light switch depressed.

### 5.4.2 Gas supply

#### General

This section provides information about the gas supply system in the caravan.

The installed gas appliances (depending on the selected equipment: heater, boiler, hob, oven, grill, refrigerator) - are explained in detail in the accompanying operating manuals provided by the respective manufacturers.

## WARNING



### Danger of explosion and injury due to gas!

Escaping gas can cause poisoning and explosions.

- All repairs on the gas system must be performed only by authorised specialist personnel.
- If gas odour is detected:
  - Immediately shut down the gas supply.
  - Do not operate any electric devices.
  - Remove fire and sources of ignitions.
  - Do not smoke.
  - Have gas system repaired immediately.

### Gas bottle locker



Fig. 73: Gas bottle locker lock unlocked



Fig. 74: Gas bottle locker lid, open

The gas bottle locker is located in the front above the draw-bar. The gas bottle holder and the gas pressure regulator are located here.

#### NOTE



Depending on the selected equipment, a gas pressure regulator set (optional) with automatic switch-over function can be pre-mounted.

The front door key is also used to operate the gas locker lock.

#### Opening the gas locker:

- After closing the lock:
- After closing, the handle must be turned through 90 degrees to the right to unlock.
- Press the gas bottle locker lid up.

#### Closing the gas locker:

- Press the gas bottle locker lid down.
- To lock the gas bottle locker lid, press down and lock with the handle.

This is particularly useful if a bike holder is mounted on the draw-bar and bicycles are attached to the bike holder. In this case, you don't need to remove the bicycles in order to close the gas bottle valve when refuelling or after cooking, for example.

### Standard gas supply (with pressure reducer)



Fig. 75: Pressure reducing valve

For connection of a gas bottle, a flexible gas hose with pressure reducing valve is installed. The pressure reducing valve is fitted with a sleeve nut with left-hand thread, and should only be screwed hand-tight with the gas bottle. Gas hose and pressure reducer must be examined for leaks at each gas test, and replaced if the status is deficient, at the latest, however, the gas hose and pressure reducer must be replaced at the end of the permissible service life.

- Place the gas bottle in the gas locker and lash the bottle tight with the securing belt.
- Screw the pressure reducing valve directly onto the thread of the discharge valve on the gas bottle and hand tighten.

## Overview

### DuoControl CS gas supply (with Eis-Ex and remote display) (optional)



Fig. 76: Gas supply (with Eis-Ex and remote control)

A safety regulating system for gas pressure with integrated crash sensor is available at a surcharge for a two-bottle gas supply. It enables switching the gas bottle without interrupting the gas supply.

The regulating system for the gas pressure comprises an automatic switch-over valve (DuoControl), the gas pressure regulator, the regulator heating element (Eis-Ex), and a remote control displaying the status of the bottle in operation.

The regulating system for the gas pressure is mounted at the wall of the gas bottle locker and connected to the gas bottles via two high-pressure hoses. The regulating devices and hoses must be replaced at the latest ten years after the manufacturing date.

The high pressure hoses are equipped with a left-hand thread cap nut. During every gas test, the high-pressure hoses must be tested for tightness and replaced if necessary.

- Place the gas bottles in the gas bottle lockers and lash tight with the securing belt.

#### NOTE



*During an accident with a delay of  $3.5\text{ g} \pm 0.5\text{ g}$  directly affecting the trigger element (corresponding to an impact speed of 15 – 20 km/h to a solid obstacle at a mean vehicle weight), the integrated crash sensor will interrupt the gas flow.*

### Eis-Ex (optional)

Ice or propane hydrate formation on the regulator can hinder or stop the gas supply in winter.

The regulator heater prevents formation of an ice plug through electric heating. Thus, trouble-free gas supply is also ensured in winter conditions.

**Remote display (optional)**


Fig. 77: Remote display

The remote display (optional) shows the gas consumption status in the vehicle interior (normal or reserve operation), as well as the heating operation of the regulator heater:

After switching on, the display LEDs mean:

- Green LED = Gas consumption from the active bottle
- Red LED = Gas consumption from the reserve bottle
- Yellow LED = Regulator heater active

**Quick-closing valves**


Fig. 78: Quick-closing valves




Fig. 79: Shut-off and release position

The quick-action valves for the gas appliances are located in the caravan body, either in the drawer under the counter-top (as shown in the Fig.) or in the lower cabinet in the kitchen. The quick-closing valves must be accessible at all times.

Each gas appliance has its own quick-action valve.

The arrow on the quick-action valve indicates whether gas flow to the gas appliance is open or shut off.

The quick-action valves are marked as follows:

Symbol	Meaning	Symbol	Meaning
	Hob		Hot water boiler
	Oven		Heater
	Refrigerator		Combination device hot-water boiler with heating system

- Always close the quick-action valves prior to fuelling, and after using the gas appliance!

## Overview

### 5.4.3 Heater

#### General

With the heating systems hot air heating and hot water heating are completely differentiated.

With the Truma combination heater, the boiler is integrated for the first time, although it is hot air heating that is involved, so that a compact hot air heater (Truma-Combi) or a compact hot water heater (ALDE) are available alongside conventional hot air heating.

#### 5.4.3.1 TRUMA heater 3004 S and 5004 S




Fig. 80: TRUMA heater

The vehicle is always equipped with a gas heating system. It is operated via the thermostat (1).

The gas heater generates hot air that is distributed in the caravan body via a hot-air pipe system. The hot-air blower is operated with the operating switch (2) directly mounted above the heater.

The hot air blower will work only when an external 230V power supply is connected.

#### NOTE



*In many countries, the operation of gas heaters during driving is not allowed. Before starting the trip, obtain information about the locally applicable regulations on the transit route and at the destination. If in doubt, close the gas heater prior to starting the trip, as well as the quick closing valve and gas bottle valve.*



**Hot-air nozzle**

Fig. 81: Hot-air nozzle, open

To heat the caravan body, the blower drives hot air through the hot-air piping and expels the air through the hot-air nozzles into the caravan interior.

To regulate the flow of hot air as needed, the hot-air nozzles installed at various points can be manually opened or closed.

- To open and close bring the revolving dampers of the hot-air nozzles into the desired position.

**Exhaust gas stack**

Fig. 82: Exhaust gas stack of the gas heater

The exhaust gas stack to discharge burnt heating gas is installed in the caravan's roof.

The opening must always be free and clean to ensure unobstructed discharge of the exhaust gases.

**NOTE**

*Always keep the opening free of leaves, dirt, and other fouling!*

## Overview

### Floor heater system (optional)



Fig. 83: On-Off switch of the floor heating system

The electric floor heating system (optional) is activated with the On-Off switch (1). It is located above the entrance door. The corresponding transformer is fitted in the bed frame or in the bench.

The floor heating system does not require maintenance.

### 5.4.3.2 TRUMA Combination heater (optional)



Fig. 84: TRUMA Combination heater

The combination heater combines the gas heater and the hot water heater.

The gas heater generates hot air that is distributed in the caravan body via a hot-air pipe system.

The integrated hot water heater supplies the tap at the sink, the washbasin and the shower stall with hot water.

Summer or winter operation is available as an option.

### Digital TRUMA control unit CP plus



Fig. 85: Digital TRUMA control unit CP Plus

- Central control unit for the TRUMA Combi CP plus ready and a TRUMA air conditioning system
- Boost function for fast hot water supply and heating of the area
- All functions are programmable using the timer
- Individual temperature settings based on the time – for a comfortable and quiet night

It serves as an interface for the operation of connected devices via TRUMA App and iNet Box.

Detailed instructions can be found in the operating manual provided by the manufacturer.

### 5.4.3.3 ALDE- heater (optional)



Fig. 86: ALDE heater

The ALDE heater (optional) with hot-water heater is a classic heating system similar to systems used in many households.

It comprises a boiler operated with standard camping gas cartridges heating a glycol-water mixture and conveying the same into a closed circuit with convector elements (heating elements), recirculating pump and expansion vessel.

The ALDE system additionally features a 230 V electric heater for fast heating of the parked vehicle, if required.

#### NOTICE



*In many countries, the operation of gas heaters during driving is not allowed. Before starting the trip, obtain information about the locally applicable regulations on the transit route and at the destination. If in doubt, close the gas heater prior to starting the trip, as well as the quick closing valve and gas bottle valve.*

#### NOTICE



*Appropriate maintenance is important to protect the ALDE heater from damage.*

- *Replace the glycol/water mixture every two years to prevent rust in the heating system.*
- *Vent the system if the convector elements in the vehicle heat up unevenly. First vent the heating system in cold state. If the result is unsatisfactory, vent the heating system in warm state.*

*See chapter "Maintenance", section "ALDE heating maintenance overview" for a table to record the maintenance tasks performed.*

## Overview

### ALDE control unit



Fig. 87: Control elements

- A Clock.** The clock displays date and time (if activated). For its setting, please see the ALDE operating manual.
- B Outside temperature\*.** The outside temperature is displayed.
- C Interior temperature.** The interior temperature is displayed.
- D Recirculating pump.** This symbol is displayed when the recirculating pump is operating.
- E Automatic start of the heater.** This symbol is displayed when the function has been activated.
- F Day automatic.** This symbol is displayed when the function has been activated and the time is within the set period.
- G Liquefied gas bottle full/empty\*.** This symbol is displayed when the sensor at the gas regulator is connected to the bottle and activated. If "Eis-Ex" is installed, the symbols for the set mode is shown with the bottle symbol.
- H Night automatic.** This symbol is displayed when the function has been activated and the time is within the set period.
- I 230 Volt.** This symbol is displayed when 230 V voltage is applied to the heater.
- J On/Off button.** Main switch for the heater.
- K MENU button.** Button to open the Settings menu.

The functions identified with (\*) are optional.

### Wall exhaust stack



Fig. 88: Wall exhaust stack

The wall exhaust stack channels the camping gas that is burned in the gas heater to the outside. Depending on model and selected equipment, it is located on the left side of the vehicle.

The opening must always be free and clean to ensure unobstructed discharge of the exhaust gases.

#### NOTE



*Never use the cover as a clothes hook or to fasten objects!*

*Always keep the opening free of leaves, dirt, and other fouling!*

**ALDE window switch**

*Fig. 89: Window switch*

If the exhaust gas stack is installed below a window, an ALDE window switch is installed at the corresponding window.

This unit is a contact switch automatically shutting down the heater when this window is opened, in order to prevent any exhaust gases from entering the vehicle interior.

**ALDE convector (optional)**

*Fig. 90: Convector with thermally conductive panel*

Heat is dissipated in the interior of the vehicle without blower support on the convectors.

To achieve fast warming, the hot-air must be able to circulate freely. Never cover convectors as it would obstruct circulation.

You can fill the heating circuit with the glycol/water mixture (ratio 40:60) at the expansion vessel. A venting valve is installed at all convectors for ventilation purposes.

- Comply with the safety and operating instructions in the operating manual provided by the manufacturer!

## Overview

### Floor heater system (optional)




Fig. 91: Floor heating

In combination with the ALDE heater, the floor heating system (optional) represents an additional heating element in the heating circuit.

A pipe system laid out under the floor with thermally conductive layers arranged on top serves as the floor heating system (SO). A special heating fluid (glycol/water mixture) circulates through the pipe system.

A safety switch deactivates the pump if the floor temperature becomes excessively high. When the temperature falls below the set level of the safety switch, the pump switches on automatically.

### CAUTION



#### **Danger of damage to the pipes in the floor!**

Screws, nails, and other fastening material can damage the pipes in the floor and cause the heating fluid to escape.

- Do not retrofit, convert, or add individual installations in the living area.
- Never introduce any screws, nails or other fasteners into the floor.
- Do not damage the floor surface.

### NOTICE



*All claims are excluded for damage to the pipe system, consequential damage to the caravan body or fixtures and fittings due to installations in the floor*

## 5.4.4 Fresh water and waste water system

### General

The following section provides information on the fixtures for fresh water supply and waste water disposal.

### Fresh water intake port



Fig. 92: Fresh water intake port

The fresh water fill pipe connection is outside on the side wall of the caravan.

- To fill the fresh water tank, swing the hinged hatch cover upward. Insert the caravan body key in the lock and turn it by 180°. Then press the rotary cap closure, turn it 120° counter-clockwise and remove from the intake port.
- After filling, replace the rotary closure cap and lock it with the key.

### NOTE



*Standing water in the fresh water tank or in the water lines becomes unusable even after a short period. Thoroughly purge and rinse with fresh water before using the tank or water pipes after shut-down times. Special cleaning and sterilising agents are commercially available for regular use.*

## Overview

### Fresh water tank




Fig. 93: Fresh water tank, example

The fresh water tank is located in the living or sleeping area (shown in the Fig. under the bench seat of the sitting group as an example).

- 1 Fresh water tank
- 2 Cleaning cover
- 3 Ventilation - fresh water tank
- 4 Suction hose for the water pump
- 5 Supply line to the level indicator
- 6 Fill hose

### Second drain valve on the freshwater tank



Fig. 94: Drain valve, example

The second drain valve is mounted to the side on the tank and can be operated using a knurled thumb screw. It is used for simple regulation of the freshwater filling level. Opening the second drain valve reduces the filling volume of the freshwater tank. This process means the caravan loading can be increased.

When arriving at the destination, the knurled thumb screw can be closed again to utilize the entire tank volume and to fill with fresh water.

- To open the second drain valve, turn the knurled thumb screw anticlockwise
- To close the second drain valve, turn the knurled thumb screw clockwise



**Mixer tap**


Fig. 95: Mixer tap

**Drain plug in fresh water tank**
**WARNING**

**Danger of scalding due to hot water!**

Hot water can scald hands and other body parts.

- Open the mixer tap in cold-water position and carefully raise the temperature.

1. To obtain water, turn the lever in direction of the cold-water setting (blue mark), lift upward, and slowly shift in direction of the red mark.
2. To close, turn the mixer lever in direction of the blue mark and push downward.

The drain plug is integrated in the tank bottom and can be accessed after the service cover has been removed.

**Closing and draining positions**


Fig. 96: Closing position



Fig. 97: Draining position

- Rocker lever engaged: Drain plug seals and the plug cannot be removed in this position.
- Rocker lever straight: Drain plug does not seal and can be removed.

## Overview

### Waste water




Fig. 98: Waste water tank (optional)

The waste water from sink and washbasin drains into a shared waste water conduit.

Depending on the model and selected equipment, the waste water is either captured in a permanently installed waste water tank (optional), or discharged into the exterior.

In a permanently installed waste water tank (optional), the drain valve (1) is installed in the immediate vicinity of the tank for easy access.

### NOTE



*Cleaning agents, soaps, wash lotions and cosmetics contaminate the environment and ground water.*

- *Never drain waste water in free nature, dispose only at the designated disposal points!*

---

## 5.4.5 Water heater

### ATTENTION



#### **Damages after extended stand time or frost!**

If the vehicle is not used in winter, the sanitary system may be damaged due to frost.

Extended stand times can cause algae growth in the sanitary system.

- Ensure that the overflow valve is free from contamination and ice formation.
- In the event of frost or extended stand time, completely empty the water tanks, containers, hoses, and conduits. Dry-run the pump for approximately five minutes to avoid frost damage caused by residual water in the pump.

---

### NOTE



*Frost damage or contamination caused by algae growth in the water system are not covered by the guarantee!*

---

## Overview

### 5.4.5.1 TRUMA heater and TRUMA water heater system




Fig. 99: TRUMA water heating and water drain valves

The TRUMA water heater is installed in the storage compartment under the bed.

This hot water heater heats the water in three ways:

- When the gas heater is activated, a portion of the heated air flows through the hot water heater via the hot-air piping where it heats the fresh water.
- Fresh water can be heated with the integrated electric heating system when the gas heater is switched off.
- Combination mode: Accelerated heating of fresh water via hot air from the gas heater and internal electric heater

To empty the cold and/or hot water circuits, manually-activated drain valves are located directly next to the hot water heater. (→ arrows).

### Operating the hot water heater



Fig. 100: On-Off switch of the water heating system

The water heating system (SW) is activated with the On-Off switch (1). It is located above the entrance door.

The water heating system does not require maintenance.

#### 5.4.5.2 TRUMA Combination heater (optional)



Fig. 101: TRUMA Combination heater

The combination heater combines the gas heater and the hot water heater.

The gas heater generates hot air that is distributed in the caravan body via a hot-air pipe system.

The integrated hot water heater supplies the tap at the sink, the washbasin and the shower stall with hot water.

Summer or winter operation is available as an option.

#### 5.4.5.3 With installed ALDE heater (optional)



Fig. 102: Drain valves opened

The ALDE heater is fitted with a boiler (8.5 litre volume approximately). This boiler can be operated with liquefied gas or electric power. To fill the boiler, open the mixer tap for hot water.

In general, the heating system can be operated with an empty boiler as well.

When the vehicle is not in use, always drain the water system by opening the draining valves for hot and cold water (vertical lever position). They are installed directly next to the heater.

## Camping

# 6 Camping

This section describes the operation and function of the equipment of your caravan. See also the instructions provided in the "Overview" section and those in the operating manuals for the built-in devices.

## 6.1 Setting up the caravan

### 6.1.1 Establishing the power connection



Fig. 103: Power connection

1. Before connecting, check whether the electrical supply mains matches the power specification of the caravan.
2. When using cable drums, completely unroll the power cable to prevent the cable from overheating.
3. Lay the cable so that it does not cause a stumbling hazard; mark the cable routing, if necessary.
4. Lift up the hinged cover (1) of the power supply connection on the side of the vehicle.
5. Push the stopping lever (2) upward and insert the CEE mains plug.
6. Connect the plug connector of the power cable to the external supply station.
7. Switch the refrigerator to mains or gas operation (→ section "Camping").
8. Turn on the main switch.

### 6.1.2 Filling the fresh water tank

#### WARNING



#### Health hazard due to germs and bacteria in the drinking water!

Contaminated drinking water can cause serious infections.

- Prior to the first use, disinfect the fresh water system of the vehicle, and thoroughly flush with drinking water.
- Transfer water only from supply systems with proven drinking water quality.
- Filling hose and container must be approved for drinking water.



Fig. 104: Fresh water intake port



Fig. 105: Rotary cap closure, inside



Fig. 106: Fresh water intake port, open

1. Drain any residual water out of the fresh water tank (→ section "Draining fresh water").
2. Open the fresh water intake port at the vehicle side.
  - Hold the twist cap firmly with one hand, insert the caravan body key into the lock and turn the key 180°.
  - When the lock is unlocked, press the twist cap and turn it 120° anticlockwise.
  - Subsequently, remove the twist cap.
3. Thoroughly flush the filling hose (allow at least two litres of fresh water to flow through the hose). Insert the filling hose into the intake port and fill with fresh water.
4. After filling, pull out the filling hose, replace the rotary cap closure of the intake port, and lock it.
  - Insert the rotary cap closure with the pins (Fig. 105/1) in the grooves (Fig. 106/2) of the fresh water intake port.
  - Press the twist cap and turn it clockwise 120°.
  - Turn the key in the lock 180° clockwise and withdraw the key.
5. Empty the filling hose and cap the hose ends.
6. Thoroughly flush out all water lines. Open the drain valves and flush out the lines. Then re-close the drain valves.
7. Turn on the water pump, open the mixer taps to mid position and flush out the lines. Then re-close the mixer taps.

## Camping

### 6.1.3 Draining fresh water



Fig. 107: Drain plug in fresh water tank, open (rocker lever straight)

1. Open the drain valves for cold and hot water.
2. Open the mixer taps of sink and washbasin.
3. Open the service cover at the fresh water tank.
4. Move the rocker lever at the drain plug into vertical position and pull. Completely drain the water from the fresh water tank.
5. Check whether the fresh water system is completely empty. The water removal points (mixer taps, drain valves, discharge opening on the fresh water tank) must be dry.
6. Replace the drain plug in the fresh water tank and the service cover.
7. Close the mixer taps of sink and washbasin.
8. Close the drain valves for cold and hot water.

### TRUMA drain valves



Fig. 108: TRUMA combination heater drain valves

There are two drain valves in the lower cabinet:

- 1 Safety drain valve (cold water)
- 2 Manual drain valve (hot water)

The safety drain valve opens automatically at temperatures between 4 and 7 degrees to avoid damage due to freezing.

The manual drain valve is operated by hand.






Fig. 109: Safety drain valve open

- Open safety drain valve manually:

To the top rotary switch (1) until it engages. A push-button (2), which is located at the bottom of the housing, will pop out (→ observe applicable operating instructions).

- Close safety drain valve:

When closing the valve, the push-button must be pressed and the rotary knob must be turned simultaneously 90 degrees. The push-button must remain in this position; otherwise, the valve will remain open.




Fig. 110: Safety drain valve closed

## Camping

### 6.1.4 Draining the waste water

#### NOTE



*Cleaning agents, soaps, wash lotions and cosmetics contaminate the environment and ground water.*

- *Never drain waste water in free nature, dispose only at the designated disposal points!*
- *Ensure that the collection container does not overflow, regularly empty at the disposal point.*

#### Drain via the discharge pipe

1. Place collection containers (e.g. water bucket) directly under the drain pipe under the floor of the vehicle.
2. Allow the waste water from the kitchen sink, shower, and wash basin to drain into the collection container.
3. If the camping place is equipped with a waste water system, you can extend the drain pipe using a suitable waste water hose, and directly route the waste water into the designated sewage system.


**Waste water drain with permanently installed waste water tank (SW)**

Fig. 111: Draw-off tap (1)

1. Place a collection container below the drain pipe under the vehicle (or discharge into designated waste water system, if available).
2. Open the draw-off tap (1) next to the waste water tank.
3. Drain waste water from the tank (tank volume: 44 litres!), into the collection container (or directly into the waste water system). Make sure that the collection container does not overflow.
4. Empty the collection container at the designated point of disposal.

**Draining via the waste water tank (optional)**

Fig. 112: Wheeled waste water tank

- Available if this special option was selected.

1. Detach the wheeled waste water tank from its bracket in the gas bottle locker and open the cover.
2. Place the wheeled waste water tank with the intake port under the drain pipe for the waste water to flow from the caravan into the tank.
3. Regularly empty the waste water tank at an approved disposal point before it may overflow.
4. After use and before continuing your trip, insert the waste water tank in its bracket in the gas bottle locker and fasten.

## Camping

### 6.1.5 Changing the gas bottle (standard)

- For the standard model of the gas system (flexible gas hose and pressure reducer) change the gas bottle as follows:

#### WARNING



#### **Danger of explosion and injury due to gas!**

Escaping gas can cause poisoning and explosions.

- All repairs on the gas system must be performed only by authorised specialist personnel.
- If gas odour is detected:
  - Immediately shut down the gas supply.
  - Do not operate any electric devices.
  - Remove fire and sources of ignitions.
  - Do not smoke.
  - Have gas system repaired immediately.



Fig. 113: Gas bottle box



Fig. 114: Gas bottle with pressure reducing valve

1. Open the gas bottle box.
2. For changing an empty gas bottle, close the valve at the empty bottle.
3. Manually unscrew the union nut of the gas bottle valve (note left-handed thread).
4. Loosen the fastening belt of the gas bottle and remove the bottle from the gas bottle locker.
5. Inspect the gas hose. If it is porous or damaged, have it replaced by qualified personnel.
6. Place the new gas bottle in the gas bottle locker and secure with fastening belt.
7. Manually screw the cap nut of the pressure reducing valve tightly onto the gas bottle valve (note left-handed thread).
8. Close the gas bottle locker and engage the lock.
9. In order to operate the gas appliances, open the gas bottle valve and the applicable quick-action valve.

### 6.1.6 Replacing the gas bottle (DuoControl CS) (optional)

- In Control CS (with Eis-Ex and remote display) comply with the following instructions:

#### WARNING



#### **Danger of explosion and injury due to gas!**

Escaping gas can cause poisoning and explosions.

- All repairs on the gas system must be performed only by authorised specialist personnel.
- If gas odour is detected:
  - Immediately shut down the gas supply.
  - Do not operate any electric devices.
  - Remove fire and sources of ignitions.
  - Do not smoke.
  - Have gas system repaired immediately.



Fig. 115: Gas bottle box



Fig. 116: DuoControl CS gas supply

1. Open the gas bottle box.
2. Close the bottle valve of the empty gas bottle.
3. Manually unscrew the cap nut of the high-pressure hose at the gas bottle valve (note left-handed thread).
4. Loosen the fastening belt of the empty gas bottle and remove the empty bottle from the gas bottle box.
5. Place the new gas bottle in the gas bottle box and secure with the fastening belt.

#### CAUTION



#### **Gas leak if the gasket is damaged!**

If you over-tighten the high-pressure hose, you may crush the gasket causing leaks.

- Use only the supplied tool to attach and detach the high-pressure hoses! It ensures the correct tightening torque and prevents damages to the screw joints.

## Camping




Fig. 117: Gas pressure regulator set



Fig. 118: Supplied assembly/removal tool

6. Screw the cap nut of the burst hose safety-valve (3) to the gas bottle valve using the supplied tool.
7. Inspect the gas hose at the gas bottle valve, at the pressure regulator, and over the entire hose length: If it leaks, is porous or damaged, do not operate the gas bottle! Have specialised personnel replace the gas hose.
8. At the rotary knob (13), set the function of the gas bottles; for example turn the rotary knob fully to the left:
  - left gas bottle = active bottle
  - right gas bottle = reserve bottle

### NOTE



The colour display in the view window (14) shows the current operating status:

- Green = Gas consumption from the active bottle
- Red = Gas consumption from the reserve bottle

9. To operate gas devices, open the gas bottle valves and release the gas pressure regulator (→ Releasing the gas pressure regulator).
10. Close the gas bottle box and engage the lock.

### Releasing the gas pressure regulator

After each opening of the gas bottle valves, the gas pressure regulator must again be enabled.

1. Open the gas bottle valve (if you use two bottles: open both bottle valves).
2. In two-bottle operation: press and hold the safety valve of the active bottle.

### Setting the remote display (optional)




Fig. 119: Remote display

If a remote display has been installed in the vehicle interior, select the operating mode by activating the switch in the centre:

- Summer operation
- Winter operation

The illuminated displays in the ornamental ring mean:

- Green LED = Gas consumption from the active bottle
- Red LED = Gas consumption from the reserve bottle
- Yellow LED = Regulator heater active

### Switching the gas bottle




Fig. 120: Gas pressure regulator set

If the bottle pressure of the operating bottle drops below 0.5 bar, the gas pressure regulating set automatically switches to the reserve bottle. In the view window the display changes to red.

#### NOTE



*In cold weather or if there is significant gas consumption over a longer period, gas pressure can drop below 0.5 bar, although gas is still in the bottle. Thus, it can happen that gas is withdrawn from both gas bottles.*

The position of the rotary knob (14) can be changed at any time as needed.

- Always turn the rotary knob (14) to the right or left all the way to the stop. The middle position is for simultaneous withdrawal from both gas bottles.

### Single-bottle operation

you can operate the gas supply with only one bottle. Check valves prevent the outflow of gas from the unassigned connection.

1. In single-bottle operation, close the free connection with the supplied brass blind-off cap.
2. Set the rotary knob at the gas pressure regulator set to the active bottle.

## Camping

---

### 6.1.7 Gas supply maintenance (general)

- Repeat the gas supply inspection pursuant to applicable regulations (every two years in Germany, for example).
- Replace the gas pressure regulator set and the hoses at the latest ten years after their manufacturing dates.

## 6.2 Airing

### General

Regular and planned airing creates a pleasant atmosphere and prevents condensation formation and heat accumulation.

Use the hinged windows, sliding windows and skylights to air the motor caravan superstructure.

The caravan features forced ventilation openings to ensure continuous airing.

### ATTENTION



#### **Damage due to inadequate ventilation!**

Inadequate ventilation causes a lack of oxygen and worsens the room climate. Heat accumulation and water condensation cause damage to the interior furnishings.

- Never cover the louvres for forced ventilation.  
Always ensure adequate airing of the vehicle.
-



**Hinged window***Fig. 121: Hinged window***Intensive airing**

1. Turn the rotating knob upward by approximately 90°.
2. Swing the window outward and latch in the desired position or fasten with the locking mechanism.
3. To close the hinged window, swing further upward or undo the locking mechanism.
4. Swing the hinged window backward, close it and lock with sash fastener.

*Fig. 122: Continuous ventilation***Continuous ventilation**

1. Turn the rotating knob upward by approximately 90°.
2. Push the window outward by approximately one to two centimetres (one inch).
3. Turn the rotating knob back in order for the locking catch to insert in the recess of the window latching mechanism.

Close:

4. After airing, turn the rotating knob again upward until the locking catch can leave the recess.
5. Pull the window into the frame. To lock, turn the rotating knob downward by approximately 90°.

**Sliding windows***Fig. 123: Sliding windows***Opening sliding windows**

- To open, press the inner slide handle to the side and hold; at the same time slide the moveable part of the window to the side.
- To close, push the moveable window part back into position. When closing, always ensure that the slide handle again engages.

## Camping

### Combination blind



Fig. 124: Combination blind

The hinged windows are fitted combination blinds consisting of a fly screen and a blackout blind. Both blind components are hung from the window top.

For both blinds:

- To close, use the handle to pull the fly screen fully downward and slightly push against the window until the lower strip latches.
- To open, push the handle downward and slightly pull toward yourself until the lower strip detaches. Due to the tension, the blind automatically rolls up – hold the handle during this action.

The blackout blind can be lowered in three different heights. It latches in one of three possible positions in the lateral guide rails.

### ATTENTION



#### Damage to the blinds if they fly up!


To avoid damage to the blind, ensure that the blind **CANNOT** fly up.

### NOTE



*Do not keep the blind closed during driving and over a longer period of time (several weeks).*

*Over time, the springs would suffer if the blinds are permanently lowered.*

**Re-tensioning the blinds**

Use a screwdriver to re-tension the blind springs.

- Insert the screwdriver and turn once or twice clockwise.
- Check the tension and repeat the process, if required. Ensure that you don't over-tension the springs.

**Blind care**

As a rule, never use aggressive cleaning agents (solvents or abrasives). Use a damp cloth and soapy water to clean the blinds and frame parts. Use a soft brush and/or damp cloth to clean the fly screen.

## Camping

### Fly screen door (optional)



Fig. 125: Fly screen door

The entrance door can be fitted with an optional fly screen door (optional).

1. To open the screen door, push the handle into the desired position.
2. To close the screen door, push the handle back.

### Skylight

Depending on the caravan model, the skylights installed in the roof differ in design and operation.



Fig. 126: Prop-up skylight

#### Opening the prop-up skylight

1. Grasp both handles to push the internal locking levers.
2. Grasp both handles and push the skylight upward.

#### Closing the prop-up skylight

1. Grasp both handles to push the internal locking levers.
2. Grasp both handles and pull the skylight downward.



Fig. 127: Skylight 400 x 400 mm

#### Opening the skylight

1. Pull the handle down; this will unlock the skylight.
2. Push the pulled down handle forwards; this raise the skylight.
3. Latch the clip in the desired position.

#### Closing the skylight:

- Move the handle back from the latched position into the initial position.




Fig. 128: Operating the Midi Heki / Mini Heki plus

#### Opening the skylight

1. Press the safety button (1) of the skylight.
2. Move the clip (2) in the guide groove (3) backward.
3. Latch the clip in the desired position.

#### Closing the skylight:

- Move the clip from the latching position back to its original position until the safety button (1) locks the skylight.

## Camping




Fig. 129: Operating the Heki 2 lift skylight

### Operate the lift skylight (optional)

1. Push the safety button on both knobs (1, left and right) and rotate the knobs approximately 90°.
2. Pull the clip (2) with a slight jerk from its bracket and swing downward.
3. Prop the skylight open with the clip. Swing the clip all the way down.
4. Place the clip onto the bracket (3) and secure.

## 6.3 Heating and water heating

### 6.3.1 TRUMA heater




Fig. 130: TRUMA heater

The vehicle is always equipped with a gas heating system. It is operated via the thermostat (1).

The gas heater generates hot air that is distributed in the caravan body via a hot-air pipe system. The hot-air blower is operated with the operating switch (2) directly mounted above the heater.

The hot air blower will work only when an external 230V power supply is connected.

#### NOTE



*In many countries, the operation of gas heaters during driving is not allowed. Before starting the trip, obtain information about the locally applicable regulations on the transit route and at the destination. If in doubt, close the gas heater prior to starting the trip, as well as the quick closing valve and gas bottle valve.*

#### WARNING



#### Danger of fire!

Overheating the heating element can cause fire resulting in severe burns.

- Do not keep heat-sensitive items (such as aerosols) in the heater's vicinity.
- Do not place textiles in front or on the heating elements.


**Start-up**


Fig. 131: Thermostat

**Gas heater with automatic ignition**

1. Open the gas bottle and the quick-action valve in the gas feeding line.
2. Turn the multi-function thermostat (1) to one of the thermostat settings 1 – 5 and push until the stop. The system ignites automatically (audible spark) until the flame burns.

**NOTE**


*The sparks of the automatic ignition are audible when you hold the thermostat button down. The heating element is automatically ignited after some seconds (up to approximately two minutes).*

3. Continue to press down the thermostat button for another ten seconds to ensure that the safety pilot responds.

**ATTENTION**

**Risk of deflagration!**

Unconsumed gas in the heating element may deflagrate and damage the heater!

- If the gas does not ignite, wait for at least two minutes before again attempting to ignite the element.

**NOTE**


*If the flame dies after ignition, the system automatically re-ignites during the closing period of the safety pilot (approximately 30 seconds).*

- If no flame is achieved, the automatic ignition will continue to work until you switch the thermostat to "0".
- If the gas line contains air, the system may require up to two minutes before gas is delivered for consumption. During this time, keep the thermostat button pressed until you have a steady flame.
- To obtain a uniform and fast distribution of warm air and a lowered surface temperature at the warm air outlet grid, we recommend that you operate the heater with the TRUMA warm air system running.

## Camping

### Room thermostat




Fig. 132: Thermostat

The room thermostat regulates the heater output according to the setting at the thermostat installed at the heater's top.

#### NOTE



*The temperature sensor is installed at the bottom of the heater. Cold draughts, door gaps, carpeting, etc. affect the thermostat action. Eliminate any problems if you experience unsatisfactory temperature regulation.*

A mean room temperature of approximately 22 °C can be achieved without blower operation at a thermostat set to 3. We recommend an operation with blower and thermostat setting 4 to achieve a comfortable warm air distribution and lower condensation at cold surfaces.

The exact thermostat setting must be determined and adjusted according to the vehicle model and individual needs.

### Switching off

1. Set the thermostat handle of the heater (1) to "0". The automatic ignition is automatically deactivated.
2. Turn off the blower (set rotary switch to "0").

If the device will not be used for an extended time, close the quick-action valve in the gas feeder hose and the gas bottle.




**Removing the heater grille**


Fig. 133: Opening the heater grille

1. Slightly pull the heater grille top forward.
2. Push up the retaining springs at the sides and tilt the heater grille forward (Fig. 133).

**NOTE**


*If space is sparse, pull the heater grille top slightly to the front and lift until it is free. Take off the heater grille.*

3. Swing the heater grille to the side (Fig. 134).


**Closing the heater grille**


Fig. 134: Open heater grille

1. To install, place the heater grille onto the lower holding brackets (Fig. 134/1).
2. Insert the operating rod from below into the handle bush.
3. Swing the heater grille back and latch at the top.

**NOTE**


*Designs with pressure igniter: Place the operating handle from the top so that the arrows points to the "0" position.*

## Camping

### Battery change




Fig. 135: Battery change

#### Heater with automatic ignition

- Replace the battery only when the heater is turned off.
- Insert a new battery before every heating period.
- Dispose of old batteries according to environmental regulations.
- Use only heat-resistant and leak-free batteries (LR 6, AA or AM3)!

1. Remove the heater grille.
2. Push the cover of the battery compartment upward.
3. Replace the battery; ensure correct polarity.
4. Close the battery compartment.
5. Close the heater grille.

### Cleaning

- Prior to every heating period, use a small brush or paint brush to remove the dust accumulated on the heat exchanger, the bottom plate and the fan wheel.

**Hot-air nozzle**

*Fig. 136: Hot-air nozzle, open*

To heat the caravan body, the blower drives hot air through the hot-air piping and expels the air through the hot-air nozzles into the caravan interior.

To regulate the flow of hot air as needed, the hot-air nozzles installed at various points can be manually opened or closed.

- To open and close bring the revolving dampers of the hot-air nozzles into the desired position.

**Floor heater system (optional)**

*Fig. 137: On-Off switch of the floor heating system*

The electric floor heating system (optional) is activated with the On-Off switch (1). It is located above the entrance door. The corresponding transformer is fitted in the bed frame or in the bench.

The floor heating system does not require maintenance.

## Camping

### 6.3.2 TRUMA Combination heater (optional)



Fig. 138: TRUMA Combination heater

The combination heater combines the gas heater and the hot water heater.

The gas heater generates hot air that is distributed in the caravan body via a hot-air pipe system.

The integrated hot water heater supplies the tap at the sink, the washbasin and the shower stall with hot water.

Summer or winter operation is available as an option.

#### Digital TRUMA control unit CP plus




Fig. 139: Digital TRUMA control unit CP Plus

- Central control unit for the TRUMA Combi CP plus ready and a TRUMA air conditioning system
- Boost function for fast hot water supply and heating of the area
- All functions are programmable using the timer
- Individual temperature settings based on the time – for a comfortable and quiet night

It serves as an interface for the operation of connected devices via TRUMA App and iNet Box.

Detailed instructions can be found in the operating manual provided by the manufacturer.

**Display/operating elements**


Fig. 140: Digital TRUMA control unit CP Plus

- 1 Display
- 2 Status line
- 3 Menu line (top)
- 4 Menu line (bottom)
- 5 Indicator mains voltage 230V (utility power)
- 6 Timer display
- 7 Settings/values
- 8 Rotary/push-button
- 9 Back key

Menus in lines (3+4) can be selected with the rotary/push-button (8) and settings made. Output is via a display (1) with illuminated background. The back key (9) is used to jump back from a menu.

**Rotary/push-button**

The rotary/push-button (Fig. 140, Pos. 8) is used to select and change target values and then save them by tapping. Selected menu items flash.



**Rotate in a clockwise direction**

Menu is run through from left to right.

Increasing of values (+)



**Rotate in an anticlockwise direction**

Run through menu from right to left

Lowering of values (-).


**Tapping**

Apply (save) a selected value.

Selection of a menu item, change to the setting level.

**Long press**

Main ON/OFF switching function

If an iNet Box has been detected by a device search, then the function of the rotary/push-button changes (see "APP mode in conjunction with an iNet Box")

Fig. 141: Rotary/push-button

## Camping

### Back key



Fig. 142: Back key

If the back key is pressed, the display jumps back out of a menu and discards the settings. I.e., the existing values remain saved.

More information about configuration can be found in the operating manual provided by the manufacturer.

### Functions




Fig. 143: Setting level display

The functions in the menu lines (Fig. 140, Pos. 3, 4) of the control unit Truma CP plus can be selected in any sequence. The operating parameters are displayed in the status line (Fig. 140, Pos. 2) or in the displays (Fig. 140, Pos. 5, 6).

Select setting level:

- Tap rotary/push-button.

The display shows the setting level. The first symbol flashes.

### Switching on/off

Tap rotary/push-button.

#### NOTICE



*Previously set values / operating parameters are once again active after switching on.*

### Switching off

Press the rotary/push-button for longer than 4 seconds.

#### NOTICE



*After 2 seconds "APP"1 is output to the display. "OFF" is output after a further 2 seconds.*

*The switching off process of the Truma CP plus control panel can be delayed by a few minutes due to internal overruns of heating or air conditioning system.*

1) Only in conjunction with an iNet Box.



**Change room temperature**


Fig. 144: Room temperature symbol

**Heating (HEAT)**

Select the symbol in menu line (3) using the rotary/push-button.

- Change to the setting level by tapping.
- Dependent on the connected device use the rotary/push-button to select between (HEAT)(d), air condition (AC) or automatic climate control<sup>1)</sup> (AUTO)(c).
- Tap rotary/push-button to confirm the selection.
- Select the desired temperature with the rotary/push-button.
- Tap rotary/push-button to confirm the value.

Adjustable temperature range 5 – 30 °C (1 °C steps)

a = heating ) – heating is switched off.

- 1) Automatic air conditioning (AUTO) only if “ACC” has been activated in the service menu (see “Service menu”). This is switched off in the factory.
- 2) Symbol flashes until the desired room temperature is reached.



**Changing the hot water level**


Fig. 145: Hot water level symbol

Select the symbol in menu line (3) using the rotary/push-button.

- Change to the setting level by tapping.
- Use the rotary/push-button to select the desired level.
- Tap rotary/push-button to confirm the value.

- = OFF
- a = Boiler
- b = eco
- c = hot
- d = boost

Water heating is switched off.

Water heating is switched on.

Hot water temperature 40 °C


Hot water temperature 60 °C

Targeted quick heating of the boiler content (boiler priority) for a maximum time window of 40 minutes. Then the water temperature is maintained at a higher level (about 62 °C) for two post-heating cycles, not Combi Diesel. Once the water temperature is reached, heating of the room continues.

## Camping



### Select energy mode



Select the symbol in menu line (3) using the rotary/push-button.

- Change to the setting level by tapping.
- Select the desired energy mode with the rotary/push-button.
- Tap rotary/push-button to confirm the value.

Fig. 146: Energy mode symbol

Symbol	Operating mode	Energy type
a	Gas / Diesel	Gas <sup>1)</sup> / Diesel
b	MIX <sup>2)</sup>	Electrical (900 W) + Gas / Diesel
c	MIX	Electrical (1800 W)
d	EL 1	Electrical (900 W)
e	EL 2	Electrical (1800 W)

1) Gas / diesel power, see instructions for use of the corresponding heater.

2) Mixed and electrical operation. Only possible for heaters with immersion heaters, e.g. Combi E CP plus ready.





**Selecting the fan level**


Fig. 147: Fan level symbol

Select the symbol in menu line (3) using the rotary/push-button.

- Change to the setting level by tapping.
- Select the desired fan level with the rotary/push-button.
- Tap rotary/push-button to confirm the value.

Symbol	Operating mode	Description
-	OFF	Fan is switched off. (can only be selected if no device is operating).
a	VENT <sup>1)</sup>	Recirculation air, if no device is operating and water heating is switched off. Speed selectable in 10 levels.
b	ECO	Low blower level.
c	HIGH <sup>2)</sup>	High blower level
d	BOOST <sup>3)</sup>	Quick room heating is available if the difference between the selected and actual room temperature >10 °C.

**NOTICE**


*As soon as the heating is switched on (room temperature, hot water level set), the status line (2) indicates the fan level selected in the previous heating level. Pre-setting is "ECO".*

1) Can result in higher motor wear, dependent on the frequency of use

2) Fan level "HIGH" is associated with higher power consumption, increased noise level and increased motor wear.

3) Not available with Combi Diesel

## Camping

### Setting the timer

#### WARNING



Risk of poisoning due to exhaust gases.

The activated timer switches the heating on even when the camper van is parked. The exhaust gas from the heating can result in poisoning in enclosed spaces (e.g. garages, workshops).

If the camper van is parked in an enclosed space:


- Shut off the fuel supply (gas or diesel) to the heating.
- Deactivate the timer of the Truma CP plus control unit (OFF).
- Switch off the heating at the Truma CP plus control unit.

#### NOTICE




*During operation of air conditioning systems, only use the timer of the control unit Truma CP plus to clearly specify the start and end time of a desired time interval.  
If the timer is activated (ON), the menu, the Deactivate timer (OFF) menu is first displayed.*

- Select the symbol in menu line (4) using the rotary/push-button.
- Change to the adjustment level by tapping.

**Enter the start time***Fig. 148: 24 h mode display*

- Using the rotary/push-button, set the hours then the minutes.



A = a. m.  
P = p. m.

*Fig. 149: 12 h mode display*

## Camping

### Enter the end time





Fig. 150: 24 h mode display



A = a. m.  
P = p. m.

Fig. 151: 12 h mode display

### Activating the timer (ON)




Fig. 152: Timer display

Using the rotary/push-button, set the hours then the minutes.

### NOTICE



*If the start/end time is exceeded upon entry, the operating parameters are only considered once the next start/end time is reached. Until then, the operating parameters set external to the timer remain valid.*

- Use the rotary/push-button to activate the timer (ON)
- Tap rotary/push-button to confirm the value.

### NOTICE



*The timer remains active, including over a number of days, until it is deactivated (OFF).  
If the timer is programmed and active, the timer symbol flashes.*

**Deactivating the timer (OFF)**


Fig. 153: Timer symbol

- Change to the setting level by tapping.
- Use the rotary/push-button to deactivate the timer (OFF)
- Tap rotary/push-button to confirm the value.



**Switching the lighting on/off**


Fig. 154: Lighting symbol

Available if the air conditioning system is connected

Aventa comfort or Aventa eco

- Select the symbol in menu line (4) using the rotary/push-button.
- Change to the setting level by tapping.
- Select the desired function with the rotary/push-button.
  - Switch on 1 – 5 lighting.
  - Lighting selectable in 5 levels.
  - OFF - switch off lighting.
- Tap rotary/push-button to confirm the value.

## Camping

### Set time




Fig. 155: 24 h mode display

- Select the symbol “Set time” in menu line (4) using the rotary/push-button (8).

The hour display flashes.

- Set the hours using the rotary/push-button (8).
- Press the rotary/push-button (8) again so that the minute display flashes.
- Set the minutes using the rotary/push-button (8).
- Tap the rotary/push-button (8) ■ to confirm the value.




Fig. 156: 12 h mode display


**Service menu**
**Calibrating the heating room sensor (OFFSET)**


Fig. 157: Presetting: 0 °C (Celsius)

The room temperature sensor of the connected heating can be adjusted individually at the sensor installation location. Setting is possible in steps of 0.5 °C in the range 0 °C to -5 °C.

Example:

Set room temperature 23 °C, OFFSET = -1 °C;

-Heating target value = 22 °C

**Fault**


Fig. 158: Fault

In the event of a fault the Truma CP plus control panel immediately jumps to the "Fault" menu level. The cause of the fault can be determined and rectified with the aid of the troubleshooting guides.

E = Fault

112 = Error code

H = Device

H = Heating

A = Air conditioning system

**NOTICE**


Contact a specialist workshop!

## Camping

### 6.3.3 ALDE- heater (optional)

#### Liquefied gas operation

1. Select "Liquefied gas mode" at the operating unit.
2. Open the gas shut-off valve for the heater.
3. Start the heater.

When you start the heater, the system automatically ignites the burner,

#### NOTE



*The heater is active until the set temperature has been reached. If the flame dies within this time, the system automatically restarts after approximately ten seconds.*

#### Operation with electric heater cartridge

1. Connect to a 230 V mains supply.
2. Select "Electric heating mode" and any available heating level at the operating unit.

The heater starts automatically at 230 V.

#### NOTE



*For a faster heating of the vehicle, operate the system with gas and power at the same time. Electric operation will always have priority.*

#### Check and replenish the expansion tank.




Fig. 159: Expansion tank

The filling level in the sight glass (1) of the expansion tank must be between "Min" and "Max" on cold state and may be slightly above "Max" in warm state.

The expansion tank must not run empty, otherwise, the heating system must be vented.

If the level falls below the "Min" mark, refill the tank as follows (recommended: Aluminium cooler antifreeze by Ravenol):

- Mixing ratio for ALDE heater: 50% water/50% glycol
- Mixing ratio for convection heating: 60% water/40% glycol



## Operating the ALDE control unit

### NOTE



- Switch off the heating system's main switch when the vehicle is not used.
- Don't splash water directly at the exhaust chimney when you wash the vehicle.
- When camping in winter, ensure that the exhaust chimney and the inlet and discharge valves are kept free of snow and ice.
- You can heat the heating system without having filled the hot water boiler with fresh water.
- You can operate the gas boiler and the electric heater at the same time.
- Always drain the fresh water from the hot water boiler when there is a risk of freezing and the vehicle is not used.
- The liquefied gas heater must not be in operation when you refuel the vehicle within a garage or similar environment.
- Never permit the heating system to be at standstill without glycol solution.

### Starting the heater



Fig. 160: OFF



Fig. 161: ON

1. The operating unit and the heater are switched off.
2. Press the On/Off button to start the heater. The start screen appears. The heater starts with the last used settings.

## Camping

### Idle position



Fig. 162: Control elements

- A Clock.** The clock displays date and time (if activated). For its setting, please see the ALDE operating manual.
- B Outside temperature\*.** The outside temperature is displayed.
- C Interior temperature.** The interior temperature is displayed.
- D Recirculating pump.** This symbol is displayed when the recirculating pump is operating.
- E Automatic start of the heater.** This symbol is displayed when the function has been activated.
- F Day automatic.** This symbol is displayed when the function has been activated and the time is within the set period.
- G Liquefied gas bottle full/empty\*.** This symbol is displayed when the sensor at the gas regulator is connected to the bottle and activated. If "Eis-Ex" is installed, the symbols for the set mode is shown with the bottle symbol.
- H Night automatic.** This symbol is displayed when the function has been activated and the time is within the set period.
- I 230 Volt.** This symbol is displayed when 230 V voltage is applied to the heater.
- J On/Off button.** Main switch for the heater.
- K MENU button.** Button to open the Settings menu.

The functions identified with (\*) are optional.

### Settings menu



Fig. 163:  
Operating unit in  
idle state



Fig. 164:  
Operating unit  
with Settings  
menu

1. Press the MENU button to open the Settings menu.
2. The background illumination activates and the adjustable functions are displayed.

The operating unit switches to idle if you don't touch the screen within 30 seconds.

### Setting the required temperature



Fig. 165: Temperature setting

You can set the temperature in increments of 0.5 °C between +5 °C and +30 °C. You cannot adjust the temperature if the day or night automatic are active. The plus and minus symbols are displayed in grey.

1. The displayed temperature is the one set at this point.
2. Press "+" to raise the temperature. Press "-" to lower the temperature.
3. The settings are completed and the heating system will operate until the set temperature is reached.

### Hot water

The heating system features a built-in hot water boiler with a volume of approximately 8.5 litres. You can use the hot water boiler even when you have no fresh water in the boiler. You have three options in the heater settings for setting the heater in respect to hot water requirements: "No hot water", "Normal mode" or "More hot water".

- **No hot water.** If you don't need hot water, press "-" (the symbol empties).

You cannot adjust the temperature if the day or night automatic is active and hot water is switched off. The plus and minus symbols are displayed in grey.



Fig. 166: No hot water

## Camping



Fig. 167: Normal mode



Fig. 168: More hot water

- **Normal mode.** If fresh water is added and you want hot water, press "+" (the symbol is filled to the middle).

You cannot select this function if the pump is in continuous operation mode.

- **More hot water.** If more hot water is required, the water temperature can be temporarily increased to approximately 65 °C. Press "+" until the symbol is completely filled (black). The heater returns to normal operation after 30 minutes. The circulation pump does not run during heating.

If the pump is in continuous operation mode, the system disable the "continuous pump mode" function for 30 minutes. After this time has elapsed, the "continuous pump mode" is reactivated.

### NOTE



*If you only need hot water, for example, during summer operation when you don't need to heat, you don't need to adjust the settings. The heating system regulates this function automatically.*

### Heating with gas



Fig. 169: Heating with gas

If you select electricity and gas at the same time, you can set the priority for either electricity or gas (see the ALDE operating manual).

1. Press the "liquefied gas flame" symbol to start the gas mode. The symbol for liquefied gas becomes active and changes to green.
2. The heater operates until the set temperature is reached.
3. Press the "liquefied gas flame" symbol again to end the gas mode. The symbol for liquefied gas is deactivated and changes to blue.

### Heating with electricity



Fig. 170: Heating with electricity

The higher the selected capacity, the faster the heating process. If you select electricity and gas at the same time, you can set the priority for either electricity or gas (see the ALDE operating manual).

1. Start and incrementally change the various heating levels (Off, 1 kW, 2 kW or 3 kW) with "+" or "-". The set value is displayed on the screen. Upon activation, the plus sign is shown in green. If the load monitor function\* is installed and set, the heater will not use any more electricity as required, even if you have selected 3 kW.
2. The heater operates at the set temperature.
3. Press "-" until "Off" appears to switch off the electric heating mode.

### Activated functions



Fig. 171: Idle position



Fig. 172: Activated functions

Press "A" to display the individual activated functions. You can now select an individual function to change the settings.

The "A" symbol is only visible when you have activated and/or installed a particular function.

## Camping

### Tools menu



Fig. 173: Tools menu

Open the Tools menu from the Main menu. In the Tools menu, you can change the remaining functions of the operating unit.

- Click the "wrench" symbol in the Settings menu to open the Tools menu.

### NOTE



*For additional functions of the operating unit, please see the separate ALDE manual.*

### ALDE control knobs



Fig. 174: ALDE control knobs

Two control knobs for the ALDE heater are installed in the sleeping area.

The heater's temperature is controlled with the operating unit. However, using the control knobs as an extension of the operating unit, you can variably regulate the heating capacity of the floor heater and the heater in the sleeping area.

### 6.3.4 Water heater

#### ATTENTION



##### Damages after extended stand time or frost!

If the vehicle is not used in winter, the sanitary system may be damaged due to frost.

Extended stand times can cause algae growth in the sanitary system.

- Ensure that the overflow valve is free from contamination and ice formation.
- In the event of frost or extended stand time, completely empty the water tanks, containers, hoses, and conduits. Dry-run the pump for approximately five minutes to avoid frost damage caused by residual water in the pump.

#### NOTE



*Frost damage or contamination caused by algae growth in the water system are not covered by the guarantee!*

#### Mixer tap



Fig. 175: Mixer tap

#### WARNING



##### Danger of scalding due to hot water!

Hot water can scald hands and other body parts.

- Open the mixer tap in cold-water position and carefully raise the temperature.

1. To obtain water, turn the lever in direction of the cold-water setting (blue mark), lift upward, and slowly shift in direction of the red mark.
2. To close, turn the mixer lever in direction of the blue mark and push downward.

## Camping

### 6.3.4.1 TRUMA heater and TRUMA water heater system




Fig. 176: Drain valves

#### Filling the hot water heater

1. Fill the cold water tank (→ "Filling with cold water").
2. Turn on main switch (power supply).
3. Close cold and hot water drain valves.
4. Open mixer tap in kitchen or bathroom in "hot water" position.
5. Close mixer tap as soon as water starts running.

#### NOTE



*After filling the hot water heater, cold water will be released from the mixer tap at first because the water is not yet heated.*

#### Emptying the hot water heater

If there is danger of frost or the fresh water system is not in use, drain water as described below:

1. Turn off the hot air blower of the gas heater.
2. Turn off the electric heater of the hot water heater.
3. Turn off main switch (power supply).

#### WARNING



#### **Danger of scalding due to hot water!**


When emptying the hot-water heater, hot water can escape and may cause severe scalding injuries on hands and skin.

- Prior to draining the water from the hot water heater, cool water to ambient temperature.

4. Open the drain valves.
5. Drain fresh water (→ "Draining fresh water").



### Operating the hot water heater



*Fig. 177: On-Off switch of the water heating system*

The water heating system (SW) is activated with the On-Off switch (1). It is located above the entrance door.

The water heating system does not require maintenance.

#### 6.3.4.2 Applicable if the TRUMA combination heater is installed

1. Close the freshwater tank valve.
2. Fill fresh water tank.
3. Close valves for cold and hot water pipes, see safety drain valve.
4. Fill the boiler. Turn the mixer lever of the mixer tap in direction of the hot water setting (red mark) and pull upward. Cold water is pumped from the fresh water tank into the boiler.
5. Close the mixer lever after all air has been expelled from the water pipe and cold water flows.
6. Start the heater.

Hot water will be available after approximately 30 minutes.

## Camping

### Digital TRUMA control unit CP plus




Fig. 178: Digital TRUMA control unit CP Plus

- Central control unit for the TRUMA Combi CP plus ready and a TRUMA air conditioning system
- Boost function for fast hot water supply and heating of the area
- All functions are programmable using the timer
- Individual temperature settings based on the time – for a comfortable and quiet night

It serves as an interface for the operation of connected devices via TRUMA App and iNet Box.

Detailed instructions can be found in the operating manual provided by the manufacturer.

### 6.3.4.3 With installed ALDE heater (optional)




Fig. 179: Closed drain valves

1. Close the freshwater tank valve.
2. Close valves for cold and hot water pipes.
3. Close the combined drain valve.
4. Fill fresh water tank.
5. Fill the boiler. Turn the mixer lever of the mixer tap in direction of the hot water setting (red mark) and pull upward. Cold water is pumped from the fresh water tank into the boiler.
6. Close the mixer lever after all air has been expelled from the water pipe and cold water flows.
7. Start the heater.

Hot water will be available after approximately 30 minutes.

## 6.4 Sitting and sleeping

### 6.4.1 Converting the sitting area

The layout of the sitting area depends on the selected model. By lowering the table, you can create additional sleeping spaces.



Fig. 180: Table, rectangular

#### Lowering a table with support leg

1. Push the sliding bush (1) upward and fold the lower part of the table leg (2).
2. Tilt the table top upward and lift from the wall rail (3).
3. In tilted position, hang the table top in the lower wall rail (4).
4. Tilt the table top forward until the folded leg is securely placed on the floor.




Fig. 181: Table with table lift frame

#### Lowering a table with lift frame

1. Turn handle (1) counter-clockwise and hold to unlock the folding mechanism.
2. Push the table top (2) downward.
3. After latching the lower position, release the handle (1).

## Camping

### "Ilse-Lift" lifting frame (optional)




Fig. 182: "Ilse-Lift" lifting frame

#### Functions:

Lowerable single leg table foot

Rotating table plate

#### Raising the table

- Swivel operating lever (2) through 180 degrees.  
The table automatically raises to its normal position.  
Once the desired height of the tabletop is reached, lock the operating lever again

#### Rotating the tabletop

- After loosening the knurled screw (1) the tabletop can be rotated and aligned.  
(Only if the lifting table is extended)  
The knurled screw must be tightened again after aligning the tabletop.

#### Lowering the table

- Before lowering the table, swivel it back into the home position.  
After swivelling, re-tighten the knurled screw.  
Then activate the operating lever (2) to lower the table.
- Swivel the operating lever (2) through 180 degrees and simultaneously push the tabletop downward.  
Once the desired height of the tabletop is reached, lock the operating lever again.

**“Click-clack” lifting frame (optional)****Functions:**

Lowerable single leg table foot

Rotating table plate

**Raising the table**

- Raising of the table by pressing the table plate twice (pressing releases the lock = click, pressing down = clack)

**Swivelling the table plate**

- Swivel the table plate by undoing the knurled screw below the table

**Lowering the table**

- Lowering or raising of the table by pressing the table plate twice (pressing releases the lock = click, pressing down = clack)



Fig. 183: “Click-clack” lifting frame

## Camping

### 6.4.2 Folding console as bed extension



Fig. 184: Folding console as bed extension

Depending on the model, a folding console may be installed as an extension of the bed.




Fig. 185: Undoing the latching mechanism

#### Folding the folding console

- Push both latches (1) upward at the same time and fold the console downward.

#### Opening the folding console

- Lift the folding console upward until both latches (1) have latched.

### 6.4.3 Sitting group conversion to a sleeping area



*Fig. 186: Round sitting group*

The free surfaces must be padded out with additional (optional) cushions to provide a continuous sleeping surface.



*Fig. 187: Round seating group with filling cushions*

The round seating group is padded out with additional (optional) cushions.

## Camping

### Dinette with hook-in table




*Fig. 188: Table with hinged table foot*



*Fig. 189: Table foot folded in*

Raise table, fold in hinged table foot.



*Fig. 190: Hook table into lower rail.*

Raise the table further until it can be taken out of the upper rail and hook back into the lower rail.





Fig. 191: Sleeping area with cushions.

Pad out the free surface with additional cushions (optional).

Pull the seat cushion out to the table and turn over a back cushion to obtain a closed sleeping surface.

Disassembly back to the seating group takes place in the reverse sequence.

#### **6.4.4 Setting up the lighting**

Depending on the selected model and equipment, the living and sleeping areas are fitted with various types and different number of lamps, e.g., spotlights, light strips or LED battery lights.

##### **Adjusting the brightness**

The brightness of the ceiling lights can be adjusted as required.

- Press the light buttons on the multifunction switch and hold until the desired brightness is set.
- To simply switch the lights on/off without regulating brightness, briefly press the respective light button once.
- Maintain the ON/OFF switch of the LED battery light depressed until the desired brightness is set.

##### **Switching the bathroom and kitchen light**

Bathroom and kitchen lights have their own ON/OFF switches in the vicinity of the respective lamps.

These light fixtures cannot be switched from the multifunction switch and have a fixed brightness.

## Camping

### Relocating the LED battery lights



Fig. 192: LED battery light relocation

In the living and sleeping areas there are magnetic holders attached beneath the wall cupboards so that the lights can be docked there. Alternatively, the LED battery lights can be swivelled so that they can be used as a table light.

#### NOTE



- The LED battery lights must be docked above the sitting area for charging
- Red LED = Charging running
- Green LED = 12V LI-ION battery is fully charged
- The batteries must be recharged at least every six months - otherwise they will have to be replaced
- Take off the LED battery lights prior to setting off and stow safely

#### NOTE



- Dispose of old batteries environmentally

## 6.4.5 Opening and closing the pop-up roof

### Safety instructions

#### DANGER



##### Life-threatening danger due to lightning!

During a thunderstorm, any persons in the pop-up roof can suffer life-threatening injury.

- Never stay in the pop-up roof during thunderstorms.

#### WARNING



##### Danger of injury due to falling!

When sleeping, playing, or if they are in the pop-up roof unattended, small children can fall through the passage and suffer broken limbs and permanent bodily injury.

Persons with limited mobility can fall when climbing up and climbing down or can injure themselves in the hinged pop-up roof.

- The pop-up roof is not suited for unsupervised use by children under six years.
- Persons with limited mobility should avoid using the pop-up roof.

#### CAUTION



##### Health damages due to exhaust gases!

In adverse wind conditions, the heating system's exhaust gases may be drawn into the sleeping area.

- Close all tent windows when operating the heater.

#### ATTENTION



##### Risk of fire due to the ceiling light

The ceiling light may scorch the interior furnishings.

- Turn off ceiling light after every use.

## Camping

### Care tips

#### NOTE



*Thoroughly vent the roof bellows several times during the season, to prevent stagnant moisture and musty odour.*

*Do not fold the pop-up roof in damp or wet condition immediately after rainfall, for example.*

*Prior to longer breaks in use, remove the bed pad from the pop-up roof to avoid stagnant moisture and mildew.*

### Opening the pop-up roof

#### ATTENTION



##### **Risk of damage to the pop-up roof!**

Sharp-edged and pointed objects may cause rents, dents or holes in the pop-up roof and rip the expansion bellows during unfolding.

- Before unfolding, check that no roofs, eaves, masts, pipes, overhead wires, signs, trees, branches or other objects may touch the unfolded roof.

#### ATTENTION



##### **Risk of damage to the expansion bellows!**

The unfolded pop-up roof offers a large target for winds and gusts. Strong winds at the coast or in the mountains for example, can rip the expansion bellow and damage the pop-up roof.

- Always park the vehicle with the wind and the lower roof side facing the wind direction.
- Ensure that the pop-up roof is closed whenever you leave the vehicle, or in case of stormy weather.




Fig. 193: Opening the pop-up roof




Fig. 194: Locking mechanism (1) of the access ladder

1. Park the vehicle in a position appropriate to the prevalent wind situation.
2. Remove any loads on the roof.
3. Open the access hatch.
4. Assemble both parts of the access ladder and interlock the components (Fig. 194/1).
5. Hang the access ladder in the corresponding rail (Fig. 193/2) in the access and solidly anchor on the floor.
6. Open the roof latches (Fig. 193/1).

### ATTENTION



#### Risk of damage to the roof canopy!

The roof canopy may be damaged when the pop-up roof is pushed up.

- Never press against the roof canopy!

7. Carefully push the rod at the rope against the GFRP shell until the pneumatic springs automatically lift the pop-up roof.
8. Always close the access hatch from above when sleeping in the pop-up roof.
9. Do not touch the interior of the expansion bellows or place objects against them (such as bedding) as water may permeate.

## Camping

### Folding the pop-up roof




Fig. 195 Pulling rope (1), Expansion bellows (2)




Fig. 196 Loops (1)




Fig. 197: Roof locking mechanisms



Fig. 198: Access hatch

1. Fully close the venting windows and zips.
2. Open the roof canopy to prevent overpressure in the pop-up roof during the folding process. This would push the expansion bellows to the outside.

### CAUTION



#### Risk of injury when exiting!

Jumping from the pop-up roof may cause injuries due to breaking objects.

- Never jump from the pop-up roof to the floor or climb down without checking where you step.
- Do not step on furniture or the covers of the hob or sink.
- Always use the access ladder to exit the pop-up roof.

3. Before closing the pop-up roof, remove any items that could put pressure onto the roof shell (blankets, sleeping bags, clothing, etc.) and leave the pop-up roof.

### ATTENTION



#### Risk of damage to the expansion bellows!

When folding, the expansion bellows may be pinched between objects and damaged.

- Always ensure during folding that the expansion bellows properly fold to the inside and is not pinched between the outer edges of the pop-up roof, pneumatic springs, chassis components or between the roof locking mechanisms.
4. From the access ladder, use the pulling rope (Fig. 195/1) to slowly pull the pop-up roof down. Very carefully use the lateral loops (Fig. 196/1) to pull the expansion bellows to the inside and ensure no pinching of the bellows between objects and components.
  5. Look around the vehicle's exterior to ensure that the bellows nowhere hangs outside.
  6. Securely brace the pop-up roof with the roof locking mechanisms (Fig. 197/1).
  7. Stow the access ladder and pulling rope; and close the access hatch (Fig. 198).

## 6.5 Bathroom

### 6.5.1 Using the shower and washbasin

The shower and washbasin are supplied by the heating system or a hot water boiler (optional).

- Activate the mixer tap to draw hot water.

### 6.5.2 Flushing the toilet with fixed installed toilets (optional)



1. Before flushing, open the slide gate of the waste holding tank. Pull the lever (3) forward.
2. Press the blue push-button (1) to flush.
3. After flushing, push the lever (3) backward to close the slide gate of the waste holding tank.
4. Monitor the filling level on the display (2), empty if required.

Fig. 199: Cassette toilet

## Camping

### Emptying the waste holding tank



Fig. 200: Waste holding tank in the disposal shaft




Fig. 201: Emptying the waste holding tank

#### NOTE



The waste holding tank must be emptied at the latest when the fill level indicator next to the flushing button is illuminated.

Completely empty the holding tank if there is danger of freezing and the caravan superstructure is not heated.

#### NOTE



Faeces and chemicals harm the environment.

- Drain the waste holding tank only at the designated disposal stations.

1. Close the slide gate at the toilet bowl.
2. Open the sanitary compartment at the outside of the caravan body.
3. Press the coloured bracket (1) and use the handle (2) to pull the tank from the disposal shaft.
4. At a designated disposal station, swivel the discharge pipe (3) to the side and unscrew the cap (4).
5. Press and hold the coloured button (5) of the venting valve and empty the waste holding tank.
6. Use fresh water to clean the tank, replace the cap on the discharge pipe and return the pipe to its position.
7. Push the waste holding tank into the disposal shaft until the bracket latches.
8. Lock the sanitary compartment.
9. Refill with new sanitary fluid.



### 6.5.3 Flushing the toilet with revolving toilets (optional)



*Fig. 202: Pivoting toilet*

1. Manually rotate the toilet seat in closed state into the desired position.
2. To flush, turn the lever (1) at the toilet bowl side counter-clockwise.
3. Push the flushing button (2). The operating panel is activated.
4. Push again the flushing button (2).
5. After flushing, turn the lever (1) clockwise.

## Camping



Fig. 203: Waste holding tank in the disposal shaft




Fig. 204: Emptying the waste holding tank

### NOTE



The waste holding tank must be emptied at the latest when the fill level indicator next to the flushing button is illuminated.

Completely empty the holding tank if there is danger of freezing and the caravan superstructure is not heated.

### NOTE



Faeces and chemicals harm the environment.

- Drain the waste holding tank only at the designated disposal points.

1. Close the slide gate at the toilet bowl.
2. Open the sanitary compartment at the outside of the caravan body.
3. Use the handle (1) to remove the waste tank from the disposal shaft.
4. At a designated disposal station, swivel the discharge pipe (2) to the side and unscrew the cap (3).
5. Press and hold the coloured button (4) of the venting valve and empty the waste holding tank.
6. Use fresh water to clean the tank, replace the cap on the discharge pipe and return the pipe to its position.
7. Push the waste holding tank into the disposal shaft until the bracket latches.
8. Lock the sanitary compartment.
9. Refill with new sanitary fluid.

### NOTE



Emptying of the DOMETIC waste holding tank takes place in the same way.

## 6.6 Kitchen area

### 6.6.1 Using the gas hob

#### WARNING



##### Burn injuries due to open gas flame!

Improper operation can cause injury.

- Prior to operation, open the kitchen window.
- Never let gas escape without igniting.
- Do not use the gas hob to heat the caravan interior.

#### Minimum and maximum pot sizes




Fig. 205: Pot sizes

#### ATTENTION



##### Risk of fire due to oversized pots!

Using oversized pots can cause overheating and thus a heightened risk of fire.

- Place the pots and pans centred above the burner.
- Used pots and pans must not be larger than the pan stand on top of the burner.
- The sticker on the glass plate provides information about the permissible pot sizes.

#### NOTE



- *This device must be only operated with liquefied gas.*
- *Use only the specified gas pressure.*
- *This device is approved solely for the use with propane or butane gas.*
- *We recommend to use propane with this device.*
- *Using butane may lower the device output if the ambient temperature is less than 10 °C.*
- *Do not use butane if the ambient temperature drops below 5 °C.*
- *This device must be earthed.*

## Camping

### Cooking




Fig. 206: Gas hob

The gas hob is under a safety glass panel.

1. Lift the glass plate.
2. Open the gas bottle valve and open the "Hob" quick-action valve.
3. Press and turn the regulator knob of the required burner in the operating panel (1) and keep pressed.
4. Press the ignition switch (2) several times until the gas ignites.
5. Keep the regulator knob pressed for an additional 10-15 seconds before releasing it.
6. Use the regulator knob to adjust the gas flame to the required level. Do not push the knob when adjusting.
7. After cooking, turn the regulator knob to "0".

#### NOTE



*After the flame extinguishes, the safety pilot valve automatically blocks the gas supply.*

8. Close the "Hob" quick-action valve and the gas bottle valve.
9. Wait until the hob has cooled down, clean, and cover with the glass plate.

## 6.6.2 Using the combination ceramic hob

### WARNING



#### Burn injuries due to open gas flame!

Improper operation can cause injury.

- Prior to operation, open the kitchen window.
- Never let gas escape without igniting.
- Do not use the gas hob to heat the caravan interior.

### Minimum and maximum pot sizes




Fig. 207: Pot sizes

### ATTENTION



#### Risk of fire due to oversized pots!

Using oversized pots can cause overheating and thus a heightened risk of fire.

- Place the pots and pans centred above the burner.
- Used pots and pans must not be larger than the pan stand on top of the burner.
- The sticker on the glass plate provides information about the permissible pot sizes.

### NOTE



- *This device must be only operated with liquefied gas.*
- *Use only the specified gas pressure.*
- *This device is approved solely for the use with propane or butane gas.*
- *We recommend to use propane with this device.*
- *Using butane may lower the device output if the ambient temperature is less than 10 °C.*
- *Do not use butane if the ambient temperature drops below 5 °C.*
- *This device must be earthed.*

## Camping

### Cooking



Fig. 208: Combination cooker




Fig. 209: Settings of the operating elements:  
OFF, High flame, Low flame

The gas hob is under a safety glass panel.

1. Lift the glass plate. The separate glass plate of the sink can remain closed.
2. Open the gas bottle valve and the "Hob" quick-action valve.
3. Press the button and turn counter-clockwise to the highest level (high flame).
4. Press the button further and hold a burning match or barbecue lighter against the burner. In models with automatic ignition, the procedure is similar, except for the automatic ignition when the button is pressed. In models with manual ignition, the procedure is similar, except that you must press the ignition button on the front plate to ignite the burner.
5. After ignition, keep the button pressed for another 10 to 15 seconds.
6. Release the button and use the regulator to adjust the gas flame to the required level. Do not push the regulator when adjusting.
7. If the burner does not ignite within 15 seconds, release the button and wait for at least one minute before you repeat steps (3) to (6).
8. To shut down, turn the button until the line on the button is aligned with the dot at the control panel.

### NOTE



After the flame extinguishes, the safety pilot valve automatically blocks the gas supply.

9. Close the "Hob" quick-action valve and the gas bottle valve.
10. Wait until the hob has cooled down, clean, and cover with the glass plate.

### 6.6.3 Folding console to extend the kitchen counter-top



Fig. 210: Folding console to extend the kitchen counter-top

Depending on the model, a folding console may be installed as an extension of the kitchen counter-top.




Fig. 211: Undoing the latching mechanism

#### Opening the folding console

- Lift the folding console upward until both latches (1) have latched.

#### Folding the folding console

- Push both latches (1) upward at the same time and fold the console downward.

### 6.6.4 Using the oven with grill function (optional)

The baking oven with grill (optional) is installed on special request.

#### WARNING



#### Risk of burns due to hot oven!

A hot oven can cause burn injuries.

- Never touch hot surfaces. Keep children away.
- Always open the door when igniting the oven.
- When grilling, remove the heat protection shield and keep the door slightly ajar.

## Camping

### Baking



Fig. 212: Oven with grill

1. Open the gas bottle valve and the "Oven" quick-action valve.
2. Open the oven door.
3. Turn the operating knob to 240 °C, push and keep pushed.
4. Quickly press the ignition button with the lightning symbol several times, until the flame ignites in the oven space.
5. Keep the operating knob depressed for an additional 10-15 seconds, then release it. If the burner does not ignite, wait for at least 1 minute before the next ignition attempt.
6. Slide in the oven rack and close the oven door.
7. Turn the operating knob to 180 °C and preheat the oven for approx. 10 minutes (full heat will be obtained after 15-20 minutes).
8. Place the food to be baked in the oven, close the oven door, and select the baking temperature on the operating knob.
9. After baking, turn the operating knob to "0".
10. Use pot holders or oven gloves to remove the baked goods out of the oven; let the oven cool down.

### Grilling



Fig. 213: Heat protection shield

1. Open the gas bottle valve and the "Oven" quick-action valve.
2. Open the oven door and pull the heat protection shield from below the operating panel.
3. Press and turn the operating knob with the symbol for "top heat" (= grill operation) and keep pressed.
4. Quickly press the ignition button with the lightning symbol several times, until the flame ignites in the oven space.
5. Keep the operating knob depressed for an additional 10-15 s, then release it. If the burner does not ignite, wait for at least one minute before the next ignition attempt.
6. Place the food in the oven, fold up the door and leave slightly ajar.
7. Select the required temperature at the operating knob.
8. After grilling, turn the operating knob back to the "0" position.
9. Use pot holders or oven gloves to take the grilled food from of the oven, and let the oven cool down.



### 6.6.5 Using the Thetford refrigerator (optional)

#### NOTE



Prior to first use and cleaning, and when parking for longer periods (e.g. winter break) read the accompanying operating manual provided by the manufacturer of the refrigerator!

#### Overview




Fig. 214: Thetford Model A refrigerator

The refrigerator can be operated with 12V, 230V or with gas.

- To prevent discharging the supply battery, do not use the 12V battery when the engine is running.
- Gas ignition at altitudes higher than 1000 m above sea level may be disturbed - this is not a malfunction but a reaction to changed pressure levels.
- The refrigerator works trouble-free at inclines to approximately 5°.
- Attach the winter cover for winter operation.
- To open, press the door lock (2) on the upper edge of the refrigerator door downward and swing the door open.

#### LED operating panel (1)

- A ON-OFF switch
- B Operating button
- C Arrow buttons
- D Power source symbols
- E Cooling level indicators
- F "Anti-condensation" symbol (only Model B)
- G "Batteries empty" symbol (optional)




Fig. 215: LED operating panel

## Camping

### Activating the refrigerator

1. Press the ON-OFF switch (A) for one second. The integrated lamp illuminates green.
2. The LED operating panel dims after ten seconds. The green lamp indicates that refrigerator is operating.

### Selecting the power source

1. After activating the refrigerator, press the operating button (B) for two seconds. The power source symbols (D) are flashing.
2. Select the desired power source by pressing the arrow buttons (C).
3. Press the operating button (B) to confirm your selection.

### Selecting the cooling level

1. After activating the refrigerator, press the operating button (B) for two seconds. The power source symbols (D) are flashing.
2. Press again the operating button.
3. The cooling level indicators (E) are flashing. Select the desired cooling level by pressing the arrow buttons (C).
4. Press the operating button (B) to confirm your selection.

### On the road

Close the refrigerator and push against the refrigerator door to automatically lock the door. The door lock (1) also secures the door during the drive.

#### NOTE



*Ensure that all objects in your refrigerator are well secured against shifting. Secure bottles in the door with the bottle holder (3) and ensure that foodstuff in the shelves is fastened.*

### Deactivating the refrigerator

- Press the ON-OFF switch (A) for two seconds. All lamps at the LED operating panels extinguish.

## 6.6.6 Using the Domestic refrigerator (optional)

### General



Fig. 216: Opening the refrigerator

The refrigerator can be operated with 12V, 230V or with gas.

- To prevent discharging the supply battery, do not use the 12V battery when the engine is running.
- Gas ignition at altitudes higher than 1000 m above sea level may be disturbed - this is not a malfunction but a reaction to changed pressure levels.
- The refrigerator works trouble-free at inclines to approximately 5°.
- Attach the winter cover for winter operation.
- To open, press the push element on the upper edge of the refrigerator door downward and swing the door open.
- Prior to first use and cleaning, and when parking for longer periods (e.g. winter break) read the accompanying operating manual provided by the manufacturer of the refrigerator!

### Activating the refrigerator with automatic ignition

#### Control elements

- 1 Energy selector switch
- 2 Fault display
- 3 Mode display
- 4 Temperature level display
- 5 Temperature level button




Fig. 217: Control elements on the refrigerator with automatic ignition

#### Electrical operation

1. Press the energy selector switch (1) for approx. two seconds.
2. Press the energy selector switch (1) several times until the operating mode display (3) shows battery or mains operation.
3. Press the energy selector switch (5) several times until the temperature level indicator (4) shows the desired cooling level.



## Camping

---

### Gas operation

1. Open the glass bottle valve.
2. Open the quick-action valve for the refrigerator.
3. Press the energy selector switch (1) for approx. two seconds.
4. Press the energy selector switch (1) several times until the operating mode display (3) shows gas operation.
5. Press the energy selector switch (5) several times until the temperature level indicator (4) shows the desired cooling level.

### Switching off the refrigerator

1. Press the energy selector switch for approximately two seconds.
2. Press in the closing fixture of the door locking mechanism and slide it forward. This causes the refrigerator door to remain slightly open when it closes and prevents mould growth.

After gas operation:

3. Close the quick-action valve for the refrigerator.
4. Close the gas bottle valve.

### NOTE




*Prior to parking for longer periods of time (e.g. for the winter break), attach the winter covering.*

---

**Switching on the refrigerator with manual ignition****Control elements**

- 1 Energy selector switch
- 2 Temperature level regulator
- 3 Ignition knob
- 4 Gas operation display



*Fig. 218: Control elements on the refrigerator with manual ignition*

**Electrical operation**

1. Switch the energy selector switch (1) to mains operation or battery operation.
2. Press the temperature level regulator (2), turn it to the desired cooling level and release it.

## Camping

### Gas operation




Fig. 219: Changing the batteries of the battery igniter (only if present)

1. Open the glass bottle valve.
2. Open the quick-action valve for the refrigerator.
3. Switch the energy selector switch (1) to gas operation.
4. Press the temperature level regulator (2), turn it to the desired cooling level and keep it depressed.
5. To ignite, press the ignition knob (3).

#### NOTE



*Some refrigerator models are equipped with a battery igniter. If there is no ignition, check the polarity of the battery or replace the battery (→ chapter "Faults", section Refrigerator).*

6. After ignition, keep the temperature level regulator (2) depressed for approximately 15 seconds before releasing it.

### Switching off the refrigerator

1. Set the energy selection switch to the OFF position in refrigerators with manual ignition.
2. Press in the closing fixture of the door locking mechanism and slide it forward. This causes the refrigerator door to remain slightly open when it closes and prevents mould growth.

After gas operation:

3. Close the quick-action valve for the refrigerator.
4. Close the gas bottle valve.

#### NOTE



*Prior to parking for longer periods of time (e.g., winter break), attach the winter covering.*

## 7 Maintenance

### 7.1 Exterior cleaning

#### NOTE



*Acrylic glass window panes are very sensitive and require special care.*

*Only clean wet with a clean sponge or soft cloth.*

*Avoid using chemical cleaning agents, glass cleaner and other aggressive cleaners.*

*Use special acrylic glass cleaner for stubborn stains.*

1. Prior to cleaning the vehicle, close all doors, windows, and skylights.
2. Apply a weak water jet to the entire caravan at an approved vehicle washing facility.
3. Wash the vehicle with a soft sponge and mild shampoo solution and rinse with water.
4. Dry the caravan (e.g. with a chamois); remove, in particular, moisture on lamp holders, window frames, etc.
5. Treat the surfaces with a suitable preserving agent.

#### NOTE



*Because GFRP surfaces age faster than coated surfaces, they may become dull and attract moss and algae growth. For this reason, GFRP surfaces must be polished and sealed with wax at least once year to be protected against UV light and ageing. Suitable polishes and sealants are available from specialist distributors for camping and water sports products.*

6. Plastic parts such as bumpers and skirting panels should be cleaned with off-the-shelf, non-aggressive plastic cleaning agents.
7. Apply a rubber care agent (talcum for example) to rubber door and window elements.
8. Grease door hinges, stabilisers and joints as needed.

## Maintenance

---

### 7.2 Interior cleaning

1. Use standard, non-aggressive household cleaning and care products for the interior and floor.
2. Wipe off furniture surfaces with a damp cloth, use furniture polish if necessary.
3. Vacuum off the upholstery or clean it carefully with a mild foam cleaner. Do not wash.
4. Thoroughly rinse and disinfect the fresh water tank and fresh water lines, empty and clean the waste water tank.
5. Use designated non-abrasive steel cleaners to clean the sink and hob to avoid scratching.
6. Use designated plastic cleaning and care products to clean plastic parts such as shower and washbasin.
7. No aggressive cleaning agents containing solvents or alcoholic substances should be used to clean the 3D thick edges in the furnished area.

### 7.3 Pop-up roof (optional)

#### Care tips for the hinged pop-up roof

- Treat the roof bellows with an off-the-shelf impregnating agent each year before the start of the season.
- Thoroughly vent the roof bellows several times a year, to prevent stagnant moisture and musty odour.
- Do not fold the pop-up roof in damp or wet condition immediately after rainfall, for example.
- Rub a suitable separating agent (e.g. talcum) into the sealing rubber on the roof shell before winter, so that the sealing rubber does not freeze to the vehicle body in freezing temperatures.
- Treat the roof shell with GRP polish.
- Check the strap bands of the roof locking mechanism for faultless condition and function before each trip. Replace torn belt straps before starting the trip.
- Prior to longer periods of non-use, remove the bed pad from the hinged pop-up roof to avoid stagnant moisture and rotting.



---

## 7.4 Supply battery (optional)

1. Check the charge status of the supply battery (if purchased), recharge if necessary (see "Overview").

### NOTE



*The caravan is delivered with a maintenance-free supply battery that does not require special care.*

---

If a different type of rechargeable battery has been used when changing rechargeable batteries, the following steps are required:

2. Check the acid level of the supply battery.
3. If the fill-level is below the MIN mark, add distilled water to the battery concerned until the MAX mark is reached.
4. Charge the supply battery for at least 12 hours with the mains charger.



## Maintenance

### 7.5 Preparing the caravan for periods of non-use

- Take the following measures.
- Supplemental tasks for winter care are indicated by the letter **W**.
- Amend this list to meet your specific requirements.

Component	Activity	
<b>Chassis</b>		
	Park the caravan where it is safe and secure it from rolling off. <b>Do not</b> engage the parking brake.	
	Thoroughly clean under-body, repair rust and paint damage.	
	Check the air in the tyres, inflate to specified pressure.	
	If possible, jack up the vehicle, otherwise move the vehicle every 4 weeks to prevent pressure marks on tyres and wheel bearings.	
<b>Caravan body</b>		
Exterior	Free the entire vehicle, particularly the roof, from deposits such as branches, leaves, snow and ice.	
	Thoroughly clean the superstructure, repair rust and paint damage.	
	Clean and lubricate the hinges on doors and hatches.	<b>W</b>
	Treat locks with graphite dust.	<b>W</b>
	Rub talcum into the sealing rubber.	<b>W</b>
Interior	If possible, remove the upholstery from the caravan and store it in a dry location; if this is not possible, put it in a vertical position for better ventilation.	<b>W</b>
	Remove clothing, objects of daily use, cosmetics, canned goods and perishable goods from closets, storage areas and compartments.	
	Clean all closets, storage areas, and compartments with a damp cloth.	
	Remove groceries and drinks from the refrigerator. Defrost and clean the refrigerator. Arrest the refrigerator in a position that ensures an air gap.	
	Set up air de-humidifiers.	<b>W</b>
	Repeatedly and thoroughly ventilate the interior.	<b>W</b>

Component	Activity	
Electrical system	Check the supply battery (optional), fill, recharge if necessary.	
	Remove the supply battery (optional) and store it in a frost-free location.	<b>W</b>
	Spray contact spray into the contacts of the plug connector for connection to the towing vehicle.	
Water system	Empty the fresh water tank, open the tank locking mechanism.	
	Drain the hot and cold water system, open all water cocks to middle position and leave them open.	
	Blow out any water remaining in the water lines with compressed air (oil-free, max. 0.5 bar).	
	Empty the siphons in the kitchen and bathroom area.	<b>W</b>
	Empty and clean the waste water tank.	
Sanitary system	Flush the toilet.	
	Empty and clean the waste holding tank.	
Heater	Remove water from the boiler. Open the drain valve.	
Gas supply	Close the gas bottle valves and remove the gas bottles from the gas fastening belt.	
	Close the quick-action valves.	

# 8 Maintenance and inspection

### General

Maintenance tasks described in the sections below are required for optimal and trouble-free vehicle operation.

- If increased wear is determined on specific components in regular inspections, shorten the required maintenance interval based on the actual indications of wear!

In addition to this operating manual, the operating manuals supplied for the built-in devices also apply. The instructions contained therein - particularly the safety instructions cited in these manuals - must be complied with!

If you have questions concerning maintenance work and maintenance intervals:

Contact the manufacturer (service address → page 2).

## WARNING



### **Danger of accident and injury due to improper maintenance!**

Improper maintenance or repair can cause serious accidents or injuries.

- Have repairs to the vehicle or chassis, electrical system, gas system and gas consumers performed only by authorised specialists.
-

## 8.1 Maintenance schedule

Interval	Component	Action required
Weekly	Supply battery (optional)	Check charge status
Monthly	Main switch (FI)	Function check
	Tyres	Check the tyres: Condition, tread depth, fill pressure
	Fresh water tank and fresh water system	Clean and disinfect
	Blackwater tank and waster water tank (optional)	Empty and clean
	Coupling: Check the wear indicator of the stabilising device.	. If the wear limit has been reached, replace the friction elements of the stabilizing device.
Every 6 months	Doors, service hatches, storage compartments	Clean and grease joints, hinges
	Hinged windows, sliding windows, skylights	Check for leaks Clean and grease joints and hinges
	Support elements	Clean and grease joints and threaded rods



## Maintenance and inspection

Interval	Component	Action required
Every 12 months	Electrical system	Function check
	Fresh water and waste water system	Function check, leak test
	Heater, boiler, gas hob	Function check
	Lighting, refrigerator	Function check
	Gas burner, refrigerator	Have them cleaned by an authorised workshop
	Seals on the doors, storage and service hatches, windows, skylights, and safety straps	Function check
	Sealing strips, sealing edges, sealing rubber	Check for damage
	Support wheel spindle	Grease
	Lubricating nipple on the overrun brake device	Grease
	Thrust rod of the overrun brake device	Grease (below the rubber sleeve)
	Parking brake lever	Oil
Under-body protection	Check	
Every 6 years	Gas pressure regulator	Have it replaced by an authorised workshop
Every 10 years	Smoke detector	Replace

## 8.2 Inspection schedule

Interval	Component	Action required	✓
Every 12 months	Superstructure	Tightness test (annual inspection by authorised specialist workshop pursuant to the 5-year guarantee for tightness)	
Every 2 years	Overall vehicle	General vehicle inspection	
	Entire gas supply	Official inspection by an authorised specialised company	

## 8.3 Wheels and tyres

### General

#### WARNING



#### **Danger to life due to incorrect tyre pressure!**

Incorrect tyre pressure causes excessive wear and tear and damages the tyre which ultimately could burst.

- Prior to every trip or in two-week intervals, check the tyre pressure in cold tyres.

- The vehicle is fitted with tubeless tyres. Never install tubes in these tyres.
- When using aluminium rims, you cannot use snow chains.
- In the event of a flat tyre, move the rig to the right (continent) or left (UK) side of the road. Secure the rig with a warning triangle. Activate the hazard warning lights.
- Due to the design, vehicles with tandem axle may exhibit higher tyre wear.
- Tyres must not be older than six years as the material starts to break down. The four-digit DOT at the tyre side indicates the date of manufacture. The first two digits identify the week, the latter two the year of manufacture.
- Regularly (every fortnight) inspect the tyres for even tread abrasion, tread depth, and outer damages.
- Comply with the legal minimum tread depth.
- Always use tyres of the same model, same manufacturer and same type (summer or winter tyres).
- After having installed new tyres, use only moderate speeds for approx. 100 km in order for them to develop optimum grip properties.

## Maintenance and inspection




Fig. 220: Always tighten tyre nuts and bolts crosswise

- Regularly check tyre bolts and nuts for proper seating. Re-tighten the nuts or bolts of a replacement after 50 km driving (crosswise sequence, see Fig. 220).  
See section "Tightening torques" for the correct tightening torque.
- If you use new or repainted rims, re-tighten the tyre nuts or bolts again after 1000 to 5000 km.
- If the vehicle is not used for extended times, prevent pressure marks at tyres and wheel bearings. Jack up the vehicle to remove stress on the tyres, or move the vehicle every four weeks to change the wheel position.

### Tyre selection

#### WARNING



#### **Danger to life due to incorrect tyre selection!**

Incorrect tyre selection causes may damage the tyres during driving, and they may burst.

- Use only tyres that are approved for your vehicle.

- Using tyres not approved for the specific vehicle will cancel the operating licence and ultimately the insurance coverage. Consult your authorised distributor or service point.

The tyre sizes approved for your vehicle are shown in the vehicle documents or can be requested from your authorised distributor or service point. Every tyre must fit the vehicle at which it is to be used. This applies to external dimensions (diameter and radius) indicated by the standardised size designation. But the tyres must also meet the requirements of the respective vehicle regarding weight and speed.



## Maintenance and inspection

The weight is governed by the maximum permissible axle load to be distributed over two tyres (do not load one-sided). The maximum bearing capacity of a tyre is specified by its load index (= LI load bearing capacity identifier).

The permissible top speed for a tyre (at full load capacity) is specified by its speed rating (= GSY, speed code). Load index and speed rating together form the operational tyre code. It is an official component of the complete and standardised dimension identifier to be found on the tyre itself. The data on the tyre must match those in the vehicle documentation.

### Tyre codes

Example: 215/70 R 15C 109/107 Q

Code	Explanation
215	Tyre width in mm
70	Tyre height to width ratio in percent
R	Tyre design (R = radial)
15	Rim diameter in inches
C	Commercial (transporter)
109	Lead bearing code, single tyre
107	Load bearing code, twin tyre
Q	Permissible speed symbol (Q = 100 mph/160 km/h)

## Maintenance and inspection

---

### Treating tyres properly

- Drive over curbs at an obtuse angle. The tyres may possibly be jammed at the flank. Driving over curbs at an acute angle may cause damage to the tyre and subsequently bursting.
- Drive slowly over elevated manhole covers. The tyres may possibly be jammed. Fast driving over elevated manhole covers may cause damage to the tyre and subsequently bursting.
- Have the shock absorbers inspected regularly. Driving with poor shock absorbers causes significantly higher wear and tear.
- Avoid wheel locking when braking. This can cause the tyres to become more or less brake plates and reduces driving comfort. It can also cause the tyres to become unusable.
- Never clean tyres with a high-pressure washer. They can be damaged within just a few seconds and may subsequently burst.

### 8.3.1 Changing wheels

#### General

The spare wheel (optional) is stored in the draw-bar box. Use an off-the-shelf scissor jack to change wheels.

#### **WARNING**



#### **Danger to life due to rolling or falling of the vehicle!**

Severe injuries can be the result if the vehicle rolls or falls when a wheel is changed.

- The vehicle must stand on level, solid, and non-slipping ground.
- Fully engage the parking brake prior to lifting the vehicle.
- Use wheel chocks on the opposite vehicle side to secure it against rolling.
- Never lift the vehicle with the supports installed.
- Never place the jack at the superstructure, but only under the axle.
- Never overload the jack. The maximum permissible load is shown on the jack's nameplate.
- Use the jack only for a short-time lifting of the vehicle for the purpose of changing the tyre.
- Never lay under the lifted vehicle.
- If you have installed aluminium rims and have to use a steel spare wheel: Do not drive longer than necessary to reach the next distributor, workshop or tyre dealer. Adjust your driving speed. The different wheel will adversely affect the driving behaviour.


## Maintenance and inspection

- Do not damage the thread of the gudgeon when changing wheels.
- Always tighten tyre nuts and bolts crosswise.
- If you switch to different rims (e.g. aluminium rims or winter tyres), use the corresponding wheel bolts with correct length and head shape. The proper seating of the wheels and the functioning of the brake system depend on this.
- Rims and tyres not approved for the vehicles can adversely affect its roadworthiness.
- Secure a stranded vehicle according to the national regulations, e.g., warning triangle, flares, etc.
- Prior to changing the wheel, check the rim size and tyre size, the tyre load bearing capacity and the speed index shown on the tyre. Use only rim and tyre sizes specified in the vehicle documentation.

### Tightening torque

Rim	Tightening torque [Nm]
Steel rim	90
Aluminium rim	120

### Preparation



*Fig. 221: Securing the support wheel*



*Fig. 222: Securing the vehicle wheel*

**Preparing the coupled caravan**

- In caravan couplings with a stabilisation device, loosen the stabilisation device. The friction linings will be overstressed otherwise.
- Engage the parking brake of the towing vehicle and shift to first gear.

**Preparing the uncoupled caravan**

- Park the vehicle on as level and firm a ground as possible.
- Engage the parking brake
- turn the support wheel diagonally to the driving direction and secure with suitable means (Fig. 221).

**Jack**

Risk of injury when changing a wheel.

Always ensure that:

- The jack base must securely rest on the ground.
- Do not tilt the jack.
- Always insert the profile of the AL-KO lift jack (optional) to the stop in the retaining pocket.



Fig. 223: Off-the-shelf jack




Fig. 224: AL-KO lift jack

## Maintenance and inspection

### Procedure

1. To secure the vehicle, use wheel chocks or similar object on the opposite wheel (Fig. 222).
2. Remove the spare wheel (optional) from its bracket.
3. In the case of soft ground, place a stable base (e.g., wooden board) under the jack.
4. Position the jack.
- a Off-the-shelf jacks:  
Position the scissor jack (Fig. 223) or hydraulic jack at the frame or the axle.
- b AL-KO automotive jack (optional):  
Insert the profile (Fig. 224, Pos 2) of the AL-KO lift jack to the stop in the retaining pocket (Fig. 224, Pos 1). Hold the jack with one hand, and turn the crank (Fig. 224, Pos 4) clockwise until the base plate (Fig. 224, Pos 3) touches the ground and stands evenly.
5. Use a ratchet wrench to loosen the wheel bolts, but do not remove them!
6. Lift the vehicle until the wheel is two to three cm (just over one inch) above ground.
7. Remove the wheel bolts and take off the wheel.
8. Place the spare wheel (optional) on the hub and align.
9. Insert the wheel bolts and lightly tighten crosswise.
10. Crank down and remove the jack.
11. Use the ratchet wrench to evenly tighten the wheel bolts.

### Changing a wheel with an aluminium rim

- The bearing surfaces of the wheel on the brake drums must be clean and free of burrs.
- Lightly tighten the wheel, using only the supplied fastening means, and check for proper bearing and operating clearance. Use a torque wrench to crosswise tighten the wheel bolts.
- Various axle designs do not have a centring aid, collar or bolts. Ensure that the wheel bolts are evenly centred across the bore circle (no canting).

**8.3.2 Tyre pressure table**

Tyre type	Technically permissible total weight [kg] for vehicles with		Tyre pressure [bar]
	Single axle	Tandem axle	
185/70 R14 LI88	≤ 900	1800	2.60
	1000	2000	2.80
	1100	2200	2.80
185 R14C LI102	≤ 1100		3.30
	1200		3.30
	1300		3.50
	1400		3.80
	1500		4.25
	1600	2800	4.50
195/65 R14 LI89	≤ 1000	2000	2.50
	1100	2200	3.00
195/65 R15 LI91	≤ 1000	2000	2.50
	1100	2200	2.70
195/65 R15XL LI95	≤ 1100	2000	2.50
	1200	2200	2.80
	1300	2500	3.10
195/70 R14 LI91	≤ 1000	2000	2.50
	1100	2200	2.70
195/70 R14XL LI95	≤ 1100	2000	2.50
	1200	2200	2.80
	1300	2500	3.10



## Maintenance and inspection

Tyre type	Technically permissible total weight [kg] for vehicles with		Tyre pressure [bar]
	Single axle	Tandem axle	
195/70 R14XL LI96	≤ 900	1800	2.50
	1000	2000	2.50
	1100	2200	2.50
	1200		2.70
	1300	2500	3.00
195 R14C LI106	≤ 1100		3.00
	1200		3.00
	1300		3.20
	1400		3.40
	1500		3.75
	1600	2800	4.00
	1700		4.50
	1800	3500	4.50
205/70 R15C LI106	≤ 1100	2000	3.00
	1200	2200	3.00
	1300	2500	3.20
	1400		3.50
	1500		3.80
	1600	2800	4.00
	1700		4.20
	1800	3500	4.50





## Maintenance and inspection

Tyre type	Technically permissible total weight [kg] for vehicles with		Tyre pressure [bar]
	Single axle	Tandem axle	
205 R14C LI109	≤ 1600		3.70
	1700		4.00
	1800	3500	4.25
	1900		4.50
215/55 R16XL LI97	≤ 1100		2.70
	1200		2.70
	1300		3.00
	1400		3.00
215 R14C LI112	≤ 1600		3.30
	1700		3.50
	1800	3500	3.80
	1900		4.00
	2000		4.30
225/70 R15C LI112	≤ 1100	2000	3.00
	1200	2200	3.00
	1300	2500	3.00
	1400		3.00
	1500		3.00
	1600	2800	3.50
	1700		3.50
	1800	3500	3.70
	1900		4.00
	2000		4.30



## Maintenance and inspection

### 8.4 ALDE heating maintenance overview

Date	Maintenance task	Distributor or service centre
	<input type="checkbox"/> Changing the glycol/water mixture <input type="checkbox"/> Heating system vented in cold state <input type="checkbox"/> Heating system vented in warm state	Stamp, signature
	<input type="checkbox"/> Changing the glycol/water mixture <input type="checkbox"/> Heating system vented in cold state <input type="checkbox"/> Heating system vented in warm state	Stamp, signature
	<input type="checkbox"/> Changing the glycol/water mixture <input type="checkbox"/> Heating system vented in cold state <input type="checkbox"/> Heating system vented in warm state	Stamp, signature
	<input type="checkbox"/> Changing the glycol/water mixture <input type="checkbox"/> Heating system vented in cold state <input type="checkbox"/> Heating system vented in warm state	Stamp, signature
	<input type="checkbox"/> Changing the glycol/water mixture <input type="checkbox"/> Heating system vented in cold state <input type="checkbox"/> Heating system vented in warm state	Stamp, signature
	<input type="checkbox"/> Changing the glycol/water mixture <input type="checkbox"/> Heating system vented in cold state <input type="checkbox"/> Heating system vented in warm state	Stamp, signature
	<input type="checkbox"/> Changing the glycol/water mixture <input type="checkbox"/> Heating system vented in cold state <input type="checkbox"/> Heating system vented in warm state	Stamp, signature
	<input type="checkbox"/> Changing the glycol/water mixture <input type="checkbox"/> Heating system vented in cold state <input type="checkbox"/> Heating system vented in warm state	Stamp, signature
	<input type="checkbox"/> Changing the glycol/water mixture <input type="checkbox"/> Heating system vented in cold state <input type="checkbox"/> Heating system vented in warm state	Stamp, signature
	<input type="checkbox"/> Changing the glycol/water mixture <input type="checkbox"/> Heating system vented in cold state <input type="checkbox"/> Heating system vented in warm state	Stamp, signature
	<input type="checkbox"/> Changing the glycol/water mixture <input type="checkbox"/> Heating system vented in cold state <input type="checkbox"/> Heating system vented in warm state	Stamp, signature

## Maintenance and inspection

Date	Maintenance task	Distributor or service centre
	<input type="checkbox"/> Changing the glycol/water mixture <input type="checkbox"/> Heating system vented in cold state <input type="checkbox"/> Heating system vented in warm state	Stamp, signature
	<input type="checkbox"/> Changing the glycol/water mixture <input type="checkbox"/> Heating system vented in cold state <input type="checkbox"/> Heating system vented in warm state	Stamp, signature
	<input type="checkbox"/> Changing the glycol/water mixture <input type="checkbox"/> Heating system vented in cold state <input type="checkbox"/> Heating system vented in warm state	Stamp, signature
	<input type="checkbox"/> Changing the glycol/water mixture <input type="checkbox"/> Heating system vented in cold state <input type="checkbox"/> Heating system vented in warm state	Stamp, signature
	<input type="checkbox"/> Changing the glycol/water mixture <input type="checkbox"/> Heating system vented in cold state <input type="checkbox"/> Heating system vented in warm state	Stamp, signature
	<input type="checkbox"/> Changing the glycol/water mixture <input type="checkbox"/> Heating system vented in cold state <input type="checkbox"/> Heating system vented in warm state	Stamp, signature
	<input type="checkbox"/> Changing the glycol/water mixture <input type="checkbox"/> Heating system vented in cold state <input type="checkbox"/> Heating system vented in warm state	Stamp, signature
	<input type="checkbox"/> Changing the glycol/water mixture <input type="checkbox"/> Heating system vented in cold state <input type="checkbox"/> Heating system vented in warm state	Stamp, signature
	<input type="checkbox"/> Changing the glycol/water mixture <input type="checkbox"/> Heating system vented in cold state <input type="checkbox"/> Heating system vented in warm state	Stamp, signature
	<input type="checkbox"/> Changing the glycol/water mixture <input type="checkbox"/> Heating system vented in cold state <input type="checkbox"/> Heating system vented in warm state	Stamp, signature
	<input type="checkbox"/> Changing the glycol/water mixture <input type="checkbox"/> Heating system vented in cold state <input type="checkbox"/> Heating system vented in warm state	Stamp, signature

## Malfunctions

# 9 Malfunctions

### General

This chapter provides information about troubleshooting. Malfunctions for which causes and remedies are not explained here must be corrected by an authorised workshop.

Additional information concerning malfunctions is also provided in the operating manuals for the built-in devices. If the malfunction correction measures described in those manuals are not successful, then contact an authorised workshop.

## WARNING



### Danger of accident and injury due to improper troubleshooting!

Improper troubleshooting can cause serious accidents and injuries.

- Have repairs to the electrical system, gas system and gas consumers only performed by authorised specialists.

## 9.1 Caravan body

Malfunction	Cause	Remedy
Exterior:		
Hinges on the outside door, storage and service hatches do not move easily	Insufficient hinge lubrication	Lubricate hinges with acid-free and resin-free grease
Interior:		
Hinges and joints in the bathroom, the storage compartments and cupboard do not move easily	Insufficient hinge/joint lubrication	Lubricate hinges and joints with acid-free and resin-free grease

## 9.2 Electrical system

### DANGER


**Life-threatening danger due to electric shock!**

Touching live components can cause serious or fatal injury.

- Prior to any work, switch off the electrical system and disconnect from the mains supply.
- Switch off the ELCB.

### 9.2.1 Malfunctions in standard equipment

Malfunction	Cause	Remedy
No 230 V mains power, although system is connected	Power cable is not connected	Connect the power cable.
	230 V miniature circuit breaker in the caravan has tripped	Determine the defect and correct it; if necessary go to a workshop, then switch on the 230 V circuit breaker
	The 230 V fuse of the camp site has tripped	Have the 230 V at the camp site checked and switched on by the facility attendant.
12 V power supply does not work during 230 V operation	MCB is not switched on	Activate the MCB
	Automatic 230 V circuit breaker has tripped	Have the electrical system checked by a specialised workshop.
Lighting system does not function or does not function completely	Lighting fixture is defective	Replace the lighting fixture, comply with voltage and watt specifications
	The fuse for the lighting circuit is defective	Identify the defect and correct it; if necessary, visit a workshop, then replace the fuse

## Malfunctions

### 9.2.2 Faults of the stand-alone package (optional)

Malfunction	Cause	Remedy
Supply battery does not charge with 230 V connection	Charger defective	Contact a specialist workshop
	Charging current fuse defective	Identify the defect and correct it; if necessary, visit a workshop, then replace the fuse
12 V power supply does not work during 230 V operation	230 V circuit breaker has tripped	Have the electrical system checked by a specialised workshop.
	Disconnect switch of supply battery turned off	Switch on the disconnect switch
12 V power supply does not work during 12 V battery operation	Circuit breaker switched off	Activate the MCB
	Supply battery discharged	Recharge the supply battery
	Charging current fuse defective	Identify the defect and correct it; if necessary, visit a workshop, then replace the fuse
	Disconnect switch of supply battery turned off	Switch on the disconnect switch
	Charger defective	Contact a specialist workshop
Supply battery does not charge during driving	Charger defective	Contact a specialist workshop
No voltage at the supply battery	Supply battery discharged	Immediately charge the supply battery; prevent total discharge

### 9.2.3 Changing light bulbs

#### DANGER



##### Life-threatening danger due to electric shock!

Danger of electric shock potentially resulting in serious or fatal injury when working on electrical equipment.

- Any repair tasks on the electrical system must be performed by qualified personnel.
- Replace defective fuses only after the cause of the fault has been identified and rectified.

#### Light bulb change

Changing light bulbs is simple. Depending on the model:

1. Carefully open and remove the housing.
  2. Unscrew the dead bulb from the socket and replace with a new bulb.
  3. Carefully place and close the housing.
- If there are defects in the lighting fixtures that you cannot correct yourself, visit a customer service facility!

#### Replacing LEDs




Fig. 225: Replacing LEDs

1. Carefully open and remove the housing.
  2. Remove dead LED from the socket.
  3. If necessary, shorten the contact of the new LED to a length of 10 to 15 mm and insert.
  4. Carefully place and close the housing.
- If there are defects in the lighting fixtures that you cannot correct yourself, visit a customer service facility!

#### ATTENTION



##### Risk of fire due to incorrect light bulbs!

Using halogen bulbs may overheat the lap fixture and cause a fire.

- Replace LEDs only with LEDs of the same type.

## Malfuncions

### Replacing the bulb of the rear lamp unit



Fig. 226: Undoing the hybrid light

The tail lights are fitted with hybrid bulb assemblies. The single-unit housings are fitted with both LEDs and conventional incandescent bulbs. Only the incandescent bulbs can be replaced. For replacement of the LEDs, visit an authorised dealer or service centre.

1. Insert a flat tool in the groove (1) and carefully lever out the housing.



Fig. 227: Changing light bulbs

2. Reach into the hole on the rear side of the housing. Rotate bulb holder (2) (bayonet fitting) and pull out. The brake lamp is shown here as an example.
3. Replace the bulb.
4. Insert the bulb holder (2) in the hole and rotate it until it is fixed.
5. Align the housing on the tapered pins and press against the vehicle tail.



## 9.2.4 Changing the smoke detector battery

The smoke detector is fitted with a 9 V block battery. To maintain the function of the smoke detector, the block battery must be replaced regularly, at the latest when the battery indicator signal sounds.

- Comply with the safety and operating instructions in the operating manual provided by the manufacturer!



Fig. 228: Removing the housing



Fig. 229: Replacing the block battery



Fig. 230: Replacing the housing

1. Carefully rotate the housing of the smoke detector counter-clockwise ( $15^\circ$  approximately) until it can be taken from the bracket.
2. Remove the spent block battery and disconnect it from the contact strip.
3. Connect the new block battery with the contact strip. The contact strip must engage on the poles of the block battery.
4. Insert the connected new battery in the battery compartment of the smoke detector.
5. place the smoke detector's housing with the notch (1) at the mark (2) and strongly press onto the bracket.
6. Carefully rotate the housing clockwise ( $15^\circ$  approximately) until it latches in the bracket.

## Malfunctions

### 9.3 Gas supply

#### WARNING



#### Danger of injury due to escaping gas!

Escaping gas can explode.

- All repair work must be performed by an authorised gas specialist workshop.
- If gas odour is detected:
  - Immediately shut down the gas supply.
  - Do not operate any electric devices.
  - Remove fire and sources of ignitions.
- Do not smoke.

Malfunction	Cause	Remedy
Gas odour or higher gas consumption	Gas supply leaks	Have a specialist workshop inspect and repair the gas supply system
Gas device does not function	Quick-action valve closed	Open the quick-action valve
	Gas bottle valve closed	Open the gas bottle valve
	Outside temperature too low for camping gas	Only use propane if outdoor temperatures are low
	Gas device defective	Contact a specialist workshop

### 9.4 Hob

Malfunction	Cause	Remedy
No flame when igniting	Gas bottle valve or quick-action valve is closed	Open the gas bottle valve and quick-action valve
	Gas bottle empty	Replace gas bottle
Flame extinguishes immediately after the regulator is released	Warm-up period too short	Keep the rotary knob depressed for approximately 10 seconds after ignition.
	Safety pilot is defective	Contact a specialist workshop
Flame extinguishes when it is reduced	Safety pilot sensor is defective	Contact a specialist workshop

## 9.5 Heater and hot water

### 9.5.1 Malfunctions, TRUMA heater

Malfunction	Cause	Remedy
Red indicator light, "Malfunction", is illuminated	Lack of gas	Open the gas bottle valve and quick-action valve Connect a full gas bottle
	Air in the gas line system	Switch off the heater and switch it on again. After two unsuccessful ignition attempts, wait for 10 minutes and try again
Green indicator light is not illuminated	Fuse defective	Identify the defect and correct it; if necessary, visit a workshop, then replace the fuse
Fan propeller of the gas heater is noisy or does not run evenly	Fan propeller is fouled	Contact a specialist workshop

## Malfunctions

### 9.5.2 Malfunctions, ALDE heater

Malfunction	Cause	Remedy
Battery low	Battery voltage in vehicle below 10.5 V (heater shuts down)	Charge battery (automatic reset as soon as the voltage is again above 11 V)
Fan failure	Wrong fan speed	Automatic reset after 5 minutes
Gas failure	No gas supply.	Switch off and restart the heater, visit specialist workshop, if necessary.
Overheating red	Triggered by overtemperature protection (red cable)	Disconnect and reconnect the 12 V power supply
Overheating blue	Triggered by overtemperature protection (blue cable)	Disconnect and reconnect the 12 V power supply
Window open	An opened window forces the heater to close the gas supply (electric heater continues)	Close the window
Connection failure	Connection fault between heater and operating panel	Switch off and on the main power for the heater; if necessary, visit specialist workshop.
Panel failure 1	Panel error	Contact a specialist workshop
Panel failure 2	Panel error	Contact a specialist workshop

## 9.6 Refrigerator

Malfunction	Cause	Remedy
Refrigerator does not switch on:		
at 230 V mains operation	Circuit breaker has tripped	Determine the defect and correct it; if necessary go to a workshop, then switch on the circuit breaker.
	230 V operating voltage is too low	Have the 230 V system checked by a specialised workshop
At 12 V operation	12 V power supply from the towing vehicle does not function	Check the supply lines, e.g. coupling connectors, for damage or contact problems
	230 V operating voltage is too low	Have the 230 V system checked by a specialised workshop
	Battery empty	Replace battery
at gas operation	Lack of gas	Open the gas bottle valve and quick-action valve
		Connect a full gas bottle



## Malfunctions

### 9.7 Fresh water and waste water system

Malfunction	Cause	Remedy
Water leaks in the vehicle	Fresh water system or waste water system leaks	Identify leak points, repair the leaks
No fresh water	Freshwater tank empty	Fill the fresh water tank
	Water pump fuse defective	Identify the defect and correct it; if necessary, visit a workshop, then replace the fuse
	Water pump filter clogged	Clean or replace filter
	Water pump defective	Replace the water pump
	12 V supply defective	Contact a specialist workshop
Turbidity, changes in taste and/or smell of the fresh water Deposits in the fresh water tank or in the lines	Tank has been filled with contaminated water	Clean the water system mechanically and chemically; disinfect the water system and flush thoroughly with drinking water
	Residues in the tank or fresh water system	
	Microbiological deposits in the fresh water system	
	Untreated fresh water has been in the system too long	
No toilet flushing water	Freshwater tank empty	Fill the fresh water tank
Incorrect display of the filling level in the fresh water tank	Filling level sensor in the fresh water tank is fouled	Clean the filling level sensor, or have it replaced by a specialised workshop.
	Filling level sensor defective	
Water does not drain in the shower, washbasin or kitchen sink	Siphon plugged	Clean siphon

---

## 10 Tightness guarantee

### 10.1 Guarantee certificate

The guarantee certificate for your vehicle was given to you by your authorised distributor when the vehicle was transferred to you. This guarantee is only valid if it has been signed by the buyer and the authorised distributor.

- Keep the guarantee certificate in a safe place!

### 10.2 Guarantee conditions and terms

1. BÜRSTNER GmbH & Co. KG, Weststraße 33, 77694 Kehl, Germany (guarantor) grants on the vehicles manufactured by it from the MJ 2019 a tightness guarantee of 10 years - up to a total mileage of 120,000 km - that the following listed components of the caravan/motor home or camper vans are sealed so that during usual, contractual and non-commercial use of the vehicle no moisture penetrates from the outside to the inside (interior).

#### Outer connection seams

- Roof/side wall
- Roof/rear wall
- Roof/cab
- Walls/under-body
- Chassis/under-body

Outer sealing welds between mounted parts and the cut-outs of the body:

- Doors
- Windows
- Service and garage flaps
- Roof hatches
- Water filling devices
- Electrical supply flaps

It is incumbent on the guarantee holder to provide evidence that a guarantee case exists.

## Tightness guarantee

---

2. If proof is provided of a guarantee claim due to a faulty seal (see item 1.), the guarantor shall be obligated, within the terms of these guarantee conditions, to repair the vehicle parts in question free of charge or replace all affected parts, depending on the steps necessary in the opinion of the guarantor for the elimination of the leak. The required work will be carried out by the guarantor or by a workshop authorised by it in accordance with the guidelines of the guarantor. If the elimination of leaks caused by mounted parts or other changes to the vehicle results in additional costs compared to the original condition, these shall be borne by the guarantee holder. The cost of guarantee work that has not been performed by either the guarantor or a repairer authorised by the guarantor is non-reimbursable, irrespective of the existence of a guarantee claim. Further claims, in particular for subsequent delivery, rescission of the purchase contract, reduction or compensation for damage (including consequential damage) as well as compensation for direct or indirect, material or immaterial consequential damage are not due to the guarantee holder from the guarantor under this guarantee. Excluded for example are compensation claims for transport or travel costs, towing costs, loss of earnings or holiday and compensation for futile expenses. The legal rights of the guarantee holder against his seller remain unaffected by this guarantee. The legal guarantee rights of the guarantee holder against their seller remain independent of the claims under this guarantee.

3. The guarantee period begins, dependent on which event occurs first, on the date of initial registration or transfer of the vehicle to the buyer, but at the latest one year after the initial delivery of the vehicle to the dealership.

The guarantee shall be in force for the duration of the usability of the vehicle, but at the most for 10 years or a maximal of up to 120,000 km, whichever event occurs first. If the vehicle changes hands, the guarantee obligations remain unaffected. The guarantee expires if the annual inspections specified in item 4 are not performed. The performance of guarantee work does not extend the guarantee period nor does it cause the period to restart.



## Tightness guarantee

---

4. Prerequisite for the successful making of a guarantee claim is that the vehicle be annually inspected for leaks by an authorised BÜRSTNER workshop. The inspection must be performed annually between the 11th and 13th month after the start of the guarantee period (see item 3.). The costs for the performance of the leak inspection are borne by the guarantee holder. The guarantee holder can claim compensation under this guarantee only if he is able to provide evidence of proper performance of the annual inspection by an authorised BÜRSTNER workshop.

This includes an inspection certificate filled out by the BÜRSTNER authorised dealer. Proof of the regular performance of the tightness inspections must be provided by the guarantee holder.
5. The guarantee holder must report the occurrence of moisture indicating potential leaks in written text to an authorised BÜRSTNER workshop within 15 days of their being detected. Knowledge is considered to exist in the event of grossly negligent and negligent ignorance. Decisive for the observation of the 15 day term is the receipt of the message at a BÜRSTNER authorised workshop. The guarantee certificate must be attached to this report. No claim arising from this guarantee shall be accepted if the leak is not reported in a timely manner in due form as indicated above.
6. The necessity as well as the nature and extent of the rectification of the leak is solely at the discretion of the guarantor or their authorised workshops.



## Tightness guarantee

---

7. Guarantee claims are excluded in the event of:
  - Forces of nature (e.g. flooding, hail, etc.) and animal damage of any type.
  - Damage as a result of an accident.
  - Leakage due to modifications or additions to the vehicle, that have not been carried out by a BÜRSTNER authorised workshop.
  - Leakage due to improperly repaired damage where the repairs were not carried out by a BÜRSTNER authorised workshop.
  - Damage to the outer skin detected during inspections that has not been immediately remedied by the guarantee holder.
  - Aluminium corrosion that cannot be traced back to a leak.
  - If the vehicle has been changed through the use of spare parts that have not been authorised by BÜRSTNER and as a result a guarantee claim has arisen.
  - Condensation due to inadequate ventilation.
  - Improper, non-contractual handling and use of the vehicle.
  - Damage due to incorrect use of care or cleaning agents (see also the instructions under care in the operating manual).
  - Damage due to non-observance of the operating manual as well as the repair and maintenance instructions of the manufacturer.
  - All other damage that is neither the responsibility of the guarantor nor of an authorised dealer of the guarantor.
  
8. Tightness inspections are subject to a charge. The costs for the inspection are borne by the guarantee holder (see item 4.).
  
9. The exclusive place of jurisdiction is, to the extent permitted by law, Kehl. The place of performance for all claims arising under this guarantee is Kehl. Solely the law of the Federal Republic of Germany applies to this guarantee. This applies irrespective of the place of residence or registered office of the guarantee holder.

### 10.3 Inspection schedule and inspection certificates

#### Verification

#### NOTE



*The annual tightness tests are prerequisite for the tightness guarantee for the caravan body.*

*Verification of inspection must be completed by your authorised dealer after every executed test; it must be entered in the On-line system and printed for you.*

#### 10.3.1 Vehicle data

The following leak tests and inspection verifications apply exclusively for the vehicle:

Specification	Entry
Model, type	
Chassis no.	
Key no.	
Initial registration/ transfer date	
Purchased from	

The following pages contain the scope of the annual leak tests and inspection verifications.



## Tightness guarantee

### 10.3.2 Leak test after 12 months

#### Inspection certificate

Stamp of the Bürstner commercial partner	
Date	Signature

<b>Visual inspections - interior</b>	✓
Entry section	
Front bulkhead including connections on the floor plate and side walls	
Front bulkhead including connections on the floor plate and side walls	
Left side wall including connections on the floor plate and side walls	
Right side wall including connections on the floor plate and side walls	
Wheel cases left and right	
Roof cut-outs	
<b>Visual inspections of the motor home's outside</b>	✓
Exterior sheet metal	
Edge seals	
Under-body	
Damages to the exterior shell	

## Tightness guarantee

### Measurements

Measured values up to 20 % are considered normal. For measured values greater than 20 %, check whether condensation has accumulated.

Measurement	Measured value
Floor measurements on the connecting points of the front/rear/side	
Measurements in the interior: walls, window apertures, roof hatch, cable conduit, etc.	

### Spray with special sealant

Sealed points/edges	✓
Wheel housing	
Cut-out edges in the floor plates	
Butt joints	
Installation openings in the under-body	



## Tightness guarantee

### 10.3.3 Leak test after 24 months

#### Inspection certificate

Stamp of the Bürstner commercial partner	
Date	Signature

<b>Visual inspections - interior</b>	✓
Entry section	
Front bulkhead including connections on the floor plate and side walls	
Front bulkhead including connections on the floor plate and side walls	
Left side wall including connections on the floor plate and side walls	
Right side wall including connections on the floor plate and side walls	
Wheel cases left and right	
Roof cut-outs	
<b>Visual inspections of the motor home's outside</b>	✓
Exterior sheet metal	
Edge seals	
Under-body	
Damages to the exterior shell	

## Tightness guarantee

### Measurements

Measured values up to 20 % are considered normal. For measured values greater than 20 %, check whether condensation has accumulated.

Measurement	Measured value
Floor measurements on the connecting points of the front/rear/side	
Measurements in the interior: walls, window apertures, roof hatch, cable conduit, etc.	

### Spray with special sealant

Sealed points/edges	✓
Wheel housing	
Cut-out edges in the floor plates	
Butt joints	
Installation openings in the under-body	



## Tightness guarantee

### 10.3.4 Leak test after 36 months

#### Inspection certificate

Stamp of the Bürstner commercial partner	
Date	Signature

<b>Visual inspections - interior</b>	✓
Entry section	
Front bulkhead including connections on the floor plate and side walls	
Front bulkhead including connections on the floor plate and side walls	
Left side wall including connections on the floor plate and side walls	
Right side wall including connections on the floor plate and side walls	
Wheel cases left and right	
Roof cut-outs	
<b>Visual inspections of the motor home's outside</b>	✓
Exterior sheet metal	
Edge seals	
Under-body	
Damages to the exterior shell	



## Tightness guarantee

### Measurements

Measured values up to 20 % are considered normal. For measured values greater than 20 %, check whether condensation has accumulated.

Measurement	Measured value
Floor measurements on the connecting points of the front/rear/side	
Measurements in the interior: walls, window apertures, roof hatch, cable conduit, etc.	

### Spray with special sealant

Sealed points/edges	✓
Wheel housing	
Cut-out edges in the floor plates	
Butt joints	
Installation openings in the under-body	



## Tightness guarantee

### 10.3.5 Leak test after 48 months

#### Inspection certificate

Stamp of the Bürstner commercial partner	
Date	Signature

<b>Visual inspections - interior</b>	✓
Entry section	
Front bulkhead including connections on the floor plate and side walls	
Front bulkhead including connections on the floor plate and side walls	
Left side wall including connections on the floor plate and side walls	
Right side wall including connections on the floor plate and side walls	
Wheel cases left and right	
Roof cut-outs	
<b>Visual inspections of the motor home's outside</b>	✓
Exterior sheet metal	
Edge seals	
Under-body	
Damages to the exterior shell	

## Tightness guarantee

### Measurements

Measured values up to 20 % are considered normal. For measured values greater than 20 %, check whether condensation has accumulated.

Measurement	Measured value
Floor measurements on the connecting points of the front/rear/side	
Measurements in the interior: walls, window apertures, roof hatch, cable conduit, etc.	

### Spray with special sealant

Sealed points/edges	✓
Wheel housing	
Cut-out edges in the floor plates	
Butt joints	
Installation openings in the under-body	



## Tightness guarantee

### 10.3.6 Leak test after 60 months

#### Inspection certificate

Stamp of the Bürstner commercial partner	
Date	Signature

<b>Visual inspections - interior</b>	✓
Entry section	
Front bulkhead including connections on the floor plate and side walls	
Front bulkhead including connections on the floor plate and side walls	
Left side wall including connections on the floor plate and side walls	
Right side wall including connections on the floor plate and side walls	
Wheel cases left and right	
Roof cut-outs	
<b>Visual inspections of the motor home's outside</b>	✓
Exterior sheet metal	
Edge seals	
Under-body	
Damages to the exterior shell	

## Tightness guarantee

### Measurements

Measured values up to 20 % are considered normal. For measured values greater than 20 %, check whether condensation has accumulated.

Measurement	Measured value
Floor measurements on the connecting points of the front/rear/side	
Measurements in the interior: walls, window apertures, roof hatch, cable conduit, etc.	

### Spray with special sealant

Sealed points/edges	✓
Wheel housing	
Cut-out edges in the floor plates	
Butt joints	
Installation openings in the under-body	



## Tightness guarantee

### 10.3.7 Leak test after 72 months

#### Inspection certificate

Stamp of the Bürstner commercial partner	
Date	Signature

<b>Visual inspections - interior</b>	✓
Entry section	
Front bulkhead including connections on the floor plate and side walls	
Front bulkhead including connections on the floor plate and side walls	
Left side wall including connections on the floor plate and side walls	
Right side wall including connections on the floor plate and side walls	
Wheel cases left and right	
Roof cut-outs	
<b>Visual inspections of the motor home's outside</b>	✓
Exterior sheet metal	
Edge seals	
Under-body	
Damages to the exterior shell	

## Tightness guarantee

### Measurements

Measured values up to 20 % are considered normal. For measured values greater than 20 %, check whether condensation has accumulated.

Measurement	Measured value
Floor measurements on the connecting points of the front/rear/side	
Measurements in the interior: walls, window apertures, roof hatch, cable conduit, etc.	

### Spray with special sealant

Sealed points/edges	✓
Wheel housing	
Cut-out edges in the floor plates	
Butt joints	
Installation openings in the under-body	



## Tightness guarantee

### 10.3.8 Leak test after 84 months

#### Inspection certificate

Stamp of the Bürstner commercial partner	
Date	Signature

<b>Visual inspections - interior</b>	✓
Entry section	
Front bulkhead including connections on the floor plate and side walls	
Front bulkhead including connections on the floor plate and side walls	
Left side wall including connections on the floor plate and side walls	
Right side wall including connections on the floor plate and side walls	
Wheel cases left and right	
Roof cut-outs	
<b>Visual inspections of the motor home's outside</b>	✓
Exterior sheet metal	
Edge seals	
Under-body	
Damages to the exterior shell	



## Tightness guarantee

### Measurements

Measured values up to 20 % are considered normal. For measured values greater than 20 %, check whether condensation has accumulated.

Measurement	Measured value
Floor measurements on the connecting points of the front/rear/side	
Measurements in the interior: walls, window apertures, roof hatch, cable conduit, etc.	

### Spray with special sealant

Sealed points/edges	✓
Wheel housing	
Cut-out edges in the floor plates	
Butt joints	
Installation openings in the under-body	



## Tightness guarantee

### 10.3.9 Leak test after 96 months

#### Inspection certificate

Stamp of the Bürstner commercial partner	
Date	Signature

<b>Visual inspections - interior</b>	✓
Entry section	
Front bulkhead including connections on the floor plate and side walls	
Front bulkhead including connections on the floor plate and side walls	
Left side wall including connections on the floor plate and side walls	
Right side wall including connections on the floor plate and side walls	
Wheel cases left and right	
Roof cut-outs	
<b>Visual inspections of the motor home's outside</b>	✓
Exterior sheet metal	
Edge seals	
Under-body	
Damages to the exterior shell	

## Tightness guarantee

### Measurements

Measured values up to 20 % are considered normal. For measured values greater than 20 %, check whether condensation has accumulated.

Measurement	Measured value
Floor measurements on the connecting points of the front/rear/side	
Measurements in the interior: walls, window apertures, roof hatch, cable conduit, etc.	

### Spray with special sealant

Sealed points/edges	✓
Wheel housing	
Cut-out edges in the floor plates	
Butt joints	
Installation openings in the under-body	



## Tightness guarantee

### 10.3.10 Leak test after 108 months

#### Inspection certificate

Stamp of the Bürstner commercial partner	
Date	Signature

<b>Visual inspections - interior</b>	✓
Entry section	
Front bulkhead including connections on the floor plate and side walls	
Front bulkhead including connections on the floor plate and side walls	
Left side wall including connections on the floor plate and side walls	
Right side wall including connections on the floor plate and side walls	
Wheel cases left and right	
Roof cut-outs	
<b>Visual inspections of the motor home's outside</b>	✓
Exterior sheet metal	
Edge seals	
Under-body	
Damages to the exterior shell	

## Tightness guarantee

### Measurements

Measured values up to 20 % are considered normal. For measured values greater than 20 %, check whether condensation has accumulated.

Measurement	Measured value
Floor measurements on the connecting points of the front/rear/side	
Measurements in the interior: walls, window apertures, roof hatch, cable conduit, etc.	

### Spray with special sealant

Sealed points/edges	✓
Wheel housing	
Cut-out edges in the floor plates	
Butt joints	
Installation openings in the under-body	

## Index

### 11 Index

- A**
- AGM battery 83
  - Air-conditioning 59
  - Airing 120
  - ALDE heater 99, 144
  - Awning fastening 63
  - Awning light 91
- B**
- Baking 176
  - Bathroom 69, 70, 167
  - Bathroom lighting 161
  - Battery charge status 86
  - Battery charging process 87
  - Blackout blind 58, 59, 122
- C**
- Camping 110
  - Caravan body 32, 51, 204
  - Changing light bulbs 207
  - Changing wheels 195
  - Charger 84
  - Check list 37
  - Cleanliness 31
  - Combination blind 58, 122
  - Convector 101
  - Coupling 39, 42
  - Crockery 72
- D**
- Door lock 54
  - Drain plug 105
  - Driving 34
- E**
- Electrical system 26, 79
  - Entrance door 52, 54
  - Environmental protection 10, 31
  - Equipment, technical 79
  - Exhaust gas stack 97
  - Explanation of symbols used 9
  - Extending and retracting the support elements 48
  - Exterior cleaning 183
- F**
- Filling levels 64
  - Fire safety 15
  - Floor heating 64, 98, 102, 131
  - Flushing the toilet 167, 169
  - Fly screen 58, 59, 122
  - Fly screen door (SW) 124
  - Folding console as bed extension 158
  - Folding console to extend the kitchen counter-top 175
  - Forced ventilation 59
  - Fresh water 103
    - draining 112
    - fresh water tank 104
    - intake port 103
    - tank cap 103
  - Fresh water tank
    - filling 110
  - Furnishings 66
- G**
- Gas bottles
    - Single-bottle operation 119
    - Switching 119
  - Gas heater 96, 126
  - Gas heating
    - Battery change 130
    - Cleaning 130
    - Closing the heater grille 129
    - Removing the heater grille 129
  - Gas hob 72
  - Gas locker 93
  - Gas pressure regulator 118
  - Gas supply 23, 92, 93, 94
  - Grilling 176
  - Guarantee 215

**H**

Hatch lock 54  
Hatch locks 54  
Heater 96, 99  
Heating 126  
Heating system 64  
Hinged window 57, 121  
Hot-air nozzle 97, 131

**I**

Inspection 188  
Inspection certificate 219  
Inspection schedule 190, 219  
Intended use 12  
Interior cleaning 184  
Introduction 7

**K**

Keys 11, 51  
Kitchen 72  
    lower cabinet 77  
    upper cabinet 76  
Kitchen area 171  
Kitchen light 161  
Kitchen window 57

**L**

Leak test 219  
LED 207  
LED battery light relocation 162  
Light bulb change 207  
Light switch 64  
Linen closet 75  
Load 20, 34  
Loading 34  
Loads 33  
Lower cabinet 75

**M**

Maintenance 183, 188  
Maintenance schedule 189  
Malfunction 204

Stand-alone package (optional) 206

**Malfunctions**

cooking hob 210  
electrical system 205  
fresh water and waste water 214  
gas supply 210  
heater, hot water 211  
light bulbs 207  
refrigerator 213

Multifunction light switch 64

**N**

Nameplate 33

**O**

Operational reliability 23  
Overview 50

**P**

Parking 45  
Pop-up roof 61, 163, 184  
Power connection 110  
Preparing the caravan for periods of non-use 186  
Pressure reducer 93

**R**

Rear lamp unit 208  
Rearranging the cushions 159  
Refrigerator 179  
Remote control 92  
Remote display 95, 119  
Responsibility of the vehicle owner 13  
Room thermostat 128

**S**

Safety 12  
    after the road trip 22  
    before the trip 21  
    brakes 18  
    dimensions and weight 16  
    electrical 26  
    fire safety 15  
    gas devices 24

## Index

---

- gas supply 23
- general requirements 14
- on the road 22
- rig operation 17
- sanitary system 29
- vehicle equipment 19
- Safety and warning signs 9
- Sanitary system 29
- Setting up the lighting 161
- Shower 70
- Sink 72
- Sitting 155
- Sitting area 66
- Skylight 59, 125
- Skylights 59
- Sleeping 155
- Sleeping area 68
- Sliding windows 57, 121
- Smoke detector 65, 209
- Stabiliser system 44
- Stand-alone package 84
- Storage
  - under-bed 76
- Storage compartment
  - built-in wardrobe 74
  - linen closet 75
  - mirror cabinet 77
  - wall cupboards 75, 76
  - washbasin cabinet 77
- Storage compartments 74
- Storage space
  - kitchen 76, 77
  - lower cabinet 75
  - upper cabinet 75
- Supply battery 82, 185
- Supply battery pack 84
- T**
- Table 67
- Technical data 32
- Technical documentation 8
- Technical equipment 79
- Toilet 71
- Toilet chemistry 31
- Towing preparation 17
- Traffic safety 16
- Travelling and parking 45
- TRUMA Combination heater 98, 109
- TRUMA heater 96, 126
- TV bracket 78
- Tyre pressure table 199
- Tyres 18, 191
- U**
- Uncoupling 44
- Upper cabinet 75
- V**
- Vehicle
  - Checking the 38
  - loading 34
  - parking 22
  - stopping 22
- Vehicle data 219
- Vehicle documents 8
- Vehicle license 11
- Vehicle registration 11
- W**
- Wall cupboards 75, 76
- Wall exhaust stack 100
- Wardrobe 74
- Washbasin 69
- Waste 31
- Waste container 78
- Waste water 31, 103, 106
- Waste water tank 69
- Water drain valve 108
- Water heater 107, 151
- Water heating 69





---

Wheels 18, 191

Window 57

Window switch 101



**Bürstner GmbH & Co. KG**

Weststraße 33  
D-77694 Kehl / Rhein  
Tel. +49 7851 / 85 - 0  
Service-Hotline 85-950  
Fax +49 7851 / 85 - 201  
info@buerstner.com

**Bürstner Service-Center**

Elsässer Straße 80  
D-77694 Kehl / Neumühl

[www.buerstner.com](http://www.buerstner.com)



05.2019