

#### Dear Reader ...

We would like to congratulate you on the purchase of your new caravan. You have selected a top-quality vehicle which will afford you many years of enjoyment.

To enable you to always use and operate your caravan properly and easily, your Bürstner dealer will first provide you detailed instructions for all important functions when you take delivery.

This manual, as well as the instruction manuals from the appliance manufacturers are your constant travelling companions and will help answer any questions you may have regarding your caravan.

## Before your first journey

Please familiarise yourself with this manual rather than relying on it strictly for reference.

Fill in the warranty cards for the appliances and special equipment in the individual instructions and send these cards to the respective manufacturers. This ensures your warranty claim for each appliance.





## **Contents**



1	Introduction 7	5.8.1	Equipment with automatic antenna
1.1	General 8		alignment (Alden)
1.2		5.8.2	Equipment with semi-automatic
1.2	Environmental tips 8	5.6.2	• •
^	0-5-1		antenna alignment (Alden) 40
2	Safety	•	I factoria
2.1	Fire prevention	6	Living43
2.1.1	Avoidance of fire risks	6.1	Conversion door
2.1.2	Fire-fighting	6.1.1	Conversion door, outside43
2.1.2		6.1.2	Conversion door, inside
_	In case of fire	6.1.3	
2.2	General	6.1.3	Window conversion door (Seitz)
2.3	Road safety		(special equipment) 44
2.4	Towing	6.1.4	Folding insect screen on the
2.5	Gas system		conversion door (special
2.5.1	General instructions		equipment)44
2.5.2	Gas bottles	6.2	External flaps 45
_		6.2.1	Flap lock, elliptical-shaped 45
2.6	Electrical system 16		
2.7	Water system	6.2.2	Flap lock with recessed handle 46
		6.2.3	Flap lock, rectangular 47
3	Before the journey 17	6.2.4	Flap for toilet cassette 47
3.1	Keys	6.2.5	Flap for the 230 V connection,
3.2	Registration		square
3.3		6.2.6	Cap for the drinking water filler
	Connecting	0.2.0	neck (only for water tank 40 l) 48
3.4	Caravan couplings 19	0.0	, ,
3.4.1	AKS 1300 stabiliser 19	6.3	Furniture flaps
3.4.2	AKS 3004 stabiliser	6.3.1	Furniture flaps with push button 49
3.5	Caravan control system (ATC)	6.3.2	Furniture flaps with handle49
	(special equipment)	6.3.3	Furniture flaps with handle and
3.6	Detaching		push button 50
3.7	Manoeuvring system (special	6.3.4	Furniture flaps with pressurised
0.1		0.0	release
0.0	equipment)	6.4	Light switch 50
3.8	Payload		•
3.8.1	Terms	6.4.1	Entrance area50
3.8.2	Calculating the payload	6.4.2	Living area 51
3.8.3	Loading the caravan correctly 27	6.4.3	Recessed light with LED 52
3.8.4	Caravan load, nose weight and	6.5	Spotlight
	axle load 28	6.6	Spotlight (moveable) 52
3.8.5	Bike rack (special equipment) 29	6.7	Holder for flat screen53
3.9		6.7.1	Holder on the column54
	External mirrors	6.7.1	Rail-mounted holder 54
3.10	TV unit (special equipment) 31		
3.11	Road safety	6.7.3	Holder in the TV cabinet
		6.7.4	Holder in the TV compartment55
4	During the journey 35	6.8	Heating
4.1	Driving with the caravan	6.9	Ventilation
4.2	Brakes	6.10	Windows
4.3	Driving in reverse	6.10.1	Hinged window with rotary hinges 57
4.5	Driving in reverse	6.10.2	Hinged window with automatic
5	Ditching the caravan	0.10.2	
	Pitching the caravan 37	0.40.0	hinges
5.1	Handbrake37	6.10.3	Blind and insect screen 61
5.2	Wheel chocks	6.10.4	Blind and insect screen 62
5.3	Corner steadies	6.10.5	Roman shade and insect screen 63
5.4	Entrance step (free-standing) 38	6.11	Skylights
5.5	Waste water tank, mobile	6.11.1	Heki skylight (mini and midi)
3.0	(special equipment)		(partially special equipment) 64
5.6	· · · · · · · · · · · · · · · · · · ·	6.11.2	,
5.6	230 V connection		Heki skylight (special equipment) 66
5.7	Refrigerator	6.12	Tables
5.8	Satellite unit (special equipment) 39	6.12.1	Suspension table with folding leg 68
		6.12.2	Swivel table





6.12.3	Suspension table and swivel	8.6.1	12 V fuses102
	table	8.6.2	230 V fuse
6.12.4	Fixed table (movable table-top)	8.7	Thirteen-pin plug connection
	(special equipment) 69		diagram
6.12.5	Lift-off table, movable 70	8.8	External socket (special
6.13	Beds70	0.0	equipment)
6.13.1	Bunk bed	8.9	Circuit diagrams
6.13.1		8.9.1	
	Fixed bed (manual setup) 71		Circuit diagram, interior
6.13.3	Pull-down bed, manually operated (Averso Plus)	8.9.2	Circuit diagram, exterior
6.13.4	Pull-down bed, electrically operated	9	Appliances109
0.13.7	(Averso Plus) (special equipment)73	9	Chapter overview
C 40 E	, , , , , , , , , , , , , , , , , , , ,	9.1	General109
6.13.5	Widening single beds (special		
	equipment)76	9.2	Heater110
6.14	Converting seating groups for	9.2.1	Models with waste gas vent on the
	sleeping		right-hand side of the vehicle 110
6.14.1	Bench and central seating group	9.2.2	To heat properly
	without additional cushion 77	9.2.3	Hot-air heater
6.14.2	Bench and central seating group		Trumatic S 3002/S 5002111
	with additional cushion78	9.2.4	Circulation fan (partially special
6.14.3	Bench and central seating group		equipment)
	with bed widening79	9.2.5	Trumatic S 3004/S 5004 hot-air
6.14.4	Round seating group with additional	0.2.0	heater
0.14.4	cushion (foldable)80	9.2.6	Airmix comfort package (special
6.14.5	Round seating group without	5.2.0	equipment)
0.14.5		9.2.7	
0.44.0	additional cushion	9.2.7	Ultraheat additional electric heater
6.14.6	Round seating group with additional	0.00	(special equipment)
	cushion82	9.2.8	Warming unit for waste water pipes
6.14.7	Round seating group with bed		(special equipment)
	widening83	9.2.9	Electrical floor warming unit
6.15	Shower connection point for external		(special equipment)118
	shower (special equipment)84	9.3	Air conditioning unit (special
			equipment)
7	Gas system85	9.3.1	Dometic
7.1	General	9.3.2	Telair120
7.2	Gas bottles86	9.3.3	Truma
7.3	Changing gas bottles 87	9.4	Boiler
7.4	Gas isolator taps	9.4.1	Models with waste gas vent on the
7.5	External gas connection (special	5.4.1	right-hand side of the vehicle
7.5		9.4.2	
7.6	equipment)		Truma boiler (special equipment)124
7.6	DuoControl switching facility	9.4.3	Hot water source (special
	(special equipment) 89	0.5	equipment)
0	Flootwicel eveters 94	9.5	Cooker
8	Electrical system91	9.5.1	Gas cooker
8.1	General safety instructions91	9.5.2	Gas oven (Dometic) (special
8.2	Terms91		equipment)
8.3	12 V power supply 91	9.5.3	Microwave oven (special
8.3.1	Power supply unit CSV 300 92		equipment)
8.4	Electric kit (special equipment) 93	9.5.4	Extractor hood (special
8.4.1	Living area battery		equipment)
8.4.2	Power supply unit CSV 409 94	9.6	Refrigerator133
8.4.3	Panel LT 408	9.6.1	Refrigerator ventilation grill
8.4.4	Connection diagrams98	9.6.2	Operation (Dometic 8 series with
8.5	230 V power supply	0.0.2	manual ignition)
8.5.1	230 V connection	062	Operation (Dometic 8 series with
		9.6.3	·
8.5.2	Connecting 230 V power supply 101		manual power selection MES) 136
8.6	Fuses		

## **Contents**



9.6.4	Operation (Dometic 8 series with		12.2	Maintenance work	
	automatic power selection AES)		12.3	Stabilisers	
9.6.5	Operation (Thetford N3000)	140	12.3.1	General	
9.6.6	Refrigerator door locking		12.3.2	AKS 1300	
	mechanism	142	12.3.3	AKS 3004	
40	Canitam dittings	4.4=	12.4	Manoeuvring system	
10	Sanitary fittings		12.5	Braking system	
10.1	Water supply, general		12.6	Doors	
10.2	Water tank		12.7	Replacing bulbs, external	
10.2.1	Water tank 16 I	146	12.7.1	Front lights	
10.2.2	Water tank 22 I with external flap	4.40	12.7.2	Rear lights	
40.00	(special equipment)	146	12.7.3	Side lights	181
10.2.3	Water tank 40 I (partially special	4.47	12.8	Types of bulbs for exterior	400
40.0	equipment)	147	40.0	lighting	
10.3	Waste water tank (special	440	12.9	Replacing bulbs, internal	
10.4	equipment)		12.9.1	Ceiling lamp (cover with clips)	
10.4	Filling the water system		12.9.2	Recessed halogen light	
10.5	Emptying the water system		12.9.3	Recessed halogen light (flat)	
10.6	Toilet compartment		12.9.4	Recessed light with LED	
10.7	Toilet		12.9.5	Ceiling lamp	
10.7.1	Swivel toilet (Thetford C-200)	152	12.9.6	Spotlight with flexible arm	
10.7.2	Toilet with fixed seat	157	12.9.7	Halogen spotlight (swivelling)	
	(Thetford C-402)	157	12.9.8	Halogen spotlight (movable)	
11	Care	165	12.9.9	Halogen spotlight (movable)	
11.1	External care		12.9.10	Cooker lamp	
11.1.1	General		12.9.11	Garage light	
11.1.1	Washing with a high-pressure	100	12.10 12.11	Spare parts	
11.1.2	cleaner	165	12.11	Vehicle identification plate	
11.1.3	Washing the vehicle		12.12	Warning and information stickers	190
11.1.3	Windows of acrylic glass		13	Wheels and tyres	101
11.1.4	Hot galvanized chassis		13.1	General	
11.1.6	Underbody		13.1	Tyre selection	
11.1.7	Waste water tank		13.2	Tyre specifications	
11.1.7	Interior care		13.4	Handling of tyres	
11.3	Water system		13.4	Changing wheels	
11.3.1	Cleaning the water tank		13.5.1	General instructions	
11.3.1	Cleaning the water tank		13.5.1	Tightening torque	
11.3.2	Disinfecting the water system		13.5.2	Changing a wheel	
11.4	Extractor hood		13.5.4	Changing a wheel at alloy wheel	130
11.5	Air conditioning unit		10.0.4	rims	107
11.5.1	Dometic		13.6	Spare wheel support	
11.5.2	Telair		13.6.1	Spare wheel support in gas bottle	100
11.5.3	Truma		10.0.1	compartment	198
11.6	Winter care		13.6.2	Spare wheel support under the	100
11.6.1	Preparations		10.0.2	vehicle (special equipment)	198
11.6.2	Winter operation		13.7	Tyre pressure	
11.6.3	At the end of the winter season		10.7	Tyre pressure	100
11.7	Lay-up		14	Troubleshooting	201
11.7.1	Temporary lay-up		14.1	Chassis	
11.7.2	Winter lay-up		14.2	Braking system	
11.7.3	Starting up the vehicle after		14.3	Caravan control system (ATC)	
	a temporary lay-up or after		14.4	Manoeuvring system	
	lay-up over winter	175	14.5	Electrical system	
	- 7 - E		14.6	Gas system	
12	Maintenance	177	14.7	Cooker	
12 1	Inspection work	177	1471	Gas cooker/gas oven	





14.7.2 14.8	Microwave oven	205
	source	205
14.8.1	Trumatic S hot-air heater	205
14.8.2	Truma boiler	
14.8.3	Truma hot water source	
14.9	Refrigerator	
14.9.1	Dometic 8 series and Thetford	
14.9.2	Dometic 8 series with MES	
14.9.3	Dometic 8 series with AES	209
14.10	Air conditioning unit	210
14.10.1	Dometic	210
14.10.2	Telair	211
14.10.3	Truma	211
14.11	Water supply	211
14.12	Body	213
15	Special equipment	215
15.1	Weight details for special	
	equipment	215
16	Technical data	
16.1	Table of linear measures	
16.2	Power supply	218
17	Helpful notes	
17.1	Traffic rules in foreign countries	
17.2	Help on Europe's roads	
17.3	Speed limits	221
17.4	Driving with low beam in European	
	countries	223
17.5	Sleeping in the vehicle away from	
	camping areas	223
17.6	Gas supply in European	
	countries	225
17.7	Toll regulations in European	
4= 0	countries	225
17.8	Tips on staying overnight safely	000
47.0	during travel	
17.9	Tips for winter campers	
17.10	Travel checklists	221
18	Inspection plan	229



# Please read this instruction manual completely before using the vehicle for the first time!

Always keep this instruction manual in the vehicle. Also inform all other users of the safety regulations.



▶ The non-observance of this symbol can lead to personal injury.



The non-observance of this symbol can lead to damage being caused to, or inside the vehicle.





This instruction manual contains sections which describe model-specific equipment or special equipment. These sections are specially marked. It may be that your vehicle has not been fitted with this special equipment. In some cases, the actual equipment of your vehicle may therefore be different from that shown in some illustrations and descriptions.

However, your vehicle may be fitted with other special equipment not described in this instruction manual.

Special equipment is described when an explanation is required.

Adhere to the instruction manuals which are separately enclosed.



- ➤ The details "right", "left", "front" and "rear" always refer to the vehicle in direction of travel.
- All dimensions and weight details are "approximate".

Should the vehicle be subjected to damage due to a failure to follow the instructions in this instruction manual, then the guarantee claim is deemed invalid.

Our vehicles are subjected to continuous development. Please understand that we reserve the right to alter the form, equipment and technology. Therefore, no claims can be made against the manufacturer as a result of the contents of this instruction manual. The equipment which was known and included at the time of going to press is described.

The reprinting, translation and copying, including extracts is not permitted without prior written authorisation from the manufacturer.



➤ The vehicle comes without a wheelbrace and vehicle jack. We suggest you obtain a commercially available wheelbrace before you first use your caravan, in case of an emergency. If no AL-KO vehicle jack (special equipment for AL-KO chassis) is present, obtain a conventional commercial scissor-type jack or an hydraulic vehicle jack, in order to have it ready in the case of mishap or emergency. Our authorised dealers and service centres will be happy to advise you.



#### 1.1 General

The vehicle is constructed in accordance with the latest technology and the recognised safety regulations. Nevertheless, personal injury may result and the vehicle may be damaged if the safety instructions in this instruction manual are not followed.

Only use the vehicle in a technically impeccable condition. Follow the instructions in the instruction manual.

Malfunctions which impair the safety of persons or the vehicle should be immediately remedied by qualified personnel.

Have the vehicle's braking and gas systems inspected and repaired by an authorised specialist workshop only.

Alterations to the body are only to be carried out with the authorisation of the manufacturer.


Luggage and accessories may only be transported up to the maximum permissible gross weight.

Observe the test and inspection periods stipulated by the manufacturer.

## 1.2 Environmental tips



- ▷ Be considerate of the environment.
- On board, collect waste water only in the waste water tank or if necessary – in other containers designed for that purpose.
- Only empty the waste water tank and toilet cassette or sewage tank at disposal stations at the camping or caravan sites, which are especially provided for this purpose. When stopping in towns and communities, observe the instructions at caravan sites or ask where there are disposal stations.
- Empty waste water tank as often as possible, even when it is not completely full (hygiene).
  - If possible, flush out waste water tank and, if necessary, drainage pipe with fresh water every time it is emptied.
- Never allow the toilet cassette or sewage tank to become too full. Empty the toilet cassette or sewage tank frequently, at the latest as soon as the level indicator lights up.
- ➢ Separate household waste according to glass, tin cans, plastic and wet waste also when on a journey. Enquire at the town or community authority about disposal points. Household waste is not to be disposed of in waste paper baskets which are situated at car parks.
- Empty waste bins as often as possible into the containers provided for this purpose. This helps to avoid unpleasant smells and an accumulation of rubbish on board.
- When parked, do not allow the engine of the towing vehicle to run more than necessary. When running idle, a cold engine releases more contaminants than usual. The running temperature of the engine is achieved more quickly whilst the vehicle is in motion.
- Use an environmentally-friendly WC chemical agent for the WC which can also be biologically degraded and only use small doses.









- ▶ When staying in towns and communities for long periods, search for parking areas which are specially reserved for caravans and towing vehicles. Enquire at the town or community authority about parking spaces.
- > Always leave the parking places in a clean condition.



## Introduction





## **Chapter overview**

This chapter contains important safety instructions. The safety instructions are for the protection of persons and property.

The instructions address the following topics:

- fire prevention and what to do in case of fire
- general care of the vehicle
- road safety of the vehicle
- towing
- gas system of the vehicle
- electrical system of the vehicle
- water system of the vehicle

#### 2.1 Fire prevention

#### 2.1.1 Avoidance of fire risks



- ▶ Never leave children in the vehicle unattended.
- ▶ Keep flammable materials clear of heating and cooking appliances.
- ▶ Lights can get very hot. When the light is switched on, there must always be a safety distance of 30 cm between light and flammable objects. Fire hazard!
- ▶ Never use portable heating or cooking appliances.
- ▶ Only authorised qualified personnel may make changes to the electrical system, gas system or appliances.

#### 2.1.2 Fire-fighting



- ▶ Always carry a dry powder fire extinguisher in the vehicle. The fire extinguisher must be approved, tested and close at hand.
- ▶ The fire extinguisher is not included in the scope of delivery.
- ► Have the fire extinguisher tested at regular intervals by authorised qualified personnel. Observe the date of testing.
- ▶ Always keep a fire blanket near the cooker.

#### 2.1.3 In case of fire



- Evacuate all passengers.
- ▶ Cut off the electrical power supply and disconnect from the mains.
- ▶ Close regulator tap on the gas bottle.
- ▶ Sound the alarm and call the fire brigade.
- ▶ Fight the fire if this is possible without risk.



- > Acquaint yourself with the position and operation of the emergency exits.
- ▷ Observe the fire extinguisher instructions for use.



All windows and doors which meet the following requirements are considered as emergency exits:

- Open to the outside or can be shifted in horizontal direction
- Opening angle at least 70°
- Minimum diameter of clearance = 450 mm
- Maximum distance from the vehicle floor = 950 mm

#### 2.2 General



- ▶ The oxygen in the vehicle interior is used up by breathing and the use of gas operated appliances. That is why the oxygen needs to be replaced on a constant basis. For this purpose, forced ventilation options (e.g. skylights with forced ventilation, mushroom-shaped vents or floor vents) are fitted to the vehicle. Never cover or block forced ventilations from the inside or outside with objects such as e.g. a winter mat. Keep forced ventilations clear of snow and leaves. There is a danger of suffocation due to increased CO₂ levels.
- ▶ Observe the headroom of the doors.



- As far as the appliances (heater, cooker, refrigerator, etc.) are concerned, the instruction manuals are authoritative. It is imperative that they be observed.
- Fitting accessories or special equipment can alter the dimensions, weight and road behaviour of the vehicle. Some of the parts must be entered in the vehicle papers.
- Only use wheel rims and tyres which are approved for the vehicle. Information concerning the size of the approved wheel rims and tyres is included in the vehicle documents or can be obtained from authorised dealers and service centres.



- ▶ When leaving the vehicle, it is imperative that all doors, external flaps and windows are closed.
- The vehicle may only be driven by drivers who hold a driving licence which is valid for the respective vehicle class.
- ▶ When selling the vehicle, hand over all instruction manuals for the vehicle and the fitted appliances.

## 2.3 Road safety



- ▶ Before commencing the journey, carry out a functional check of indicating and lighting equipment and the brakes.
- ▶ If the vehicle has been stationary for a long period (approx. 10 months) have the braking and gas systems checked by an authorised specialist workshop.
- ▶ Before commencing the journey, secure the hinged pull-down bed.
- ▶ Before commencing the journey, remove the television from the support and store it securely.
- Before commencing the journey, place and secure the flat screen and screen support in the initial position. If the screen holder is installed in a TV cabinet: Close TV cabinet.





- ▶ During the journey, no persons are to travel inside the caravan.
- ▶ In case of underpasses, tunnels or similar obstacles, note the total height of the vehicle (including the roof load).
- ▶ In winter, the roof must be free of snow and ice before commencing the journey.
- ▶ Before commencing the journey, empty the waste water tank.
- ► Check tyre pressure before a journey or every 2 weeks. Wrong tyre pressure causes excessive wear and can lead to damage or even to tyre burst. You can lose control of the vehicle.



- ▷ Before commencing the journey, distribute the payload evenly within the vehicle (see chapter 3).
- When loading the vehicle and when taking a rest from driving, in order to load luggage or food, for example, observe the maximum permissible gross weight and axle loads (refer to vehicle documents).
- Do not exceed the maximum permissible nose weight on the caravan coupling and do not let the weight fall below the minimum nose value. Load the caravan accordingly.
- ▶ While driving with your caravan, the towing vehicle must be equipped with two external mirrors.
- ▷ Before commencing the journey, ensure that all cupboard doors, the toilet compartment door and all drawers and flaps are secure. Engage the refrigerator door securing device.
- ▷ Before commencing the journey, close windows and skylights.
- ▶ Before commencing the journey, close all external flaps and lock them.
- ▷ Before commencing the journey, remove the external supports and retract the corner steadies or steady legs, which are fitted to the vehicle.
- ▷ Before commencing the journey, crank the jockey wheel up as far as possible.
- ▷ Before commencing the journey, put the antenna in park position.
- During the initial journey and each time after changing a wheel, re-tighten the wheel bolts/wheel nuts after 50 km (30 miles). Subsequently inspect them at regular intervals in order to ensure that they are firmly seated.
- > Tyres may not be older than 6 years as the material becomes brittle over time (see chapter 13).

## 2.4 Towing



- ► Care is to be taken when connecting and detaching a trailer. Risk of accident and injury!
- ▶ No persons are to be between the towing vehicle and the trailer during positioning for connecting and detaching.



## 2.5 Gas system

#### 2.5.1 General instructions



- ▶ Before commencing the journey, when leaving the vehicle or when gas equipment is not in use, close all gas isolator taps and the main isolator tap on the gas bottle.
- ▶ No appliance operated by a naked flame (e.g. heater or refrigerator) may be in operation when filling the tank, on ferries or in the garage. Danger of explosion!
- ▶ Do not use appliances operated with a naked flame in closed spaces (e.g. garages). Danger of poisoning and suffocation!
- ▶ Only have the gas system maintained, repaired or altered by an authorised specialist workshop.
- ▶ Have the gas system checked by an authorised specialist workshop according to the national regulations before commissioning. This also applies for not registered vehicles. For modifications to the gas system have the gas system immediately checked by an authorised specialist workshop.
- ➤ The gas pressure regulator and exhaust gas pipes must also be inspected. The gas pressure regulator has to be replaced after 10 years at the latest. The vehicle owner is responsible for seeing that this is carried out.
- ▶ In case of a defect of the gas system (gas odour, high gas consumption) there is danger of explosion! Close regulator tap on the gas bottle immediately. Open doors and windows and ventilate well.
- ▶ If the gas system is defective: Do not smoke; do not ignite any open flames, and do not operate electric switches (light switches etc.).
- ▶ Before using the cooker make sure that there is sufficient ventilation. Open windows or the skylight.
- ▶ Do not use the gas cooker or gas oven for heating purposes.
- ▶ If there are several gas devices, each gas device must have its own gas isolator tap. If individual gas devices are not in use, close the respective gas isolator tap.
- ▶ Ignition safety valves must close within 1 minute after the gas flame has extinguished. A clicking sound is audible. Check function from time to time.
- ► The built-in gas devices are exclusively meant for use with propane or butane gas or a mixture of both. The gas pressure regulator as well as all built-in gas devices are designed for a gas pressure of 30 mbar.
- ▶ Propane gas is capable of gasification up to -42 °C, whereas butane gas gasifies at 0 °C. Below these temperatures no gas pressure is available. Butane gas is unsuitable for use in winter.
- ▶ Regularly inspect the gas tube fitted to the gas bottle connection for tightness. The gas tube must not have any tears and must not be porous. Have the gas tube replaced by an authorised specialist workshop no later than ten years after the manufacturing date. The operator of the gas system must see to it that the parts are replaced.
- ▶ Due to its function and construction, the gas bottle compartment is a space which is open to the exterior. Never cover or block up the standard forced ventilations. Otherwise gas that is emitted can not be diverted to the outside.





- ▶ Do not use the gas bottle compartment as storage space as it is not moisture-proof.
- ➤ Secure the gas bottle compartment against unauthorised access. To do this, lock the compartment.
- ▶ The regulator tap on the gas bottle must be accessible.
- ▶ Only connect gas-operated devices (e.g. gas grill) which have been designed for a gas pressure of 30 mbar.
- ➤ The exhaust gas pipe must be fitted tightly to the heating system and to the vent and must be sealed. The exhaust gas pipe must not show any evidence of damage.
- ▶ Exhaust fumes must be able to escape into the atmosphere unhindered and fresh air must be able to enter unhindered. For this reason, keep the exhaust pipe and intake openings clean and unobstructed (e.g. free from snow and ice). For this reason, no snow walls or aprons may lie against the vehicle.

#### 2.5.2 Gas bottles



- ► Gas bottles are only to be transported within the designated gas bottle compartment.
- ▶ Place the gas bottles in vertical position in the gas bottle compartment.
- ▶ Fasten the gas bottles so that they are unable to turn or tilt.
- ▶ If the gas bottles are not connected to the gas tube, always place the protective cap on top.
- ► Close the regulator tap on the gas bottle before the gas pressure regulator or gas tube are removed from the gas bottle.
- ▶ Use your hands only to connect the gas pressure regulator or the gas tube to the gas bottles. Do not use any tools.
- Only use special gas pressure regulators with a safety valve designed for vehicle use. Other gas pressure regulators are not permitted and cannot meet the demanding requirements.
- Use the gas pressure regulator defroster if the temperature falls below 5 °C.
- ▶ Use only 11 kg or 5 kg gas bottles. Camping gas bottles with built-in check valve (blue bottle with max. 2.5 or 3 kg content) are can be used in exceptional cases with a safety valve.
- ▶ Use the shortest possible tube lengths (150 cm max.) for external gas bottles.
- ▶ Never block the floor ventilation openings below the gas bottles.



## 2.6 Electrical system



- Only allow qualified personnel to work on the electrical system.
- ▶ Prior to carrying out work on the electrical system, switch off all devices and lights, disconnect the battery and disconnect the vehicle from the mains.
- Only use original fuses with the stipulated values.
- ▶ Only replace defective fuses when the cause of the defect is known and has been remedied.
- ▶ Never bridge or repair fuses.

## 2.7 Water system



- ▶ Water left standing in the water tank or in the water pipes becomes undrinkable after a short period. Therefore, before each use of the vehicle, thoroughly clean the water pipes and the water tank. After each use of the vehicle completely empty the water tank and the water pipes.
- ▶ In the case of lay-ups lasting more than a week disinfect the water system before using the vehicle (see chapter 11).



▷ If the vehicle is not used for several days or if it is not heated when there is a risk of frost, empty the entire water system. Make sure that the 12 V power supply on the panel is switched off. Otherwise, the water pump will overheat and may get damaged. Leave the water taps on in central position. Leave the safety/drainage valve (if there is one) and all drain cocks open. Frost damage to appliances, frost damage to the vehicle and deposits in water-carrying components can be avoided in this way.



## **Chapter overview**

This chapter contains important information which has to be noted before commencing your journey or carrying out any tasks before the journey.

The instructions address the following topics:

- keys
- registration
- connecting and detaching to the towing vehicle
- caravan coupling
- caravan control system
- manoeuvring system
- calculating the payload
- · correct loading of the caravan
- external mirrors
- storing the television

At the end of the chapter there is a checklist which once again summarises the most important points.

## 3.1 Keys



Fig. 1 Keys

Two keys (Fig. 1) are included with the caravan.

The keys fit the:

- Conversion door
- Service flaps
- Toilet flap
- Gas bottle compartment flap

Always deposit a replacement key outside the vehicle. Make a note of the key number. Our authorised dealers and workshops can offer assistance in case of loss.

## 3.2 Registration

Your caravan is a vehicle which must be registered. Observe national regulations on registration.

Please remember that certain countries require a separate national code sticker in addition to the EU plate.



## 3.3 Connecting



- ► Care is to be taken when connecting and detaching a trailer. Risk of accident and injury!
- ▶ No persons are to be between the towing vehicle and the trailer during positioning for connecting and detaching.
- ▶ Observe the permissible nose weight and rear axle load of the towing vehicle. Nose weight and rear axle load must not be exceeded. The values of the nose weight and rear axle load are included in the documents of the vehicle and the caravan coupling.
- ▶ Ensure that the interior of the coupling is not soiled and that the movable parts of the coupling (not the ball retainer) are lubricated.
- ▶ The tow ball is not to be lubricated when using a stabiliser. The friction pads are pressed against the coupling ball and thereby generate an antirolling moment. This anti-rolling effect is only guaranteed when the towing vehicle coupling head is free of lubricant and other residues. When lubricating the stabiliser ensure that no lubricant is on the friction pads.



- Caravan with an overrun brake: Do not connect or detach caravan with the overrun brake on.
- Caravan coupling with detachable ball neck: If the ball neck is mounted incorrectly, there is the danger of the trailer breaking away. Observe the instruction manual for the caravan coupling.
- ▷ Do not climb onto the drawbar covering risk of breakage!
- ▷ In order to connect the vehicle, crank the supporting jockey wheel down and set it down on the ground.
- ▷ Do not use the stabilising lever of the stabiliser as a maneuvering aid.



- Check whether the caravan's connector plug fits into the socket of the towing vehicle. If connector plug and socket do not match, ask your authorised dealers and workshops for adapting options.
- > Further information about the stabiliser can be obtained in the manufacturer's instruction manual.

#### Connecting:

- Connect the caravan (see section 3.4). The coupling jaw and the ball must interlock and are not to be loosely superposed. The coupling jaw must completely surround the ball.
- Connect the breakaway brake cable with a loop to a suitable anchorage point on the vehicle, do **not** attach to the tow ball. Thereby, observe the cable length: The cable must not trail on the ground or trigger the braking function around corners.
- Crank the jockey wheel up as far as possible. Adjust the running role in parallel to the direction of travel and to the draw box.
- Insert the connector plug of the caravan in the socket of the towing vehicle. Ensure that the hooks of the safety cover engage with the plug. The hooks prevent the plug from becoming loose during the journey.
- Put the connection cable in a loose loop across the drawbar. Make sure that it does not touch the ground.
- Check whether the caravan coupling is mounted correctly on the coupling ball. Pay attention to the safety indicator.



- Check whether corner steadies and jockey wheel are raised.
- Check the caravan lighting system whilst the towing vehicle is connected.

## 3.4 Caravan couplings



▷ Before connecting, ensure that the tow ball of the coupling device is free of dirt and grease.

#### 3.4.1 AKS 1300 stabiliser




Fig. 2 AKS 1300 stabiliser

#### Connecting:

- Pull up the stabilising lever (Fig. 2,1) as far as possible.
- Turn the handwheel (Fig. 2,2) in an anticlockwise direction as far as possible in the open position.
- Pull the coupling handle (Fig. 2,3) upwards.
- Place the opened stabiliser on the caravan coupling. The coupling handle must audibly lock back into its initial position.
- In addition, push the coupling handle downwards by hand (not with your foot). Closing and securing is carried out automatically.
- Conduct a visual inspection: The green cylinder on the safety indicator (Fig. 2,4) must be visible.
- Turn handwheel in a clockwise direction until it can be felt and heard that the torque limiting mechanism grates.
- Push the stabilising lever down until the marking on the stabilising lever is aligned with that on the stabilising housing (Fig. 2,5).



#### 3.4.2 AKS 3004 stabiliser





Fig. 3 AKS 3004 stabiliser

Fig. 4 Check "AKS closed"

#### Connecting:

- Pull up the stabilising lever (Fig. 3,1) as far as possible.
- Pull the coupling handle (Fig. 3,2) upwards.
- Place the opened stabiliser on the caravan coupling. The coupling handle must audibly lock back into its initial position.
- In addition, push the coupling handle downwards by hand (not with your foot). Closing and securing is carried out automatically.
- Conduct a visual inspection: The green cylinder on the safety indicator (Fig. 3,3) must be visible.
- Activate the stabilising mechanism. Push the stabilising lever (Fig. 3,1) down to its stop limit.
- Conduct a visual inspection: The arrow (Fig. 4,2) must point to "2" (Fig. 4,1).

## 3.5 Caravan control system (ATC) (special equipment)



- ► The steady plus on the connection socket on the towing vehicle must be protected with 15 A or 20 A fuses. Fire hazard!
- ➤ The caravan control system cannot override the physically preset limits. Do not exceed the maximum speed of 100 km/h intended by the designers, and always adapt your speed to suit the weather, road and traffic conditions.



Also read the manufacturer's instruction manual.



Fig. 5 Control LED

1 Control LED



- Couple caravan.
- Use the connection cable to connect the caravan to the towing vehicle. The caravan control system starts a self test. The control LED (Fig. 5, 1) on the caravan lights up red for about 3 seconds.
- Check whether the control LED lights up green after the self test. The caravan control system is now active.

## 3.6 Detaching



- ► Care is to be taken when connecting and detaching a trailer. Risk of accident and injury!
- ▶ In addition, observe the safety instructions with respect to connecting included in this instruction manual.



Do not climb onto the drawbar covering − risk of breakage!

#### Detaching:

- Apply the caravan handbrake.
- Place the wheel chocks behind both of the wheels.
- Remove the connector plug of the caravan from the towing vehicle socket and insert it in the holder on the drawbar.
- Remove the breakaway cable from the towing vehicle.
- Crank the jockey wheel down until it is set firmly on the ground. Now loosen the caravan coupling.
- Using the jockey wheel, lift the drawbar until the towing vehicle can be driven away without risk.

## 3.7 Manoeuvring system (special equipment)



- No persons are to remain inside the caravan while it is being manoeuvred.
- ▶ No persons (in particular children) are to remain inside the manoeuvring area while manoeuvring.
- ▶ In the event of malfunctions, apply the handbrake.
- ▶ Do not use the manoeuvring system as a handbrake.
- ▶ Store the remote control in a safe place inaccessible to children.
- ▶ Always swivel the drive rollers away from the tyres before commencing a journey. If the drive rollers are swivelled onto the tyres during the journey, the tyres could burst.



- ▶ Before manoeuvring, check the tyres and drive rollers and if necessary, remove any sharp stones or similar objects.
- ▶ When manoeuvring on a slope, make sure the drawbar is facing downhill. This will prevent the vehicle from tilting backwards.
- Do not store sensitive devices like cameras of DVD players directly next to the control device or the cable. The manoeuvring system generates electromagnetic fields that can damage such devices.

## Before the journey





- ▶ When manoeuvring, the interval between the remote control and the middle of the vehicle may be a maximum of 10 meters.
- ▷ After switching off the manoeuvring system via the remote control, the control remains in stand-by mode. To shut the manoeuvring system down altogether, it must be disconnected from the battery.
- After manoeuvring is complete, pull the 13-pin plug from the safety socket. The living area battery can otherwise lose its charge.
- ▷ If both brake lights are defective, the circuit of the safety socket is not closed and the manoeuvring system will not work.

Using the manoeuvring system (Mover), the vehicle can be moved without any other aids.

#### Remote control



▷ If the remote control is switched on and no button is pressed for approx. 2 minutes, or a button is pressed and held down for approx. 7 minutes, the remote control switches itself off.

To reactivate the remote control, push the sliding switch to "OFF" (0), wait approx. 2 seconds and then push the sliding switch back to "ON" (I).




Fig. 6 Direction buttons

The vehicle is steered using the direction buttons on the remote control (Fig. 6). The following table describes the function of the individual direction buttons:

No. in Fig. 6	Movement	Function
1	Vehicle forwards	Both wheels turn forwards
2	Vehicle forwards to the left	The right wheel turns forwards
3	Vehicle backwards to the left	The right wheel turns backwards
4	Vehicle backwards	Both wheels turn backwards
5	Vehicle backwards to the right	The left wheel turns backwards
6	Vehicle forwards to the right	The left wheel turns forwards
3+6	The vehicle turns on the spot clockwise	The left wheel turns forwards and the right wheel turns backwards
2+5	The vehicle turns on the spot anti-clockwise	The left wheel turns backwards and the right wheel turns forwards






Fig. 7 Remote control

#### Manoeuvring:

- Detach vehicle (see section 3.6).
- Insert 13-pole plug into the safety socket of the manoeuvring system.
- Push the sliding switch (Fig. 7,3) on the remote control (Fig. 7,1) to "ON"
   (I). If the green LED (Fig. 7,2) lights up, the manoeuvring system is operational.
- Swivel the drive rollers onto the tyres on both sides. To do so, press the "Engage" (Fig. 7,4 and 7) buttons.
- Release the handbrake and remove the wheel chocks.
- Move the vehicle into the required position using the direction buttons (Fig. 7,8).
- Apply the handbrake again (see section 5.1).
- Swivel the drive rollers away from the tyres on both sides. To do so, press the "Disengage" (Fig. 7,5 and 6) buttons.
- Push the sliding switch (Fig. 7,3) on the remote control to "OFF" (0).



Further information can be obtained in the manufacturer's instruction manual.

## 3.8 Payload



- ▶ Overloading the vehicle and wrong tyre pressure can cause tyres to burst. You can lose control of the vehicle.
- ▶ Only the maximum permissible gross weight and the mass in a ready-to-drive condition, not the actual weight of the vehicle, is stated in the vehicle documents. For your own safety, we recommend that you have your loaded vehicle (with all luggage and personal objects) weighed on a public weighbridge before you set out on your journey.



- ▷ Do not exceed the maximum permissible gross weight stated in the vehicle documents by the payload.
- > Adhere to the axle load stated in the vehicle documents.

Load the caravan so that the drawbar coupling head is not pushed downwards due to the permissible nose weight. Heavy objects should be close to the axles and a weight centre should be in the centre of the vehicle.



When loading the caravan observe:

- The permissible maximum caravan load
- The maximum permissible nose weight (e.g. 50 kg)
- The minimum nose weight in accordance with national regulations

This information is in the towing vehicle instruction manual.

## Maximum permitted payloads

Description		Load (kg)
Roof load		200
Bunk beds		100
Pull-down bed		200
Bike rack	Double	35

#### 3.8.1 Terms



- ➤ Technically speaking, the term "mass" has now replaced the term "weight".
   However, "weight" is still the term more frequent in common use. For better understanding, "mass" is therefore only used in the following sections for fixed formulations.
- ▷ All specifications according to EU norm DIN EN 1645-2.

# Maximum permissible gross weight in a laden condition

The maximum permissible gross weight in a laden condition is the weight that a vehicle may never exceed.

The maximum permissible overall weight in laden condition consists of the mass in ready-to-drive condition and of the payload.

In the vehicle documents, the manufacturer has specified the maximum permissible gross weight in a laden condition.

#### **Permitted mass**

The permitted mass is the weight specified by the manufacturer for issuing the type approval. The permitted mass must never exceed the maximum permissible gross weight of the loaded vehicle.

## Mass in ready-to-drive condition

The mass in ready-to-drive condition is the weight of the ready-to-drive standard vehicle.

The mass in ready-to-drive condition is made up as follows:

- Unladen weight (mass of the empty vehicle) with factory-installed standard equipment
- Basic equipment weight

Basic equipment includes all equipment and fluids required for safe and proper vehicle use. The weight of the basic equipment includes:

- Water system filled up to 100 % (water tank and pipes)
- Gas bottles filled up to 100 %
- A full heating system
- A full toilet flushing system
- The power cables for the 230 V power supply
- The installation kit for an auxiliary battery if an auxiliary battery can be used

The waste water and sewage tanks are empty.





## Example for calculating the basic equipment

Water tank with 16 I	16 kg
Gas bottle (11 kg <sub>gas</sub> + 5.5 kg <sub>bottle</sub> )	+ 16.5 kg
230 V power cable	+ 4 kg
Total	= 36.5 kg

In the vehicle documents, the manufacturer specifies the mass in ready-todrive conditions.

#### **Payload**

The payload is made up as follows:

- Additional equipment
- Personal equipment

You will find explanations on the individual components of the payload in the following text.



 ➤ The vehicle's payload can be increased by reducing the weight in a readyto-drive condition. To do this, it is allowed for example to empty the fluid containers or to remove the gas bottles.

#### **Additional equipment**

Additional equipment includes accessories and special equipment. Examples of additional equipment include:

- Spare wheel
- Bike rack
- Satellite unit
- Microwave oven
- Hot water supply

Chapter 15 lists the weights of the various items of special equipment; they may also be obtained from the manufacturer.

#### Personal equipment

Personal equipment includes all items in the vehicle that are not included in the additional equipment. For example, personal equipment can include the following:

- Foodstuffs
- Crockery
- Television
- Radio
- Clothes
- Bedding
- Toys
- Books
- Toiletries

No matter where kept, personal equipment also includes:

- Bikes
- Boats
- Surfboards
- Sports equipment



For the personal equipment, according to the applicable regulations, the manufacturer must use a minimum weight that is determined according to the following formula:

Formula Minimum weight M (kg) =  $10 \times N + 10 \times L + 30$ 

**Explanation** N = maximum number of beds, as stated by the manufacturer L = total length of the caravan in metres, not including the drawbar

Example Caravan with 4 beds and a length of 5 m: Minimum weight M (kg) =  $10 \times 4_{beds} + 10 \times 5_{metres} + 30 = 120 \text{ kg}$ 

## 3.8.2 Calculating the payload



- ► The payload calculation at the factory is partly based on all-inclusive weights. For safety reasons, the maximum permissible gross weight in a laden condition must not be exceeded.
- ▶ Only the maximum permissible gross weight and the mass in a ready-todrive condition, not the actual weight of the vehicle, is stated in the vehicle documents. For your own safety, we recommend that you have your loaded vehicle (with all luggage and personal objects) weighed on a public weighbridge before you set out on your journey.

The payload (see section 3.8.1) is the difference in weight between

- Maximum permissible gross weight in a laden condition and
- Vehicle mass complete in a ready-to-drive condition.

## Example for calculating the payload

	Mass in kg to be calculated	Calculation
Maximum permissible gross weight according to vehicle documents	1500	
Vehicle mass in a ready-to-drive condition, including basic equipment according to vehicle documents	- 1200	
This results in a permissible payload of	300	
Additional equipment	- 40	
For the personal equipment this results in	= 260	

The calculation of the payload from the difference between the maximum permissible gross weight in laden condition and the mass specified by the manufacturer in ready-to-drive condition is however only a theoretical value.

Only if the vehicle is weighed with full tanks, full gas bottles and complete additional equipment on a public weighbridge, can the actual payload be determined.

The actual payload is the difference between the maximum permissible gross weight in laden condition and the weighed vehicle weight.

The result is the weight that is permitted for the actual load of the personal equipment.



## 3.8.3 Loading the caravan correctly



- ▶ Never exceed the maximum permissible gross weight.
- ▶ Distribute the load evenly on the left and right sides of the vehicle.
- ▶ Store all objects in such a way that they cannot slip.
- ➤ Store heavy objects (awning, tin cans, etc.) close to the axles. Low-lying storage compartments whose doors do not open in the direction of travel are particularly suited for storing heavy objects.
- ► Stack light objects (laundry) in the roof storage cabinets.
- ▶ Never concentrate the caravan load at the rear.

The payload arrangement recommended cannot be adhered to consequently as the storage facilities are to be found throughout the complete caravan. Ensure that heavy items are close to the axles and the lower area, i.e. directly above the vehicle floor. Store heavy objects (awning, tin cans, etc.), if possible, in the towing vehicle.




Fig. 8 Incorrect weight distribution

#### Incorrectly loaded

Loads stored apart from each other (Fig. 8) lead to inclination to skid.




Fig. 9 Correct weight distribution

#### **Correctly loaded**

Do not store heavy objects such as awnings, tin cans, etc. in the caravan but rather in the towing vehicle. Secure bicycles on the roof of the towing vehicle. Store all loads close to the axle (Fig. 9).



## 3.8.4 Caravan load, nose weight and axle load



The nose weight of the caravan may not exceed 100 kg.



▷ The information on the towing vehicle documents is important for the selection of the car and caravan.




Fig. 10 Caravan load, nose weight and

- 1 Caravan load
- 2 Nose weight
- 3 Axle load

#### Caravan load

The caravan load (Fig. 10,1) stipulated in the towing vehicle documents provides information as to the **maximum weight** which the towing vehicle is permitted to tow. The caravan load refers to the **actual** weight of the caravan and **not** to the maximum permissible gross weight of the caravan.

#### Example

The towing vehicle may tow 1,200 kg. If the caravan has a maximum permissible gross weight of 1,200 kg and in fact weighs 900 kg, it can be loaded with another 300 kg. If however the caravan has a maximum permissible gross weight of 1,400 kg, it may only be loaded to a maximum of 1,200 kg.

## Nose weight

The nose weight (Fig. 10,2) specifies how much weight the caravan drawbar can apply to the caravan coupling of the towing vehicle. Information is to be found in description of the caravan couplings and the vehicle documents. Therefore, a caravan coupling with a permissible nose weight of 50 kg may not support a loaded caravan which has a nose weight of 75 kg. Additionally, for the permissible gross weight the nose weight must be taken into consideration. If necessary the payload in the towing vehicle must be reduced by the amount of the nose weight.

The maximum permissible gross weight for the towing vehicle and for the caravan is not to be exceeded.

Only when the nose weight is adapted optimal to the towing vehicle and caravan combination, the towing vehicle and caravan achieves its maximum stability and safety in highway traffic. The optimal nose weight is simultaneously the maximum possible nose weight.

- Please refer to the vehicle documents and the description of the caravan coupling for the maximum permissible nose weight.
- If different values are specified in the vehicle documents and in the description of the caravan coupling: Please select the lowest value. This value is the maximum possible nose weight for the towing vehicle and caravan.

## Before the journey



- Check the nose weight before each journey, e.g. with a nose weighing scales. To obtain a correct value, position the nose weighing scales vertical under the coupling jaw and place the caravan drawbar horizontal.
- The payload in the caravan must be distributed in such a way that the measured nose weight comes as close as possible to the maximum permissible nose weight. The maximum permissible nose weight is not be exceeded.

#### Axle load

The axle load (Fig. 10,3) is also specified in the vehicle documents of the towing vehicle and provides information concerning the permissible maximum load for the front and rear axles. The axle load may not be exceeded by a trailer. The above illustration shows where which forces act on the car and caravan.

#### 3.8.5 Bike rack (special equipment)



- ▶ Observe the permissible axle loads and maximum permissible gross weight when loading the bike rack.
- ▶ Do not fall below the minimum nose weight.
- ▶ Bicycles may protrude at the side by a maximum of 40 cm, measured from the outer edge of the tail lights. However, a total width of 2.5 m must not be exceeded. Adjust the attachments for the bikes accordingly. The lateral overhang must be marked with a red flag.
- ▶ Load the bike rack with bicycles only (max. two units).
- ► Fasten bicycles using the straps provided and check to see that they are secure after you have driven a few kilometres.
- ► Check the secure attachment of the bicycles on the bike rack after the first 10 km and then at each break in the journey.
- Do not use the bike rack as luggage rack or ladder.



- > The bike rack is only to be used for transporting bicycles.
- ➤ The gross weight specified by the manufacturer must not be exceeded.
- > The identification plate and rear lights must not be covered.
- > The maximum permissible payload of the bike rack is 35 kg.
- When loading the bike rack, observe the centre of gravity. If the bike rack is only loaded with **one** bicycle, position the bicycle as closely as possible to the vehicle wall.
- Driving with a folded out bike rack without bicycles is not permitted.
- Before every journey, check: Is the bike rack without bicycles folded in correctly? Are the bicycles securely fastened to the bike rack using the bike rack belts?

## Before the journey



#### Front bike rack

The bike rack is attached to the struts of the drawbar with the installation material.




Fig. 11 Front bike rack

Loading the bicycles:

■ Put the bikes on to the bike rack (Fig. 11,2) and secure them with quick straps (Fig. 11,1).

#### Bike rack on the rear wall

Depending on the model, the bike rack is either screwed directly onto the rear wall or clipped into special brackets at the rear. Beneath the vehicle the bike rack is screwed to the floor plate.



Fig. 12 Bike rack on the rear wall

Loading the bicycles:

- Put the bikes onto the bike rack and secure them with quick straps.
- In addition, secure each bicycle on the retaining bracket or retaining arm.

#### 3.9 External mirrors



▶ Before every journey, re-adjust the external mirrors on the towing vehicle for safety reasons.



 Additional mirrors must be EC-type certified and thus meet the EC guidelines.






Fig. 13 External mirrors

When towing a trailer, the towing vehicle must be equipped with two external mirrors. The external mirrors ensure that the roadway next to the trailer can be clearly seen.

The following applies when purchasing additional mirrors

- If possible, take the towing vehicle and caravan with you.
- Test on site to see if they fit.
- Check that the mirror is suitable for the vehicle and the seating position of the driver.

## 3.10 TV unit (special equipment)



- ▶ Before commencing the journey, place and secure the flat screen and screen support in the initial position. If the screen holder is installed in a TV cabinet: Close TV cabinet.
- ▶ Before commencing the journey, ensure that the antenna is in park position. Danger of accidents! Park position means: The antenna points towards the back, is fully lowered and is locked in this position.



▷ If there is a risk of frost, do not leave the flat screen television in the vehicle.



Further information on positioning the flat screen can be obtained from chapter 6.



## 3.11 Road safety



► Check tyre pressure before a journey or every 2 weeks. Wrong tyre pressure causes excessive wear and can lead to damage or even to tyre burst. You can lose control of the vehicle.

Before commencing the journey, work through the checklist:

## Towing vehicle with caravan

No.	Checks	Checked
1	All vehicle documents are on board	
2	Two external mirrors fitted to towing vehicle	
3	Nose weight has not been exceeded or fallen below the minimum	
4	Tyres in proper condition	
5	Road lighting system working	
6	Overrun brake functions correctly	
7	Brakes react evenly	
8	When braking, the towing vehicle and caravan remain in the lane	
9	Total height determined and noted. Keep the height information close at hand in the towing vehicle	

#### Housing body, outside

10	Awning completely retracted	
11	Roof free of snow and ice (in winter)	
12	External connections and lines disconnected and stored away	
13	External supports removed	
14	Corner steadies and jockey wheel cranked as high as possible	
15	Wheel chocks removed and stored away	
16	Entrance step is stored securely or retracted	
17	External flaps closed and locked	
18	Conversion door locked	

#### Housing body, inside

19	Windows and skylights closed and locked	
20	Television removed from the support and securely stored	
21	Flat screen secured	
22	Television antenna retracted (if one is built in)	
23	Loose parts stored away or fixed in position	
24	Open storage spaces empty	
25	No gas cartridges or other easily flammable materials stored in the roof cupboard of the awning light	
26	Refrigerator door secured	
27	Refrigerator set to 12 V operation	
28	All drawers and flaps closed	
29	Inner doors and table secured	
30	Pull-down bed secured	





## Gas system

No.	Checks	Checked
31	Gas bottles firmly fixed in the gas bottle compartment so that they are unable to turn	
32	If the gas bottles are not connected to the gas tube, always place the protective cap on top	
33	If there is no supplied crash protection unit: Regulator tap on the gas bottle and gas isolator taps are closed	

## **Electrical system**

34	Check the battery voltage of the living area battery (see chapter 8). If a battery voltage is displayed on the panel which is too low then the living area battery must be re-charged. Observe the notes and instructions in chapter 8	
	Commence journey with fully charged living area battery.	

# Water system housing body

35	Mobile waste water tank stored away and secured in the gas bottle compartment	
36	Water system emptied in case of risk of frost. Watertaps and drain cocks open	









## **Chapter overview**

This chapter contains instructions on how to drive the caravan.

The instructions address the following topics:

- driving speed
- brakes
- driving in reverse

## 4.1 Driving with the caravan



- ▶ During the journey, no persons are to travel inside the caravan.
- ► The caravan constructions were designed for a maximum permissible speed of 100 km/h (60 mph). Therefore never drive faster than 100 km/h (60 mph).
- ▶ Please always observe the speed limits in the individual countries (see chapter 17).

The main differences between driving with a caravan and driving without a caravan are the increased vehicle width and length, a decreased acceleration and an increased vehicle stopping distance. Therefore, adapt your driving technique to the altered road behaviour resulting from driving with a caravan.

#### 4.2 Brakes



Have defects on the braking system immediately remedied by an authorised specialist workshop.

#### Before each journey

Before each journey, check by means of a braking test:

- Does the overrun brake function?
- Do the brakes react evenly?
- Do the towing vehicle and the caravan remain in the lane when braking?


## 4.3 Driving in reverse



- When driving in reverse, the caravan reacts in exactly the opposite direction to the steering movements of the towing vehicle. If you steer the towing vehicle to the left, the caravan moves to the right.
- Never back up without a second person to direct you.

As far as all models with an automatic reverse driving mechanism are concerned, the caravan can be reversed without difficulty. In addition to the rolling resistance, residual braking power must be taken into account.









Fig. 14 Approach

Fig. 15 Steer to the left

#### Driving in reverse:

- Drive up to the entrance until the rear of the caravan is roughly level with the entrance (Fig. 14).
- Steer the stationary towing vehicle and trailer to the left (Fig. 15).
- Reverse with caution. The caravan moves to the right.






Fig. 16 Approach

Fig. 17 Steer to the right



- ➤ The angle between the vehicles must not be too narrow, otherwise the corners will bump against each other. This can cause major damage to the vehicles. Get someone to direct you!
- As soon as both vehicles are at an approximate angle of 120° to each other, come to a stop (Fig. 16).
- Steer to the right and reverse with caution (Fig. 17).
- Continue to reverse, correcting the steering if necessary.
- For the last 2 to 3 m, steer to the left once more so that the towing vehicle and trailer are in line.



## **Chapter overview**

This chapter contains instructions on how to pitch the vehicle.

The instructions address the following topics:

- handbrake
- wheel chocks
- operation of the supports
- entrance step
- mobile waste water tank
- 230 V connection
- refrigerator
- aligning the antenna



Pitch the vehicle so that it is as horizontal as possible. Secure the vehicle to prevent it from rolling.

#### 5.1 Handbrake



▷ Do not climb onto the drawbar covering – risk of breakage!

Firmly apply the handbrake when parking the vehicle.




Fig. 18 Handbrake

To release it, push the handbrake (Fig. 18,1) forwards.

## 5.2 Wheel chocks

Use the two wheel chocks even when the upward or downward gradients are of a minimum.

#### 5.3 Corner steadies



- Do not use the fitted corner steadies as a vehicle jack. The corner steadies are only for stabilising the pitched vehicle. The vehicle wheels are not to be raised above the ground.
- When pitching the vehicle, ensure that the corner steadies are evenly loaded.
- ▷ Before driving away, wind up the corner steadies as far as they can go.






▶ When the ground is soft, place a pad or block under the supports in order to prevent the vehicle from sinking into the ground.

In order to stabilise the pitched caravan use the corner steadies fitted as standard.

With the assistance of the jockey wheel position the pitched caravan in a horizontal position. For control purposes use a small spirit level.

Crank down the corner steadies after the caravan is in an absolutely horizontal position.



1 2 HYW07437

Fig. 19 Corner steady cranked down (variant 1)

Fig. 20 Corner steady cranked down (variant 2)

Cranking down:

- Place the hand crank handle provided as standard on the hexagonal nut (Fig. 19,1 or Fig. 20,1) of the corner steady (Fig. 19,2 or Fig. 20,2).
- Rotate the hand crank in a clockwise direction. The corner steady is swung downwards.

Cranking upwards:

Turn the crank handle in an anticlockwise direction. The corner steady is swung upwards.

## 5.4 Entrance step (free-standing)



- ► Make sure that the entrance step stands on secure and level ground. This will prevent the entrance step from toppling over.
- ▶ Do not step on the edges of the entrance step. Danger of slipping!
- ► Secure the entrance step to the ground, for example, with tent pegs. This way the entrance step cannot slip away.




Fig. 21 Entrance step (free-standing)

■ Place the entrance step (Fig. 21,1) in front of the entrance to the caravan.



## 5.5 Waste water tank, mobile (special equipment)




Fig. 22 Waste water tank, mobile

The waste water tank (Fig. 22,1) is stored inside the caravan gas bottle compartment during the journey. The drain pipe (Fig. 22,3) of the caravan is located at the bottom of the vehicle - on the left hand side in the direction of travel.

Before using the water system: Place the waste water tank under the caravan in such a way that the opening (Fig. 22,2) of the waste water tank is under the drain pipe.

### 5.6 230 V connection

The vehicle can be connected to a 230 V power supply (see chapter 8).

## 5.7 Refrigerator

The 12 V operation of the refrigerator is only possible when a towing vehicle is connected and the vehicle engine is running. When the vehicle engine is switched off, switch the refrigerator to 230 V operation or gas operation.

## 5.8 Satellite unit (special equipment)



▶ Before commencing the journey, ensure that the antenna is in park position. Danger of accidents!



- The vehicle must be still during the satellite search. Do not walk through the vehicle.
- > Satellite reception is only possible, when the antenna is positioned in direct line of sight of the chosen satellite and the view is not blocked in any way.
- > Also read the manufacturer's instruction manual.

## 5.8.1 Equipment with automatic antenna alignment (Alden)

The satellite unit is equipped with an automatic positioning unit. This automatic positioning unit ensures that the antennas are aligned accurately.

The flat screen incorporates a digital receiver.

The satellite unit is operated via remote control.






Fig. 23 Remote control

- 1 TV button
- 2 On/Off key
- Memory buttonsFunction buttons

Setting up the unit:

- Switch on the television.
- Press the key "(Fig. 23,2) on the remote control.

  The satellite antenna repositions itself out of the park position and into search mode. When the unit finds the satellite, you will hear a signal tone.
- Use the memory buttons (Fig. 23,3) or the function buttons (Fig. 23,4) to set the required transmitter.

## 5.8.2 Equipment with semi-automatic antenna alignment (Alden)

The satellite unit is equipped with a semi-automatic positioning unit.

The flat screen incorporates a digital receiver.

The satellite unit is operated via remote control.




Fig. 24 Remote control for television

- 1 TV button
- 2 On/Off key
- 3 Memory buttons
- 4 Function buttons

Switching on the satellite unit:

- Switch on the television.
- Press the key "()" (Fig. 24,2) on the remote control for the television. The unit switches to search mode. You will hear a continuous tone.
- Press the key "☐" on the remote control for the antenna. The satellite antenna lifts out of the park position and moves to the last position entered.
- To switch to television reception on the TV remote control, press the TV button (Fig. 24,1). The signal tone will stop. An image will appear on the screen.

Setting up the antenna:

- Use the memory buttons (Fig. 24,3) on the TV remote control or the function buttons (Fig. 24,4) to select the desired station.
- On the remote control for the antenna, use the keys "☐" or "☐" to correct the angle of the antenna in accordance with the enclosed cards.
- Loosen antenna mast clamp.

## Pitching the caravan



- Turn antenna slowly. When the antenna finds the satellite, you will hear a signal tone.
- Optimise the reception by turning and tilting the antenna.
- Slightly retighten the antenna mast clamp.

## Lowering the antenna for driving:

- Loosen antenna mast clamp.
- Turn the antenna until the slot in the clamp and the slot in the antenna mast are congruent with each other.
- Press the key "「" on the remote control for the antenna. The satellite antenna moves into park position.
- Check whether the antenna is fully lowered and points to the rear of the vehicle.
- Slightly retighten the antenna mast clamp.
- Switch off the television.





## Chapter overview

This chapter contains instructions about living in the vehicle.

The instructions address the following topics:

- opening and closing the doors and external flaps
- light switches
- adjusting the halogen spotlights
- positioning the television
- heating the vehicle
- ventilation of the vehicle
- opening and closing the windows and blinds
- opening and closing the skylights
- converting tables
- use of the beds
- use of the external shower

#### 6.1 **Conversion door**



Only drive with locked doors.



- during an accident.
- When leaving the vehicle, always lock the doors.

#### 6.1.1 Conversion door, outside



Fig. 25 Door lock of conversion door, outside

#### Opening:

■ Insert the key into the locking cylinder (Fig. 25,1) and turn towards the "[1]" symbol. The door lock is unlatched.



- Return the key to the central position and remove it.
- Pull on the handle (Fig. 25,2). The door is open.

#### Locking:

■ Insert the key into the locking cylinder (Fig. 25,1) and turn towards the "[7]" symbol. The door lock is locked.



Return the key to the central position and remove it.





For conversion doors with a left-hand opening, locking and opening is done
 in the reverse directions to those of the conversion door shown.

## 6.1.2 Conversion door, inside




Fig. 26 Door lock of conversion door, inside

Opening: ■ Push the handle (Fig. 26,1) down.

*Locking:* ■ Turn the handle (Fig. 26,1) approx. 45° upward and leave it in this position.

## 6.1.3 Window conversion door (Seitz) (special equipment)

The conversion door window is fitted with a Roman shade.



Fig. 27 Roman shade

Closing:

■ Grip the Roman shade (Fig. 27,2) in the middle of the holding bar (Fig. 27,1), pull it upwards and then release it at the desired height. The Roman shade will stay at this height.

*Opening:* ■ Grip the Roman shade in the middle of the holding bar and push it down.

# 6.1.4 Folding insect screen on the conversion door (special equipment)



▷ Open the insect screen completely before closing the conversion door.





Fig. 28 Insect screen

*Closing:* ■ Pull out the insect screen completely by the bar (Fig. 28,1).

*Opening:* Push the insect screen into its initial position by the bar (Fig. 28,1).

## 6.2 External flaps



- ▷ Before commencing the journey, close all external flaps and lock them.
- > To open and close the external flap, open or close all locks that are fitted to the external flap.



When leaving the vehicle, close all external flaps.

The external flaps fitted to the vehicle are all fitted with identical locking cylinders. Therefore, all locks can be opened with a single key.

## 6.2.1 Flap lock, elliptical-shaped



During rain, water can penetrate the opened flap lock. Therefore close the lock handle.




Fig. 29 Flap lock, elliptical-shaped, closed

Opening:

- Insert key into locking cylinder (Fig. 29,1) and turn a quarter turn in an anticlockwise direction. The lock handle (Fig. 29,2) snaps out.
- Remove the key.
- Turn lock handle one quarter turn in an anticlockwise direction. The flap lock is open.



#### Closing:

- Firmly close the external flap.
- Turn lock handle in a clockwise direction until it is horizontal. The flap lock is now engaged but not locked.
- Insert key into locking cylinder.
- Press down lock handle with key inserted and turn key a quarter turn in a clockwise direction. The lock handle will stay bolted.
- Remove the key.

## 6.2.2 Flap lock with recessed handle



➤ To open the external flap, pull all the lock handles fitted to that particular external flap at the same time.



Fig. 30 Flap lock with recessed handle

### Opening:

- Insert key into locking cylinder (Fig. 30,1) and turn a quarter turn. The flap lock is unlatched.
- Remove the key.
- Pull on the lock handle (Fig. 30,2). The external flap is open.

#### Closing:

- Firmly close the external flap.
- Insert key into locking cylinder and turn a quarter turn. The flap lock is locked.
- Remove the key.



## 6.2.3 Flap lock, rectangular



Fig. 31 Flap lock, rectangular, closed

Opening:

- Insert key into locking cylinder (Fig. 31,1) and turn a quarter turn. The lock handle (Fig. 31,2) snaps out.
- Remove the key.
- Turn the lock handle one quarter turn. The flap lock is open.

Closing:

- Firmly close the external flap.
- Turn lock handle until it is horizontal. The flap lock is now engaged but not locked.
- Insert key into locking cylinder.
- Press down lock handle with key inserted and turn key a quarter turn. The lock handle will stay bolted.
- Remove the key.

## 6.2.4 Flap for toilet cassette




Fig. 32 Flap for toilet cassette

Opening:


- Insert key into locking cylinder (Fig. 32,1) of the push-button lock and turn a quarter turn.
- Remove the key.
- Press both push-button locks (Fig. 32,2) simultaneously with your thumb and open the flap for the toilet cassette.

Closing:

- Close the flap for the toilet cassette and press it shut.
- Insert key into locking cylinder (Fig. 32,1) and turn a quarter turn.
- Remove the key.



## 6.2.5 Flap for the 230 V connection, square



Recessed grip
 External flap

Fig. 33 Flap for the 230 V connection

Opening:

- Reach into the recessed grip (Fig. 33,1) on the external flap (Fig. 33,2) and swing the external flap upward.
- *Closing:* Swivel the external flap downwards and press it shut.

# 6.2.6 Cap for the drinking water filler neck (only for water tank 40 l)




Fig. 34 Cap for the drinking water filler neck



▶ The drinking water filler neck is indicated by the symbol "♣7" (Fig. 34,1).

Opening:

- Insert the key in the locking cylinder (Fig. 34,2) and turn it in an anticlockwise direction.
- Remove cap.

Closing:

- Insert the cap in the drinking water filler neck.
- Turn key in a clockwise direction.
- Remove the key.

## 6.3 Furniture flaps



- ▷ Before commencing the journey, close all furniture flaps and inner doors and lock them.
- ➤ The furniture flaps shown in this section are examples. Depending on the model, the locks and handles on the furniture flaps may differ to those displayed here.



## 6.3.1 Furniture flaps with push button








Fig. 36 Furniture flap with push button (square)

Opening:

- Press inner part of the lock. The push button jumps out (Fig. 35 or Fig. 36).
- Hold push button and open furniture flap.

Closing:

- Press furniture flap shut.
- Press push button in until it locks. The furniture flap is closed correctly when the fastener locks into place.

## 6.3.2 Furniture flaps with handle




Fig. 37 Furniture flap with handle (example)

Opening:

■ Pull handle (Fig. 37) until furniture flap is open.

Closing:

■ Push down furniture flap until flap hinge perceptibly closes.



## 6.3.3 Furniture flaps with handle and push button



Fig. 38 Furniture flap with handle (example)

Opening:

- Press the release knob (Fig. 38,1) on the handle (Fig. 38,2) and hold it down
- Pull handle until furniture flap is open.

Closing:

■ Press the furniture flap down until you can feel the flap hinge close and hear the lock snap into place.

## 6.3.4 Furniture flaps with pressurised release



Fig. 39 Furniture flaps with pressurised release (example)

Opening:

- Press against the lower edge of the furniture flap.
- Reach behind the lower edge and open the furniture flap.

Closing:

■ Press the furniture flap down until you can feel the flap hinge close and hear the lock snap into place.


## 6.4 Light switch

### 6.4.1 Entrance area



➤ The light switches shown in this section are examples. Depending on the model, the type and allocation of the light switches may differ to those displayed here.








Fig. 40 Light switch

Fig. 41 Awning light

The entrance area has light switches (Fig. 40,1-4) for the following lamps:

- Entrance lights
- Awning light (light points downwards)
- Awning light (light points upwards)
- Living area lights

## 6.4.2 Living area



➤ The lamps shown in this section are examples. Not all lamps used in the vehicle are shown. The examples are intended to clarify the possible positions for the light switches. The type and appearance of the light switches can deviate from those shown here.




Fig. 42 Interior light, switch mounted directly on the lamp




Fig. 43 Interior light, light switch separate from the lamp

The light switches in the living area are located directly on the corresponding lamp (Fig. 42,1) or next to the lamp (Fig. 43,1).



## 6.4.3 Recessed light with LED



Fig. 44 Recessed light, light switch in the lamp

The light switch is located in the recessed light. To switch on and off, press the interior of the recessed light (Fig. 44,1).

## 6.5 Spotlight



- ▶ Bulbs and light fittings can be extremely hot.
- ▶ Allow the light bulbs and lamp holders to cool down before touching them.
- ▶ If the light is switched on or still hot, there must always be a safety distance of at least 30 cm between stores or curtains and flammable objects. Fire hazard!



Fig. 45 Spotlight




Fig. 46 Spotlight with flexible arm

#### Rotating:

■ Grasp the housing (Fig. 45,1 or Fig. 46,1) and swivel it.

The housing can be pivoted in various directions:

- To the left and to the right
- Up and down

## 6.6 Spotlight (moveable)



- ▶ Bulbs and light fittings can be extremely hot.
- ▶ Allow the light bulbs and lamp holders to cool down before touching them.
- ▶ If the light is switched on or still hot, there must always be a safety distance of at least 30 cm between stores or curtains and flammable objects. Fire hazard!






Fig. 47 Spotlight

Rotating:

■ Grasp the housing (Fig. 47,2) and turn it.

The housing can be turned in different directions:

- To the left and to the right
- Up and down

Shifting:

- Grip holder (Fig. 47,1) and turn by approx. 45°.
- Push spotlight along the rail system to desired position.

Removal:

- Grip holder (Fig. 47,1) and turn by approx. 90°.
- Remove spotlight from rail.

The spotlight can be installed in any position into the rails.

## 6.7 Holder for flat screen



▶ Before commencing the journey, place and secure the flat screen and screen support in the initial position. If the screen holder is installed in a TV cabinet: Close TV cabinet.



▷ If there is a risk of frost, do not leave the flat screen television in the vehicle.



> Also read the manufacturer's instruction manual.



#### 6.7.1 Holder on the column

The holder for the flat screen is attached to a column.




Fig. 48 Holder on the column

Positioning:

- Push the release lever (Fig. 48,2) to the side and turn the holder (Fig. 48,3) with the flat screen to the desired position.
- Press flat screen slightly upward and swivel it to the desired position. Three different inclination angles may be used.

Storing away:

■ Turn flat screen back until the holder (Fig. 48,3) engages in the lock (Fig. 48,1).

#### 6.7.2 Rail-mounted holder

The holder for the flat screen is fixed to a rail.




Fig. 49 Rail-mounted holder

Positioning:

- Undo the tommy screw (Fig. 49,2) and adjust the holder (Fig. 49,4) in the rail (Fig. 49,1) until it is at the desired height.
- Re-tighten the tommy screw.
- Undo the tommy screw (Fig. 49,3).
- Pull the release knob (Fig. 49,6). The jointed arm (Fig. 49,5) is unlocked.
- Swivel flat screen into desired position.
- Re-tighten the tommy screw (Fig. 49,3).

Storing away:

- Undo the tommy screw (Fig. 49,3).
- Swing the flat screen back into its original position until you hear the jointed arm (Fig. 49,5) lock into position.
- Re-tighten the tommy screw (Fig. 49,3).
- Undo the tommy screw (Fig. 49,2), adjust the holder (Fig. 49,4) to the desired height and re-tighten the tommy screw.



### 6.7.3 Holder in the TV cabinet

The flat screen is attached to a console in the TV cabinet.




Fig. 50 Holder in the TV cabinet

Positioning:

- Push the unlocking bar (Fig. 50,1) in.
- Pull out the extension (Fig. 50,2) as far as possible.
- Swivel flat screen into the desired position.

Storing away:

- Swing back flat screen into its original position.
- Push in the extension (Fig. 50,2) until the unlocking bar (Fig. 50,1) engages.

## 6.7.4 Holder in the TV compartment

The flat screen is fixed to a lifting mechanism in the TV compartment.




Fig. 51 TV compartment



Fig. 52 Lifting mechanism

Positioning:

- Lightly depress the cover (Fig. 51,1) of the TV compartment in the centre. The extension column (Fig. 52,3) is released and starts to move upwards.
- Pull the release knob (Fig. 52,1) and swivel holder (Fig. 52,2) with flat screen to the desired position.

Storing away:

- Turn the flat screen back into the original position until holder (Fig. 52,2) engages in the lock.
- Press the middle of the cover (Fig. 51,1) downwards against the resistance of the extension column (Fig. 52,3) until the locking mechanism engages.



## 6.8 Heating



▶ During heater operation, the exhaust gas pipe in the wardrobe will get hot. Therefore do not keep any heat-sensitive garments right next to the exhaust gas pipe (see also chapter 9).



The operation of the heater is described in chapter 9.

### 6.9 Ventilation



The oxygen in the vehicle interior is used up by breathing and the use of gas operated appliances. That is why the oxygen needs to be replaced on a constant basis. For this purpose, forced ventilation options (e.g. skylights with forced ventilation, mushroom-shaped vents or floor vents) are fitted to the vehicle. Never cover or block forced ventilations from the inside or outside with objects such as e.g. a winter mat. Keep forced ventilations clear of snow and leaves. There is a danger of suffocation due to increased CO<sub>2</sub> levels.



- ➢ Although sufficient ventilation is provided, in certain weather conditions, condensation can form on metal objects (e.g. screwed connections in the floor).
- Additional cold spots can occur at thermal "bridges" (e.g. lifting roof edges, mushroom-shaped vents, skylight edges, sockets, filler necks, flaps, etc.).

#### Condensation

Ensure that there is a continuous exchange of air by providing frequent and efficient ventilation. This is the only method for ensuring that condensation and resulting mould is not formed during cool weather. During the colder season, a pleasant living climate is created if heating output, air distribution and ventilation are synchronised.

If the vehicle is laid up for a longer period, occasionally ventilate it well, especially in summer as heat accumulation can occur. Do not only air the interior, but also the storage compartments which are accessible from the outside. Air the parking place as well if the vehicle is parked in a closed space (e.g. garage). The occurrence of condensation could lead to the formation of mould.

#### 6.10 Windows



- ▶ The windows are fitted with a blind or Roman shade and with an insect screen or folding insect screen. After the latch has been released, the blind and insect screen automatically spring back to the initial position by tensile force. In order not to damage the tension mechanics, hold onto the blind or insect screen and allow it to slowly return to the initial position. The Roman shade and folding insect screen are made of thin woven fabric. In order not to damage the Roman shade or the insect screen, grasp the respective handle and carefully return it to the initial position.
- Do not keep blinds closed over a longer period of time as that can cause increased material wear.





▷ If the blind or the Roman shade is completely closed, exposure to direct sunlight can cause heat to accumulate between the blind/the Roman shade and the window. The window could be damaged.

Therefore, if the shade is installed in the bottom blind box, close the shade only 2/3 when sunlight is intense. This allows the heat to escape between the window and the shade.

If the shade is installed in the top blind box, close the shade fully and open it regularly.

Also move the window into the "continuous ventilation" position.

- ▷ Before commencing the journey, close the windows.
- Depending on the weather, close the windows far enough to prevent moisture from entering.
- > To open and close the window, open or close all catch levers which are fitted to the window.




- When leaving the vehicle, always close the windows.
- ▷ In extreme weather conditions or if the temperature fluctuates strongly, a light condensation film can form on the double-glazed acrylic glass. The glass is designed in such a way that condensation can evaporate when the external temperature increases. There is no danger of the double-glazed acrylic glass being damaged by condensation.

## 6.10.1 Hinged window with rotary hinges



- ▶ When opening the hinged windows, ensure that there are no torsional forces. Open and close the hinged windows evenly.
- If the catch lever is equipped with a safety knob, press the safety knob when operating the catch lever.








Fig. 53 Catch lever with safety knob in "closed" position

Fig. 54 Catch lever in "closed" position

#### Opening:

- Press and hold the security button (Fig. 53,1), if present.
- Turn the catch lever (Fig. 53,2 or Fig. 54,3) a quarter turn towards the centre of the window.



Fig. 55 Hinged window with rotary hinges


■ Open the hinged window until the required position has been reached and use knurled knob (Fig. 55,1) to secure in position.

The hinged window remains locked in the required position.


#### Closing:

- Turn knurled knob (Fig. 55,1) until the latch is released.
- Close the hinged window.
- Press and hold the security button (Fig. 53,1), if present.
- Turn the catch lever (Fig. 53,2 or Fig. 54,3) a quarter turn towards the window frame. The locking catch (Fig. 53,3 or Fig. 54,2) on the catch lever is entirely on the inner side of the window catch (Fig. 53,4 or Fig. 54,1).





Catch lever with safety knob in Fig. 56 "continuous ventilation" posi-



Catch lever in the "continuous Fig. 57 ventilation" position

#### **Continuous ventilation**

With the catch lever, the hinged window can be placed in two positions:

- "Continuous ventilation" (Fig. 56 and Fig. 57)
- Firmly closed (Fig. 53 and Fig. 54)

To place the hinged window into the "continuous ventilation" position:

- Press and hold the security button (Fig. 56,1), if present.
- Turn the catch lever (Fig. 56,2 or Fig. 57,3) a guarter turn towards the centre of the window.
- Slightly open the hinged window outwards.
- Return the catch lever to its initial position. Move the locking catch (Fig. 56,3 or Fig. 57,2) on the catch lever into the recess of the window catch (Fig. 56,4 or Fig. 57,1).
- Press and hold the security button (Fig. 56,1), if present.
- Make certain that the safety knob is not pushed in but rather that it secures the catch lever.

During the journey, the hinged window may not be in "continuous ventilation" position.


If it rains, the "continuous ventilation" hinged window position could lead to splashing water penetrating the living area. Therefore, close the hinged windows completely.

#### 6.10.2 Hinged window with automatic hinges



- > Open the window completely, to release the lock. If the locking device is not released and the window is closed nevertheless, there is the danger of the window breaking due to the massive counter-pressure.
- forces. Open and close the hinged windows evenly.
- ▷ If the catch lever is equipped with a safety knob, press the safety knob when operating the catch lever.








Fig. 58 Catch lever with safety knob in "closed" position

Fig. 59 Catch lever in "closed" position

#### Opening:

- Press and hold the security button (Fig. 58,1), if present.
- Turn the catch lever (Fig. 58,2 or Fig. 59,3) a quarter turn towards the centre of the window.




Fig. 60 Hinged window with automatic hinges

■ Open the hinged window to the desired latched position. The automatic hinge (Fig. 60,1) locks in place automatically.

The hinged window remains locked in the required position.

#### Closing:

- Open the hinged window as wide as is necessary to release the lock.
- Close the hinged window.
- Press and hold the security button (Fig. 58,1), if present.
- Turn the catch lever (Fig. 58,2 or Fig. 59,3) a quarter turn towards the window frame. The locking catch (Fig. 58,3 or Fig. 59,2) on the catch lever is entirely on the inner side of the window catch (Fig. 58,4 or Fig. 59,1).






Fig. 61 Catch lever with safety knob in "continuous ventilation" position




Fig. 62 Catch lever in the "continuous ventilation" position

#### **Continuous ventilation**

With the catch lever, the hinged window can be placed in two positions:

- "Continuous ventilation" (Fig. 61 and Fig. 62)
- Firmly closed (Fig. 58 and Fig. 59)

To place the hinged window into the "continuous ventilation" position:

- Press and hold the security button (Fig. 61,1), if present.
- Turn the catch lever (Fig. 61,2 or Fig. 62,3) a quarter turn towards the centre of the window.
- Slightly open the hinged window outwards.
- Return the catch lever to its initial position. Move the locking catch (Fig. 61,3 or Fig. 62,2) on the catch lever into the recess of the window catch (Fig. 61,4 or Fig. 62,1).
- Press and hold the security button (Fig. 61,1), if present.
- Make certain that the safety knob is not pushed in but rather that it secures the catch lever.

During the journey, the hinged window may not be in "continuous ventilation" position.

If it rains, the "continuous ventilation" hinged window position could lead to splashing water penetrating the living area. Therefore, close the hinged windows completely.

#### 6.10.3 Blind and insect screen



○ Open blinds before commencing the journey. When the blinds are closed, vibrations can damage the spring shaft.



Depending on the window size, the blinds are fitted with one or two handles.

The windows are fitted with a blind and an insect screen. The blind and insect screen are adjusted separately.






Fig. 63 Hinged window

**Blind** The blind is located in the upper blind box.

Closing:

■ Pull blind at the handle (Fig. 63,2) downwards. If the blind is to be completely closed, it is suspended into the locking devices (Fig. 63,3) situated on both sides of the window frame.

Opening:

- If the blind is completely closed: Press handle (Fig. 63,2) downwards and, at the same time, tilt it slightly inward. The blind can be taken out of the locking devices situated on both sides of the window frame.
- If the blind is in an intermediate position: Pull the handle (Fig. 63,2) slightly downwards until the locking device releases.
- Use handle to return blind slowly to its initial position.

Insect screen

The insect screen is located in the upper blind box.

Closing:

■ Pull insect screen at the handle (Fig. 63,1) down and hang it into the locking devices (Fig. 63,3) situated on both sides of the window frame.

Opening:

- Press handle (Fig. 63,1) downwards and, at the same time, tilt it slightly inward. The insect screen can be taken out of the locking devices situated on both sides of the window frame.
- Use handle to return the insect screen slowly to its initial position.

#### 6.10.4 Blind and insect screen

The windows are fitted with a blind and an insect screen. The blind can be used separately.




Fig. 64 Hinged window

**Blind** The blind is located in the bottom blind box.



Closing:

- Press handle (Fig. 64,4) and draw blind (Fig. 64,3) from the bottom to the top up to the desired height.
- Release handle. The blind locks into the nearest locking position.

Opening:

- Clench handle (Fig. 64,4). The latch is released.
- Slowly return the blind (Fig. 64,3) to its initial position.

#### Insect screen

The insect screen is located in the upper blind box.

Closing:

■ Pull insect screen (Fig. 64,2) down until it touches the blind (Fig. 64,3), and engage the closure latch (Fig. 64,1) in the locking device (Fig. 64,5).

Opening:

- Release the closure latch (Fig. 64,1).
- Slowly return insect screen into its initial position.

#### 6.10.5 Roman shade and insect screen

The windows are fitted with a Roman shade and an insect screen. Roman shade and insect screen are fixed to each other.




Fig. 65 Hinged window

#### Roman shade

The Roman shade is located in the upper window frame.

Closing:

■ Hold the Roman shade in the centre of the bottom rod (Fig. 65,2) and carefully draw it downwards.

Opening:

■ Hold the bottom rod (Fig. 65,2) of the Roman shade in the centre and carefully slide the Roman shade upwards.

#### Insect screen

The insect screen is located in the upper window frame.

Closing:

- Pull insect screen at the handle (Fig. 65,1) downwards.
- Move the insect screen continuously.

If the insect screen is not drawn fully to the bottom, the Roman shade can be stretched up to the end of the side window frame.

Opening:

■ Move insect screen at the handle (Fig. 65,1) fully upwards.



## 6.11 Skylights

Depending on the model, skylights with or without forced ventilation are fitted to the vehicle. If a skylight is fitted without forced ventilation, the forced ventilation is performed using mushroom-shaped vents.



➤ The apertures for forced ventilation must always be kept open. Never cover or block forced ventilations with objects such as e.g. a winter mat. Keep forced ventilations clear of snow and leaves.





- ➤ The skylights are fitted with a blind or Roman shade and with an insect screen or folding insect screen. After the latch has been released, the blind and insect screen automatically spring back to the initial position by tensile force. In order not to damage the tension mechanics, hold onto the blind or insect screen and allow it to slowly return to the initial position. The Roman shade and folding insect screen are made of thin woven fabric. In order not to damage the Roman shade or the insect screen, grasp the respective handle and carefully return it to the initial position.
- Do not keep blinds closed over a longer period of time as that can cause increased material wear.
- ▷ If the blind or the Roman shade is completely closed, exposure to direct sunlight can cause heat to accumulate between the blind/the Roman shade and the skylight. The skylight could be damaged. For that reason, close the blind/Roman shade only 2/3 of the way in direct sunlight. Open the skylight slightly or move it to ventilation position.
- Depending on the weather, close the skylights far enough to prevent moisture from entering.
- Do not climb on the skylights.
- ▷ Before commencing the journey, close the skylights.
- ▷ Before commencing the journey, check that the skylights are closed and locked.



When leaving the vehicle, always close the skylights.

## 6.11.1 Heki skylight (mini and midi) (partially special equipment)








Fig. 67 Heki skylight, guide

The Heki skylight is opened on one side only.





Opening:

- Press the safety knob (Fig. 66,2) and pull the bar (Fig. 66,1) down with both hands.
- Pull the bar (Fig. 67,1) in the guides (Fig. 67,2) to the rearmost position (Fig. 67,3).

Closing:

- Use both hands to push the bar (Fig. 67,1) slightly upwards.
- Push the bar back in the guides.
- Push the bar upwards with both hands until it is above the safety knob (Fig. 66,2).








Fig. 69 Ventilation position locking mechanism

#### **Ventilation position**

The Heki skylight can be put in two ventilation positions: Bad weather position (Fig. 68,1) and central position (Fig. 68,2). Depending on the model, the skylight can be locked in the central position with both left and right latches (Fig. 69,1) on the skylight frame.

- Press the safety knob (Fig. 66,2) and pull the bar (Fig. 66,1) down with both hands.
- Pull the bar in the guides (Fig. 67,2) to the desired position.
- Push the bar slightly upwards and into the selected guide (Fig. 68,1 or 2) and lock if necessary.

#### Roman shade

To close and open the Roman shade:

Closing:

Pull out Roman shade at the handle and release in the required position. The Roman shade will stay in that position.

Opening:

■ Slowly push the Roman shade at the handle to its initial position.

#### Insect screen

To close and open the insect screen:

Closing:


■ Pull the insect screen by the handle to the opposite handle of the Roman shade.

Opening:

- Press the rear part of the handle of the insect screen. The latch is released.
- Use handle to return the insect screen slowly to its initial position.



## 6.11.2 Heki skylight (special equipment)






Fig. 70 Heki skylight, closed

Fig. 71 Heki skylight in ventilation position 1

The Heki skylight may be opened on one side only.

#### Opening:

- Press the safety knob (Fig. 70,1) and turn the catch lever (Fig. 70,2) one quarter turn inward.
- Pull the bar (Fig. 70,4) downwards out of the latch.
- Press the Heki skylight upwards using the bar.
- Press the bar back into the latch.

#### Closing:

- Pull the bar (Fig. 70,4) downwards out of the latch.
- Pull the Heki skylight downward using the bar.
- Turn the catch lever (Fig. 70,2 and Fig. 71,2) one quarter turn. The hook of the roof lock (Fig. 71,5) must engage in the upper locking fork (Fig. 71,3).
- Press the bar back into the latch.

## Ventilation position (variant 1):

- Open Heki skylight and push lightly outwards.
- Press the safety knob (Fig. 71,1) and turn the catch lever (Fig. 71,2) back. The hook of the roof lock (Fig. 71,5) must engage in the lower locking fork (Fig. 71,4).
- Press the bar back into the latch.




Fig. 72 Heki skylight in ventilation position 2

# Ventilation position (variant 2):

- Open Heki skylight.
- Insert the bar (Fig. 72,3) into the holder (Fig. 72,1).
- Place the lever (Fig. 72,2) over the bar.






Fig. 73 Heki skylight, blind lock

**Blind** To close and open the blind:

Closing:

Opening:

Closing:

Opening:

■ Pull blind at the handle (Fig. 73,2) to the opposite handle of the insect screen (Fig. 73,1) and allow to engage.

Hold the blind screen by the handle with one hand.
 With your other hand, push the unlocking bar on the handle of the insect screen (Fig. 73,1) towards the handle. The lock is released.

■ Use handle to return the blind slowly to its initial position.

**Insect screen** To close and open the insect screen:

■ Pull insect screen at the handle (Fig. 73,1) to the opposite handle of the blind (Fig. 73,2) and allow to engage.

■ Hold the insect screen (Fig. 73,1) by the handle and push the unlocking bar towards the handle. The lock is released.

■ Use handle to return the insect screen slowly to its initial position.



#### 6.12 Tables

## 6.12.1 Suspension table with folding leg




Fig. 74 Suspension table with folding lea

The suspension table may also be used as a bed foundation.

## Conversion to bed foundation:

- Slightly lift the front of the table-top.
- Move the locking device (Fig. 74,4) toward the table-top.
- Fold the lower section of the foot (Fig. 74,3) under by 90°.
- Detach the suspension table from the upper attachment rail (Fig. 74,1).
- Attach the suspension table to the lower attachment rail (Fig. 74,2) and rest it onto the table leg hinge.

#### 6.12.2 Swivel table










Fig. 76 Swivel table with plastic frame


The swivel table's swivel mechanism enables it to be used as a bed foundation.

## Conversion to bed foundation:

- Push the handle (Fig. 75,2) upwards or turn the handle (Fig. 76,2) to the horizontal position.
- Swivel the table-top (Fig. 75,1 or Fig. 76,1) downward in a circular movement.
- Allow the (Fig. 75,2) handle to click into place or turn the handle (Fig. 76,2) back into the vertical position. The swivel mechanism is locked.



## 6.12.3 Suspension table and swivel table








Fig. 78 After conversion to round seating group

The combination consisting of suspension table and swivel table can be converted into a round seating group.

## Conversion to round seating group:

- Open two locks (Fig. 77,2) on the underside of the table top.
- Pull swivel table (Fig. 77,3) slightly toward the centre.
- Lift the table-top of the suspension table (Fig. 77,1) approx. 45°.
- Pull lower section of the suspension table foot downwards and fold over by 90°.
- Remove the suspension table from its upper retainer.
- Hook suspension table into the lower retainer and use the foot to place on the ground.
- Place additional cushions.
- Push swivel table to the rear again (Fig. 78).

## 6.12.4 Fixed table (movable table-top) (special equipment)



Fig. 79 Fixed table

The top of the fixed table can be moved.

#### Moving the table-top:

- Loosen knurled screw (Fig. 79,1).
- Move table-top (Fig. 79,2) to the desired position.
- Re-tighten the knurled screw.



### 6.12.5 Lift-off table, movable




Fig. 80 Lift-off table, movable

The top of the lift-off table can be moved.

Moving the table-top:

- Loosen knurled screw (Fig. 80,3).
- Move table-top (Fig. 80,2) to the desired position.
- Retighten the knurled screw.

The table's lifting mechanism enables it to be also used as a bed foundation.

## Conversion to bed foundation:

- Swivel the catch lever (Fig. 80,1) to the left. The lock of the lifting mechanism is open.
- Press table-top (Fig. 80,2) in the middle down to the stop limit and hold it down.
- Swivel the catch lever (Fig. 80,1) to the right (Fig. 80). The lifting mechanism is locked.

Conversion to table:

- Swivel the catch lever (Fig. 80,1) to the left. The lock of the lifting mechanism is open. The table-top moves upwards to the limit stop.
- Swivel the catch lever to the right (Fig. 80). The lifting mechanism is locked.

#### **6.13** Beds

#### 6.13.1 Bunk bed



- Only use the upper bunk bed if the safety guard is fitted.
- ▶ The maximum permitted bunk bed load is 100 kg.
- ▶ The upper bunk bed must not be used by children under 6 years of age.
- ▶ Never allow small children to remain in the bunk bed without supervision.
- ▶ But in particular with regard to small children less than 6 years of age, users should ensure that they cannot fall out of the bunk bed.
- ▶ Use separate children's beds or travel cots suitable for children.

Depending on the model, the vehicle is fitted with a bunk bed. The bunk bed can be used immediately, without additional conversion.

Always use the access ladder provided to climb up to the top bed.



## 6.13.2 Fixed bed (manual setup)



▶ Do not let the slatted frame fall down when closing the bed!





Fig. 81 Fixed bed

The bedding box is located underneath the bed. The bedding box may be used to store bedding.

Fold up the slatted frame to place items in the bedding box or to empty it.

Depending on the model, a rail has been fitted to the slatted frame to set it up.

Opening:

■ Lift the slatted frame (Fig. 81,1), release the rail (Fig. 81,2) from its bracing and insert into the cavity in the holder (Fig. 81,3).

Closing:

- Lift the slatted frame (Fig. 81,1), release the rail (Fig. 81,2) from the holder (Fig. 81,3) and clamp into the bracing.
- Carefully let go of the slatted frame.

## 6.13.3 Pull-down bed, manually operated (Averso Plus)




- Switch off the reading lamps in the pull-down bed before the bed is pushed up. Fire hazard!
- ► Switch off the reading lamps on the underside of the pull-down bed when the bed is lowered. Fire hazard!
- ▶ The maximum permitted pull-down bed load is 200 kg.
- ▶ Before commencing the journey, secure the pull-down bed. To do this, lock the pull-down bed.
- ▶ Before use, pull the pull-down bed into the lower end position. Ensure that the pull-down bed is not resting on obstacles such as headrests, cushions or similar.
- ▶ Only use the pull-down bed, if the safety net is set up.
- ▶ Never allow small children to remain in the pull-down bed without supervision.
- ▶ But in particular with regard to small children less than 6 years of age, users should ensure that they cannot fall out of the pull-down bed.
- ▶ Use separate children's beds or travel cots suitable for children.





➤ You must be able to close the pull-down bed without any great effort, so that there is no tension in the locking position. Objects on the pull-down bed can distort the lifting mechanism on one side, resulting in damage.






Fig. 82 Release

Fig. 83 Pull-down bed complete with applied safety net

The pull-down bed is located above the rear seating group.

The pull-down bed has two locking positions in the uppermost position. The pull-down bed is securely locked in both locking positions.

#### Opening the pull-down bed:

- Switch off the lamps underneath the pull-down bed.
- Remove any obstacles in the area into which the pull-down bed extends (e.g. headrests).
- Fold over the back cushions.
- Pull out the release area (Fig. 82,1) at the bottom. The lock is released.
- With both hands, pull the pull-down bed down as far as it will go.
- If the pull-down bed was in the uppermost locking position: Pull the release area out again to override the second locking position. With both hands, pull the pull-down bed down as far as it will go.
- Make sure that the pull-down bed is in the lower end position and is not resting on obstacles such as headrests or cushions.



When closing the pull-down bed, pull the side fabric panels inwards. This
 prevents the fabric from getting trapped in the lock of the pull-down bed.

#### Closing the pull-down bed:

- Switch off the reading lamps on the ceiling.
- Using both hands, push the pull-down bed upwards as far as the first locking position. If necessary, push the pull-down bed further upwards as far as the uppermost locking position. When doing this, ensure that the snap latch engages audibly in the locking bracket.
- Check that the pull-down bed is locked correctly. To do this, pull down the pull-down bed firmly.



Depending on the model, the pull-down bed is equipped with a one-piece or two-piece safety net.

#### Safety net

The safety net (Fig. 83,2) and the retaining belts are located underneath the mattress in the pull-down bed. Only use the safety net if persons are already in the pull-down bed.

Setting up:

■ Attach the retaining belts (Fig. 83,1) to the hooks on the ceiling.



#### Access ladder

Always use the provided access ladder (Fig. 83,5) to climb up to the pull-down bed.

Attaching:

■ Hook access ladder (Fig. 83,5) to the pull-down bed by attaching the two hooks (Fig. 83,4) in the holding bar (Fig. 83,3).

Storing away:

- Hang the access ladder (Fig. 83,5) from the holding bar (Fig. 83,3) on the pull-down bed.
- Store the access ladder securely.

# 6.13.4 Pull-down bed, electrically operated (Averso Plus) (special equipment)



- ▶ Switch off the reading lamps in the pull-down bed before the bed is pushed up. Fire hazard!
- ➤ Switch off the reading lamps on the underside of the pull-down bed when the bed is lowered. Fire hazard!
- ▶ The maximum permitted pull-down bed load is 200 kg.
- ▶ Do not reach into the area between the bed and the side wall when lowering or raising. Danger of bruises!
- ▶ Do not lower or lift the bed when there are people using the pull-down bed.
- ▶ Bring the pull-down bed into the lower end position before use. Ensure that the pull-down bed is not resting on obstacles such as headrests, cushions or similar.
- ▶ Only lower the bed if the lowering area is clear.
- ▶ Do not allow children to play with the pull-down bed.
- ▶ Store the remote control in a safe place inaccessible to children.
- Only use the pull-down bed, if the safety net is set up.
- ▶ Never allow small children to remain in the pull-down bed without supervision.
- ▶ But in particular with regard to small children less than 6 years of age, users should ensure that they cannot fall out of the pull-down bed.
- ▶ Use separate children's beds or travel cots suitable for children.



- Only raise or lower the pull-down bed if it is loaded with a maximum of 15 kg. This maximum load includes the contents of the wall-mounted cupboard at the base of the pull-down bed. If the pull-down bed is overloaded, the overload protection switches off the lifting motor. However, the lifting mechanism can still be damaged.
- ▷ Before starting a journey, the pull-down bed must be brought into the uppermost end position. No objects must be stuck between the roof and the pull-down bed.



 ➤ To allow the electrically adjustable pull-down bed to be operated, the vehicle must be connected to a 230 V power supply or a living area battery (electric kit) must be present.








Fig. 84 Manual control unit

Fig. 85 Pull-down bed complete with applied safety net



▶ When making ready for operation, overload protection is not in use.

## Making ready for operation

Every time the power supply is interrupted, the electrical drive must be made ready for operation again. To do so carry out a reference run.

Carrying out a reference run:

- Using the arrow key (Fig. 84,3) on the manual control unit, bring the pull-down bed down as far as it will go or into any intermediate position.
- Press the "R" key (Fig. 84,2) five times in a row.
- Within 10 seconds, bring the pull-down bed upwards using the arrow key (Fig. 84.4).
- When the end position is reached, a beeping noise is emitted. Release the arrow key.

Opening the pull-down bed:

- Switch off the lamps underneath the pull-down bed.
- Remove any obstacles in the area into which the pull-down bed extends (e.g. headrests).
- Fold over the back cushions.
- On the manual control unit (Fig. 84,1), press the arrow key (Fig. 84,3) and keep it pressed until the pull-down bed has moved downwards to its end position.
- Make sure that the pull-down bed is in the lower end position and is not resting on obstacles such as headrests or cushions.

Closing the pull-down bed:

- Switch off the reading lamps on the ceiling.
- On the manual control unit (Fig. 84,1), press the arrow key (Fig. 84,4) and keep it pressed until the pull-down bed has moved up into its end position.
- Ensure that there are no objects stuck between the roof and the pull-down bed

#### Overload protection

If the pull-down bed meets an obstacle during opening or closing (e.g. a person or a headrest), the overload protection stops the movement. For release, move the pull-down bed with the arrow keys in the opposite direction.



▷ Depending on the model, the pull-down bed is equipped with a one-piece or two-piece safety net.



#### Safety net

The safety net (Fig. 85,2) and the retaining belts are located underneath the mattress in the pull-down bed. Only use the safety net if persons are already in the pull-down bed.

Setting up:

■ Attach the retaining belts (Fig. 85,1) to the hooks (Fig. 85,3) on the ceiling.

#### Access ladder

Always use the provided access ladder to climb up to the pull-down bed.

Attaching:

■ Hook access ladder (Fig. 85,5) to the pull-down bed by attaching the two hooks (Fig. 85,4) in the holding bar (Fig. 85,6).

Storing away:

- Hang the access ladder (Fig. 85,5) from the holding bar (Fig. 85,6) on the pull-down bed.
- Store the access ladder securely.




Fig. 86 Drive

#### **Emergency operation**

If the pull-down bed can no longer be moved via the manual control unit (e.g. due to loss of the vehicle's power supply), it can also be operated manually. To do this, proceed as follows:

- Remove the connection (e.g. splint and pin) (Fig. 86,2) between the push rod (Fig. 86,1) and lever (Fig. 86,3).
- Open or close the pull-down bed manually.
- Contact customer service.



#### 6.13.5 Widening single beds (special equipment)




Fig. 87 Prior to conversion

- 1
- Bedside locker cover
- 3 Bedside locker extension
- Slatted frame
- 4 5 Additional cushion
- Additional cushion




Fig. 88 During conversion




Fig. 89 After conversion

- Remove the bedside locker cover (Fig. 87,2) and put it to one side.
- Pull out slatted frame (Fig. 88,4) completely. To do this, pull on the extension (Fig. 88,3).
- Place the additional cushion (Fig. 89,5) on the bedside locker.
- Place the additional cushion (Fig. 89,6) between the mattresses (Fig. 89,1).

Back cushion

Seat cushion

Table

3



#### Converting seating groups for sleeping 6.14

#### 6.14.1 Bench and central seating group without additional cushion





Fig. 90 Prior to conversion

1

2

2 1






Fig. 91 After conversion

- Convert the table (Fig. 90,3) to a bed foundation (see section 6.12).
- Pull the seat cushions (Fig. 91,2) into the centre.
- Insert the back cushions (Fig. 91,1) between the seat cushions and the wall.



#### 6.14.2 Bench and central seating group with additional cushion






Fig. 92 Prior to conversion

- Back cushion
- 2 Seat cushion
- Table
- 4 Seat cushion
- 5 Back cushion
- Additional cushion (basic)




Fig. 93 **During conversion** 




Fig. 94 After conversion

- Convert the table (Fig. 92,3) to a bed foundation (see section 6.12).
- Remove the back cushion (Fig. 93,5) and lay it aside.
- Pull the seat cushion (Fig. 93,2) into the middle.
- Place the back cushion (Fig. 94,1) between the seat cushion and the wall.
- Place the additional cushion (Fig. 94,6) between the seat cushions (Fig. 94,2 and 4).



#### 6.14.3 Bench and central seating group with bed widening






Fig. 95 Prior to conversion

- Back cushion
- 2 Seat cushion
- Table
- 4 Seat cushion
- Back cushion
- 5 Bedding box extension
- Support
- 8 Additional cushion
- Additional cushion




Fig. 96 **During conversion** 




Fig. 97 After conversion

- Convert the table (Fig. 95,3) to a bed foundation (see section 6.12).
- Unlatch and fold up the bedding box extension (Fig. 95,6).
- Place support (Fig. 96,7) into the holder on the bedding box extension.
- Remove the back cushion (Fig. 96,5) and lay it aside.
- Insert the back cushion (Fig. 97,1) between the seat cushion (Fig. 97,2) and the side wall. To do this, move the seat cushion slightly towards the table.
- Place the additional cushion (Fig. 97,9) between the seat cushions (Fig. 97,2 and 4).
- Lay the additional cushion (Fig. 97,8) on the bedding box extension (Fig. 96,6).



#### 6.14.4 Round seating group with additional cushion (foldable)






Fig. 98 Prior to conversion

- Back cushion
- 2 Seat cushion
- Table
- 4 Back cushion
- 5 Back cushion
- Additional cushion (foldable)



Fig. 99 **During conversion** 





Fig. 100 After conversion


- Convert the table (Fig. 98,3) to a bed foundation (see section 6.12).
- Remove all back cushions (Fig. 99,1, 4 and 5) and lay them aside.
- Unfold the additional cushion (Fig. 100,6) and lay it between the seat cushions (Fig. 100,2).



#### Round seating group without additional cushion 6.14.5








Back corner cushion 2 3 Back cushion Seat cushion

- 4 Back cushion
- 5 Seat cushion
- 6 Table
- Bedding box

Fig. 101 Prior to conversion







Fig. 102 During conversion






Fig. 103 After conversion

- Remove the back corner cushions (Fig. 101,1) and the back cushion (Fig. 101,2) and store them under the table.
- Place the seat cushions (Fig. 102,5) in an upright position.
- Convert the table (Fig. 102,6) to a bed foundation (see section 6.12).
- Place the back cushions (Fig. 103,4) against the exterior wall. Observe the wedged form.
- Push the two seat cushions (Fig. 103,5) between the back cushions. Observe the wedged form.



#### 6.14.6 Round seating group with additional cushion






Fig. 104 Prior to conversion

- Back cushion
- 2 Seat cushion
  - Table
- 4 Back cushion
- 5 Back cushion
- Additional cushion




Fig. 105 During conversion




Fig. 106 After conversion

- Convert the table (Fig. 104,3) to a bed foundation (see section 6.12).
- Remove all back cushions (Fig. 104,1, 4 and 5) and lay them aside.
- Place the additional cushion (Fig. 106,6) on the table.
- Slide the right-hand seat cushion (Fig. 106,2) against the additional cushion.
- Insert a back cushion (Fig. 106,1) between the seat cushion (Fig. 106,2) and the side wall.



#### 6.14.7 Round seating group with bed widening



Depending on the model, the seating group can be different in shape and position to the one shown here.

2

5

6

7

8

10

11 12 Back cushion

Seat cushion Table Seat cushion

Back cushion

Back cushion

Back cushion

Back cushion

Support

Bedding box extension

Additional cushion

Additional cushion




Fig. 107 Prior to conversion

5 4

9




Fig. 108 During conversion

2




Fig. 109 After conversion

- Convert the table (Fig. 107,3) to a bed foundation (see section 6.12).
- Unlatch and fold up the bedding box extension (Fig. 107,9).
- Place support (Fig. 108,10) into the holder on the bedding box extension.
- Remove the back cushions (Fig. 108,1, 5, 6, 7 and 8) and lay them aside.
- Place the additional cushion (Fig. 109,11) between the seat cushions (Fig. 109,2 and 4).
- Lay the additional cushion (Fig. 109,12) on the bedding box extension (Fig. 109,9).



# 6.15 Shower connection point for external shower (special equipment)



▶ Only use the external shower if there is a gap of at least 1.20 m between the shower and the nearest electrical device or connection. Risk of electric shock!



▷ If decommissioned for a longer time or if there is a risk of frost, drain the water system.




Fig. 110 External shower connection point

Connecting an external shower:

- Unlock and open the cover (Fig. 110,4).
- Attach hose of the external shower to the quick closure (Fig. 110,3).

Using the shower:

- Switch on the water pump using the switch (Fig. 110,2).
- Adjust the water temperature with the rotary knob (Fig. 110,1) as desired.
- Switch off the water pump using the switch (Fig. 110,2).

Shutting off the shower connection point:

- Switch off the water pump using the switch (Fig. 110,2).
- Disconnect the hose from the quick closure. The quick closure is equipped with a check value to prevent any further water from escaping.
- Close the cover (Fig. 110,4) and lock with key.

Emptying:

- Attach hose of external shower to quick closure. The check valve is opened and the connections can run dry.
- Turn knob (Fig. 110,1) to the centre position.
- Empty the water system (see section 10.5).



### **Chapter overview**

This chapter contains instructions regarding the gas system of the vehicle. The instructions address the following topics:

- safety
- changing the gas bottles
- gas isolator taps
- external gas connection
- automatic switching facility

The operation of the gas operation appliances of the vehicle is described in chapter 9.

#### 7.1 General



- ▶ Before commencing the journey, when leaving the vehicle or when gas equipment is not in use, close all gas isolator taps and the main isolator tap on the gas bottle.
- No appliance operated by a naked flame (e.g. heater or refrigerator) may be in operation when filling the tank, on ferries or in the garage. Danger of explosion!
- ▶ Do not use appliances operated with a naked flame in closed spaces (e.g. garages). Danger of poisoning and suffocation!
- ▶ Only have the gas system maintained, repaired or altered by an authorised specialist workshop.
- ▶ Have the gas system checked by an authorised specialist workshop according to the national regulations before commissioning. This also applies for not registered vehicles. For modifications to the gas system have the gas system immediately checked by an authorised specialist workshop.
- ➤ The gas pressure regulator and exhaust gas pipes must also be inspected. The gas pressure regulator has to be replaced after 10 years at the latest. The vehicle owner is responsible for seeing that this is carried out.
- ▶ In case of a defect of the gas system (gas odour, high gas consumption) there is danger of explosion! Close regulator tap on the gas bottle immediately. Open doors and windows and ventilate well.
- ▶ If the gas system is defective: Do not smoke; do not ignite any open flames, and do not operate electric switches (light switches etc.).
- ▶ Before using the cooker make sure that there is sufficient ventilation. Open windows or the skylight.
- ▶ Do not use the gas cooker or gas oven for heating purposes.
- ▶ If there are several gas devices, each gas device must have its own gas isolator tap. If individual gas devices are not in use, close the respective gas isolator tap.
- ▶ Ignition safety valves must close within 1 minute after the gas flame has extinguished. A clicking sound is audible. Check function from time to time.
- ► The built-in gas devices are exclusively meant for use with propane or butane gas or a mixture of both. The gas pressure regulator as well as all built-in gas devices are designed for a gas pressure of 30 mbar.





- ▶ Propane gas is capable of gasification up to -42 °C, whereas butane gas gasifies at 0 °C. Below these temperatures no gas pressure is available. Butane gas is unsuitable for use in winter.
- ▶ Regularly inspect the gas tube fitted to the gas bottle connection for tightness. The gas tube must not have any tears and must not be porous. Have the gas tube replaced by an authorised specialist workshop no later than ten years after the manufacturing date. The operator of the gas system must see to it that the parts are replaced.
- ▶ Due to its function and construction, the gas bottle compartment is a space which is open to the exterior. Never cover or block up the standard forced ventilations. Otherwise gas that is emitted can not be diverted to the outside.
- ▶ Do not use the gas bottle compartment as storage space as it is not moisture-proof.
- ➤ Secure the gas bottle compartment against unauthorised access. To do this, lock the compartment.
- ▶ The regulator tap on the gas bottle must be accessible.
- ▶ Only connect gas-operated devices (e.g. gas grill) which have been designed for a gas pressure of 30 mbar.
- ► The exhaust gas pipe must be fitted tightly to the heating system and to the vent and must be sealed. The exhaust gas pipe must not show any evidence of damage.
- ▶ Exhaust fumes must be able to escape into the atmosphere unhindered and fresh air must be able to enter unhindered. For this reason, keep the exhaust pipe and intake openings clean and unobstructed (e.g. free from snow and ice). For this reason, no snow walls or aprons may lie against the vehicle.

#### 7.2 Gas bottles



- Gas bottles are only to be transported within the designated gas bottle compartment.
- ▶ Place the gas bottles in vertical position in the gas bottle compartment.
- ▶ Fasten the gas bottles so that they are unable to turn or tilt.
- ▶ If the gas bottles are not connected to the gas tube, always place the protective cap on top.
- ► Close the regulator tap on the gas bottle before the gas pressure regulator or gas tube are removed from the gas bottle.
- ▶ Use your hands only to connect the gas pressure regulator or the gas tube to the gas bottles. Do not use any tools.
- Only use special gas pressure regulators with a safety valve designed for vehicle use. Other gas pressure regulators are not permitted and cannot meet the demanding requirements.
- Use the gas pressure regulator defroster if the temperature falls below 5 °C.
- ▶ Use only 11 kg or 5 kg gas bottles. Camping gas bottles with built-in check valve (blue bottle with max. 2.5 or 3 kg content) are can be used in exceptional cases with a safety valve.





- Use the shortest possible tube lengths (150 cm max.) for external gas bottles
- ▶ Never block the floor ventilation openings below the gas bottles.



- > For gas-operated units the gas pressure must be reduced to 30 mbar.
- Connect gas pressure regulator complete with safety valve directly to bottle valve.
  - The gas pressure regulator reduces the gas pressure in the gas bottle down to the operating pressure of the gas devices.
- For filling and connecting the gas bottles in Europe the accessories shops have corresponding Euro filling sets and Euro bottle sets.
- > Information available at the dealers or service centre.
- For information on the gas supply in Europe see chapter 17.

## 7.3 Changing gas bottles



- ▶ When changing gas bottles, do not smoke or create any open fire.
- ▶ When you have changed the gas bottle, check whether gas escapes at the connection points and unions. Use a leakage search spray to spray the relevant connection point or union. These agents are available at the accessories shop.



Fig. 111 Gas bottle compartment

- Open external gas bottle compartment (see chapter 6).
- Close the regulator tap (Fig. 111,1) on the gas bottle (Fig. 111,2). Pay attention to the direction of the arrow.
- Unscrew the gas tube (Fig. 111,3) by hand from the gas bottle.
- Release the fixing belts and remove the gas bottle.
- Place a filled gas bottle in the gas bottle compartment.
- Fix gas bottle in place with the fixing belts.
- Screw gas tube on gas bottle by hand.



## 7.4 Gas isolator taps




Fig. 112 Symbols for the gas isolator taps

- 1 Cooker
- 2 Boiler (special equipment)
- 3 Oven (special equipment)
- Refrigerator Heater

A gas isolator tap (Fig. 112) for every gas device is built into the vehicle. The

## 7.5 External gas connection (special equipment)

gas isolator taps are located behind a flap in the kitchen area.



- ▶ If the external gas connection is not in use, always close the gas isolator tap.
- ▶ Only gas appliances with a suitable adapter should be connected to the external gas connection.
- ► Connect only external gas appliances which are designed for an operation pressure of 30 mbar.
- Once you have made the connection and opened the gas isolator tap, make sure that no gas is escaping at the connection point. If there is a leak in the external gas connection, gas will escape into the open air. Immediately close the gas isolator tap and the regulator tap on the gas bottle. Have the external gas connection checked by an authorised specialist workshop.
- ▶ When connecting an external gas appliance, make sure that there is nothing near the external gas connection that could cause a spark.
- ▶ Do not use the external gas connection to fill gas bottles. Observe the information stickers on the external gas connection.




Fig. 113 External gas connection, gas isolator tap closed

The external gas connection (Fig. 113) is located at the rear or to the left or right of the vehicle depending on the model.



- Connect the external gas device to the connection point (Fig. 113,1).
- Open the gas isolator tap (Fig. 113,2).


### 7.6 DuoControl switching facility (special equipment)



▶ Do not use the switching facility in closed spaces.



The DuoControl is an automatic switching facility with a remote display for a two-bottle gas system. The DuoControl switching facility automatically switches gas supply from the primary bottle to the reserve bottle as soon as the primary bottle is either empty or no longer ready for operation. The gas appliances may still continue operation. The DuoControl switching facility is suitable for all commercial gas bottles from 3 kg to 33 kg.






Fig. 114 DuoControl switching facility

Fig. 115 Operating unit

#### Construction of the unit

The DuoControl switching facility consists of a reversing valve (Fig. 114,3) and an operating unit (Fig. 115). The reversing valve is installed between the gas tubes (Fig. 114,2 and 5). The knob (Fig. 114,4) on the reversing valve is used to select which of the gas bottles is to be used as a primary bottle and which is to be used as a reserve bottle.

The reversing valve is equipped with the regulator defroster Eis-Ex. This prevents damage to the gas system during the winter months.

Only the electrical functions can be switched at the operating unit (Fig. 115). The regulator taps on the gas bottles (Fig. 114,1 and 6) must be opened manually.

The reversing valve provides a constant gas pressure, regardless of which gas bottle is being drawn upon. The two indicator lamps on the operating unit indicate the level of the primary bottle. When the green indicator lamp (Fig. 115,6) illuminates, the primary bottle is full. When the red indicator lamp (Fig. 115,5) illuminates, the primary bottle is empty. In this case, the reserve bottle is used for the gas supply.

#### **Operating modes**

The DuoControl switching facility has two operating modes:

- Winter operation "On and heating"
- Summer operation "On"

## Gas system



#### Putting into operation:

- Open the regulator taps on the gas bottles (Fig. 114,1 and 6).
- Use the knob (Fig. 114,4) on the reversing valve (Fig. 114,3) to select the gas bottle which is to be the primary source of gas (primary bottle). Always turn the knob as far as it will go.
- Switch on the DuoControl switching facility at the operating unit (Fig. 115). To do so, set the rocker switch (Fig. 115,7) to winter operation "On and heating" (Fig. 115,2) or to summer operation "On" (Fig. 115,4). The reversing valve is now deaerated. The yellow indicator lamp (Fig. 115,1) illuminates if the winter operation has been selected and the regulator defroster is activated.

#### Switching off:

- Set the rocker switch (Fig. 115,7) to "O" (Fig. 115,3). The yellow indicator lamp (Fig. 115,1) goes out.
- Close the regulator taps on the gas bottles (Fig. 114,1 and 6).

#### Remote display

The indicator lamps on the operating unit (Fig. 115,5 and 6) indicate in the vehicle interior whether the primary bottle is ready for operation.

#### Changing gas bottles

If the green indicator lamp (Fig. 115,6) stops illuminating during operation and the red indicator lamp (Fig. 115,5) illuminates, the gas bottle selected as primary bottle is empty and needs to be changed. The reserve bottle continues supplying the gas appliances with gas.



▶ When changing gas bottles, do not smoke or create any open fire.

#### Changing gas bottles:

- Close the regulator tap on the empty gas bottle.
- Unscrew the gas tube of the gas bottle.
- Connect the full gas bottle to the gas tube.
- Open the regulator tap on the gas bottle.
- Set the knob on the reversing valve with a half-turn, so that the newly replaced gas bottle will serve as a reserve bottle.



## **Chapter overview**

This chapter contains instructions regarding the electrical system of the caravan.

The instructions address the following topics:

- safety
- explanations of terms relating to the battery
- 12 V power supply
- power supply unit
- electric kit
- 230 V power supply
- connection to the 230 V power supply
- fuse rating
- towing vehicle connection
- external socket
- electrical wiring

The operation of the electrical appliances of the housing body is described in chapter 9.

## 8.1 General safety instructions



▶ Only allow qualified personnel to work on the electrical system.

The vehicle is a safe place during a storm (Faraday cage). However, to protect the electrical devices, disconnect the 230 V connection and retract the antennae as a precaution.

### 8.2 Terms

#### Capacity

Capacity refers to the amount of electricity which can be stored in a battery.

The capacity of a battery is given in ampere hours (Ah). The so-called K20 value is normally used.

The K20 value indicates how much current a battery is able to dispense over a time period of 20 hours without causing damage, or how much current is required to charge a flat battery within 20 hours.

For example, if a battery can dispense 4 amps for 20 hours, then it has a capacity of  $4 A \times 20 h = 80 Ah$ .

If more current flows, the capacity of the battery reduces proportionately.

External influences, such as temperature and age may alter the storage capacity of the battery. Capacity details refer to new batteries operating at room temperature.

## 8.3 12 V power supply



- ▷ If you use the battery of the towing vehicle to provide power for the caravan, bear in mind that the battery capacity is restricted. If you place too great a burden on the battery, this may lead to starting difficulties.
- ▷ Always disconnect the electrical connection between the towing vehicle and the caravan before the caravan is connected to the local power supply. In order to carry this out, disconnect the plug from towing vehicle socket.



When the caravan is not connected to the 230 V power supply, 12 V power supply is performed by the starter battery of the connected towing vehicle or by the living area battery (electric kit). The starter battery has a limited power supply only. For this reason, the electrical appliances should not be operated for a long time without using the 230 V power supply when the engine of the towing vehicle is switched off.

If the caravan is electrically connected to the towing vehicle and the vehicle engine is running, the living area battery is charged by the vehicle generator (electric kit).

#### 8.3.1 Power supply unit CSV 300



Do not cover the ventilation slots on the power supply unit. Danger of overheating.




Fig. 116 Power supply unit CSV 300

- 1 Power supply unit
- 2 Flat fuses
- 3 Two-pole automatic circuit breaker
- Fault current protection switch

#### **Functions**

The power supply unit distributes the current to the 12 V circuits and secures them.

If the vehicle is **not** connected to the 230 V supply, the requisite power supply is provided by the battery of the towing vehicle, as long as contact 9 "constant positive" is connected to the towing vehicle socket (see connection diagram at the end of this chapter). The 12 V living area lamps and the 12 V plug sockets can be used, with the exception of the TV output plug socket.

Devices with a maximum of 10 A can be connected to the sockets.

If the vehicle is connected to the 230 V power supply, the power supply unit switches the power supply in the living area automatically from the towing vehicle battery to mains operation. The internal power pack in the power supply unit provides 12 V plug sockets and 12 V appliances with power.



▶ The power supply unit is not used to charge the starter battery of the towing vehicle.

#### **Position**

The power supply unit (Fig. 116) is installed in the wardrobe.

#### Thermal cut-out

If the power supply unit becomes too hot during operation due to high ambient temperatures or insufficient ventilation, the power pack reduces the power output. As a result, the activated appliances which are connected to the power supply unit are supplied with a lower voltage than 12 V. If the power supply unit is still too warm, switch it off completely. If this over-temperature protection (thermal cut-out) is activated, improve the ventilation of the power supply unit and reduce the number of 12 V appliances that are switched on.





➢ Further information can be obtained in the manufacturer's instruction manual.

## 8.4 Electric kit (special equipment)

**Scope** The following components belong to the electric kit:

- Battery 12 V, 90 or 110 Ah
- Power supply unit with charging function for the living area battery
- Pane

### 8.4.1 Living area battery



- ▷ The living area battery may not be opened.
- During the trip, use every opportunity to charge the living area battery.
- ▷ After the trip, charge the living area battery fully.
- ▷ Before a temporary lay-up, charge the battery fully.
- For long periods of inactivity (4 weeks or more), either disconnect the living area battery or recharge it regularly.
- ▶ When the living area battery is changed, only use batteries of the same type.
- ▷ Before disconnecting or connecting the terminals of the living area battery, switch off the engine of the towing vehicle as well as the 230 V and 12 V power supplies and all appliances. Danger of short circuit!
- ▷ If the living area battery is disconnected and the caravan and towing vehicle are connected electrically, do not apply the ignition. There is a danger of short circuit from exposed cable ends.



- ▷ If possible, begin the trip with a fully charged living area battery. Therefore, charge the living area battery before starting the trip.
- During the trip, use every available opportunity to charge the living area battery.

It is not necessary to check the acid level.

It is not necessary to lubricate the battery poles.

It is not necessary to refill the distilled water.

Even a maintenance-free battery must be charged regularly.

When the vehicle is not connected to the 230 V power supply or the 230 V power supply is switched off, the living area battery supplies the living area with 12 V DC. The living area battery has a limited power supply only. For this reason, electrical appliances such as the radio and the lights should not be operated for a long time without using the 230 V power supply.

#### **Discharging**

The living area battery is discharged by the closed circuit current which some electrical appliances continuously require.





Low temperatures outside reduce the capacity available.

The self-discharge rate of the battery is also dependant on temperature. At 20 to 25  $^{\circ}$ C the self-discharge rate is approx. 3  $^{\circ}$ 0 of the capacity per month. The self-discharge rate will increase with rising temperatures: At 35  $^{\circ}$ C the self-discharge rate is approx. 20  $^{\circ}$ 0 of the capacity per month.

An older battery no longer has the complete capacity available.

The higher the number of active electrical appliances, the faster the energy of the living area battery is consumed.

In order to prevent fast discharge of the living area battery, the refrigerator is operated on 12 V power supply only when the engine is running and when there is an electrical connection between the towing vehicle and caravan.

#### Charging

Only use the power supply unit to charge the living area battery. Therefore, connect the vehicle to a 230 V power supply system as often as possible.



- Charge the battery for at least 48 hours after a total discharge.
- At temperatures below 0 °C, a living area battery consumes less power. At approx. -15 °C, there will be no more power. The living area battery can no longer be charged.

The living area battery is recharged by the alternator of the towing vehicle if the caravan is connected electrically to the towing vehicle and the towing vehicle's engine is running.



Further information can be obtained in the separate documentation for the living area battery.

#### Changing the battery



- ► The acid in the battery is poisonous and corrosive. Any contact with the skin or the eyes is to be avoided.
- ▶ In the event of contact with the skin or eyes, rinse immediately with clear water.
- ► Keep naked flames and possible sources of sparks away from the battery. Danger of explosion!



When replacing the battery, only use the same type of battery (same capacity and voltage, cycle stability).

#### Changing the battery:

- Release negative (-) terminal clamp.
- Release positive (+) terminal clamp.
- Remove the battery.
- Put in a new battery.
- Connect the new battery in the reverse order.

## 8.4.2 Power supply unit CSV 409



▷ Do not cover the ventilation slots on the power supply unit. Danger of overheating.

## **Electrical system**






Fig. 117 Power supply unit CSV 409

- 1 Connections: Consumer circuit 3 and 5 (awning light, TV), water pump
- 2 Fuses (see table in section 8.6)
- 3 Connections: Consumer circuits 1 and 2, refrigerator control
- 4 Connections: Solar charge regulator, panel
- 5 Connection: Living area battery
- 6 Connections: Towing vehicle, refrigerator load circuit

#### **Functions**

The power supply unit performs the following tasks:

- The power supply units charges the living area battery.
- The power supply unit distributes the current to the 12 V circuits and secures them. Devices with a maximum of 10 A can be connected to the sockets.
- The power supply unit provides connections for a solar charge regulator as well as other control and monitoring functions.
- The power supply unit separates the starter battery of the towing vehicle electrically from the living area battery of the caravan if there is an electric connection between the towing vehicle and the caravan and if the vehicle engine and the ignition are turned off. In this way the 12 V appliances of the caravan cannot discharge the starter battery of the towing vehicle.

The power supply unit only works in conjunction with a panel.

The power in the power supply unit (> 28 A) is divided into charging current and current to the appliances. The charging current is always just the portion that is not being used by any appliances. If the current to the appliances exceeds the current available, then the living area battery is discharged.

#### **Position**

The power supply unit is installed in the wardrobe or in a storage compartment.



> Further information can be obtained in the manufacturer's instruction manual.

### **Battery selector switch**



▶ If the battery selector switch is set incorrectly, there is the danger of the formation of detonating (oxy-hydrogen gas). Danger of explosion!



- ▷ Incorrect setting of the battery selector switch damages the living area battery.

#### **Charging the battery**

During mobile operation, the alternator of the towing vehicle charges the living area battery. If the engine and the ignition of the towing vehicle are cut off, then the power supply unit disconnects the starter battery electrically from the living area battery so that it is not possible to discharge the starter battery of the towing vehicle by using 12 V living area appliances.


When the vehicle is connected to the 230 V power supply, the living area battery is charged by the power supply unit.





> The power supply unit is not used to charge the starter battery of the towing vehicle.

#### 8.4.3 Panel LT 408



- 230 V indicator lamp
- Display V
- Button for reading the battery voltage of the living area battery
- Indicator lamp for water pump
  Indicator lamp for the 12 V power supply for the living area
- 12 V main switch
- Rocker switch for water pump

Fig. 118 Panel LT 408

230 V indicator lamp

The yellow 230 V indicator lamp (Fig. 118,1) is on whenever line voltage is available at the power supply unit input.

#### **Display V for battery** voltage

The LEDs for display V (Fig. 118,2) indicate the battery voltage of the living area battery.

Displays:

■ Press the button (Fig. 118,3) at the top or bottom: The battery voltage of the living area battery is displayed.

The tables below will help you correctly interpret the displayed battery voltage of the living area battery.

Battery volt- age (values during operation)	Mobile operation (vehicle moving, no 230 V connec- tion)	Battery operation (vehicle station- ary, no 230 V connection)	Power operation (vehicle station- ary, 230 V con- nection)	
Less than 11 V	No charging via	If appliances are	No charging by the	
Danger of total discharge	the alternator	switched off: Bat- tery flat	CSV	
	12 V power supply overload	If appliances are switched on: Bat- tery overload	12 V power supply overload	
11.5 V to 13 V	No charging via the alternator <sup>1)</sup>	Normal range	No charging by the CSV 1)	
	12 V power supply overload <sup>1)</sup>		12 V power supply overload <sup>1)</sup>	
13.5 V or more	Battery being charged	Occurs only briefly after charging	Battery being charged	

<sup>1)</sup> If the voltage does not exceed this range for several hours.





Values for off-load voltage	Charging condition of the battery		
Less than 12 V	Discharge or totally discharge		
12.2 V	25 %		
12.5 V	50 %		
More than 12.7 V	100 %		





▶ Measure the off-load voltage preferably several hours after the previous charging (e.g. in the morning) and not directly after a current drain.

#### 12 V main switch

The 12 V main switch (Fig. 118,6) switches the panel and the 12 V power supply of the living area on and off.

Switching on:

■ Press the upper part of the rocker switch (Fig. 118,6): The 12 V living area power supply is switched on. Indicator lamp (Fig. 118,5) lights up yellow.

#### Switching off:

■ Press the lower part of the rocker switch (Fig. 118,6): The 12 V living area power supply is switched off. The indicator lamp (Fig. 118,5) goes out.



- ▶ When leaving the vehicle, switch off the main 12 V power supply at the panel. This prevents any unnecessary discharge of the living area battery.
- The refrigerator control takes power from the battery capacity, even if the
   12 V main switch is switched off. Therefore disconnect the living area bat tery from the 12 V power supply, if the vehicle will not be used for a long
   period of time.

#### 12 V indicator lamp

The 12 V indicator lamp (Fig. 118,5) lights up yellow whenever the 12 V main switch (Fig. 118,6) is switched on.

#### Switch for water pump

The button for the water pump (Fig. 118,7) switches the water supply on and off.

Switching on:

■ Press the upper part of the rocker switch (Fig. 118,7): The water supply is ON. Indicator lamp (Fig. 118,4) lights up yellow.

Switching off:

■ Press the lower part of the rocker switch (Fig. 118,7): The water supply is OFF.



 If the vehicle is not connected to the 230 V power supply and the water pump is not used for a longer period of time: Switch off the power supply for the water pump. The pump relay uses around 4 Ah current each day.


## Indicator lamp for water pump

The indicator lamp (Fig. 118,4) lights up yellow whenever the switch for the water pump (Fig. 118,7) is switched on.



## 8.4.4 Connection diagrams

# Power supply unit CSV 409



BUE01377

Fig. 119 Connection diagram

Α	Connections: Towing vehicle, refrigerator load circuit
1	+ Caravan coupling – 12 V switched
2	– Caravan coupling – switched to 12 V
3	+ Caravan coupling – 12 V steady plus
4	– Caravan coupling – to 12 V steady plus
5	+ Refrigerator cartridge, fuse in vehicle
6	Refrigerator cartridge, fuse in vehicle
7	+ Refrigerator control
8	- Refrigerator control
В	Molex Minifit SR-F
С	Living area battery



D	Pin header MSFQ/0 6Fh
E	Connections panel
1	12 V Off white
2	12 V On green
3	12 V control
4	Mains check
5	– 12 V brown
6	+ 12 V brown
F	Pump
G	Pump switch 1
Н	Pump switch 2
1	Circuit 1
J	Circuit 2
K	Circuit 3
L	Circuit 5
1	+ Awning light
2	- Awning light
3	+ TV
4	-TV
5	+ Spare
6	- Spare
М	Connector LF-PA 401 6.3x0.8 - 32-pin
N	Solar charge regulator LRS 1214
0	MNL-connector socket-3F
Р	Changeover switch "Blei-Säure/Blei-Gel" (lead-acid/dryfill)
Q	Connector cable 6.3x0.8 3 G 1.5 L = 1.2 m 230 V~ 50 Hz



#### **Panel**




Fig. 120 Connection diagram

Α	Flat plug 6.3 mm Switched supply voltage to water pump
В	Flat plug 6.3 mm  Voltage supply for water pump - inlet
С	MSFWQ/0 6-pin
D	Printed circuit board
E	Connections battery charger
1	12 V Off white
2	12 V On green
3	12 V control
4	Mains check
5	– 12 V brown
6	+ 12 V brown

## 8.5 230 V power supply



▶ Only allow qualified personnel to work on the electrical system.

The 230 V power supply provides electricity for:

- sockets with earth contact for appliances with maximum 16 A
- refrigerator
- power supply unit

The electrical appliances connected to the 12 V power supply of the living area are supplied by the power supply unit or living area battery (electric kit).

Connect the vehicle to an external 230 V power supply system as often as possible. If a living area battery is installed, this is automatically charged via a charger module (electric kit).



#### 8.5.1 230 V connection



Overvoltage can damage connected devices. Overvoltage can be caused by lightning, irregular voltage sources (e.g. petrol-operated generators) or power connections on ferries for example.

## Requirements concerning the 230 V connection

- The connection cable, the plug connectors at the point of supply and the plug connector to the vehicle must comply with IEC 60309. The standard designation for the plug connectors is "CEE blue".
- Use H07RN-F rubber sheathed cable with a minimum cable cross-section of 2.5 mm<sup>2</sup> and a maximum length of 25 m.
- Earth contact connectors (safety) are not permitted. The interconnection of CEE/safety adapters is also prohibited.

### 8.5.2 Connecting 230 V power supply



- ➤ The external 230 V power supply must be protected by fuse with a fault current protection switch (FI-switch, 30 mA).
- ► To prevent overheating, the cable must be fully uncoiled from the cable reel
- ▶ In case of doubt or if the 230 V supply is not available or is faulty, contact the operator of the power supply device.



▷ Always disconnect the electrical connection between the towing vehicle and the caravan before the caravan is connected to the local power supply. In order to carry this out, disconnect the plug from towing vehicle socket.



- The 230 V connection in the vehicle is equipped with a fault current protection switch (FI-switch).
- For the connection points on camp sites (camping distributors) fault current protection switches (FI-switches, 30 mA) are obligatory.

The vehicle can be connected to an external 230 V power supply.




Fig. 121 230 V fuse box with safety cutout and FI-switch



Fig. 122 230 V connection on vehicle

#### Connecting the vehicle:

- Check whether the power supply device is suitable regarding connection, voltage, frequency and current.
- Check whether the cables and connections are suitable.
- Check the plug connectors and cables for visible damage.
- Switch off the safety cut-out (Fig. 121,1) in the fuse box (Fig. 121,2).



- Open the cover of the 230 V connection on the vehicle (Fig. 122) and insert the plug connector. Ensure that the detent of the spring-mounted pivoting cover is engaged in position.
- Plug the connector of the connecting cable into the socket of the power supply device. Ensure that the detent of the spring-mounted pivoting cover is engaged in position.
- Switch on the safety cut-out in the fuse box.

## Checking the fault current protection switch:

- When the vehicle is connected to the 230 V supply, press the check button (Fig. 121,4) of the fault current protection switch (FI switch) (Fig. 121,3) in the fuse box (Fig. 121,2). The fault current protection switch must trip.
- Switch the fault current protection switch back on again.

#### Unplugging the connection:

- Switch off the safety cut-out (Fig. 121,1) in the fuse box (Fig. 121,2).
- Loosen the detent on the power supply device and unplug the connection cable from the socket.
- Loosen the detent on the vehicle, unplug the plug connector and close the cover of the 230 V connection.

#### 8.6 Fuses



- ▶ Only replace defective fuses when the cause of the defect is known and has been remedied.
- ▶ Replace defective fuses only after the power supply has been turned off.
- ▶ Never bridge or repair fuses.
- ▶ Only replace faulty fuses with a new fuse with the same rating.

#### 8.6.1 12 V fuses

The appliances connected to the 12 V power supply in the living area are fused individually. The fuses are accessible at the power supply unit or in a fuse holder close to the power supply unit.




Fig. 123 12 V fuse

Unbroken fuse elementBroken fuse element

An intact 12 V fuse can be detected by the unbroken fuse element (Fig. 123,1). If the fuse element is broken (Fig. 123,2), change the fuse.

Before changing fuses, take the function, value and colour of the relevant fuses from the following specifications. When changing fuses, only use flat fuses with the values shown below.





Fuses on the power supply unit CSV 300

Function	Type of fuse	Value/colour
Fuse circuit 1	Flat fuse	15 A blue
Fuse circuit 2	Flat fuse	15 A blue
Fuse circuit 3	Flat fuse	15 A blue
Fuse circuit 4	Flat fuse	15 A blue
Fuse circuit 5	Flat fuse	15 A blue

#### Fuse for the refrigerator

The fuse is located in a fuse holder in the vicinity of the power supply unit unit.

• Type of fuse: Flat fuse 15 A/blue

Changing:


- Remove cover on the floor of the wardrobe.
- Replace fuse.
- Reattach cover once fuse has been replaced.

Fuses on the power supply unit CSV 409 (Electric kit)

Function	Value/colour	
Circuit 5 (TV, awning light)	7.5 A brown	
Circuit 3	15 A blue	
Water pump	5 A light brown	
Internal charger	30 A yellow	
Circuit 1	15 A blue	
Circuit 2	15 A blue	
Refrigerator control	2 A grey	
Solar	15 A blue	

# Fuse for the Thetford toilet (swivel toilet)

The fuse is located in the locker wall of the Thetford cassette.



1 Flat fuse 3 A/purple

Fig. 124 Fuse for the Thetford toilet


Changing:

- Open the flap for the Thetford cassette on the outside of the vehicle.
- Pull out the Thetford cassette completely.
- Replace fuse (Fig. 124,1).

# Fuse for the Thetford toilet (fixed seat)

The fuse is located in the locker wall of the Thetford cassette.





1 Flat fuse 3 A/purple

Fig. 125 Fuse for the Thetford toilet

#### Changing:

- Open the flap for the Thetford cassette on the outside of the vehicle.
- Remove the Thetford cassette and swing out the flap in the housing panel.
- Replace fuse (Fig. 125,1).

#### 8.6.2 230 V fuse



Check the fault current protection switch for each connection to the 230 V power supply, at least once every 6 months.




Fig. 126 230 V automatic circuit breaker and FI-switch (CSV 300)

A fault current protection switch (FI-switch) (Fig. 126,3) in the power supply unit CSV 300 (Fig. 126,2) protects the complete vehicle from fault current (0.03 A).

A downstream two-pole safety cut-out (Fig. 126,1) in the power supply unit protects the 230 V power supply.

#### **Position**

The power supply unit is installed in the wardrobe.

Checking fault current protection switch:

■ When the vehicle is connected to the 230 V power supply, press the test button (Fig. 126,4). The fault current protection switch (FI-switch) must trip.

### 8.7 Thirteen-pin plug connection diagram



- Note the colours of the connecting cable of the socket which is fitted to the towing vehicle. This makes any new connection which may be necessary easier.
- ➤ To connect the thirteen-pin plug to a seven-pin socket, use a commercially available adaptor.






Fig. 127 Contact diagram of the thirteen-pin plug

## **Connection diagram**

Con- tact no.	DIN- specifi- cation	Function	Cable colour caravan	Cable colour plug	Cross section of the wire
1	L	Left direction indicator	Yellow	Yellow	1.5 mm <sup>2</sup>
2	54 G	Fog tail light	Blue	Grey	1.5 mm <sup>2</sup>
3 <sup>1)</sup>	31	Earth (contacts 1, 2, 4 - 8)	White	White	2.5 mm <sup>2</sup>
4	R	Right direction indicator	Green	Green	1.5 mm <sup>2</sup>
5	58 R	Right tail light, side marker light (white/ red), clearance light, li- cence plate light	Brown	Brown	1.5 mm <sup>2</sup>
6	54	Brake lights	Red	Red	1.5 mm <sup>2</sup>
7	58 L	Left tail light, side marker light (white/ red), clearance light, li- cence plate light	Black	Black	1.5 mm <sup>2</sup>
8		Back-up light	Grey	Purple	1.5 mm <sup>2</sup>
9		Constant positive	Blue (cable no. 78)	Blue	2.5 mm <sup>2</sup>
10		Positive charging line	_	Orange	2.5 mm <sup>2</sup>
11		Earth charging line	-	Orange- white	2.5 mm <sup>2</sup>
12		Not assigned	_	_	-
13 <sup>1)</sup>		Earth (contacts 9 - 12)	Brown (cable no. 78)	Blue- white	2.5 mm <sup>2</sup>

These earth cables may not be connected to electrical conductors on the trailer side.



## 8.8 External socket (special equipment)




Fig. 128 External socket

- 1 TV socket
- 2 12 V socket
- SAT socket 230 V socket

The 230 V socket and the 12 V socket can be used to power electrical devices in the awning.

#### **Connection possibilities**

TV socket and SAT socket offer various possibilities for TV operation:




Fig. 129 TV inside the vehicle




Fig. 130 TV in the awning

- TV inside the vehicle (Fig. 129,4): Connection to roof antenna (Fig. 129,1) with connection cable (Fig. 129,2)
- TV inside the vehicle (Fig. 129,4): Connection to external antenna (Fig. 129,3)
- TV inside the awning (Fig. 130,4): Connection to roof antenna (Fig. 130,1) with connection cable (Fig. 130,2)
- TV inside the awning (Fig. 130,4): Connection to external antenna (Fig. 130,3)



#### 8.9 **Circuit diagrams**

#### 8.9.1 Circuit diagram, interior




Fig. 131 Circuit diagram, interior (CSV 300)

- 230 V automatic circuit breaker
- Battery towing vehicle (external fuse max. 15 A)
  12 V output, circuit 1
  12 V output, circuit 2
- 2 3 4

- 12 V output, circuit 2 12 V output, circuit 3 12 V output, circuit 4 12 V output, circuit 5



#### 8.9.2 Circuit diagram, exterior



Cable installation can differ depending on the model.




Fig. 132 Circuit diagram, exterior

- Side marking light (number depends on type) Left direction indicator (yellow)
- Fog tail light (blue)
- Earth 1 8 (white)
  Right direction indicator (green)

- Brake lights (red)
  Right tail light (brown)
  Right side marking lamps (brown)
- 9 Left tail light (black)
  10 Left side marking lamps (black)
  11 Constant positive (blue)
  12 Earth 9 12 (brown)

- Wiring harness, bumper (dependent on type)



## **Chapter overview**

This chapter contains instructions regarding the appliances of the vehicle.

The instructions refer exclusively to the operation of the appliances.

Further information about the appliances can be found in the instruction manuals for the appliances, included separately with the vehicle.

The instructions address the following topics:

- heater
- air conditioning unit
- boiler
- gas cooker
- gas oven
- microwave oven
- extractor hood
- refrigerator

### 9.1 General



- ➤ The heat exchanger of the Truma hot-air heater has to be replaced after 30 years. Only the manufacturer of the heater or an authorised specialist workshop is allowed to replace the heat exchanger. The operator of the heater must see to it that the parts are replaced.
- ➢ For safety reasons, spare parts for pieces of heating appliances must correspond with manufacturer's instructions and be permitted by the manufacturer as a spare part. These spare parts may only be fitted by the manufacturer or an authorised specialist workshop.



Further information can be obtained in the instruction manual for the respective appliance.

The heater, boiler, cooker and refrigerator are fitted depending on the model of the vehicle.

In this instruction manual a description is given only for the operation of the appliances and their particular features.

To operate gas appliances, first open the regulator tap on the gas bottle and the gas isolator tap corresponding to the appliance.




Fig. 133 Symbols for the gas isolator

- I Cooker
- 2 Boiler (special equipment)
- 3 Oven (special equipment)
- 4 Refrigerator
- 5 Heater



#### 9.2 Heater



- ▶ In winter, check that the waste gas vent on the vehicle roof is free of snow and ice before using the heater.
- ▶ Never let gas escape unburned due to danger of explosion.
- ▶ Never run the heater in gas operation when refuelling, on ferries or in the garage. Danger of explosion!
- ► Never operate the heater in gas operation in closed spaces (e.g. garages). Danger of poisoning and suffocation!
- ▶ If the circulation fan does not activate automatically, switch the circulation fan on from heating level 3 to 4. There is danger of overheating for the heater!
- ▶ Do not damage the exhaust gas pipe.
- ▶ The waste gas vent may neither be closed nor blocked.
- ▶ When camping in winter, the Truma waste gas vent extension should be used to prevent snow from choking the waste gas vent.
- ▶ Do not use the space behind the heater as a storage compartment.

When lighting the heater for the first time a small amount of smoke and odour will occur. Immediately set the operating switch of the heater to its highest position. Open doors and windows and ventilate well. Smoke and odour will disappear by themselves after a while.

# 9.2.1 Models with waste gas vent on the right-hand side of the vehicle



▶ If the awning is put up and the heater is running in gas operation, exhaust gases from the heater can escape into the awning area. Danger of suffocation! Make sure the area is sufficiently ventilated.

## 9.2.2 To heat properly



Fig. 134 Air outlet nozzle

#### Hot air distribution

Several air outlet nozzles (Fig. 134) are built into the vehicle. Pipes conduct the warm air to the air outlet nozzles. Turn the air outlet nozzles in a suitable position so the air can escape as required.

## Adjusting the air outlet nozzles

- Fully open: Full hot air stream
- Half or partially open: Reduced hot air stream



When five air outlet nozzles are completely opened, less warm air escapes through each nozzle. However, if only three air outlet nozzles are opened, more warm air flows out of each nozzle.

#### 9.2.3 Hot-air heater Trumatic S 3002/S 5002



▶ In case of problems wait for two minutes before trying again.



Fig. 135 Heater control knob

Switching on:

- Open the regulator tap on the gas bottle and the gas isolator tap "Heater".
- Turn control knob on the heater to the required position and press it firmly. The automatic ignition produces ignition sparks. A clicking noise can be heard.
- Keep the control knob pressed until the flame burns. The burning of the flame can be checked in the inspection window in the heater cover.
- Hold the control knob down for a further 10 seconds, until the ignition fuse starts up.



- ➤ The automatic ignition sparks until the gas ignites. If there is no gas, it will continue to spark until the battery in the automatic ignition is empty. When the heater is not required, set the control knob to "0" to avoid the battery in the automatic ignition running flat.
- ▷ If the clicking noise cannot be heard at all or only at intervals of several seconds during ignition: Change the battery in the automatic ignition.
- ▷ Insert a new batteries before the start of every heating season.


Switching off:

- Turn the control knob on the heater to "0". The automatic ignition is switched off simultaneously.
- Close the gas isolator tap "Heater" and the regulator tap on the gas bottle.



> Further information can be obtained in the manufacturer's instruction manual.








Fig. 136 Removing heater cover

Fig. 137 Heater opened

## Changing the battery on the automatic ignition:

- Make certain that the heater is switched off.
- Remove heater cover (Fig. 136,2). Pull the heater cover upwards and forwards, press up the retaining springs (Fig. 136,1) to the side and tip the cover forwards.
- Turn the cover (Fig. 137,1) to the side, so that the connecting cables for the hot-air fan as well as the ignition control lamp do not need to be disconnected.
- Push battery chamber cover on the automatic ignition (Fig. 137,2) upward.
- Remove the old battery out of the battery chamber of the automatic ignition.
- Insert a new battery (Fig. 137,3) of the same type, correctly aligned (+/-), into the battery chamber of the automatic ignition. Only use temperature resistant (+70 °C) and leak-proof Mignon batteries.
- Push battery chamber cover on the automatic ignition upward.
- Press the stop lever to the right, until the lock engages audibly.




Fig. 138 Heater cover, retaining clips

- Mount the heater cover. To do this, place the cover (Fig. 138,1) on the lower retaining clips (Fig. 138,2).
- Insert the operating rod from underneath into the grip socket and allow the cover to catch in place above.



## 9.2.4 Circulation fan (partially special equipment)

The circulation fan together with the hot-air heater ensures a better distribution of hot air throughout the caravan.




Fig. 139 Operating switch for circulation

Switching circulation fan on:

- Set sliding switch (Fig. 139,1) to "¬" (manual control) or "A" (automatic operation).
- Turn the knob (Fig. 139,2) to set (manual control) or limit (automatic operation) the power of the circulation fan.

Switching circulation fan off:

■ Set sliding switch (Fig. 139,1) to "•" (off).



Further information can be obtained in the manufacturer's instruction manual.

### 9.2.5 Trumatic S 3004/S 5004 hot-air heater



▶ In case of problems wait for three minutes before trying again.




- The heater and fan can also be operated independently of each other. This
   means that the fan can also be used without the heater for air circulation.
- ➤ To ensure that warm air is distributed quickly and evenly, switch on the fan when the heater is in operation. This also reduces the surface temperature of the outlet grille.
- > Type S 5004 is equipped with a second fan and has a greater output.

The heater is equipped with an adjustable fan and is controlled via a thermostat.

Depending on the model and equipment level, the type S 3004 or type S 5004 may be fitted.








Fig. 140 Hot-air heater control knob

Fig. 141 Knob and rotary switch for fan

#### Switching on:

- Open the regulator tap on the gas bottle and the gas isolator tap "Heater".
- Turn control knob on the heater to the required position and press it firmly. The automatic ignition produces ignition sparks. A clicking noise can be heard.
- Keep the control knob pressed until the flame burns. The burning of the flame can be checked in the inspection window in the heater cover.
- Hold the control knob down for a further 10 seconds, until the ignition fuse starts up.



- ➤ The automatic ignition ignites until the gas is burning. If there is no gas, it will continue to spark until the battery in the automatic ignition is empty. When the heater is not required, set the control knob to "0" to avoid the battery in the automatic ignition running flat.
- ▷ If the clicking noise cannot be heard at all or only at intervals of several seconds during ignition: Change the battery in the automatic ignition.
- ▷ Insert a new batteries before the start of every heating season.

#### Switching off:

- Turn the control knob on the heater to "0". The automatic ignition is switched off simultaneously.
- Close the gas isolator tap "Heater" and the regulator tap on the gas bottle.

#### Fan operating modes

Switch position	Operating mode	Function
А	Automatic	The required fan output is regulated electronically
M	Manual	The fan output is set manually using the knob (Fig. 141,1)
×	Booster level	The fan works at maximum output (for maximum air flow)

Switching on the fan:

■ Set the rotary switch (Fig. 141,2) to the required operating mode.


Switching off the fan:

■ Turn the rotary switch (Fig. 141,2) to "0".

### **Automatic ignition**

The automatic ignition ignites until the gas is burning or the battery in the automatic ignition is empty.








Fig. 142 Removing heater cover

Fig. 143 Automatic ignition

Changing the battery on the automatic ignition:

- Ensure that the heater is switched off and cooled down.
- Remove heater cover (Fig. 142,2). To do this, press the two locking levers (Fig. 142,1) to the outside at the same time and tip the cover forwards.
- Lift the heater cover out of the bottom brackets and remove it.
- Push battery chamber cover (Fig. 143,2) on the automatic ignition (Fig. 143,1) upward.
- Remove the old battery out of the battery chamber of the automatic ignition.
- Insert a new battery (Fig. 143,3) of the same type, correctly aligned (+/-), into the battery chamber of the automatic ignition. Only use temperature resistant (+70 °C) and leak-proof Mignon batteries.
- Close the battery chamber cover on the automatic ignition.




Fig. 144 Heater cover, lower brackets

- Mount the heater cover. To do this, place the heater cover (Fig. 144,1) on the lower brackets (Fig. 144,2).
- Swivel the heater cover onto the heater and allow the heater cover to engage at the top.



Further information can be obtained in the manufacturer's instruction manual.



## 9.2.6 Airmix comfort package (special equipment)

The air circulation fan can be installed on the floor or on the wall with the Airmix comfort package. This guarantees a particularly quiet running, since no noise transferring connection is made to the fitted cover of the heater.




Fig. 145 Airmix comfort package

Fresh outside air is guided into the caravan by the Airmix. Advantages of outside air are:

- Cooling effect in the summer
- Drying effect in the winter

The outside air can be mixed progressively with the inside air that has already been heated by adjusting the operating controls (Fig. 145,1).



▷ See installation instructions of the separate instruction manual for the Airmix comfort package.

### 9.2.7 Ultraheat additional electric heater (special equipment)

The Ultraheat additional electric heater is built-in to the hot-air heater. Therefore there are three heating options:

- Only the hot-air heater
- Hot-air heater and electric heater
- Only the electric heater

The vehicle can be heated more quickly with the additional electric heater.



- The additional electric heater only operates if the vehicle is connected to the 230 V power supply.
- ▷ If the heater is operated by electricity and gas simultaneously, the additional electric heater switches off to prevent possible overheating by the stronger gas burner.





Fig. 146 Operating unit for Ultraheat additional electric heater

- 1 Rotary switch
- 2 Off
- 3 Temperature control knob

Switching on:

- Connect the vehicle to the 230 V power supply (see section 8.5).
- Turn the rotary switch (Fig. 146,1) to the desired output level (500, 1000 or 2000 W).
- Turn temperature control knob (Fig. 146,3) to the desired output level.

Switching off:

■ Turn the rotary switch (Fig. 146,1) to "O" (Fig. 146,2).

## 9.2.8 Warming unit for waste water pipes (special equipment)



> Always only press the test button briefly.



The warming unit only functions when the vehicle is connected to a 230 V power supply.

In order to prevent waste water pipes freezing up, the waste water pipes can be electrically warmed.

When the warming unit is turned on, the temperature of the waste water pipes is monitored by temperature sensors. If the temperature falls below 5 °C, the heating elements are switched on and the waste water pipes are warmed. If the temperature rises above a certain level, the heating elements are switched off again.




Fig. 147 Transformer with control unit

The 230 V AC/12 V DC transformer (Fig. 147,2) is installed in the wardrobe or in the storage area beneath the seating group, depending on the model.



The control unit is integrated in the transformer housing. The control lamps have the following meanings:

- The indicator lamp (Fig. 147,5) lights up in green: Regulation in operation
- The indicator lamps (Fig. 147,4 and 6) light up in red: Waste water pipes are warmed

A test button (Fig. 147,3) is integrated in the housing with which the control unit can be operated for a short time. By pressing the test button, the function of the warming unit can be tested, even if the ambient temperature is above  $5\,^{\circ}\text{C}$ .

Switching on:

- Connect the vehicle to a 230 V power supply (see section 8.5.1).
- Turn switch (Fig. 147,1) on the transformer (Fig. 147,2) to "ON".

Switching off:

■ Turn switch (Fig. 147,1) on the transformer (Fig. 147,2) to "OFF".

## 9.2.9 Electrical floor warming unit (special equipment)



▶ On models with electrical floor warming unit, never drill holes in the floor or screw in any screws. Careful with sharp objects. There is danger of a power cut or a short circuit due to damage to a heater wire.



▷ Do not cover the transformer. Danger of overheating!



- The electrical floor warming unit only operates if the vehicle is connected to the 230 V power supply.
- > The output of the electrical floor warming unit alone is not sufficient to heat the living area.



Fig. 148 Transformer for electrical floor warming unit



Fig. 149 Switch for electrical floor warming unit

The transformer (Fig. 148,1) for the electrical floor warming unit is installed either in the bench seat or in the bedding box, depending on the model.

Switching on:

- Connect the vehicle to the 230 V power supply (see chapter 8).
- Press the rocker switch (Fig. 149,2). The indicator lamp (Fig. 149,1) on the switch is illuminated.

Switching off:

■ Press the rocker switch (Fig. 149,2). The indicator lamp (Fig. 149,1) on the switch goes off.



After switching off, the floor remains warm for a while, due to residual heat. If the transformer is overloaded, the overload protection is actuated. The pin (Fig. 148,2) jumps out.

Switching on overload protection:

■ Press the pin (Fig. 148,2) on the overload protection when the transformer is cooled.

## 9.3 Air conditioning unit (special equipment)

#### 9.3.1 Dometic



▷ If the unit is operating, always open at least one ventilation flap.



- ▷ In the winter, vehicle heating can be supported but not replaced by the air conditioning unit.




Fig. 150 Remote control

- 1 Symbol for automatic mode
- 2 Symbol for cold mode
- 3 Symbol for warm mode
- 4 Symbol for ventilation mode
- 5 Symbol for discharged batteries
- 6 Time
- 7 Temperature display
- 8 Fan speed display
- 9 ON/OFF button
- 10 Fan speed button
- 11 "MODE" button
- 12 "CLOCK" button
- 13 Reset key14 Interior tem
- 14 Interior temperature display button "ROOM"
- 15 Store button "SET"
- 16 Light button "LIGHT"(optional)
- 17 Temperature unit change button "F/C°"
- 18 Temperature decrease button "-"
- 19 Temperature increase button "+"
- 20 Display

To execute the individual switching commands, always point the remote control in the direction of the ceiling unit.

#### **Operating modes**

The air conditioning unit has the following operating modes:

- Automatic
- Ventilation, manual
- Cooling, manual
- Heating, manual

#### Switching on:

- Press the ON/OFF button (Fig. 150,9).
- Press the "Mode" button (Fig. 150,11) as often as required until the required mode (Fig. 150,1, 2, 3 or 4) is indicated on the display (Fig. 150,20).
- Use the "+" (Fig. 150,19) and "—" (Fig. 150,18) buttons to set the desired temperature.
- Use the fan speed button (Fig. 150,10) to select the desired fan level.



#### Switching off:

■ Press the ON/OFF button (Fig. 150,9).



Fig. 151 Air conditioning unit (Dometic)

**LED** The LED (Fig. 151,4) on the ceiling unit (Fig. 151,1) displays the operating status of the air conditioning unit:

Status LED	Signification
Off	Air conditioning unit off
Orange	Air conditioning unit ready to operate
Green	Air conditioning unit in operation
Red (continuous)	No 230 V power connection
Red (flashes once intermit- tently)	Fault in the interior temperature gauge
Red (flashes twice intermit- tently)	Fault in the exterior temperature gauge

#### Air current

The air current can be directed in different directions. The distribution of the air current toward the front or back is continuously adjustable.

#### Adjusting air current:

- Align the two deflectors (Fig. 151,3 and 5) in the desired position.
- Rotate knob (Fig. 151,2) on sliding regulator in an anticlockwise direction. The sliding regulator for air distribution is released.
- Slide the sliding regulator forwards or backwards to the desired position. The side on which the sliding regulator is located is closed.
- Turn the knob tight in the clockwise direction.

### 9.3.2 Telair



- ▷ If the unit is operating, always open at least one ventilation flap.



- The air conditioning unit only runs if the vehicle is connected to a 230 V power supply.
- ▷ In the winter, vehicle heating can be supported but not replaced by the air conditioning unit.
- ▶ Following switch-on the air conditioning unit needs approx. 3 minutes until the compressor starts to run and cold air or hot air is output.
- > Also read the manufacturer's instruction manual.

## **Appliances**






Fig. 152 Remote control

- Symbol for automatic
- 2 Symbol for cooling
- 3 Symbol for heater
- Temperature (set) display
- 5 Fan speed display
- Temperature increase button "ON/OFF" button 6
- Temperature reduction button
- Ventilation speed button 9
- 10 "Mode" button
- Display 11




Fig. 153 Display on the diffusor

- Mains connection indicator lamp
- Temperature (current) display
- Mode indicator lamp Green: Cooling Red: Heater

To execute the individual switching commands, always point the remote control in the direction of the receiver.

#### **Operating modes**

- Automatic
- Cooling
- Heater

### Switching on:

- Press the "ON/OFF" button (Fig. 152,7).
- Press the "Mode" button (Fig. 152,10) as often as required until the required mode (Fig. 152,1, 2 or 3) is indicated on the display. The corresponding indicator lamp on the diffusor display (Fig. 153,3) lights up.
- Use the temperature increase button (Fig. 152,6) or temperature reduction button (Fig. 152,8) to set the required temperature.
- Use the ventilation speed button (Fig. 152,9) to select the required ventilation level.

#### Switching off:

■ Press the "ON/OFF" button (Fig. 152,7).




 ▷ If the air conditioning unit has run in heating mode, the blower will run on for some minutes in order to dissipate the heat completely.



#### 9.3.3 Truma



- The air conditioning unit only runs if the vehicle is connected to a 230 V power supply.
- The external 230 V power supply must be protected by a fuse of at least
   3 A. It is otherwise not possible to operate the air conditioning unit properly.






Fig. 154 Receiver

Fig. 155 Remote control

To execute the individual switching commands, always point the remote control in the direction of the receiver.

#### Switching on:

- Connect the vehicle to the 230 V power supply. The air conditioning unit is ready to operate.
- Switch on the remote control with the switch (Fig. 155,7). The green indicator lamp (Fig. 154,1) indicates cooling mode.
- Set the desired operating mode with the key (Fig. 155,8).
  - "FAN": Only ventilation without cooling.
  - "COMFORT": Cooling. The fan output and the room temperature can be set separately. The green indicator lamp in the receiver indicates the compressor is in operation and therefore cooling mode.
- Set the desired fan output and room temperature with the keys (Fig. 155,3 and 4) if necessary. The arrow (Fig. 155,9) indicates the selected setting mode.

If the temperature set on the remote control is reached, the green indicator lamp goes out, the compressor is switched off and the circulation fan continues to run.



An additional key switch (Fig. 154,2) is on the receiver, which can be used to switch the air conditioning unit off or on without remote control. If the air conditioning unit is switched on by means of this key switch, the operating mode set last on the remote control is automatically selected.

#### Switching off:

■ To switch off, press the key (Fig. 155,7) on the remote control again.



Condensation accumulates on the vaporiser in cooling mode. To counteract any formation of germs, operate the air conditioning unit about 5 to 10 minutes in the "FAN" and "HIGH" positions to dry the vaporiser.

#### **Timer**

The air conditioning unit can be switched on or off automatically from the current time up to 15 hours in advance with the integrated timer. Pre-programming up to a certain time is not possible.



- To program, switch on the air conditioning unit with the key (Fig. 155,7) on the remote control.
- Set the desired operating mode and room temperature with the keys (Fig. 155,8, 3 and 4).
- Use the key (Fig. 155,5) to select the desired function (Fig. 155,1):
  - "ON": Switching on"OFF": Switching off
- Use the keys (Fig. 155,4) to select the desired switching time (1 to 15 hours). The arrow (Fig. 155,2) flashes and indicates the setting mode.
- If "ON" (switch on) was selected, the air conditioning unit must be switched off again with the remote control after the setting process. The indicator lamp in the receiver flashes and confirms the programming.
- The indicator lamp in the receiver flashes and confirms the programming if "OFF" (switch off) was selected. Do **not switch off** the air conditioning unit with the remote control.



- ➤ To go easy on the batteries in the remote control, the infrared transmitter can be covered by hand and the remote control then switched off after the "OFF" programming. In this way no signal is transferred to the receiver and the programming is retained.
- The key (Fig. 155,6) is used to send the settings of the remote control repeatedly to the receiver.
- > Further information can be obtained in the manufacturer's instruction manual.

### 9.4 Boiler



- ▶ Never let gas escape unburned due to danger of explosion.
- ► Never run the boiler in gas operation when refuelling, on ferries or in the garage. Danger of explosion!
- ► Never operate the boiler in gas operation in closed spaces (e.g. garages). Danger of poisoning and suffocation!
- ▶ The water in the boiler can be heated up to 65 °C. Risk of scalding!



- > Switch on the boiler and empty it if the vehicle is not used.
- Never use boiler when empty.
- ▷ If the boiler is not being used, empty it if there is any risk of frost.
- Only operate the boiler with the maximum temperature setting if you require a large quantity of warm water. This protects the boiler against the build-up of limescale.



▷ Do not use the water from the boiler as drinking water.



## 9.4.1 Models with waste gas vent on the right-hand side of the vehicle



▶ If the awning is put up and the boiler is running in gas operation, exhaust gases from the boiler can escape into the awning area. Danger of suffocation! Make sure the area is sufficiently ventilated.

## 9.4.2 Truma boiler (special equipment)



▶ Remove cap from waste gas vent before using the Truma boiler.

#### **Operating modes**

The boiler has three operating modes:

- Gas operation
- 230 V electrical operation
- Combined operation

The operating mode is set with the operating controls.

The regulation of the water temperature in the boiler is only possible with gas operation.

#### Gas operation

The boiler is operated exclusively with gas.



Fig. 156 Operating unit for Truma boiler (gas operation)

- 1 Temperature control knob
- 2 Red indicator lamp "Fault"
- 3 Rotary switch
- 4 Off
- 5 On

### Switching on:

- Remove cap from waste gas vent.
- Open the regulator tap on the gas bottle and the gas isolator tap "Boiler".
- Set the rotary switch (Fig. 156,3) to "♠" (Fig. 156,5). The green "Operation" indicator lamp illuminates the knob (Fig. 156,1).
- Adjust the knob (Fig. 156,1) to the required water temperature.

The red indicator lamp (Fig. 156,2) illuminates when there is a fault (see chapter 14).

#### Switching off:

- Set the rotary switch (Fig. 156,3) on the operating unit (Fig. 156) to "O" (Fig. 156,4).
- Close the gas isolator tap "Boiler" and the regulator tap on the gas bottle.
- Place cap on waste gas vent.

The red indicator lamp (Fig. 156,2) illuminates when there is a fault (see chapter 14).



#### 230 V electrical operation

The boiler is operated exclusively with electricity.



≥ 230 V electrical operation is only possible when the vehicle is connected to the 230 V power supply.



Fig. 157 Flip switch for Truma boiler (230 V electrical operation)

Switching on:

- Connect the vehicle to the external 230 V power supply and switch on the 230 V automatic circuit breaker.
- Set flip switch (Fig. 157,1) to on. The indicator lamp on the switch is illuminated. The water in the boiler is heated up to 65 °C.

Switching off:

■ Set the flip switch (Fig. 157,1) to "O". The indicator lamp on the switch goes off.

#### **Combined operation**

The water is heated more quickly in the boiler if gas operation and 230 V electrical operation are switched on simultaneously.



> Further information can be obtained in the manufacturer's instruction manual.

#### Filling/emptying the boiler

The boiler can be supplied with water from the water tank.

Depending on the model, the vehicle is fitted with one or several boiler drain cocks. The drain cocks can have different designs (rocking lever or twist cap).




Fig. 158 Drain cocks

Filling the boiler with water:

- Close all boiler drain cocks. To do this, position the rocking lever (Fig. 158,1) horizontally or turn the cap (Fig. 158,2) in a clockwise direction.
- Set all the water taps to "Hot" and open them. The water pump is turned on. The warm water pipes are filled with water.



- Keep the taps open until the water flowing out of the taps has no bubbles in it. This is the only way to ensure that the boiler is full of water.
- Close all water taps.

#### Emptying the boiler:

- Set the rotary switch (Fig. 156,3) on the operating unit (Fig. 156) to "O" (Fig. 156,4) or the flip switch (Fig. 157,1) to "O".
- Turn knob (Fig. 156,1) anticlockwise until it can go no further.
- Open all boiler drain cocks. To do this, position the rocking lever (Fig. 158,1) vertically or turn the cap (Fig. 158,2) in an anticlockwise direction.
- Check whether the water has been drained completely from the boiler (approx. 12.5 litres).

## 9.4.3 Hot water source (special equipment)



- Do not fit a check valve in the cold water pipe between the hot water source and the water pump.
- Use a pressure reducer when connecting to a central water supply or with strong pumps. The hot water source is designed only for pressures of up to 1.2 bar. In addition, insert a safety/drainage valve in to the cold water pipe.



Do not use the water from the hot water source as drinking water.



Fig. 159 Operating switch for hot water source

The hot water source can either be operated using the 230 V power supply (electrical mode of operation), with the hot air of the heater system or both types of energy. The hot water source heats approx. 5 I water to a temperature of approx. 65  $^{\circ}$ C.

The electrical mode of operation is activated using the operating switch (Fig. 159). The indicator lamp (Fig. 159,1) on the switch must illuminate.

During hot air operation, the water in the hot water source is heated up by the heater and the circulating air.

Depending on the model, the vehicle is fitted with one or two hot water source drain cocks.



Switching on:

- Connect the vehicle to the external 230 V power supply and switch on the 230 V automatic circuit breaker.
- Switch on the operating switch (Fig. 159). Indicator lamp (Fig. 159,1) on the switch is illuminated. The water in the hot water source is heated up to 65 °C.

Switching off:

■ Switch off the operating switch (Fig. 159). Indicator lamp (Fig. 159,1) on the switch goes off.




Fig. 160 Drain cock for hot water source

Filling the hot water source with water:

- Connect the vehicle to the external 230 V power supply and switch on the 230 V automatic circuit breaker.
- Switch off the operating switch (Fig. 159). Indicator lamp (Fig. 159,1) in the switch is not on.
- Close all drain cocks. To do this, close the caps (Fig. 160,1) by turning them in a clockwise direction.
- Set all the water taps to "Hot" and open them. The water pump is turned on. The warm water pipes are filled with water.
- Keep the taps open until the water flowing out of the taps has no bubbles in it. This is the only way to ensure that the hot water source is full of water.
- Close all water taps.

Emptying the hot water source:

- Switch off the 230 V power supply on the 230 V automatic circuit breaker.
- Open the stopper of the water tank.
- Open all water taps and set to the central position.
- Hang the shower handset up in the shower position.
- Hold the water pump up until the water pipes are completely empty.
- Open all drain cocks of the hot water source. To do this turn the caps (Fig. 160,1) in an anticlockwise direction.
- Check whether the water is completely drained from the hot water source.



> Further information can be obtained in the manufacturer's instruction manual.



### 9.5 Cooker



- ▶ Never let gas escape unburned due to danger of explosion.
- ▶ Before using the cooker make sure that there is sufficient ventilation. Open windows or the skylight.
- ▶ Do not use gas cooker or gas oven for heating.
- ▶ Do not fit any curtains in the immediate proximity of the cooker. Fire hazard!
- Always protect your hands with cooking gloves or potholders when handling hot pots, pans and similar items. There is a risk of injury.

#### 9.5.1 Gas cooker



- ▶ During activation and operation of the gas cooker, no flammable objects or highly inflammable objects such as dishcloths, napkins etc. must be near the gas cooker. Fire hazard!
- ► The process of ignition must be visible from above and must not be covered by cooking pans placed on the cooker.
- ▶ If there is a flame protection, always put it up when using the gas cooker.
- ► The gas cooker lid is held closed by a spring. When closing there is danger of getting injured!



- Do not place hot objects such as cooking pans on the sink cover. The plastic can become deformed.
- Do not use the glass gas cooker lid as a hob.
- Do not close the gas cooker lid while the gas cooker is in operation.
- ▷ Do not apply pressure on the gas cooker lid when it is closed.
- Do not place hot cooking pans on the gas cooker lid.



- Only use pots and pans whose diameter is appropriate for the gas cooker burners.
- ▶ When the flame goes out, the thermocouple automatically cuts the gas supply.
- ➢ Further information can be obtained in the device manufacturer's instruction manual.

The kitchen unit is fitted with a three-burner gas cooker.

Depending on the model, the gas cooker may be lit manually or with automatic ignition.



#### **Manual ignition**

The gas cooker must be lit manually.



Fig. 161 Operating controls for gas cooker

### Switching on:

- Open the regulator tap on the gas bottle and the gas isolator tap "Cooker".
- Open the gas cooker lid.
- Turn the control knob (Fig. 161,1) on the burner you wish to use to the ignition position (large flame).
- Press the control knob down and hold it.
- Light the burner with a gas lighter, a match or other suitable means of lighting.
- Once the flame is burning, the control knob must be held down for 10 to 15 seconds, until the thermocouple automatically keeps the gas supply open.
- Release the control knob and turn to the desired setting.
- If ignition is unsuccessful, repeat the entire procedure.

#### Switching off:

- Turn the control knob to the 0-position. The flame fades.
- Close the gas isolator tap "Cooker" and the regulator tap on the gas bottle.

## **Automatic ignition**

The gas cooker is equipped with electronic ignition.




Fig. 162 Operating controls for gas cooker

### Switching on:

- Open the regulator tap on the gas bottle and the gas isolator tap "Cooker".
- Open the gas cooker lid.
- Depending on the model, fold out and lock the flame protection.
- Turn the control knob (Fig. 162,2) on the burner you wish to use to the ignition position (large flame).



- Press the push button (Fig. 162,1).
  The automatic ignition produces ignition sparks. A clicking noise can be heard.
- Once the flame is burning, the control knob must be held down for 10 to 15 seconds, until the thermocouple automatically keeps the gas supply open.
- Release the control knob and turn to the desired setting.

#### Switching off:

- Turn the control knob to the 0-position. The flame fades.
- Close the gas isolator tap "Cooker" and the regulator tap on the gas bottle.

### 9.5.2 Gas oven (Dometic) (special equipment)



- ▶ Keep the ventilation openings on the gas oven open at all times.
- ► There must be no flammable or highly inflammable objects such as dishcloths, clothes, etc. near the gas oven when it is being lit or during operation. Fire hazard!
- ▶ If ignition has not taken place, repeat the entire procedure. If necessary, check if there is gas and/or current in the gas oven.
- ▶ If the gas oven still does not work, close the gas isolator tap and notify your service centre.
- ▶ If the burner flame is accidentally extinguished, turn the control knob to "O" and leave the burner off for at least 1 minute. Then ignite it again.
- ▶ Parts of the gas oven become very hot during operation. Never touch hot parts with bare hands.
- ▶ Place the meals, wire rack and drip pan into the gas oven so that they do not come into contact with the flame.
- ▶ Only ignite the oven and grill when the oven door is open.
- ▶ Always leave the oven door half open when grilling.
- ▶ Do not use the grill for longer than 25 minutes.



- There are two different versions of the gas oven, depending on the model.
   Although their appearance is not identical, operation is the same for both.
- Depending on the model the gas oven may come equipped with a grill.
- ▷ Before using the gas oven for the first time run it for 30 minutes at maximum temperature without any contents.
- ▶ When the flame goes out, the thermocouple automatically cuts the gas supply.
- > A safety switch prevents ignition when the oven door is closed.
- If the ignition procedure fails repeatedly, turn the control knob to "O". Wait
   at least 1 minute and then ignite the gas oven manually. If necessary,
   check if there is gas and/or current in the gas oven. If the gas oven still does
   not work, close the gas isolator tap and notify your service centre.
- > Further information can be obtained in the manufacturer's instruction manual.



The gas oven is equipped with electronic ignition.






Fig. 163 Gas oven (Dometic TecTower)

Fig. 164 Gas oven (Dometic)

The meaning of the symbols on the control knobs (Fig. 163,1 and Fig. 164,1) of the two gas ovens is identical:

- A and SSS mean oven
- and mean grill.

Switching the oven on:

- Open the regulator tap on the gas bottle and the gas isolator tap "Oven".
- Open oven door completely. The safety switch then releases the ignition.
- Press and hold control knob (Fig. 163,1 and Fig. 164,1) and turn it anticlockwise to the required setting. Keep control knob pressed for a further 5-10 seconds. Ignition will take place automatically.
- Release control knob.
- Close oven door.

Switching the grill on:

- Open the regulator tap on the gas bottle and the gas isolator tap "Oven".
- Open the oven door to at least the first locking position (approx. 45°).
- Press and hold control knob and turn it clockwise to the grill symbol. Keep control knob pressed for a further 5-10 seconds. Ignition will take place automatically.
- Release control knob.



▷ Do not close the oven door when grilling.

Switching off:

- Turn the control knob to "O". The flame fades.
- Close the gas isolator tap "Oven" and the regulator tap on the gas bottle.

### 9.5.3 Microwave oven (special equipment)



- Only qualified personnel may repair the microwave oven. Improper repairs can cause major risks to the user.
- ▶ The protection device against the escape of microwave energy should never be removed.
- ▶ Use the microwave oven only if it has been properly installed.
- ▶ Only use the microwave oven when the door seal is free of damage.





- ▶ Never leave the microwave oven unattended when it is in operation.
- ▶ If there is smoke, keep the microwave oven closed, switch it off and interrupt the power supply.



- Departe the microwave oven only with the rotary plate and the rotary cross in place.
- Only operate the microwave with appropriate contents and never run it empty.



- ➢ For cooking times under 2 minutes: First twist the cooking time control knob past "2" and then twist it back to the desired cooking time.
- > Further information can be obtained in the manufacturer's instruction manual.



Fig. 165 Operating controls for microwave oven

#### Switching on:

- Press the key (Fig. 165,3) to open the door and place food into the cooking
- Close the door. A clicking noise can be heard when it engages.
- Select the output on the control knob (Fig. 165,1).
- Select the cooking time with the control knob (Fig. 165,2). Cooking begins.

The end of the cooking process is signaled by a signal tone. The microwave oven will switch off automatically.

#### Switching off:

■ Press the key (Fig. 165,3) to open the door and take out the food.

### 9.5.4 Extractor hood (special equipment)

The cooking area is equipped with an extractor hood. The powerful fan blows the cooking steam directly outside. To switch on the extractor hood, press the flip switch.



## 9.6 Refrigerator

During the journey, only operate the refrigerator via the 12 V power supply. At high ambient temperatures the refrigerator is unable to reach its full cooling power. At high external temperatures, the full cooling power of the cooling unit is only guaranteed if the refrigerator is ventilated sufficiently. In order to achieve a better ventilation the refrigerator ventilation grill can be removed.



- ▶ When leaving the vehicle, always mount the refrigerator ventilation grill. Otherwise water can enter during rain.
- The cooling power of the refrigerator depends on the vehicle setup. The cooling power can decrease if the vehicle is inclined by 5° or more. Therefore, always park the vehicle on level ground.
- Absorption refrigerators operate at normal room temperature (approx. 21 °C) within the specified temperature range. At significantly higher ambient temperatures (> 30 °C), the cooling power is reduced. This is because the "evaporating temperature" of the refrigerant is lower in absorption refrigerators than it is in compressor refrigerators.

### 9.6.1 Refrigerator ventilation grill

#### **Dometic**



Fig. 166 Refrigerator ventilation grill (with sliding trap)

#### Removal:

- Push sliding trap (Fig. 166,1) upward.
- Remove refrigerator ventilation grill.



Fig. 167 Refrigerator ventilation grill (with screw)

#### Removal:

- Turn screw (Fig. 167,1) one quarter turn using a coin.
- Remove refrigerator ventilation grill.



#### **Thetford**




Fig. 168 Refrigerator ventilation grill (Thetford)

#### Removal:

- Move the locking device (Fig. 168,1) to the middle.
- Remove refrigerator ventilation grill.

## 9.6.2 Operation (Dometic 8 series with manual ignition)

#### **Operating modes**

The refrigerator has 3 operating modes:

- Gas operation
- 230 V AC
- 12 V DC

The operating mode is set with the operating controls on the refrigerator panel.



- > Select only one energy source.
- Even when the 12 V power supply is switched off, a small electrical power flows which puts an extra load on the living area battery. Always switch off the refrigerator for a temporary lay-up.

#### Gas operation



- Never let gas escape unburned due to danger of explosion.
- ▶ It is not permitted to operate the refrigerator with car gas.




Fig. 169 Operating controls for the refrigerator (Dometic 8 series)

- 1 Flame indicator
- 2 Energy selector switch
- 3 Control knob for setting the temperature
- 4 Gas ignition button

#### Switching on:

- Open the regulator tap on the gas bottle and the gas isolator tap "Refrigerator".
- Set the energy selector switch (Fig. 169,2) to "△".
- Press the control knob (Fig. 169,3), turn it to the highest level and hold it down. Wait until gas gets into the burner.



- Press the gas ignition button (Fig. 169,4) and keep it pressed. Ignition will take place automatically.
- Keep gas ignition button (Fig. 169,4) pressed down until the flame indicator (Fig. 169,1) becomes green and then release it.
- Keep the control knob (Fig. 169,3) pressed for another 10 to 15 seconds, then release it.
- Adjust the refrigerating temperature with the control knob.

#### Switching off:

- Set energy selector switch to "O". Refrigerator is switched off.
- Close the gas isolator tap "Refrigerator" and the regulator tap on the gas bottle.

### **Electrical operation**



○ Close the gas isolator tap "Refrigerator" when the refrigerator is operated electrically.

The refrigerator can be operated with the following voltages:

- 230 V AC
- 12 V DC

Switching the 230 V operation on:

- Set the energy selector switch (Fig. 169,2) to "⇒=".
- Use the control knob (Fig. 169,3) to adjust the refrigerating temperature.

Switching the 230 V operation off:

■ Set energy selector switch to "O". Refrigerator is switched off.

Switching the 12 V operation on:

- Set the energy selector switch (Fig. 169,2) to "+--".
- Use the control knob (Fig. 169,3) to adjust the refrigerating temperature.

Switching the 12 V operation off:

■ Set energy selector switch to "O". Refrigerator is switched off.

When operated with 12 V, the refrigerator draws power only from the starter battery of the towing vehicle. The starter battery of the towing vehicle only supplies the refrigerator with 12 V when the vehicle engine is running and the alternator receives adequate voltage. When the vehicle engine is not running, the refrigerator is cut off from the power supply in the living area. For this reason, change over to gas operation during prolonged driving breaks.



Further information can be obtained in the device manufacturer's instruction manual.



# 9.6.3 Operation (Dometic 8 series with manual power selection MES)

#### **Operating modes**

The refrigerator has 3 operating modes:

- Gas operation
- 230 V AC
- 12 V DC

The operating mode is set with the operating controls on the refrigerator panel.



- > Select only one energy source.
- ➤ The refrigerator always requires a 12 V control voltage, regardless of which type of energy it is using. The control voltage is present as soon as the transformer/rectifier is switched on. Therefore the closed circuit current always flows even if the refrigerator is switched off. Always switch off the transformer/rectifier for a temporary lay-up.

#### Gas operation



Never let gas escape unburned due to danger of explosion.




Fig. 170 Operating controls for the refrigerator (Dometic 8 series with MES)

- 1 On/off switch/energy selector switch
- 2 Display-LED "open door" (only for central locking system of the refrigerator door)
- 3 Display-LED "fault"
- 4 Operating indicators
- 5 Display-LED "temperature range"
- 6 Switch for temperature setting
- 7 Door opener (only for refrigerator door central locking system)

#### Switching on:

- Open the regulator tap on the gas bottle and the gas isolator tap "Refrigerator".
- Press the on/off switch/energy selector switch (Fig. 170,1) down for 2 seconds in order to switch on the appliance. The LED of the operating mode chosen most recently lights up.
- If appropriate press the on/off switch/energy selector switch (Fig. 170,1) until the gas operating indicator " " lights up. Gas supply is open. Ignition will take place automatically. A ticking sound can be heard until ignition has been completed successfully.
- Use switch (Fig. 170,6) to adjust refrigerating temperature.



#### Switching off:

- Press down the on/off switch/energy selector switch for 2 seconds. Refrigerator is switched off.
- Close the gas isolator tap "Refrigerator" and the regulator tap on the gas bottle.

### **Electrical operation**



○ Close the gas isolator tap "Refrigerator" when the refrigerator is operated electrically.

The refrigerator can be operated with the following voltages:

- 230 V AC
- 12 V DC

## Switching the 230 V operation on:

- Press the on/off switch/energy selector switch (Fig. 170,1) down for 2 seconds in order to switch on the appliance. The LED of the operating mode chosen most recently lights up.
- Use switch (Fig. 170,6) to adjust refrigerating temperature.

## Switching the 230 V operation off:

Press down the on/off switch/energy selector switch for 2 seconds. Refrigerator is switched off.

## Switching the 12 V operation on:

- Press the on/off switch/energy selector switch (Fig. 170,1) down for 2 seconds in order to switch on the appliance. The LED of the operating mode chosen most recently lights up.
- If appropriate press the on/off switch/energy selector switch (Fig. 170,1) several times until the operating indicator 12 V "☐ ☐" lights up.
- Use switch (Fig. 170,6) to adjust refrigerating temperature.

## Switching the 12 V operation off:

Press down the on/off switch/energy selector switch for 2 seconds. Refrigerator is switched off.

When operated with 12 V, the refrigerator draws power only from the starter battery of the towing vehicle. The starter battery of the towing vehicle only supplies the refrigerator with 12 V when the vehicle engine is running and the alternator receives adequate voltage. When the vehicle engine is not running, the refrigerator is cut off from the power supply in the living area. For this reason, change over to gas operation during prolonged driving breaks.





## 9.6.4 Operation (Dometic 8 series with automatic power selection

#### Operating modes




Fig. 171 Operating controls for the refrigerator (Dometic 8 series with AES)

- On/off switch/energy selector switch
- Display-LED "open door" (only for central locking system of the refrigerator door) Display-LED "fault"
- Operating indicator
- Display-LED "temperature range"
- Switch for temperature setting
- Door opener (only for refrigerator door central locking system)

The refrigerator is equipped with automatic power selection (AES). If automatic operation (AU) is selected, the AES automatically selects the optimum energy source and regulates the refrigerator operation. Manual intervention to select the type of power is possible but not required.

The AES selects from the following types of power:

- 230 V AC
- Gas
- 12 V DC

Choosing the available energy source highest on the list.

In the case of a fault, the LED display fault will flash "/!\" (Fig. 171,3).



type of energy it is using. The control voltage is present as soon as the transformer/rectifier is switched on. Therefore the closed circuit current always flows even if the refrigerator is switched off. Always switch off the transformer/rectifier for a temporary lay-up.

#### 230 V operation

If the automatic mode is selected and the 230 V supply is switched on, the AES selects this energy source first.

### 12 V operation

12 V operation is only selected by the AES if the engine of the towing vehicle is running and the alternator supplies sufficient 12 V operating power.

### Gas operation



Never let gas escape unburned due to danger of explosion.



○ Open the regulator tap on the gas bottle and the gas isolator tap "Refrigerator".



If the 230 V power supply is **not** connected and the engine of the towing vehicle is **not running** the AES selects the gas supply. When selecting gas operation the ignition fuse is opened automatically so gas can get into the burner. At the same time the electronic ignition is activated. If the gas flame is extinguished, e.g. by blast of wind, the ignition is activated immediately and reignites the gas. In the case of a fault in gas operation the text "GAS" flashes in the operating indicator (Fig. 171,4).

## Change-over between energy sources



Open flames are prohibited at petrol stations. If the stop takes longer than 15 minutes, the refrigerator has to be turned off at the energy selector switch.

When changing over from 230 V or 12 V to gas, delay times are built into the AES. For example, when changing over from 12 V operation to gas operation, a 15 minute delay is built in the AES. This prevents a change-over to gas operation when the vehicle is stopped briefly and the engine is switched off (e.g. stop to fill tank).

## Refrigerating temperature control

When turned on the first time the refrigerator automatically selects the middle thermostat position. This position can be adjusted manually by using the switch for temperature setting (Fig. 171,6). The indicator LEDs (Fig. 171,5) show the selected thermostat position. The refrigerating temperature for the three types of energy is set with the switch. It takes a few hours till the refrigerator reaches its normal operating temperature. When changing over the operating mode the thermostat setting will be maintained. The refrigerating temperature is retained regardless of the type of power being used.

#### **Manual operation**

Switching on:

- Open the regulator tap on the gas bottle and the gas isolator tap "Refrigerator".
- Press the on/off switch/energy selector switch (Fig. 171,1) down for 2 seconds in order to switch on the appliance. The operating mode selected most recently is shown in the operating indicator (Fig. 171,4).
- Select the energy type with the on/off switch/energy selector switch (Fig. 171,1).
- Set the refrigerating temperature on the switch for temperature setting (Fig. 171,6). The indicator LEDs (Fig. 171,5) show the selected thermostat position.

When operated with 12 V, the refrigerator draws power only from the living area battery.



▷ If the refrigerator is manually set to "12 V", it will constantly consume current. Therefore, switch over to gas operation when the vehicle engine is not running, and the vehicle is not connected to the 230 V power supply.

Switching off:

- Press down the on/off switch/energy selector switch (Fig. 171,1) for 2 seconds. All displays close.
- Close the gas isolator tap "Refrigerator" and the regulator tap on the gas bottle.





Further information can be obtained from the separate instruction manual "Refrigerator".

## 9.6.5 Operation (Thetford N3000)



### **Operating modes**

The refrigerator has 3 operating modes:

- Gas operation
- 230 V operation
- 12 V operation




Fig. 172 Operating controls for the refrigerator

- 1 On/Off key
- 2 Arrow keys
- 3 Confirmation button
- 4 Indicator for operating mode (230 V operation/12 V operation/gas operation)
- 5 Indicator for cooling level (lowest highest cooling level)

The current operating mode is indicated by an illuminated symbol (Fig. 172,4) on the operating unit.



➤ The refrigerator always requires a 12 V control voltage, regardless of which type of energy it is using. The control voltage is present as soon as the transformer/rectifier is switched on. Therefore the closed circuit current always flows even if the refrigerator is switched off. Always switch off the transformer/rectifier for a temporary lay-up.



▶ We recommend that the refrigerator be operated in 12 V operation when the vehicle is in motion.

When the vehicle is stationary, we advise you to operate the refrigerator in 230 V operation, assuming a 230 V connection is available.

In all other cases, the refrigerator can be operated in gas operation.

## Refrigerating temperature control

When turned on the refrigerator automatically selects the thermostat position selected last. This position can be adjusted manually by using the arrow keys (Fig. 172,2). The illuminated bars of the cooling level indicator (Fig. 172,5) show the selected thermostat position. The refrigerating temperature for the three types of energy is set with the arrow keys. It takes a few hours till the refrigerator reaches its normal operating temperature. When changing over the operating mode the thermostat setting will be maintained. The refrigerating temperature is retained regardless of the type of power being used.



#### Gas operation



▶ Never let gas escape unburned due to danger of explosion.

#### Switching on:

- Open the regulator tap on the gas bottle and the gas isolator tap "Refrigerator"
- Press and hold the On/Off button (Fig. 172,1) for 1 second. Button (Fig. 172,1) lights up green. To save energy, after approximately 10 seconds the display is dimmed.
- Press confirmation button (Fig. 172,3). The current setting of the operating is displayed.
- If the operating mode gas is not set: To change the setting, press and hold the confirmation button (Fig. 172,3) for approximately 2 seconds.
- Using the arrow keys (Fig. 172,2) select the operating mode gas. Gas supply is open. Ignition will take place automatically. A ticking sound can be heard until ignition has been completed successfully.
- Press and hold the confirmation button (Fig. 172,3) for about 2 seconds.
- Press confirmation button (Fig. 172,3) again. The current cooling level is shown by the illuminated bars (Fig. 172,5).
- To change the setting, press the arrow keys (Fig. 172,2) until the desired setting is displayed.

#### Switching off:

- Press and hold the On/Off button (Fig. 172,1) for about 2 seconds. All lights go out. Refrigerator is switched off.
- Close the gas isolator tap "Refrigerator" and the regulator tap on the gas bottle.

### **Electrical operation**



○ Close the gas isolator tap "Refrigerator" when the refrigerator is operated electrically.

The refrigerator can be operated with the following voltages:

- 230V AC
- 12 V DC

## Switching the 230 V operation on:

- Press and hold the On/Off button (Fig. 172,1) for 1 second. Button (Fig. 172,1) lights up green. To save energy, after approximately 10 seconds the display is dimmed.
- Press confirmation button (Fig. 172,3). The current setting of the operating is displayed.
- If 230 V operating mode is not set: To change the setting, press and hold the confirmation button (Fig. 172,3) for approximately 2 seconds.
- Using the arrow keys (Fig. 172,2) select the 230 V operating mode.
- Press and hold the confirmation button (Fig. 172,3) for about 2 seconds.
- Press confirmation button (Fig. 172,3) again. The current cooling level is shown by the illuminated bars (Fig. 172,5).
- To change the setting, press the arrow keys (Fig. 172,2) until the desired setting is displayed.



Switching the 230 V operation off:

■ Press and hold the On/Off button (Fig. 172,1) for about 2 seconds. All lights go out. Refrigerator is switched off.

## Switching the 12 V operation on:

- Press and hold the On/Off button (Fig. 172,1) for 1 second. Button (Fig. 172,1) lights up green. To save energy, after approximately 10 seconds the display is dimmed.
- Press confirmation button (Fig. 172,3). The current setting of the operating is displayed.
- If the 12 V operating mode is not set: To change the setting, press and hold the confirmation button (Fig. 172,3) for approximately 2 seconds.
- Using the arrow keys (Fig. 172,2) select the 12 V operating mode.
- Press and hold the confirmation button (Fig. 172,3) for about 2 seconds.
- Press confirmation button (Fig. 172,3) again. The current cooling level is shown by the illuminated bars (Fig. 172,5).
- To change the setting, press the arrow keys (Fig. 172,2) until the desired setting is displayed.

## Switching the 12 V operation off:

■ Press and hold the On/Off button (Fig. 172,1) for about 2 seconds. All lights go out. Refrigerator is switched off.

When operated with 12 V, the refrigerator draws power only from the starter battery of the vehicle. The starter battery only supplies the refrigerator with 12 V when the vehicle engine is running. If the vehicle engine is switched off, the cooling no longer operates. However the refrigerator continues to operate via the transformer/rectifier with a control voltage from the living room area battery. For this reason, change over to gas operation during prolonged driving breaks.



## 9.6.6 Refrigerator door locking mechanism

With some models, the refrigerator has a separate freezer compartment. The specifications in this section correspondingly also apply to the door of the freezer compartment.



During the journey the refrigerator door must always be closed and locked in the closed position.



▶ Lock the refrigerator door in ventilation position when the refrigerator is switched off. This prevents mould forming.


There are two positions for locking the refrigerator door in place:

- Closed refrigerator door during travel and when the refrigerator is in operation
- Slightly opened refrigerator door as a ventilation position when the refrigerator is switched off



#### **Dometic 8 series**








Fig. 174 Lock hook fixture

Opening:

Press the release button (Fig. 173,1) and open the refrigerator door.

Closing:

■ Close the refrigerator door. The lock hook engages audibly.

When the vehicle has been positioned, the lock hook can be fixed. The refrigerator door can now be opened without having to press the release button.

Fixing the lock hook:

■ Press the fixture (Fig. 174,1) upwards. The lock hook (Fig. 174,2) is pressed upwards and has no function.

Unlocking the lock hook:

■ Push the lock hook (Fig. 174,2) down. The lock hook functions again.




Fig. 175 Locking device in normal position




Fig. 176 Locking device in ventilation position

Locking in the ventilation position:


- Open the refrigerator door.
- Press down the unlocking device (Fig. 175,2).
- Push locking device (Fig. 175,1) forwards (Fig. 176).


If the refrigerator door is closed now, a gap will remain between the refrigerator door and the refrigerator.

## **Appliances**



### **Thetford**








Fig. 178 Refrigerator door in ventilation position (Thetford)

Opening:

■ Open the refrigerator door at the handle (Fig. 177,2). The lock (Fig. 177,1) is released automatically.

Closing:

■ Fully close the refrigerator door. Ensure that the lock is engaged.

Locking in the ventilation position:

■ Slightly open refrigerator door.

■ Open the lock (Fig. 178,2) and snap it into the locking catch (Fig. 178,1). The refrigerator door will then stay slightly open.



# **Chapter overview**

This chapter contains instructions regarding the sanitary fittings of the caravan.

The instructions address the following topics:

- water tank
- waste water tank
- complete water system
- toilet compartment
- toilet

# 10.1 Water supply, general



- ► Fill water tank from supply systems that have been verified to provide drinking water quality.
- Only use such hoses or containers when filling that have been approved for use with drinking water.
- ► Thoroughly rinse filling hose or container with drinking water before use (2 to 3 times capacity).
- ► Empty filling hose or container completely after use and close openings of the filling hose or container.
- Water left standing in the water tank or in the water pipes becomes undrinkable after a short period. Therefore, before each use of the vehicle, thoroughly clean the water pipes and the water tank. After each use of the vehicle completely empty the water tank and the water pipes.
- ▶ In the case of lay-ups lasting more than a week disinfect the water system before using the vehicle (see chapter 11).



- ▷ If the vehicle is not used for several days or if it is not heated when there is a risk of frost, empty the entire water system. Make sure that the 12 V power supply on the panel is switched off. Otherwise, the water pump will overheat and may get damaged. Leave the water taps on in central position. Leave the safety/drainage valve (if there is one) and all drain cocks open. Frost damage to appliances, frost damage to the vehicle and deposits in water-carrying components can be avoided in this way.
- ▷ The water pump will overheat without water and can get damaged. Never operate water pump when the water tank is empty.

The vehicle is equipped with a fitted water tank. An electric water pump pumps the water to the individual water taps. Opening a water tap automatically switches on the water pump and pumps water to the tap.

A canister or a waste water tank collects the waste water.



- ▷ Before using the water fittings: Connect the 230 V power supply and switch on the 230 V automatic circuit breaker, or connect the caravans electrics to the towing vehicle. Otherwise the water pump will not work. (This only applies to caravans that are not equipped with a separate battery.)
- When the water tank is re-filled, an air bubble may form at the bottom of the pump. This air bubble will prevent water from being drawn in. Shake the water pump up and down energetically in the water.



## 10.2 Water tank



▶ When filling the water tank, observe the maximum permissible gross weight of the vehicle. Luggage must be reduced accordingly when the water tank is full.

## 10.2.1 Water tank 16 I




Fig. 179 Water tank 16 I

When transporting the water tank, close it with the cap (Fig. 179,4).

Filling the water tank with drinking water:

- Pull the water pump (Fig. 179,2) out of the water tank (Fig. 179,1).
- Release the retaining strap (Fig. 179,3).
- Remove the water tank.
- Clean or disinfect water tank.
- Fill the water tank with drinking water.

Pouring water:

Open the water taps.

Emptying the water tank:

- Pull the water pump out of the water tank.
- Release the retaining strap.
- Remove the water tank and empty it.

# 10.2.2 Water tank 22 I with external flap (special equipment)

The water tank is mobile or portable.



Fig. 180 Water tank 22 I

When transporting the water tank, close it with the cap (Fig. 180,1).



Filling the water tank with drinking water:

- Close all water taps.
- Open service flap (Fig. 180,3) (see chapter 6).
- Pull the water pump out of the water tank.
- Pull out the water tank (Fig. 180,2).
- Clean or disinfect water tank.
- Fill the water tank with drinking water.

Pouring water:

Open the water taps.

Emptying the water tank:

- Close all water taps.
- Open service flap (Fig. 180,3) (see chapter 6).
- Pull the water pump out of the water tank.
- Pull out the water tank (Fig. 180,2) and empty it.

# 10.2.3 Water tank 40 I (partially special equipment)




Fig. 181 Drinking water filler neck

The drinking water filler neck is on the right or left side of the vehicle, depending on the model.

The drinking water filler neck is indicated by the symbol "" (Fig. 181,1). The cap is open and closed using the key for the external flap locks.

The water tank is built into the seating group.

Opening:

- Insert key into locking cylinder (Fig. 181,2) and turn a quarter turn in an anticlockwise direction.
- Remove cap.

Closing:

- Place cap on the drinking water filler neck.
- Turn key one quarter turn in a clockwise direction.
- Remove key.
- Check that the cap sits firmly on the drinking water filler neck.








Fig. 182 Water tank

Fig. 183 Stopper

Filling the water tank with drinking water:

- Open drinking water filler neck (Fig. 181) (see chapter 6).
- Clean or disinfect water tank.
- Fill the water tank with drinking water.

Pouring water:

Open the water taps.

Emptying the water tank:

- Close all water taps.
- Turn the handle (Fig. 182,1) on the water tank in an anticlockwise direction as far as it will go. The stopper (Fig. 183,1) at the bottom of the tank is lifted.
- Let the water drain out.
- Turn the handle (Fig. 182,1) on the water tank in a clockwise direction as far as it will go. The stopper at the bottom of the tank (Fig. 183,1) closes the drain.

# 10.3 Waste water tank (special equipment)



▶ Before commencing the journey, empty the waste water tank.



- ▷ If there is any risk of frost, empty the waste water tank.
- Never pour boiling water directly into the sink outlet. Boiling water could cause deformation and leaks in the waste water pipe system.



○ Only empty the waste water tank at disposal stations, camping sites or caravan sites especially provided for this purpose.






Fig. 184 Waste water tank, mobile

#### Emptying:

- Use the cap (Fig. 184,3) to close the opening of the waste water tank (Fig. 184,1).
- Use the handle (Fig. 184,2) to pull out the waste water tank.
- Fold the carrying handle (Fig. 184,4) up and upright the waste water tank.
- Completely empty the waste water tank at disposal stations that are especially provided for this purpose.


# 10.4 Filling the water system



When filling the water tank, observe the maximum permissible gross weight of the vehicle. Luggage must be reduced accordingly when the water tank is full.



➤ The water pump will overheat without water and can get damaged. Never operate water pump when the water tank is empty.








Fig. 186 Drain cock (with twist cap)

- Position the vehicle horizontally.
- Connect the 230 V power supply and switch on the 230 V automatic circuit breaker. If the vehicle is equipped with a self-sufficiency package with battery, it is not necessary to connect it to a 230 V power supply.
- Clean or disinfect water system.
- Close all water taps.
- Switch off the boiler.
- Close all drain cocks. To do this, position the drain cock's rocking lever (Fig. 185,1) horizontally or turn the drain cock's cap (Fig. 186,1) in a clockwise direction.



- Close the drainage opening of the water tank.
- Fill the water tank with drinking water. Use a water hose, a water canister with a funnel or similar for filling.
- Set all the water taps to "Hot" and open them. The water pump is turned on. The warm water pipes are filled with water.
- Keep the taps open until the water flowing out of the taps has no bubbles in it. This is the only way to ensure that the boiler is full of water.
- Set all water taps to "Cold" and leave them open. This will fill the cold water pipes with water.
- Keep the taps open until the water flowing out of the taps has no bubbles in it.
- Close all water taps.
- Check that the cap on the water tank is not leaking.

# 10.5 Emptying the water system



▷ If the vehicle is not used for several days or if it is not heated when there is a risk of frost, empty the entire water system. Make sure that the 12 V power supply on the panel is switched off. Otherwise, the water pump will overheat and may get damaged. Leave the water taps on in central position. Leave the safety/drainage valve (if there is one) and all drain cocks open. Frost damage to appliances, frost damage to the vehicle and deposits in water-carrying components can be avoided in this way.



➤ Take note of the environmental tip in this chapter.

To empty and ventilate the water system, proceed as follows. Frost damage and deposits are avoided in this way:

- Position the vehicle horizontally.
- Switch off the 230 V power supply on the 230 V automatic circuit breaker.
- Open all drain cocks. To do this turn the drain cock's cap in an anticlockwise direction or set the drain cock's rocking lever in a vertical position.
- Open the drainage opening of the water tank.
- Set water tap in kitchen and shower compartment (toilet compartment) in an exact central position (hot cold), and open.
- Hang the shower handset up in the shower position.
- Remove the cap of the water tank. Hold the water pump up until the water pipes are completely empty.
- Check whether the water tank is completely empty.
- Blow out the remaining water in the water pipes (max. 0.5 bar).
- Empty the waste water tank. Take note of the environmental tip in this chapter.
- Empty toilet cassette. Take note of the environmental tip in this chapter.
- After emptying, leave all water taps open in the central position.
- Leave all drain cocks open.



# 10.6 Toilet compartment



Do not transport any loads in the shower tray. The shower tray or other items of equipment in the toilet compartment can be damaged.



- ➢ For ventilation purposes during or after a shower, and for drying wet clothing, close the toilet compartment door and open the window or the toilet compartment skylight. This improves the air circulation.
- Close the shower curtain completely when showering, so that no water is able to enter the area between the wash room wall and the shower tray.
- After taking a shower, rinse soap residue from the shower tray, otherwise cracks can appear in the shower tray over time.
- ▶ After using the shower, wipe it dry to prevent moisture from collecting.
- > Further information about cleaning the toilet compartment can be found in the section 11.2.

#### 10.7 Toilet



- If there is any risk of frost and the vehicle is not heated, empty the sewage tank (cassette).
- Do not sit on the lid of the toilet. The lid is not designed to bear the weight of a person and could break.
- Use a suitable chemical for this toilet. The ventilation will merely remove the odour but not germs and gases. Germs and gases will have a detrimental effect on the sealing rubbers.



> Further information can be obtained in the manufacturer's instruction manual.



○ Only empty the sewage tank (cassette) at disposal stations, at camping sites or caravan sites, that are especially provided for this purpose.

Depending on the design, the toilet is flushed either directly via the vehicle's water system, or via a separate water tank.



# 10.7.1 Swivel toilet (Thetford C-200)



> The Thetford cassette can only be taken out if the sliding trap is closed.




Fig. 187 Pulling the retaining clip

## Preparing toilet:

Open the flap for the Thetford cassette and pull the retaining clip upwards to remove the Thetford cassette.




Fig. 188 Removing the Thetford cassette

- Pull out the Thetford cassette as far as it can go.
- Tip the Thetford cassette slightly and then pull it out completely.




Fig. 189 Turning drainage neck

- Place the Thetford cassette upright.
- Turn the drainage neck upwards.
- Remove the cap of the drainage neck.
- Never put the sanitary liquid directly in the toilet bowl.








Fig. 190 Filling with sanitary liquid

- Fill the Thetford cassette with the specified quantity of sanitary liquid.
- Then add enough water to completely cover the bottom of the Thetford cassette.
- Close drainage neck with the cap.
- Return the drainage neck to its original position.






Fig. 191 Inserting the Thetford cassette

■ Push the Thetford cassette back to its original position.




Fig. 192 Thetford cassette secured

- Ensure that the Thetford cassette is secured by the retaining clip.
- Lock the flap for the Thetford cassette.






Fig. 193 Rotating the toilet bowl

Using the toilet:

■ Move the toilet bowl into a convenient position.




Fig. 194 Pre-flush

- Fill the toilet bowl with some water. Press the flush button. Flushing continues as long as the button is pressed.
- Use the toilet.

#### C-200 S cassette

With the C-200 S cassette, proceed as follows to flush the toilet:




Fig. 195 Operating the sliding trap

■ Open the sliding trap. To do this, turn the slide lever in an anticlockwise direction.






Fig. 196 Operating the flush

- Flush the toilet. Press the flush button.
- After flushing close the sliding trap.

## C-200 E cassette

With the C-200 E cassette, proceed as follows to flush the toilet:




Fig. 197 Opening the sliding trap

Open the sliding trap. To do this, press the left side of the sliding trap button.




Fig. 198 Closing the sliding trap

- Flush the toilet. Press the flush button.
- After flushing close the sliding trap. To do this, press the right side of the sliding trap button.



> The Thetford cassette can only be taken out if the sliding trap is closed.






Fig. 199 Removing the Thetford cassette

# Emptying the Thetford cassette:

- Open the flap for the Thetford cassette and pull the retaining clip upwards to remove the Thetford cassette.
- Pull out the Thetford cassette as far as it can go.
- Tip the Thetford cassette slightly and then pull it out completely.




Fig. 200 Carrying the Thetford cassette

■ Take the Thetford cassette to a proper disposal area. As you do this, point the drainage neck upwards.




Fig. 201 Emptying the Thetford cassette

- Turn the drainage neck upwards.
- Remove the cap of the drainage neck.
- Point the Thetford cassette with the drainage neck downwards.
- Activate the aeration knob with your thumb. The Thetford cassette empties.
- Rinse the Thetford cassette thoroughly with fresh water.
- Close drainage neck with the cap.
- Return the drainage neck to its original position.






Fig. 202 Inserting the Thetford cassette

- Prepare the Thetford toilet for use.
- Push the Thetford cassette back to its original position.
- Ensure that the Thetford cassette is secured by the retaining clip.
- Lock the flap for the Thetford cassette.

# 10.7.2 Toilet with fixed seat (Thetford C-402)

The Thetford toilet of some models is equipped with its own water tank.




Fig. 203 Fresh water filler neck, swung out

Filling the water tank:

- Open the flap for the Thetford cassette.
- Swing the fresh water filler neck towards the outside.




Fig. 204 Filling with fresh water

- Remove the screw cap.
- Fill with fresh water until the fluid level reaches the top edge. This corresponds to approx. 15 l.






Fig. 205 Fresh water filler neck, swung

- Close the screw cap.
- Swivel the fresh water filler neck inwards.



> The Thetford cassette can only be taken out if the sliding trap is closed.




Fig. 206 Pulling the retaining clip

# Preparing toilet:

 Open the flap for the Thetford cassette and pull the retaining clip upwards to remove the Thetford cassette.




Fig. 207 Removing the Thetford cassette

- Pull out the Thetford cassette as far as it can go.
- Tip the Thetford cassette slightly and then pull it out completely.






Fig. 208 Turning drainage neck

- Place the Thetford cassette upright.
- Turn the drainage neck upwards.
- Remove the cap of the drainage neck.



▷ Never put the sanitary liquid directly in the toilet bowl.




Fig. 209 Filling with sanitary liquid

- Fill the Thetford cassette with the specified quantity of sanitary liquid.
- Then add enough water to completely cover the bottom of the Thetford cassette.
- Close drainage neck with the cap.
- Return the drainage neck to its original position.



> When inserting, do not use force. The Thetford cassette can be damaged.






Fig. 210 Inserting the Thetford cassette

■ Push the Thetford cassette back to its original position.




Fig. 211 Thetford cassette secured

- Ensure that the Thetford cassette is secured by the retaining clip.
- Lock the flap for the Thetford cassette.




Fig. 212 Pre-flush

Using the toilet:

- Fill the toilet bowl with some water. Press the flush button. Flushing continues as long as the button is pressed.
- Use the toilet.






Fig. 213 Operating the sliding trap

■ Open the sliding trap. To do this, turn the slide lever in an anticlockwise direction.




Fig. 214 Operating the flush

- Flush the toilet. Press the flush button.
- After flushing close the sliding trap again. To do this turn the slide lever in a clockwise direction.






Fig. 215 Removing the Thetford cassette

Emptying the Thetford cassette:

- Open the flap for the Thetford cassette and pull the retaining clip upwards to remove the Thetford cassette.
- Pull out the Thetford cassette as far as it can go.
- Tip the Thetford cassette slightly and then pull it out completely.





Fig. 216 Transporting the Thetford cassette

- Place the Thetford cassette upright on the wheels.
- Press down the handle of the draw bar and move away from the Thetford cassette. The lock of the draw bar releases itself.
- Pull the draw bar out completely by the handle.
- Take the Thetford cassette to a proper disposal area.
- Insert the draw bar completely using the handle.




Fig. 217 Emptying the Thetford cassette

- Turn the drainage neck upwards.
- Remove the cap of the drainage neck.
- Point the Thetford cassette with the drainage neck downwards.
- Activate the aeration knob with your thumb. The Thetford cassette empties.
- Rinse the Thetford cassette thoroughly with fresh water.
- Close drainage neck with the cap.
- Return the drainage neck to its original position.






Fig. 218 Inserting the Thetford cassette

- Prepare the Thetford toilet for use.
- Push the Thetford cassette back to its original position.
- Ensure that the Thetford cassette is secured by the retaining clip.
- Lock the flap for the Thetford cassette.




Fig. 219 Emptying the water tank

# Emptying the water tank:

- Open the sliding trap. To do this, turn the slide lever in an anticlockwise direction.
- Press the flush button until water ceases to flow into the bowl.
- Close the sliding trap. To do this turn the slide lever in a clockwise direction.




Fig. 220 Emptying the fresh water filler neck

- Open the flap for the Thetford cassette.
- Swing the fresh water filler neck towards the outside.
- Remove the screw cap from the fresh water filler neck.
- Turn the fresh water filler neck in an anticlockwise direction until the residual water flows out.
- Turn the fresh water filler neck back in a clockwise direction.



# Sanitary fittings



- Screw the screw cap onto the fresh water filler neck.
- Swivel the fresh water filler neck inwards.
- Empty Thetford cassette.



# **Chapter overview**

This chapter contains instructions regarding the care of the vehicle.

The instructions address the following topics:

- exterior of the vehicle
- interior
- water system
- extractor hood
- air conditioning unit
- winter operation

At the end of the chapter there is a checklist of measures you must carry out if you are not going to use the vehicle for an extended period of time.

The checklist address the following topics:

- temporary lay-up
- winter lay-up
- start-up after a lay-up

# 11.1 External care

#### 11.1.1 General

Standard external care consists of regular washing. The use and the environmental conditions will determine how often the vehicle needs to be washed. Wash the vehicle more frequently in areas which are exposed to heavy air pollution or heavy traffic or roads treated with de-icing salts. If the vehicle is exposed to salty and humid air (coastal areas, humid climates), wash the vehicle more frequently.

Do not park under trees if at all possible. The resin-like discharge which many trees secrete, give the paintwork a matt look and can promote the onset of corrosion.

Wash off bird droppings straight away and thoroughly, as the acid it contains is extremely corrosive.

# 11.1.2 Washing with a high-pressure cleaner



- Do not clean the tyres with a high-pressure cleaner. The tyres might be damaged.
- Do not spray external applications (deco-films) directly with the high-pressure cleaner. The external applications could come off.

Before cleaning the vehicle with a high-pressure cleaner, observe the operating instructions of the high-pressure cleaner.

When cleaning with the nozzle for circular jet between the vehicle and the cleaning nozzle, maintain a minimum distance of approx. 700 mm.

Take into consideration that the jet of water comes out of the cleaning nozzle with pressure. The vehicle may be damaged by incorrect handling of the high-pressure cleaner. The temperature of the water should not be above 60 °C. Keep the jet of water in constant movement during the washing process. Do not direct the water jet at clearances, built-in electrical parts, plugs, seals, the ventilation grill or the skylights. The vehicle may be damaged or water may enter the interior.



# 11.1.3 Washing the vehicle



- Never clean the vehicle in the car wash. Water can enter the refrigerator grills, the waste gas vents, the ventilation of the extractor hoods or the forced ventilations. The vehicle could be damaged.
- Wash the vehicle only on a washing site intended for this purpose. Avoid full sunshine. Observe environmental measures.
- Only clean external applications and synthetic parts with plenty of warm water, dish washing liquid and soft cloth.
- Wash down the vehicle with plenty of water, a clean sponge or a soft brush. In the case of stubborn dirt add dish washing liquid to the water.
- Painted exterior walls may also be cleaned with a caravan cleaner.
- Add-on parts made of glass-fibre reinforced plastic (GRP) require a regular follow-up treatment with a polisher. This way these parts will not turn yellow and the sealing of the surface remains intact.
- Treat rubber seals of doors and storage flaps with talc.
- Treat locking cylinder of doors and storage flaps with graphite dust.

# 11.1.4 Windows of acrylic glass

Acrylic glass windows are delicate and require very careful handling.



- Never rub acrylic glass windows dry as dust particles might damage the surface!
- Only clean acrylic glass windows with plenty of warm water, some dish washing liquid and a soft cloth.
- Never use glass cleaning agents with chemical, abrasive or alcohol-containing additives. Premature brittleness of the panes and associated cracks may result from their use.
- Avoid contact of cleansing agents used for the body (e.g. tar- or siliconeremoving agents) with acrylic glass.
- > Do not clean vehicle in car wash.
- Do not attach stickers to the acrylic glass windows.
- > Apply talcum powder to rubber seals.



➢ An acrylic glass cleanser with antistatic effect is suitable for a follow-up treatment. Small scratches can be treated with an acrylic glass polish. These agents are available at the accessories shop.

# 11.1.5 Hot galvanized chassis

Salt deposits damage the hot galvanized chassis and can cause white rust. But so-called white rust represent no defects. It is only a visual damage.

The most frequent causes for white rust are:

- Abrasives and de-icing salts (e.g. when driving during winter months)
- Condensation (e.g. by covering the vehicle with plastic foils or awning)
- Humidity (e.g. by parking the vehicle in high grass, in puddles or sludge)
- Cleaning agents (e.g. by cleaning with aggressive cleaning agents)



- Snow (e.g. by standing too long in snow)
- Defective ventilation (e.g. by covering with aprons in the floor area)

To avoid formation of white rust or to remove any existing white rust, we recommend the following method:

- After driving in winter, rinse out the hot galvanized surfaces with clean water
- If hot galvanized parts are affected by white rust, clean with a zinc cleaner (e.g. Poligrat).

# 11.1.6 Underbody

The underbody of the vehicle is partly coated with an age-resistant underbody protection. Should the underbody protection be damaged, repair immediately. Do not treat areas coated with underbody protection with spray oil.



○ Only use products approved by the manufacturer. Our authorised dealers and service centres will be happy to advise you.

#### 11.1.7 Waste water tank

Clean the waste water tank after every use of the vehicle.

Cleaning:

- Empty the waste water tank.
- Open the cleaning opening on the waste water tank.
- Thoroughly rinse out the waste water tank with fresh water.

# 11.2 Interior care



- ▷ If possible, treat stains immediately.
- Synthetic parts in the toilet and living area are very delicate and should be treated with care. Do not use solvents, alcohol-containing cleansers or scourers. This procedure will help you to avoid brittleness and formation of cracks.
- Do not pour any corrosive agents into the drain holes. Never pour boiling water directly into the drain holes. Corrosive agents and boiling water cause damage to drainage pipes and siphon traps.
- Do not use vinegar based products to clean the toilet and water system, or for decalcification of the water system. Vinegar-based products may cause damage to seals or parts of the installation. Use standard decalcifying products for decalcification.
- > Save water. Mop up all remaining water.
- > Vacuum off carpets and cushions with a suitable brush attachment.





- For information about the use of maintenance products, our representatives and service centres will be glad to advise.
- Surface and knobs of furniture, lamps and synthetic parts in the toilet and living area should be cleaned with water and a wool cloth. A mild cleanser may be added to the water. If required, use furniture polish for the painted surfaces.
- Clean upholstery with dry foam specially manufactured for the use on upholstery or with the foam of a mild detergent. Do not wash upholstery. Always have it cleaned. Protect upholstery from direct sunlight so that it does not loose its colour.
- Clean upholstery made of novalife<sup>®</sup> with clear water only.
- Leather covers should be cleaned with a cotton cloth and a mild soap (curd soap). Make sure that the leather is not soaked through and that no water seeps through the seams of the leather covers.
- Curtains and net curtains should be dry cleaned.
- Vacuum clean the carpet, if necessary clean with carpet shampoo.
- Clean PVC-floor covering with a mild, soapy cleanser for PVC floors. Do not place carpet on wet PVC-floor covering. The carpet and the PVC-floor covering may stick together.
- Never clean the sink or the gas cooker with a scourer. Avoid anything which may cause scratching or grooves.
- Clean the burners on the gas cooker using a damp cloth only. Prevent any water from penetrating the burner covers. Water may damage the burners on the gas cooker.
- Brush insect screens on doors, windows and skylights with a soft brush or vacuum with the brush attachment of the vacuum cleaner.
- Brush blinds with a soft brush or vacuum with the brush attachment of the vacuum cleaner. Grease or stubborn dirt may be removed with a mild soap at 30 °C (curd soap).
- Brush Roman shades with a soft brush or vacuum with the brush attachment of the vacuum cleaner. Grease or stubborn dirt may be removed with a mild soap at 30 °C (curd soap).

# 11.3 Water system

# 11.3.1 Cleaning the water tank

- Empty the water tank and close the drainage opening.
- Remove the cap of the water tank.
- Fill water tank with water and some washing-up liquid (do not use any scourers).
- Using a trade standard brush for washing dishes, scrub the water tank until there is no longer any visible deposit.
- Scrub also the pump housing.
- If possible, clean fresh water sensors through the cleaning openings by hand.
- Rinse water tank with copious amounts of drinking water.



# 11.3.2 Cleaning the water pipes



- Only use suitable cleaning agents as sold by the specialist trade.
- ➤ The cleaning agent must meet national regulations and be approved (if required).



- Collect any emerging mixture of water and cleaning agent for correct disposal.
- Empty the water system.
- Close all drain holes and drain cocks.
- Fill mixture of water and cleaning agent into the water tank. Observe the manufacturer's instructions regarding the mixing ratio.
- Open the drain cocks one by one.
- Leave the drain cocks open until the mixture of water and cleaning agent has reached the respective drain.
- Close the drain cocks.
- Set all the water taps to "Hot" and open them.
- Leave the water taps open until the mixture of water and cleaning agent has reached the drain.
- Set all water taps to "Cold" and open them.
- Leave the water taps open until the mixture of water and cleaning agent has reached the drain.
- Close all water taps.
- Flush the toilet several times.
- Allow the cleaning agent to act in accordance with the manufacturer's instructions.
- Empty the water system. Collect the mixture of water and cleaning agent for correct disposal.
- For rinsing fill the entire water system with drinking water and empty again several times over.

## 11.3.3 Disinfecting the water system



- ▷ Only use suitable disinfectants as sold by the specialist trade.
- ➤ The disinfectant must meet national regulations and be approved (if required).



- Collect any emerging mixture of water and disinfectant for correct disposal.
- Empty the water system.
- Close all drain holes and drain cocks.
- Fill mixture of water and disinfectant into the water tank. Observe the manufacturer's instructions regarding the mixing ratio.
- Open the drain cocks one by one.
- Leave the drain cocks open until the mixture of water and disinfectant has reached the respective drain.



- Close the drain cocks.
- Set all the water taps to "Hot" and open them.
- Leave the water taps open until the mixture of water and disinfectant has reached the drain.
- Set all water taps to "Cold" and open them.
- Leave the water taps open until the mixture of water and disinfectant has reached the drain.
- Close all water taps.
- Flush the toilet several times.
- Allow the disinfectant to act in accordance with the manufacturer's instructions.
- Empty the water system. Collect the mixture of water and disinfectant for correct disposal.
- For rinsing fill the entire water system with drinking water and empty again several times over.

## 11.4 Extractor hood

Clean the extractor hood filter occasionally. How often cleaning is necessary depends on how often the extractor hood is used. Do not wait to clean the filter until the performance of the extractor hood has noticeably decreased.

Cleaning the filter:

■ Wash the filter with warm water and some washing-up liquid.

# 11.5 Air conditioning unit

#### 11.5.1 **Dometic**



Fig. 221 Air conditioning unit (Dometic)

A lint filter and an activated carbon filter are each located in the lower part of the air conditioning system ceiling unit (Fig. 221,2) behind the ventilation grills (Fig. 221,1 and 3). The lint filters must be cleaned at regular intervals and replaced if necessary. The manufacturer recommends replacing the activated carbon filter yearly.

On the left side of the ceiling unit (outside of the vehicle) is located the drainage opening for the condensation. Keep the drain openings free from dirt, leaves or similar to allow the condensation to be drained.



#### 11.5.2 Telair

Every now and then clean the filter and the ventilation grilles on the outside of the housing. How often cleaning is necessary depends on how often the air conditioning unit is used. Do not wait to clean the filter and the ventilation grill until the performance of the air conditioning unit has noticeably decreased.



Only use mild cleaning solutions to clean the filter, never use benzene or solvents.

Cleaning the filter:

- Wash the filter with warm water and some washing-up liquid.
- Allow the filter to dry thoroughly before reassembly.

Cleaning the ventilation grill:

Use a brush to remove coarse dirt or deposits from the external ventilation grilles. If a cleaning solution is used, ensure that no water ingresses into the inside of the housing.

## 11.5.3 Truma



Fig. 222 Air conditioning unit (Truma)

A lint filter (Fig. 222,1) for the air circulation suction system is at the front of the air conditioning unit. The lint filter must be cleaned at regular intervals, at least twice a year however, and replaced if necessary.

The condensation drain is under the floor of the vehicle. Keep the drain hose free from dirt, leaves or similar to allow the condensation to be drained.



## 11.6 Winter care

De-icing salt damages the underbody and the parts open to water spray. We recommend that you wash the vehicle more frequently during wintertime. Mechanical and surface treated parts and the underside are under particular strain, and should therefore be cleaned thoroughly.



- ▷ If there is any risk of frost, always run heater at a minimum of 15 °C. Switch the circulation fan (if there is one) to automatic. In the case of extreme external temperatures, the furniture flaps and doors should be left slightly open. The inflowing warm air can help prevent the freezing of water pipes, for example, and counteract the formation of condensation in the storage spaces.
- ▶ If there is any risk of frost, cover the outside surface of the windows with winter insulation mats.

# 11.6.1 Preparations

- Check the vehicle for paint and rust damage. Repair damage as necessary.
- Make certain that water cannot penetrate the automatic floor ventilation system and the heater.
- Use a wax-based rust inhibitor to protect the metal parts of the underbody.
- Use appropriate protection for external painted surfaces.

# 11.6.2 Winter operation

During winter operation, condensation develops when the vehicle is occupied under low-temperature conditions. To ensure good interior air quality and avoid vehicle damage from condensation, sufficient ventilation is essential.

- Attach vent extension with a length of at least 10 cm.
- When heating the vehicle, the heater should be at the highest setting and roof storage cabinets, curtains and blinds should be opened. This ensures optimal ventilation.
- If the vehicle is equipped with a circulation fan, always switch the fan on when the heater is on. Otherwise, there is a danger of overheating for the heater!
- In the morning, lift up all cushions, air out storage boxes and dry any damp areas.



- ▷ If condensation has still developed, just wipe it off.
- ▶ It is only possible to guarantee unrestricted operation during winter in connection with the "winter package" from the original equipment.



#### 11.6.3 At the end of the winter season

- Thoroughly clean the underbody. When this is done, corrosion-inducing anti-freeze agents (salts, alkaline residues) are removed.
- Clean the exterior and use regular car wax to protect metal surfaces.
- Remove vent extension.

# 11.7 Lay-up

# 11.7.1 Temporary lay-up



- ▶ If the vehicle has been stationary for a long period (approx. 10 months) have the braking and gas systems checked by an authorised specialist workshop.
- ▶ Take into consideration that water is undrinkable after only a short time.

Before laying up the vehicle, go through the following checklist:

#### Chassis

Activities	Done	
Lubricate the moving parts of the caravan coupling		
▶ Do not lubricate the friction pads on the stabiliser!		
Jack up caravan with suitable support so that the wheels do not bear any load, or move caravan every four weeks. This prevents pressure points on the tyres and wheel bearings		
Never use the fitted corner steadies as a car jack but only external support.		
Protect the tyres from direct exposure to the sun. Danger of formation of cracks!		
Inflate tyres up to the recommended maximum pressure		
Always provide for sufficient ventilation in the underbody area		
Humidity or lack of oxygen e.g. by covering with plastic film may cause optical irregularities to the underbody.		

# **Body**

All vents should be sealed with the appropriate caps and all other openings (apart from forced ventilations) should also be sealed. This prevents animals (e.g. mice) from gaining entry

Air the interior, all storage compartments accessible from the outside, and the parking space (e.g. garage) every 3 weeks in order to prevent the occurrence of condensation and resulting mould formation

#### Interior

Place upholstery in an upright position for ventilation, and cover	
Clean refrigerator	
Allow refrigerator and freezer compartment doors to remain slightly open	/
Disconnect the flat screen from the mains and, if necessary, removit from the vehicle	/e



## Gas system

Activities	Done
Close regulator tap on the gas bottle	
Close all gas isolator taps	
Always remove gas bottles from the gas bottle compartment, even if they are empty	

#### **Electrical system**

Spray the contacts on the thirteen-pin connector with contact spray

Fully charge the living area battery (if there is one)

Charge the battery for at least 20 hours before laying up.

Disconnect the living area battery from the 12 V power supply

#### Water system

Empty the entire water system. Blow out the residual water from the water pipes (0.5 bar max.). Leave the water taps on in central position. Leave the safety/drainage valve (if there is one) and all drain cocks open. Observe the notes in chapter 10

# 11.7.2 Winter lay-up

Additional measures are required if laying up the vehicle over winter:

#### Chassis

Activities	Done
Clean body and underbody thoroughly and spray with hot wax or protect with varnish	
Rectify damage to the paintwork	

#### **Body**

Clean vehicle from outside thoroughly	
Keep the forced ventilation open	
Clean and grease installed supports	
Clean and grease all door and flap hinges	
Brush oil or glycerine on all locking mechanisms	
Rub all rubber seals with talc	
Use graphite dust to treat locking cylinders	

#### Interior

Position de-humidifiers	
Remove upholstery from the vehicle and store in a dry place	
Air the interior every 3 weeks	
Empty all cabinets and storage compartments, open flaps, doors and drawers	
Thoroughly clean the interior	
If there is a risk of frost, do not leave the flat screen in the vehicle	

## **Electrical system**

Remove living area battery (if there is one) and store in a place protected from frost (see chapter 8)

## Water system

Clean the water system using a cleaning agent from a specialised store



# Complete vehicle

Activities	Done
Clean the awning area and store in a dry place	
Arrange the tarpaulins in such a way that the ventilation openings are not covered, or use porous tarpaulins	

# 11.7.3 Starting up the vehicle after a temporary lay-up or after layup over winter

Go through the following checklist before start-up:

#### Chassis

Activities	Done
Check the tyre pressure on all tyres	
Check the tyre pressure of the spare wheel	

## **Body**

Check the functioning of the fitted supports	
Check that the windows and skylights are working properly	
Check that all the external locks are working, such as the external flaps, the filler neck and the conversion door	
Remove the cover from the waste gas vent of the heater (if there is one)	
Remove the winter cover from the refrigerator grills (if there is one)	

# Gas system

Put the gas bottles in the gas bottle compartment, tie down and connect to the gas pressure regulator

#### **Electrical system**

Connect to 230 V power supply using the external socket

Fully charge the living area battery (if there is one)

Charge the battery for at least 20 hours after lay-up.

Connect the living area battery (if there is one) with the 12 V power supply (see chapter 8)

Check that the electrical system are working, e.g. interior light, socket and all installed electrical appliances

# Water system

Disinfect water pipes and water tank	
Close all drain cocks and water taps	
Check the water taps, drain cocks and water distributors for leaks	

# **Appliances**

Check the function of the appliances





# **Chapter overview**

This chapter contains instructions about inspection and maintenance work concerning the vehicle.

The maintenance instructions address the following topics:

- caravan couplings
- manoeuvring system
- braking system
- doors
- replacing light bulbs
- spare parts

At the end of the chapter you will find important instructions on how to obtain spare parts.

# 12.1 Inspection work

Like any technical appliance, the vehicle must be inspected at regular intervals.

This inspection work must be carried out by qualified personnel.

Special technical knowledge, which cannot be taught within the framework of this instruction manual, is required for these tasks. Personnel possessing this technical knowledge are available for assistance at all service centres. Their experience and regular technical instruction by the factory as well as equipment and tools guarantee expert and up-to-date inspection of the vehicle.

Have the "First Programmed Inspection" carried out at a service centre 12 months after initial registration.

Further inspections should be carried out once a year.

The service centre in charge will confirm the work performed.



- Observe the inspections indicated by the manufacturer and have them carried out at the specified intervals. The value of the vehicle is thus preserved.
- The confirmation of the inspection work carried out serves as valid proof in the event of damage and guarantee claims.

#### 12.2 Maintenance work

As with every machine, this vehicle requires maintenance. The extent and frequency of the maintenance work required depend on conditions of operation and use. More difficult operating conditions make it necessary to service the vehicle more often.

Have the appliances serviced at the intervals specified in the corresponding instruction manuals.




## 12.3 Stabilisers

## **12.3.1** General

Clean the stabiliser and the coupling head regularly. Use either thinners or white spirit. When lubricating the stabiliser ensure that no lubricant is on the friction pads.

#### 12.3.2 AKS 1300






Fig. 223 Friction control

Fig. 224 Friction control

# Checking the stabilising device (on the side of the friction pads)

Prerequisite: AKS 1300 connected, ball diameter 50 mm

- Turn the handwheel (Fig. 223,1), until it can be heard and felt that the torque limiting mechanism grates. Direction of rotation: In a clockwise direction.
- Check distance a:
  - Distance a > 0 (Fig. 223): Wear within the permissible range.
  - Distance a = 0 (Fig. 224): Check and, if necessary, replace the friction pads.



#### 12.3.3 AKS 3004



Fig. 225 Display friction pads, front and back




Fig. 226 Display friction pads, left and right



#### Stabilising device: Checking the friction pads

Prerequisite: AKS 3004 connected, ball diameter 50 mm

- Open the stabilising handle (Fig. 225,1).
- Close the stabilising handle until a resistance can be felt (the friction pads lie on the ball, they have not been tightened yet).

# Friction pads, front and

The check is made using the indicator in front of the coupling handle (Fig. 225,2).

- If the green marking is visible, the friction pads and the coupling head are okay.
- If the red marking is visible, the friction pads or the coupling head are worn out (< 49 mm). Replace the friction pads or the coupling head.

#### Side friction pads

The check is made using the indicator on the pressure pad.

- If the arrows on the pressure pad (Fig. 226,2) point to or below the green marking (Fig. 226,3), the friction pads are brand new.
- If the arrows on the pressure pad point to within the marked areas (Fig. 226,1 and 3), then the friction pads are slightly worn.
- If the arrows on the friction pad point to or above the red marking (Fig. 226,1), the friction pads are worn out. Replace the friction pads.



# 12.4 Manoeuvring system



▶ When lubricating, ensure that no oil comes into contact with the drive rollers or tyres.

Following each use, remove coarse dirt from the drive elements.

Once a year (e.g. before laying up over winter) thoroughly clean and dry the manoeuvring system and lightly grease the guides of the drive elements.

To ensure that oil is distributed throughout the drive shafts, swing the drive rollers a few times onto the tyres and back again.

# 12.5 Braking system

Have maintenance work on the braking system carried out by a specialist workshop.

Look up the following table for the inspection deadlines.

First inspection	Braking system	Brake lining
After 1,500 km or after 6 months	Every 10,000 or 15,000 km or every 12 months	Every 5,000 km or every 12 months



## 12.6 Doors

To maintain gliding capability between springs and hinges, grease the conversion door hinges occasionally.



# 12.7 Replacing bulbs, external



- ▶ Bulbs and light fittings can be extremely hot. Therefore, allow lights to cool down before changing bulbs.
- ▶ Store bulbs in a safe place inaccessible to children.
- ▶ Do not use any bulb that has been dropped or which shows scratches in its glass. The bulb might burst.



- A new bulb should not be touched with the fingers. Use a cloth when installing the new bulb.
- Use only bulbs of the same type and with the correct wattage (see table "Types of bulbs for exterior lighting").
- ▷ If LEDs in lights are defect, contact an authorised dealer or service centre.

# Types of bulbs

Different types of bulbs are used in the vehicle. Below, we have described how to change the different types of bulbs.




Fig. 227 Types of bulbs

Pos. in Fig. 227	Fixture type/bulb type	Changing
1 Plug-in fixture	To remove, pull out the bulb	
		To mount, push the bulb into the socket with gentle pressure
2	2 Bayonet socket	To remove, press the bulb down and turn in an anticlockwise direction
		To insert, place the bulb in the socket and turn in a clockwise direction
3	Cylindrical bulbs	To remove and to insert, carefully bend the contacts of the lamp holder outwards
4	Halogen bulb	To remove, release retaining springs
		After inserting, hook the retaining springs again

#### Front lights 12.7.1




Fig. 228 Front lights

1 Front light

The front lights (Fig. 228,1) have LEDs. To change the LEDs, contact an authorised dealer or a service centre.

#### 12.7.2 **Rear lights**




Fig. 229 Rear lights

- Rear light Brake light
- 2 3 4
- Direction indicator Reverse light (Averso) Fog tail light
- Licence plate light
- Brake light

- Undo five housing screws.
- Remove housing.
- Remove bulb.
- Put in a new bulb.
- Reassemble the lamp in the reverse order.



○ Only replace the third brake light (Fig. 229,7) entirely.

#### 12.7.3 Side lights




Fig. 230 Side lights

- Side marker light
- Marker light



### **Marker lights**

The marker lights (Fig. 230,2) have LEDs. To change the LEDs, contact an authorised dealer or a service centre.

### Side marker light

The side marker light (Fig. 230,1) is fixed at the top of the side wall area.

- Remove housing.
- Remove bulb.
- Put in a new bulb.
- Reassemble the lamp in the reverse order.

### 12.8 Types of bulbs for exterior lighting

Front

Item no.	Exterior lighting	Type of bulb
1	Front light	LED

### Rear

1	Rear light	Ba15s 12 V 5 W
2	Brake light	Ba15s 12 V 21 W
3	Direction indicator	Ba15s 12 V 21 W orange
4	Reverse light	Ba15s 12 V 21 W
5	Fog tail light	Ba15s 12 V 21 W
6	Licence plate light	Soffitte 12 V 5 W
7	Third brake light	T5 12 V 2.3 W

Side

1	Side marker light	Ba15s 12 V 5 W
2	Marker light	LED

## 12.9 Replacing bulbs, internal



- ▶ Bulbs and light fittings can be extremely hot. Therefore, allow lights to cool down before changing bulbs.
- ► Shut off the power supply on the safety cut-out in the 230 V fuse box before changing bulbs.
- Store bulbs in a safe place inaccessible to children.
- ▶ Do not use any bulb that has been dropped or which shows scratches in its glass. The bulb might burst.
- ▶ Lights can get very hot. When the light is switched on, there must always be a safety distance of 30 cm between light and flammable objects. Fire hazard!
- ▶ Do not replace the LEDs in lamps with standard light bulbs. Risk of fire due to intense heat build up.



- A new bulb should not be touched with the fingers. Use a cloth when installing the new bulb.
- > Only use bulbs of the same type and with the correct wattage.
- $\, \triangleright \,$  If LEDs in lights are defect, contact an authorised dealer or service centre.



## 12.9.1 Ceiling lamp (cover with clips)



Fig. 231 Ceiling lamp

### Bulb 220 V/100 W/E 27

- Carefully release the retaining clips (Fig. 231,1) on the ceiling lamp and take off the glass cover (Fig. 231,2).
- Remove the bulb from the holder.
- Insert the new bulb and turn it in a clockwise direction until you feel a slight resistance.
- Re-fasten the glass cover with the retaining clips.



## 12.9.2 Recessed halogen light




Fig. 232 Recessed halogen light

Halogen bulb 12 V/10 W

The recessed halogen light (Fig. 232,1) is installed flush with the panel.

### Changing bulbs:

- Use a suitable tool (e.g. a screwdriver) to lever out and remove the cover (Fig. 232,2).
- Remove halogen bulb.
- Put in a new halogen bulb.
- Reassemble the lamp in the reverse order.

### 12.9.3 Recessed halogen light (flat)




Fig. 233 Recessed halogen light (flat)

Halogen bulb G4 12 V/10 W

The recessed halogen light (Fig. 233,2) is installed flush with the panel.

- Use a suitable tool (e.g. a screwdriver) to lever out the internal cover ring with glass disk (Fig. 233,1) from the housing.
- Remove halogen bulb.
- Put in a new halogen bulb.
- Reassemble the lamp in the reverse order.



## 12.9.4 Recessed light with LED






Fig. 234 Recessed light

Fig. 235 Recessed light (alternative)



Changing bulbs:

■ Contact a dealer or service centre.

### 12.9.5 Ceiling lamp




Fig. 236 Ceiling lamp

The ceiling lamp has LEDs.

- Press the two ends (Fig. 236,2) of the spring ring (Fig. 236,1) together and remove.
- Remove the housing (Fig. 236,3) with LED from the lamp.
- Pull out the plug and fully replace the housing with LED.
- Reassemble the lamp in the reverse order.



### 12.9.6 Spotlight with flexible arm




Fig. 237 Spotlight with flexible arm



Changing bulbs:

■ Contact a dealer or service centre.

### 12.9.7 Halogen spotlight (swivelling)



Fig. 238 Halogen spotlight (swivelling)

Halogen bulb 12 V/10 W

- Turn outer ring (Fig. 238,2) in an anticlockwise direction until it separates from the housing.
- Remove retaining ring (Fig. 238,1).
- Remove halogen bulb.
- Put in a new halogen bulb.
- Reassemble the lamp in the reverse order.



### 12.9.8 Halogen spotlight (movable)




Fig. 239 Halogen spotlight (movable)

### Halogen bulb 12 V/10 W

Changing bulbs:

- Loosen the fixing screw (Fig. 239,1).
- Remove the lamp shade (Fig. 239,2).
- Remove halogen bulb.
- Put in a new halogen bulb.
- Reassemble the lamp in the reverse order.

### 12.9.9 Halogen spotlight (movable)




Fig. 240 Halogen spotlight (movable)




Fig. 241 Suction cup for replacing the lamp

### Halogen bulb 12 V/10 W

Changing bulbs:

- Turn the halogen spotlight (Fig. 240,1) by 90° and remove from rail.
- Turn the lamp shade (Fig. 240,3) in an anticlockwise direction.
- Withdraw lamp shade complete with halogen bulb (Fig. 240,4) carefully from the holder (Fig. 240,2).
- Remove halogen bulb.
- Screw lamp shade onto holder.
- Insert new halogen spot light into the lamp shade and press into holder.
- Insert halogen lamp into the rail.



A suction cup (Fig. 241,1) is included to help with changing the lamp.



### **12.9.10** Cooker lamp




Fig. 242 Cooker lamp

### Halogen bulb 12 V/5 W

### Changing bulbs:

- Squeeze cover (Fig. 242,2) lightly with both hands and pull downwards. Always start pulling at the very left or right end.
- Remove halogen bulb (Fig. 242,1).
- Put in a new halogen bulb.
- Reassemble the lamp in the reverse order.

### 12.9.11 Garage light




Fig. 243 Garage light

### Halogen bulb 12 V/16 W

- Carefully push the transparent cover (Fig. 243,1) together from both sides, pull it lightly from the switch and pull it off forwards.
- Remove halogen bulb.
- Put in a new halogen bulb.
- Reassemble the lamp in the reverse order.



### 12.10 Spare parts



- ► Every alteration of the original condition of the vehicle can alter road behaviour and jeopardize road safety.
- ▶ The special equipment and original spare parts recommended by us have been specially developed and supplied for your vehicle. These products are available at the authorised dealer or service centre. The authorised dealer or service centre is informed about admissible technical details and carries out the required work correctly.
- ▶ The use of accessories, parts and fittings not supplied by us may cause damage to the vehicle and jeopardize road safety. Even if an expert's report, a general type approval or a design certification exists, there is no guarantee for the proper quality of the product.
- ▶ No liability can be assumed for damage caused by products which have not been released by us. This also applies to impermissible alterations to the vehicle.

For safety reasons, spare parts for pieces of equipment must correspond with manufacturer's instructions and be permitted by the manufacturer as a spare part. These spare parts may only be fitted by the manufacturer or an authorised specialist workshop. The authorised dealers and service centres are available for any spare parts requirement.

Here are some suggestions of important spare parts:

- Fuses
- Bulbs
- Water pump (submerged pump)

When ordering spare parts please indicate the chassis number and the vehicle type to the dealer.

The vehicle described in this instruction manual is built and equipped to factory standards. Special equipment is offered depending on its purpose or use. When fitting special equipment check if such equipment has to be entered in the vehicle documents. Observe the max. permissible gross weight. The authorised dealer or service centre will be happy to advise you.



## 12.11 Vehicle identification plate




Fig. 244 Vehicle identification plate

- 1 Chassis number
- 2 Maximum permissible gross weight
- 3 Permissible drawbar nose weight
- Permissible axle load

The vehicle identification plate (Fig. 244) with the chassis number is mounted on the front right side, in the gas bottle compartment.

Do not remove the vehicle identification plate. The vehicle identification plate:

- Identifies the vehicle
- Helps with the procurement of spare parts
- Together with the vehicle documents identifies the vehicle owner



### 12.12 Warning and information stickers

There are warning and information stickers on and inside the vehicle. Warning and information stickers are for the sake of safety and must not be removed.





### **Chapter overview**

This chapter contains instructions regarding the tyres of the vehicle.

The instructions address the following topics:

- tyre selection
- handling of tyres
- changing wheels
- spare wheel support

At the end of the chapter there is a table you can use to find the correct tyre pressure for your vehicle.

### 13.1 General



► Check tyre pressure before a journey or every 2 weeks. Wrong tyre pressure causes excessive wear and can lead to damage or even to tyre burst. You can lose control of the vehicle.



- Only check the tyre pressure on cold tyres.
- ➤ Tubeless tyres have been installed on the vehicle. Never install tubes in these tyres.
- When using alloy wheel rims, snow chains should not be used.



- ▷ In the case of a puncture, pull over to the side of the road. Make vehicle and caravan safe with a hazard warning triangle. Switch on the warning lights.
- > Tyres on vehicles with tandem axles may wear faster.
- ➤ Tyres must not be older than 6 years as the material will become brittle over time. The four-digit DOT number on the tyre flank indicates the date of manufacture. The first two digits designate the week, the last two digits the year of manufacture.

Example: 0512 Week 05, year of manufacture 2012.

### Observe:

- Check the tyres regularly (every 2 weeks) for equal tread wear, tread depth and external damage.
- Replace tyres at the latest, when the minimum depth of tread stipulated by law is reached.
- Always use tyres of the same model, same brand and same style (summer and winter tyres).
- Only use tyres approved for the wheel rim type fitted. The permitted rim and tyre sizes are quoted in the vehicle documents and the authorised dealer or service centre will always be glad to give you advice.
- Run-in new tyres for approx. 100 km (60 miles) at low speed since only then do they reach full strength.






Fig. 245 Tighten the wheel nuts or wheel bolts cross-wise

- Check regularly that the wheel nuts or wheel bolts are firmly seated. Retighten the wheel nuts or wheel bolts of a changed wheel cross-wise (Fig. 245) after 50 km (30 miles).
  See section 13.5.2 for tightening torque.
- When using new or newly painted rims, re-tighten the wheel nuts or wheel bolts once again after approx. 1,000 to 5,000 km (600 miles to 3,000 miles).
- For lay-ups or long periods of inactivity, keep the tyres and tyre bearings free from pressure points: Jack up the vehicle so that the wheels do not bear any load, or move the vehicle every 4 weeks in such a way that the position of the wheels is changed.

### 13.2 Tyre selection



➤ A wrong tyre can damage the tyres during the journey and even cause it to burst.



▷ If tyres that are not approved for the vehicle are used, then the type approval for the vehicle and subsequently the insurance coverage can lapse. The authorised dealer or service centre will be happy to advise you.

The tyre sizes approved for the vehicle are given in the vehicle documents or can be obtained from the authorised dealers or service centres. Each tyre must fit the vehicle on which it will be driven. This applies to the external dimensions (diameter, width), which are indicated with the standardised size designations. In addition, the tyres must meet the requirements of the vehicle with regard to weight and speed.

Weight refers to the maximum permissible axle load which can be distributed on two tyres. The maximum load-carrying capacity of a tyre is indicated by its load index (= LI, load index code).

The maximum permissible speed for a tyre (with full load-carrying capacity) is indicated by the speed index (= SI). Together, load index and speed index form the operating code of a tyre. This is an official component of the complete, standardised dimensions description which appears on every tyre. The information on the tyres must correspond to the specifications which appear in the vehicle papers.



### 13.3 Tyre specifications

# 215/70 R 15C 109/107 Q (example)

Description	Explanation
215	Tyre width in mm
70	Height-to-width proportion in percent
R	Tyre design (R = radial)
15	Rim diameter in inches
С	Commercial (transporter)
109	Load index code for single tyres
107	Load index code for twin tyres
Q	Speed index (Q = 160 km/h)

## 13.4 Handling of tyres

- Drive over kerbs at an obtuse angle. Otherwise the flanks of the tyres may get pinched. Driving over a kerb at a sharp angle can damage the tyre and result in it getting ruptured.
- Drive over high manhole covers at a slow speed. Otherwise the tyres may get pinched. Driving over a high manhole cover at high speed can damage the tyre and result in it getting ruptured.
- Check the shock absorbers regularly. Driving with poor shock absorbers significantly increases wear.
- Avoid block brakings. Block braking gives the tyres "brake plates" of varying strength. This reduces driving comfort. It might even make the tyres unserviceable.
- Do not clean the tyres with a high-pressure cleaner. The tyres can suffer serious damage within just a few seconds and rupture as a result.

## 13.5 Changing wheels

### 13.5.1 General instructions

The spare wheel (special equipment) is located in the gas bottle compartment or in a holder underneath the vehicle (special equipment). To change the wheel, use a commercial scissor-type or hydraulic vehicle jack or the AL-KO vehicle jack (special equipment).



- The vehicle must be on level, firm ground, secure from slipping.
- ▶ Before jacking up the vehicle firmly apply the handbrake.
- ▶ Prevent the vehicle from rolling away by blocking the opposite wheel with the wheel chocks.
- ▶ Under no circumstances jack the vehicle with the fitted supports.
- ▶ Position the vehicle jack underneath the axle, not under any circumstances on the bodywork.
- Never overload the vehicle jack. The maximum permissible load is specified on the vehicle jack's identification plate.
- ▶ Use the vehicle jack only for lifting the vehicle briefly while changing the tyre.





- ▶ No persons may be in the vehicle while it is is raised.
- Whilst the vehicle is in a jacked up position, persons must not lie down under it.



- Do not damage the thread of the thread bolt or wheel bolt when changing the wheel.
- ▷ Tighten the wheel nuts or wheel bolts cross-wise (Fig. 245).
- When changing wheels (e.g. alloy wheel rims or wheels with winter tyres), use the correct wheel bolts of the correct length and shape. Otherwise the wheels may not be securely fixed or the braking system may not work correctly.
- ➤ The use of wheel rims or tyres that are not approved for the vehicle can make it less than fully roadworthy; such wheel rims or tyres must be separately inspected and approved by an accredited test centre.



- ▶ Protect the vehicle according to the national regulations, e.g. with a hazard warning triangle.
- ▷ Before changing the wheel, check the wheel rim and tyre size, the max. tyre load and the speed index on the tyres. Only use the wheel rim and tyre sizes stated in the vehicle documents.
- ▷ If different wheel nuts or wheel bolts are required for the vehicle tyres and the spare wheel, the wheel nuts or wheel bolts for the spare wheel will be supplied with the vehicle.

### 13.5.2 Tightening torque



When fitting alloy wheel rims, only use the wheel bolts supplied.



Fig. 246 Wheel bolts

- Wheel bolt spherical
- 2 Wheel bolt conical



Rim type	Tighten- ing torque	Type Shaft length (SL) Length (L) of wheel bolt [mm]	No. of holes/ Bolt circle/ Centre hole- Ø of rim [mm]	Width across flats
Steel 4-hole	90 Nm (67 ft/lbs)	Cone washer 60° M12x1,5 Q 8.8 Flange Ø 22 (Tol. +1.5/- 0.5) SL 24 L 42 (Tol. +1/-0.5)	4/100/-	19
Steel 5-hole	90 Nm (67 ft/lbs)	Spherical R12 M12x1,5 Q 8.8 Flange Ø 24 (Tol2) SL 25 L 44 (Tol. +1/-0.5)	5/112/-	19
Light alloy 4- hole OJ13/4, 14/4	120 Nm (89 ft/lbs)	Cone washer 60° M12x1,5 Q 10.9 Flange Ø 21 (Tol. +0.5) SL 28 L 48 (Tol. ±0.5)	4/100/-	17
Light alloy 4- hole GSM1- 1460-403T1	120 Nm (89 ft/lbs)	Cone washer 60° M12x1,5 Q 10.9 Flange Ø 23 SL 28 L 53.5	4/100/-	17
Light alloy 5- hole OJ14/ 5,15,5	120 Nm (89 ft/lbs)	Cone washer 60° M12x1,5 Q 10.9 Flange Ø 21 (Tol. +0.5) SL 28 L 48 (Tol. ±0.5)	5/112/-	17
Light alloy 5- hole GSM1- 1460-512T2	120 Nm (89 ft/lbs)	Cone washer 60° M12x1,5 Q 10.9 Flange Ø 23 SL 28 L 53.5	5/112/-	17



### 13.5.3 Changing a wheel



- ► The footplate of the vehicle jack must be levelly positioned on the ground.
- ▶ Do not tilt the vehicle jack.
- ▶ Always insert the insertion profile of the AL-KO vehicle jack (special equipment) into the retention pouch as far as possible.
- ▶ If alloy wheel rims are mounted and a steel spare wheel is mounted after a puncture: Do not drive any further than necessary (car dealer, car workshop, tyre dealer). Only drive at a suitable speed. The different wheels affect driving handling.



- A special vehicle jack from AL-KO with holder pockets is available as special equipment. These holder pockets are mounted on to the frame.
- The AL-KO jack has a bearing capacity of 800 kg.
- > The wheel you have replaced should be repaired immediately.
- ▶ Take note of the general instructions in this chapter.





Fig. 247 Securing support wheel

Fig. 248 Securing vehicle

# Preparing the connected caravan:

- Loosen the stabilising device in caravan couplings with stabilising devices. Otherwise the friction pads will be highly loaded.
- Pull the handbrake of the towing vehicle and go to first gear or reverse gear.

# Preparing the disconnected caravan:

- Park the vehicle on as even and stable a surface as possible.
- Apply the handbrake.
- Place the support wheel diagonal to the direction of travel and secure with suitable tools (Fig. 247).








Fig. 249 Commercial vehicle jack

Fig. 250 AL-KO vehicle jack

### Changing the wheel:

- Place chocks or other appropriate objects beneath the opposite wheel of the vehicle to secure it (Fig. 248).
- Remove the spare wheel from the spare wheel support.
- If the ground is soft, place a stable support such as a wooden board beneath the vehicle jack.
- Commercial vehicle jack: Position the commercial scissor-type jack (Fig. 249) or hydraulic vehicle jack on the frame or on the axle.
- AL-KO vehicle jack: Insert the insertion profile (Fig. 250,2) of the AL-KO vehicle jack into the retention pouch (Fig. 250,1) as far as possible.
- AL-KO vehicle jack: Hold on to the AL-KO vehicle jack with one hand and with the other turn the hand crank (Fig. 250,4) in a clockwise direction until the footplate (Fig. 250,3) is touching the ground and is in a level position.
- Turn the wheel bolts several times to loosen them, but do not remove them!
- Lift the vehicle until the wheel has been lifted 2 to 3 cm above the ground.
- Remove the wheel bolts and take off the wheel.
- Place the spare wheel on the wheel hub and adjust.
- Screw in the wheel bolts and slightly tighten them cross-wise.
- Crank down the vehicle jack and remove it.
- Using the wheelbrace, tighten the wheel bolts evenly. The target value of the tightening torque of the wheel bolts is 90 Nm (67 ft/lbs) or 120 Nm (89 ft/lbs) (see section 13.5.2).

### 13.5.4 Changing a wheel at alloy wheel rims



- ➤ The resting surfaces of the wheels on the break drums must be clean and free of burrs.
- Only use fastening parts provided for to loosen the wheels lightly and ensure that they rest correctly and move freely, subsequently tighten the wheel bolts cross-wise with a suitable wrench.
- ► Many axles do not have a centring aid, flange or bolts. It must be ensured that the wheel bolts are equally centered above the bolt circle (no jamming).
- ▶ Alloy wheel rims and steel wheel rims require different wheel bolts. When alloy wheel rims are mounted, the spare wheel (steel wheel rim) is accompanied by suitable wheel bolts.



### 13.6 Spare wheel support

### 13.6.1 Spare wheel support in gas bottle compartment





Fig. 251 Spare wheel support

The spare wheel support is fitted in the gas bottle compartment. The spare wheel (Fig. 251,2) is available for a surcharge.

Removing the spare wheel:

- Undo bolt (Fig. 251,1).
- Remove the spare wheel (Fig. 251,2).

## 13.6.2 Spare wheel support under the vehicle (special equipment)






Fig. 252 Spare wheel support

Fig. 253 Spare wheel fixture

The spare wheel support is located under the vehicle near the axle.

Removing the spare wheel:

- Unhook the safety chain (Fig. 252,2).
- Loosen and unscrew the star handle (Fig. 252,1).
- Pull out the spare wheel support (Fig. 252,3) about 10 cm and place it on the ground.
- Pull out the spare wheel support far enough that you can comfortably access the spare wheel.
- Unscrew both nuts (Fig. 253,2 and 3).
- Remove the spare wheel (Fig. 253,1) from the spare wheel support.



## 13.7 Tyre pressure



- ➤ Tyres overheat if the tyre pressure is too low. This can cause serious tyre damage.
- ► Check tyre pressure before a journey or every 2 weeks. Wrong tyre pressure causes excessive wear and can lead to damage or even to tyre burst. You can lose control of the vehicle.
- ▶ Use only valves that are approved for the specified tyre pressure.




Only check the tyre pressure on cold tyres.

The payload and the durability of tyres is directly dependent on the tyre pressure. Air is a volatile medium. It is unavoidable that it will escape from tyres.

As a rule of thumb it can be assumed that a filled tyre loses pressure at a rate of 0.1 bar every two months. To prevent the tyres becoming damaged or burst, check the tyre pressure regularly.

The contact surface of the tyre changes, depending on the tyre pressure.



1 Correct tyre pressure2 Tyre pressure too low

3 Tyre pressure too high

Fig. 254 Contact surface of the tyre



- > The information on pressure levels is valid for cold tyres and loaded vehicles
- ▶ Pressure in hot tyres must be 0.3 bar higher than in cold tyres. Recheck the pressure when the tyres are cold.
- ▷ Tyre pressures in bar.
- The tyre pressure tolerance is +/- 0.05 bar.

Tyre size	Load index (LI, minimum)	Air pres- sure in bar	With load in kg
185/70R 13 RF	90	3.4	600
185R 14 C	102	3.5	500-600
		4.0	625-700
		4.5	750-850
195R 14 C	106	4.5	750-950
195/70R 14 RF	96	3.4	710

Max. permissible speed = 100 km/h (60 mph).

Please always observe the speed limits in the individual countries (see chapter 17).



# Wheels and tyres



The vehicles are constantly brought up to the newest technical standards. It is possible that new tyre sizes are not yet included in this table. If this is the case, the Bürstner dealer will be happy to provide the newest values.



### **Chapter overview**

This chapter contains instructions about possible faults in your vehicle.

The faults are listed with their possible causes and corresponding remedies.

The instructions address the following topics:

- chassis
- braking system
- caravan control system
- manoeuvring system
- electrical system
- gas system
- gas cooker
- gas oven
- microwave oven
- heater
- boiler
- hot water source
- refrigerator
- air conditioning unit
- water supply
- body

The specified faults can be remedied with relative ease and without a great deal of specialised knowledge. In the event that the remedies detailed in this instruction manual should not be successful, an authorised specialist workshop must find and eliminate the cause of the fault.

### 14.1 Chassis

Fault	Cause	Remedy
Coupling does not lock in	Ball larger than Ø 50 mm	Remove dirt
place after being placed on top		Contact customer service
	The coupling interiors are soiled and no longer work automatically	Clean well and lubricate (not stabiliser)
Caravan cannot be detached	Ball worn	Position the caravan and towing vehicle in the same direction and detach. Immediately replace the worn ball

### 14.2 Braking system



- ► Have defects on the braking system immediately remedied by an authorised specialist workshop.
- ▶ Follow maintenance or manufacturer specifications.



# 14.3 Caravan control system (ATC)

Fault	Cause	Remedy
Control LED flashes green (possible to contin- ue journey)	ATC active Self test not yet complete	Drive approx. 30 m with the trailor at a minimum 10 km/h. If the control LED continues to flash, contact customer servic- es
Control LED lights up red (possible to continue journey)	ATC not active Fault in system	Separate the electrical connection between the caravan and the towing vehicle for at least 5 seconds  Reconnect  If the control LED continues to light up red, contact customer services
Control LED flashes red (do not continue journey)	ATC brakes	Separate the electrical connection between the caravan and the towing vehicle for at least 5 seconds  Reconnect  If the control LED continues to flash red, perform a visual check in accordance with the manufacturer's instruction manual and, if necessary, reset the braking system
Control LED does not illu- minate (only possible to continue journey after	ATC without power (only possible to continue journey after test)	Connect the electrics be- tween the caravan and the towing vehicle
test)	LED defect	Connect the electrics be- tween the caravan and the towing vehicle  If the control LED still does not illuminate, per- form a visual check in ac- cordance with the manufacturer's instruc- tion manual and contact customer service



## 14.4 Manoeuvring system

Fault	Cause	Remedy
Control does not react to the remote control sig-	Remote control batteries empty	Change batteries
nals	Plug of the caravan is not inserted into the safety socket	Insert connector
	Fuse is defective	Replace fuse
	Malfunction	Perform a reset. To do so, briefly disconnect the living room battery (for approximately 10 sec- onds) or unplug the safe- ty plug and then plug it back in.
Drive rollers do not turn	Battery flat	Charge the battery

# 14.5 Electrical system



> See chapter 8 for changing the fuses.

Fault	Cause	Remedy
Road light system does no longer work correctly	Bulb is defective	Unscrew cover of the relevant light, replace bulb. Note volts and watts specifications
	Contacts on the plug and/or in the socket have oxidised and/or are con- taminated	Clean contacts and spray with contact spray
	Short circuit caused by water in the plug and/or socket	Open plug and/or socket, dry out, and spray with contact spray
	Cable interruption on the plug and/or socket	Open plug and/or socket, re-connect cable (see connection diagram in chapter 8)
Road light system does not match the towing vehicle light system	Contact connections within the plug have been reversed	Check contact allocation and wiring on the plug/ connector of the caravan
No 230 V power supply despite connection	230 V automatic circuit breaker has triggered	Switch on 230 V auto- matic circuit breaker
12 V power supply in the living area does not work	230 V automatic circuit breaker switched off	Switch on 230 V auto- matic circuit breaker
	12 V main switch (if present) is switched off	Switch on the 12 V main switch
	Fuse on the power sup- ply unit is defective	Replace fuse
	Power supply unit is defective	Contact customer service



Fault	Cause	Remedy
Interior lighting does no longer work correctly	Bulb is defective	Unscrew cover of the relevant light, replace bulb. Note volts and watts specifications
	Fuse on the power sup- ply unit is defective	Replace the fuse on the power supply unit
No voltage from the living area battery (if there is	Living area battery is dis- charged	Charge living area battery immediately
one)		Total discharge damages the battery.
		If the vehicle is to be laid up for a long period, fully charge the living area battery beforehand
Extractor hood does not work	230 V automatic circuit breaker switched off	Switch on 230 V auto- matic circuit breaker
	Power supply unit is defective	Contact customer service
	Fuse on the power sup- ply unit is defective	Replace fuse
	Extractor hood defective	Contact customer service
Air conditioning unit can- not be switched on or off	230 V automatic circuit breaker has triggered	Switch on 230 V auto- matic circuit breaker
	Remote control battery is empty	Change remote control battery

## 14.6 Gas system



- ▶ In case of a defect of the gas system (gas odour, high gas consumption) there is danger of explosion! Close regulator tap on the gas bottle immediately. Open doors and windows and ventilate well.
- ▶ If the gas system is defective: Do not smoke; do not ignite any open flames, and do not operate electric switches (light switches etc.).
- ► Have the defective gas system repaired by an authorised specialist workshop.

Fault	Cause	Remedy
No gas	Gas bottle is empty	Change gas bottle
	Gas isolator tap closed	Open the gas isolator tap
	Regulator tap on the gas bottle is closed	Open regulator tap on the gas bottle
	External temperature is too low (-42 °C for pro- pane gas, 0 °C for bu- tane gas)	Wait for higher external temperatures
	Built-in appliance is defective	Contact customer service



### 14.7 Cooker

## 14.7.1 Gas cooker/gas oven

Fault	Cause	Remedy
Ignition fuse does not op- erate (flame does not burn after the control	Heat-up time is too short	Keep control knob pressed for approx. 15 to 20 seconds after ignition
knobs are released)	Ignition fuse is defective	Contact customer service
Flame extinguishes when being reduced to its minimum setting	Thermocouple sensor is incorrectly set	Correctly reset thermo- couple sensor (do not bend). The sensor tip should protrude by 5 mm beyond the burner. The sensor neck should not be more than 3 mm away from the burner ring; if necessary, contact cus- tomer service

### 14.7.2 Microwave oven



▶ Only qualified personnel may repair the microwave oven. Improper repairs can cause major risks to the user.

Fault	Cause	Remedy
Microwave oven does not	Fuse is defective	Replace fuse
cut in	Door of the microwave oven is not properly closed	Remove foreign bodies stuck in the door of the microwave oven and close door properly

## 14.8 Heater, boiler and hot water source

In the event of a defect contact the nearest customer service workshop of the relevant appliance manufacturer. The list of addresses is enclosed with the accompanying appliance documentation. Only authorised qualified personnel may repair the appliance.

### 14.8.1 Trumatic S hot-air heater

Fault	Cause	Remedy
For heater with automatic ignition: Heater does not ignite	Battery on the automatic ignition empty	Change the battery on the automatic ignition

# Troubleshooting



## 14.8.2 Truma boiler

## Gas operation

Fault	Cause	Remedy
Red indicator lamp "Fault" illuminates	Air in the gas pipe system	Switch off and on again. After two futile ignition attempts, wait for 10 minutes before trying again
	Lack of gas	Open regulator tap and gas isolator tap
		Connect a full gas bottle
	Defect of a safety element	Contact customer service
Green indicator lamp be- hind knob is not lit	Fuse of the boiler is defective	Replace fuse
	Fuse in the electronic control unit has been triggered	Contact customer service
Red and green indicator lamps are not lit	No power supply	Establish the power supply
	Fuse of the boiler is defective	Replace fuse

### **Electrical operation**

Boiler is connected to power supply but is not heated	Operating switch is switched off	Switch on the operating switch, the indicator lamp on the switch must light up
	Operating switch defective	Contact customer service
	230 V automatic circuit breaker is switched off	Switch on the 230 V automatic circuit breaker
	230 V power supply dis- connected	Connect 230 V power supply
	Overtemperature fuse has triggered	Switch off boiler and switch on after approx. 5 minutes
	Heating coil of the boiler is defective	Contact customer service



### 14.8.3 Truma hot water source

Fault	Cause	Remedy
The hot water source is connected to power supply but does not heat	Operating switch is switched off	Switch on operating switch; the red indicator lamp must be lit
	Operating switch defective	Contact customer service
	230 V automatic circuit breaker is switched off	Switch on the 230 V automatic circuit breaker
	230 V power supply dis- connected	Connect 230 V power supply
	Fuse is defective	Replace fuse
	Heating coil in the hot water source is defective	Contact customer service

## 14.9 Refrigerator

In the event of a defect contact the nearest customer service workshop of the relevant appliance manufacturer. The list of addresses is enclosed with the accompanying appliance documentation. Only authorised qualified personnel may repair the appliance.

### 14.9.1 Dometic 8 series and Thetford

Fault	Cause	Remedy
Refrigerator does not switch on when operating	No 230 V power supply	Connect 230 V power supply
in 230 V mode	230 V automatic circuit breaker has triggered	Switch on the 230 V automatic circuit breaker
	230 V operating voltage too low	Have the 230 V power supply checked by an au- thorised specialist work- shop
Refrigerator does not switch on when operating in 12 V mode	Contacts on the plug and/or in the socket have oxidised and/or are con- taminated	Clean contacts and spray with contact spray
	Short circuit caused by water in the plug and/or socket	Open plug and/or socket, dry out, and spray with contact spray
	Cable interruption on the plug and/or socket	Open plug and re-con- nect cable
	Fuse for refrigerator is defective	Replace fuse



Fault	Cause	Remedy
Refrigerator does not switch on when operating	Lack of gas	Open regulator tap and gas isolator tap
in gas mode		Connect a full gas bottle
	Air in the gas pipe	Repeat ignition 3 or 4 times
	Cobwebs or burnt residue in the burning chamber	Remove the ventilation grill on the outside of the vehicle and clean the burning chamber
The desired refrigerating temperature is not achieved	Incorrect setting	Set the temperature with the temperature controller
	Too much fresh food put into it	Set the temperature with the temperature controller

### 14.9.2 Dometic 8 series with MES



Fault	Cause	Remedy
LED "<=" flashes	No 230 V power supply	Connecting 230 V power supply
	230 V automatic circuit breaker has triggered	Switch on the 230 V automatic circuit breaker
	230 V operating voltage too low	Have the 230 V power supply checked by an authorised specialist workshop
LED "+" flashes	Fuse on the transformer/ rectifier is defective	Replace fuse on the transformer/rectifier
	Disconnector relay in the transformer/rectifier is defective	Contact customer service
	12 V operating voltage too low	Have the 12 V power supply checked by an authorised specialist workshop
LED " flashes	Lack of gas	Open regulator tap and gas isolator tap
		Connect a full gas bottle
	Cobwebs or burnt residue in the burning chamber	Remove the ventilation grill on the outside of the vehicle and clean the burning chamber
LEDs for display of the temperature range flash	Temperature sensor defective	Contact customer service





Fault	Cause	Remedy
LED "  " and LEDs for display of the temperature range flash	230 V heater element defective	Contact customer service
LED " and LEDs for display of the temperature range flash	12 V heater element de- fective	Contact customer service
Refrigerator does not re- frigerate sufficiently	Insufficient ventilation of unit	Check if ventilation grills are covered; remove covers if necessary
		Remove ventilation grills and clean the space behind them (of leaves etc.)
	Ambient temperatures are too high	Remove the ventilation grills periodically

## 14.9.3 Dometic 8 series with AES



Fault	Cause	Remedy
Text "230 V" flashes	No 230 V power supply	Connecting the 230 V power supply
	230 V automatic circuit breaker has triggered	Switch on the 230 V automatic circuit breaker
	230 V operating voltage too low	Have the 230 V power supply checked by an authorised specialist workshop
Text "12 V" flashes	Fuse on the transformer/ rectifier is defective	Replace fuse on the transformer/rectifier
	Disconnector relay in the transformer/rectifier is defective	Contact customer service
	12 V operating voltage too low	Have the 12 V power supply checked by an authorised specialist workshop
Text "GAS" flashes	Lack of gas	Open regulator tap and gas isolator tap
		Connect a full gas bottle
	Cobwebs or burnt residue in the burning chamber	Remove the ventilation grill on the outside of the vehicle and clean the burning chamber
LEDs for display of the temperature range flash	Temperature sensor de- fective	Contact customer service
Text "HE1" flashes	230 V heater element defective	Contact customer service



Fault	Cause	Remedy
Text "HE2" flashes	12 V heater element de- fective	Contact customer service
Refrigerator does not re- frigerate sufficiently	Insufficient ventilation of unit	Check if ventilation grills are covered; remove covers if necessary
		Remove ventilation grills and clean the space behind them (of leaves etc.)
	Ambient temperatures are too high	Remove the ventilation grills periodically

## 14.10 Air conditioning unit

## 14.10.1 Dometic

Fault	Cause	Remedy
Air conditioning unit does not start up	No 230 V power supply	Connect the vehicle to the local power supply
	230 V automatic circuit breaker has triggered	Switch on the 230 V automatic circuit breaker
	Remote control batteries empty	Change remote control batteries
Air conditioning unit does not cool	Temperature below 16 °C	_
	Temperature has been set incorrectly	Adjust the temperature
	Thermostat defective	Contact customer service
Air conditioning unit does not warm up	Temperature above 30 °C	_
	Temperature has been set incorrectly	Adjust the temperature
	Thermostat defective	Contact customer service
Water is entering the vehicle	Drainage holes for con- densation are clogged	Clean air conditioning unit
	Seal is defective	Contact customer service
No more air circulation	Air filter clogged	Clean air filter
	Fan wheel defective	Contact customer service



## 14.10.2 Telair

Fault	Cause	Remedy
Air conditioning unit does not start up	No 230 V power supply	Connect 230 V power supply
	230 V automatic circuit breaker has triggered	Switch on the 230 V automatic circuit breaker
	Remote control batteries empty	Change batteries (2 x AAA)
Air conditioning unit does not cool	Room temperature is lower than the preset temperature	Reset temperature
Air conditioning unit does not heat	Room temperature is higher than the preset temperature	Reset temperature
Insufficient ventilation rat- ing	Ventilation flaps closed	Open at least one venti- lation flap
	Filter dirty	Clean the filter
Water is entering the vehicle	Drainage holes for con- densation are clogged	Clean air conditioning unit

## 14.10.3 Truma

Fault	Cause	Remedy
Air conditioning unit does not cool	No 230 V power supply	Connect 230 V power supply
	Fuse is defective	Check fuse and replace if necessary
	Temperature below 16 °C	
	Temperature has been set incorrectly	Adjust the temperature
	Air filter contaminated	Replace air filter

## 14.11 Water supply

Fault	Cause	Remedy
Leakage water inside the vehicle	A leak has occurred	Identify leak, re-connect water pipes
No water	Water tank is empty	Replenish drinking water
	Water drain cock open	Close water drain cock
	Fuse of the water pump is defective	Replace fuse
	Water pump defective	Exchange water pump (have it exchanged)
	Water pipe snapped off	Straighten water pipe or replace
	Power pack or power supply unit defect	Contact customer service



Fault	Cause	Remedy
Toilet has no flush water	Water tank is empty	Replenish drinking water
	Fuse for toilet is defective	Replace fuse
Water drains from the shower tray slowly or does not drain at all	The vehicle is not in a horizontal position	Position the vehicle horizontally
Drain on the one-hand lever mixer is clogged	Perlator calcified	Unclip the perlator, de- calcify in vinegar water (only for products made from metal)
Milkiness of the water	Tank filled with dirty water	Clean water tank me- chanically and chemical- ly; then disinfect and rinse copiously with drinking water
	Residues in the water tank or water system	Clean water system me- chanically and chemical- ly; then disinfect and rinse copiously with drinking water
Any change in the taste or odour of the water	Tank filled with dirty wa- ter	Clean water system me- chanically and chemical- ly; then disinfect and rinse copiously with drinking water
	Fuel filled into the water tank by mistake	Clean water system me- chanically and chemical- ly; then disinfect and rinse copiously with drinking water. If not suc- cessful: Contact a spe- cialist workshop
	Microbiological deposits in the water system	Clean water system me- chanically and chemical- ly; then disinfect and rinse copiously with drinking water
Deposits in the water tank and/or water-carrying components	Water excessively long in the water tank and in wa- ter-carrying components	Clean water system me- chanically and chemical- ly; then disinfect and rinse copiously with drinking water



## 14.12 Body

Fault	Cause	Remedy
Flap hinges/door hinges are difficult to operate	Flap/door hinges are not sufficiently lubricated	Lubricate flap hinges/ door hinges with acid- free and resin-free grease
Hinges/joints in the bath- room unit/toilet compart- ment are difficult to operate/make a grating noise	Hinges/joints are not suf- ficiently lubricated	Lubricate hinges/joints with solvent-free and acid-free grease  Spray cans often contain solvents
Storage compartment hinges are difficult to operate/make a grating noise	Storage compartment hinges are not sufficiently lubricated	Lubricate storage com- partment hinges with acid-free and resin-free grease



 $\, \triangleright \,$  The authorised dealers and service centres are available for any spare parts requirement.



# Troubleshooting





## 15.1 Weight details for special equipment



- ▶ The use of accessories, parts and fittings not supplied by us may cause damage to the vehicle and jeopardize road safety. Even if an expert's report, a general type approval or a design certification exists, there is no guarantee for the proper quality of the product.
- ► Every alteration of the original condition of the vehicle can alter road behaviour and jeopardize road safety.
- ▶ No liability can be assumed for damage caused by products which have not been released by us. This also applies to impermissible alterations to the vehicle.

Weight details for Bürstner special equipment are listed in the table below. If these objects are either carried in or on the vehicle and are not part of the standard equipment, they must be taken into consideration when calculating the payload.

All weight details are approximate.

Observe the max. permissible gross weight.

Item designation	Surplus weight (kg)
Waste bin - door	1
Waste water pipes, insulated and heated	2
Waste water tank 22 litres	3
Airmix comfort package	1
AL-KO Trailer-Control	5
External shower	1
Oven	13
Direct water supply	3
Skylight Heki 2	11
Drawbar covering	3
Drawbar head theft protection	2
Extractor hood	1
Conversion door, single-section with window	8
Electric kit: Battery, battery charger, panel	23
Spare wheel 185/70 R 13	18
Spare wheel 185 R 14 C	18
Spare wheel 195/70 R 14 RF	20
Spare wheel support under vehicle	1
External gas connection	1
Drawbar bike rack for 2 bicycles	4
Rear bike rack for 2 bicycles	10
Floor warming unit	2
Gas bottle (11 kg) made of aluminium	12
Gas bottle switching facility, automatic	5
Weight increase	10



Item designation	Surplus weight (kg)
GRP roof	25
Smooth plate	20
Holder for flat screen	1
S 5002/S 5004 heater	8
Pull-down bed, electrically adjustable	3
Insect screen, door (full height)	3
Children's bunk bed with 3 levels	20
Air conditioning unit (Dometic)	40
Air conditioning unit (Telair)	34
Air conditioning unit (Truma)	20
Headphones satellite system	1
160-litre refrigerator	14
Microwave oven	14
Minisafe	5
Neck rests (round seating group)	3
Truma Mover manoeuvring system	35
Roll-up grille	2
Satellite unit (automatic) + LCD television	18
Satellite unit (semi-automatic) + LCD television	17
Service flap, garage flap (installation dependent on model)	1-3
Stabilising supports, complete set	4
TecTower	16
Truma boiler	15
Truma hot water source	2
Truma Ultraheat	6
Truma circulation system	12
Vehicle jack (AL-KO)	5
Wall pocket	1
Water tank, mobile, 22 litres, with external flap	3
Water tank, 40 litres, permanently installed	2
Truma winter package	13



## 16.1 Table of linear measures

Premio   385 TK   4350   3830   2100   5800   2580   8080   385 TS   4350   3830   2100   5820   2580   8080   395 TS   4620   4100   2300   6070   2580   8750   435 TS   5020   4500   2100   6300   2580   8750   435 TS   5020   4500   2100   6470   2580   8750   435 TS   5020   4500   2300   6720   2580   9000   485 TK   5560   5040   2300   7010   2580   9390   480 TL   5660   5140   2300   7110   2580   9390   490 TL   5660   5140   2300   7110   2580   9390   495 TK   5660   5140   2300   7110   2580   9390   455 TK   6020   5500   2500   7480   2580   9750   450 TS   5340   4500   2300   6520   2580   9750   450 TS   5340   4700   2300   6690   2580   9220   465 TS   5920   5250   2300   7280   2580   9770   475 TL   5770   5140   2300   7280   2580   9770   475 TL   5770   5140   2300   7280   2580   9820   495 TK   5940   5300   2300   7280   2580   9820   495 TK   5940   5300   2300   7280   2580   9920   470 TS   5890   5250   2300   7280   2580   99770   475 TL   5770   5140   2300   7280   2580   9820   495 TK   5940   5300   2300   7330   2580   9820   535 TL   6070   5440   2300   7420   2580   9820   535 TL   6070   5440   2300   7420   2580   9950   545 TS   6690   6050   2300   8080   2580   10570   560 TK   6420   5780   2300   7280   2580   10300   10570   560 TK   5480   5500   2300   7280   2580   10300   10570   560 TK   5480   5500   2300   7280   2580   10300   10570   560 TK   5480   5500   2300   7420   2580   10300   10570   560 TK   5880   5300   2300   7420   2580   9830   535 TL   6070   5430   2300   7420   2540   9830   535 TL		Туре	Body length, exterior	Body length, interior	Body width, exterior	Total length	Overall height	Awning dimensions
## Averso Plus  ## Averso Plus  ## Averso Plus  ## Averso Plus  ## Averso Top  ##	Premio	385 TK	4350	3830	2100	5800	2580	8080
## Averso Top  ## Ave		385 TS	4350	3830	2100	5820	2580	8080
Averso   A		395 TS	4620	4100	2300	6070	2580	8350
A50 TS		400 TS	5020	4500	2100	6300	2580	8750
## A85 TK		435 TS	5020	4500	2100	6470	2580	8750
### Averso Plus  ### Averso Plus  ### Averso Top  ### Averso Files  ### Averso Files  ### Averso Top  ### Averso Files  ### Averso Files  ### Averso Files  ### Averso Top  ### Averso Files  ### Averso Files  ### Averso Top  ### Averso Files  #### Averso Files  ##### Averso Files  ######### Averso Files  ###################################		450 TS	5270	4750	2300	6720	2580	9000
### Ayo TK		485 TK	5560	5040	2300	7010	2580	9290
Averso Plus  Averso   250		490 TL	5660	5140	2300	7110	2580	9390
Averso Plus    550 TK   6020   5500   2500   7480   2580   9750		490 TK	5820	5300	2300	7290	2580	9550
Averso 8  Averso 8  Averso 8  Averso 9  Averso 9  Averso 9  Averso 9  Averso Plus 8  Averso Top 8  Averso Plus 8  Averso Top 8  Averso Plus 9  Aver		495 TK	5660	5140	2300	7110	2580	9390
A30 TS		550 TK	6020	5500	2500	7480	2580	9750
A30 TS	_		=	=.				
450 TS       5340       4700       2300       6690       2580       9220         465 TS       5920       5290       2300       7280       2580       9800         470 TS       5890       5250       2300       7280       2580       9770         475 TL       5770       5140       2300       7140       2580       9650         480 TS       5890       5250       2300       7280       2580       9770         495 TK       5940       5300       2300       7330       2580       9820         500 TK       5940       5300       2300       7330       2580       9820         535 TL       6070       5440       2300       7420       2580       9950         545 TS       6690       6050       2300       8080       2580       10570         560 TK       6420       5780       2500       7790       2580       10300         Averso Plus         410 TS       4580       4000       2300       5970       2750       8110         40 TK       5160       4590       2300       7280       2450       9830         510 TK       60	Averso							
465 TS       5920       5290       2300       7280       2580       9800         470 TS       5890       5250       2300       7280       2580       9770         475 TL       5770       5140       2300       7140       2580       9650         480 TS       5890       5250       2300       7280       2580       9770         495 TK       5940       5300       2300       7330       2580       9820         535 TL       6070       5440       2300       7420       2580       9950         545 TS       6690       6050       2300       8080       2580       10570         560 TK       6420       5780       2500       7790       2580       10300         Averso Plus         410 TS       4580       4000       2300       5970       2750       8110         440 TK       5160       4590       2300       6520       2750       8700         510 TK       6080       5500       2300       7280       2450       9830         500 TK       5880       5300       2300       7280       2540       9830         535 TL       6								
470 TS       5890       5250       2300       7280       2580       9770         475 TL       5770       5140       2300       7140       2580       9650         480 TS       5890       5250       2300       7280       2580       9770         495 TK       5940       5300       2300       7330       2580       9820         500 TK       5940       5300       2300       7330       2580       9820         535 TL       6070       5440       2300       7420       2580       9950         545 TS       6690       6050       2300       8080       2580       10570         560 TK       6420       5780       2500       7790       2580       10300         Averso Plus         410 TS       4580       4000       2300       5970       2750       8110         440 TK       5160       4590       2300       6520       2750       8700         510 TK       6080       5500       2300       7280       2450       9830         500 TK       5880       5300       2300       7420       2540       9830         535 TL       6								
475 TL       5770       5140       2300       7140       2580       9650         480 TS       5890       5250       2300       7280       2580       9770         495 TK       5940       5300       2300       7330       2580       9820         500 TK       5940       5300       2300       7330       2580       9820         535 TL       6070       5440       2300       7420       2580       9950         545 TS       6690       6050       2300       8080       2580       10570         560 TK       6420       5780       2500       7790       2580       10300         Averso Plus         410 TS       4580       4000       2300       5970       2750       8110         440 TK       5160       4590       2300       6520       2750       8700         510 TK       6080       5500       2300       7280       2450       9830         Averso Top         495 TK       5880       5300       2300       7280       2540       9830         535 TL       6070       5430       2300       7420       2540       9950<								
480 TS       5890       5250       2300       7280       2580       9770         495 TK       5940       5300       2300       7330       2580       9820         500 TK       5940       5300       2300       7330       2580       9820         535 TL       6070       5440       2300       7420       2580       9950         545 TS       6690       6050       2300       8080       2580       10570         560 TK       6420       5780       2500       7790       2580       10300         Averso Plus         410 TS       4580       4000       2300       5970       2750       8110         440 TK       5160       4590       2300       6520       2750       8700         510 TK       6080       5500       2300       7400       2750       9610         Averso Top         495 TK       5880       5300       2300       7280       2450       9830         500 TK       5880       5300       2300       7420       2540       9830         535 TL       6070       5430       2300       7420       2540       9950<								
495 TK       5940       5300       2300       7330       2580       9820         500 TK       5940       5300       2300       7330       2580       9820         535 TL       6070       5440       2300       7420       2580       9950         545 TS       6690       6050       2300       8080       2580       10570         560 TK       6420       5780       2500       7790       2580       10300         Averso Plus         410 TS       4580       4000       2300       5970       2750       8110         440 TK       5160       4590       2300       6520       2750       8700         510 TK       6080       5500       2300       7400       2750       9610         Averso Top         495 TK       5880       5300       2300       7280       2450       9830         535 TL       6070       5430       2300       7420       2540       9950         545 TS       6690       6050       2300       8080       2540       10570			5770	5140		7140	2580	
500 TK       5940       5300       2300       7330       2580       9820         535 TL       6070       5440       2300       7420       2580       9950         545 TS       6690       6050       2300       8080       2580       10570         560 TK       6420       5780       2500       7790       2580       10300         Averso Plus         410 TS       4580       4000       2300       5970       2750       8110         440 TK       5160       4590       2300       6520       2750       8700         510 TK       6080       5500       2300       7400       2750       9610         Averso Top         495 TK       5880       5300       2300       7280       2450       9830         500 TK       5880       5300       2300       7280       2540       9830         535 TL       6070       5430       2300       7420       2540       9950         545 TS       6690       6050       2300       8080       2540       10570								
535 TL       6070       5440       2300       7420       2580       9950         545 TS       6690       6050       2300       8080       2580       10570         560 TK       6420       5780       2500       7790       2580       10300         Averso Plus         410 TS       4580       4000       2300       5970       2750       8110         440 TK       5160       4590       2300       6520       2750       8700         510 TK       6080       5500       2300       7400       2750       9610     Averso Top           495 TK       5880       5300       2300       7280       2450       9830         500 TK       5880       5300       2300       7280       2540       9830         535 TL       6070       5430       2300       7420       2540       9950         545 TS       6690       6050       2300       8080       2540       10570		495 TK	5940	5300	2300	7330	2580	9820
545 TS       6690       6050       2300       8080       2580       10570         560 TK       6420       5780       2500       7790       2580       10300         Averso Plus         410 TS       4580       4000       2300       5970       2750       8110         440 TK       5160       4590       2300       6520       2750       8700         510 TK       6080       5500       2300       7400       2750       9610         Averso Top         495 TK       5880       5300       2300       7280       2450       9830         500 TK       5880       5300       2300       7280       2540       9830         535 TL       6070       5430       2300       7420       2540       9950         545 TS       6690       6050       2300       8080       2540       10570		500 TK	5940	5300	2300	7330	2580	9820
Averso Plus  410 TS		535 TL	6070	5440	2300	7420	2580	9950
Averso Plus       410 TS       4580       4000       2300       5970       2750       8110         440 TK       5160       4590       2300       6520       2750       8700         510 TK       6080       5500       2300       7400       2750       9610         Averso Top       495 TK       5880       5300       2300       7280       2450       9830         500 TK       5880       5300       2300       7280       2540       9830         535 TL       6070       5430       2300       7420       2540       9950         545 TS       6690       6050       2300       8080       2540       10570		545 TS	6690	6050	2300	8080	2580	10570
440 TK       5160       4590       2300       6520       2750       8700         510 TK       6080       5500       2300       7400       2750       9610         Averso Top         495 TK       5880       5300       2300       7280       2450       9830         500 TK       5880       5300       2300       7280       2540       9830         535 TL       6070       5430       2300       7420       2540       9950         545 TS       6690       6050       2300       8080       2540       10570		560 TK	6420	5780	2500	7790	2580	10300
440 TK       5160       4590       2300       6520       2750       8700         510 TK       6080       5500       2300       7400       2750       9610         Averso Top         495 TK       5880       5300       2300       7280       2450       9830         500 TK       5880       5300       2300       7280       2540       9830         535 TL       6070       5430       2300       7420       2540       9950         545 TS       6690       6050       2300       8080       2540       10570	Averse Blue	410 TS	4580	4000	2300	5070	2750	8110
Averso Top     495 TK     5880     5300     2300     7400     2750     9610       500 TK     5880     5300     2300     7280     2450     9830       500 TK     5880     5300     2300     7280     2540     9830       535 TL     6070     5430     2300     7420     2540     9950       545 TS     6690     6050     2300     8080     2540     10570	Averso Flus							
Averso Top       495 TK       5880       5300       2300       7280       2450       9830         500 TK       5880       5300       2300       7280       2540       9830         535 TL       6070       5430       2300       7420       2540       9950         545 TS       6690       6050       2300       8080       2540       10570								
500 TK     5880     5300     2300     7280     2540     9830       535 TL     6070     5430     2300     7420     2540     9950       545 TS     6690     6050     2300     8080     2540     10570		010 110	0000	0000	2000	7400	2100	0010
535 TL     6070     5430     2300     7420     2540     9950       545 TS     6690     6050     2300     8080     2540     10570	Averso Top	495 TK	5880	5300	2300	7280	2450	9830
545 TS 6690 6050 2300 8080 2540 10570	-	500 TK	5880	5300	2300	7280	2540	9830
		535 TL	6070	5430	2300	7420	2540	9950
560 TK 6410 5780 2500 7780 2540 10300		545 TS	6690	6050	2300	8080	2540	10570
		560 TK	6410	5780	2500	7780	2540	10300

## Technical data



## 16.2 Power supply

Input voltage	Primary	230 V AC, 47-63 Hz
Output voltage	Secondary	12 V DC, max. 24 A
Fuse	Protection class I	



#### **Chapter overview**

This chapter contains helpful tips for the journey.

The instructions address the following topics:

- road assistance in European countries
- traffic rules in European countries
- gas supply in European countries
- toll regulations in European countries
- safe ways to spend the night during travel
- camping in winter

At the end of the chapter there is a checklist containing the most important equipment for the journey.

#### 17.1 Traffic rules in foreign countries



- ➤ The vehicle driver is required to inform himself as to the traffic rules of the countries in which he plans to travel before beginning the trip. Contact your automobile club or embassy for further information.
- ▷ In some European countries, warning vests must be worn when exiting the vehicle outside of towns in the case of vehicle failures or accidents.
- Depending on the country, different rules and regulations apply (e.g. different warning signs for rear carriers, obligation to carry breathalyzer kits, spare bulbs, high-visibility vests, size of reserve canister). The driver of the vehicle must familiarise him or herself with these rules before every journey.
- □ Up-to-date information can generally be found on the web pages of the national automobile associations.

Information about traffic regulations is especially important as state law applies in case of damage. For your own safety, always observe the following rules when travelling abroad:

- Carry your insurance certificate with you.
- Always register accidents with the police.
- Never sign documents that you have not read and understood completely.

### 17.2 Help on Europe's roads

Country	+ Emergen- cy services ★ Police	Breakdown service
Belgium	<b>+</b> 112 <b>★</b> 112	TCB Brussels 0 70 34 47 77
Bulgaria	<b>+</b> 112/150 <b>★</b> 112/166	<b>TAIL</b> UAB (02) 9 11 46/146 1)
Denmark	+ 112 free of charge ★ 112 free of charge	FDM 45 27 07 07
Germany	<b>+</b> 112 <b>★</b> 110	<b>ADAC</b> 22 22 22 <sup>1)</sup>



Country	+ Emergen- cy services ★ Police		Breakdown service
Estonia	<b>+</b> 112 <b>★</b> 110/112	<b>~</b>	EESTI (0) 6 97 91 88/18 88 <sup>1)</sup>
Finland	<b>+</b> 112 <b>★</b> 112	<b>~</b>	Helsinki (09) 77 47 64 00
France	<b>+</b> 15/112 <b>★</b> 17	<b>~</b>	Lyon (08) 25 80 08 22
Greece	<b>+</b> 112/166 <b>★</b> 100/112	<b>~</b>	ELPA 104 00
Great Britain	<b>+</b> 112 <b>★</b> 112	2	AA (08 00) 0 28 90 18
Ireland	<b>+</b> 112 <b>★</b> 112	<b>~</b>	AA Dublin 18 00 66 77 88
Iceland	<b>+</b> 112 <b>★</b> 112	2	F.I.B 5 11 21 12
Italy	<b>+</b> 118/112 <sup>1)</sup> <b>★</b> 112	<b>~</b>	ACI 8 00 11 68 00
Croatia	<b>+</b> 112 <b>★</b> 112	<b>~</b>	HAK 9 87/ 0 19 87 <sup>1)</sup>
Latvia	+ 03/112 <sup>1)</sup> * 02/112 <sup>1)</sup>	<b>*</b>	LAMB 18 88
Lithuania	+ 03/112 <sup>1)</sup> * 02/112 <sup>1)</sup>	<b>~</b>	LAS 8 80 00 00 00/18 88 <sup>1)</sup>
Luxembourg	<b>+</b> 112 <b>★</b> 113/112 1)	<b>~</b>	ACL 2 60 00
Macedonia	<b>+</b> 194 <b>★</b> 192	<b>~</b>	AMSM +389 2 31 81 196
Montenegro	<b>+</b> 94 <b>★</b> 92	<b>~</b>	AMSCG 19807
Netherlands	<b>+</b> 112 <b>★</b> 112	*	ANWB (088) 2 69 28 88
Norway	<b>+</b> 113 <b>★</b> 112	<b>~</b>	NAF 0 85 05
Austria	<b>+</b> 144/112 <sup>1)</sup> <b>★</b> 133/112 <sup>1)</sup>	<b>~</b>	ÖAMTC 120
Poland	<b>+</b> 999/112 <sup>1)</sup> <b>★</b> 997/112 <sup>1)</sup>	<b>*</b>	PZM 022 5 32 84 33
Portugal	+ 112 * 112	<b>*</b>	ACP Lissab. (21) 9 42 91 03 ACP Porto (22) 8 34 00 01
Romania	+ 961/112 <sup>1)</sup> ★ 955/112 <sup>1)</sup>	*	ACR (021) 2 22 22 22



Country	+ Emergen- cy services ★ Police	<b>~</b>	Breakdown service
Russia	+ 03 ★ 02		RAS 8- (4 95) 7 47 66 66
Sweden	<b>+</b> 112 <b>★</b> 112	<b>**</b>	(08) 6 90 38 00
Switzerland	<b>+</b> 144 <b>★</b> 117/112 1)	<b>**</b>	TCS 1 40/03 18 50 53 11 1)
Serbia	<b>+</b> 94 <b>★</b> 92		AMSS 987
Slovakia	<b>+</b> 112 <b>★</b> 112	<b>**</b>	SATC 1 81 24
Slovenia	<b>+</b> 112 <b>★</b> 113		AMZS (1) 9 87/ 00386 1 5 30 53 53 <sup>1)</sup>
Spain	<b>+</b> 061/112 <sup>1)</sup> <b>★</b> 112	<b>**</b>	RACE 9 15 93 33 33
Czech Republic	+ 112 * 112	<b>*</b>	UAMK CR 12 30
Turkey	<b>+</b> 112 <b>★</b> 155/112 1)		TTOK (02 12) 2 82 81 40
Ukraine	<b>+</b> 03 <b>★</b> 02	<b>~</b>	112 UA (8-032) 2 97 65 50
Hungary	+ 104/112 <sup>1)</sup> * 107/112 <sup>1)</sup>	<b>~</b>	MAK 1 88/(06) 13 45 17 44 <sup>1)</sup>
Cyprus	<b>+</b> 112 <b>★</b> 112		AA (022) 31 31 31

<sup>1)</sup> In the mobile communication network

Date 07/2012 Specifications without guarantee

### 17.3 Speed limits



- ▶ Please always observe the speed limits in the individual countries.
- ➤ The caravan constructions were designed for a maximum permissible speed of 100 km/h (60 mph). Therefore never drive faster than 100 km/h (60 mph).



- ▷ In the event of accidents involving speeds in excess of 100 km/h insurance payments may be reduced as caravans are only type approved for speeds up to 100 km/h.
- Additional provisions may apply in different countries (regional regulations, regulations for newly qualified drivers, etc.).

For information, the speed limits of the countries visited most (all specifications in km/h):



Country	In built-up areas	Outside built-up areas	Motorway
Belgium	50	90/120 1) 2)	120 <sup>2)</sup>
Bulgaria	50	70	100
Denmark	50	70	80
Germany	50	80	80/100 <sup>3) 4)</sup>
Estonia	50	70	70
Finland	50	80	80
France	50	90 <sup>5)</sup> /110 <sup>1) 2) 6)</sup>	130 <sup>7) 2)</sup>
Greece	50	80	80
Great Britain	48	80/96 <sup>1)</sup>	96 <sup>3)</sup>
Ireland	50	80	80
Iceland	50	80	_
Italy	50	70	80
Croatia	50	80	90
Latvia	50	80	90
Lithuania	50	90 <sup>2)</sup>	90
Luxembourg	50	75	90
Macedonia	50	80	80
Montenegro	50	80	80
Netherlands	50	80	90 <sup>2)</sup>
Norway	50	60 <sup>8)</sup> /80	60 <sup>8)</sup> /80
Austria	50	100 <sup>9)</sup>	100 <sup>9)</sup>
Poland	50	70/80 <sup>1)</sup>	80
Portugal	50	70/80 <sup>10)</sup>	100
Romania	50	70/80 <sup>1)</sup>	90
Russia	60	70	90 11)
Sweden	50	80 <sup>12)</sup>	80 <sup>12)</sup>
Switzerland	50	80	80
Serbia	50	80	80
Slovakia	50	90	90
Slovenia	50	80	80
Spain	50	70/80 <sup>1)</sup>	80
Czech Republic	50	80	80
Turkey	40	80	110
Ukraine	60	80 <sup>11)</sup>	80 <sup>11)</sup>
Hungary	50	70	80
Belarus	60	70	90



- On expressways, on roads with more than one lane in each direction and on roads resembling highways
- $^{2)}\,$  Towing vehicles with a maximum permissible gross weight less than 3.5 t
- 3) Towing vehicle/trailer combinations must not use the far left-hand lane (far right-hand lane in GB) on three-lane motorways
- 4) Only with the approval of the road traffic authority for the relevant towing vehicle/ trailer combination.
- 5) In wet conditions 80 km/h
- 6) In wet conditions 100 km/h
- 7) In wet conditions 110 km/h
- 8) Trailers with no brakes and a current gross weight exceeding 300 kg
- <sup>9)</sup> With trailer of over 750 kg (max. perm. gross weight of 3.5 t), the following applies: On highways 80 km/h, on motorways 100 km/h. For towing vehicles over 3.5 t perm. gross weight, 70 km/h out of town, 80 km/h on motorways
- <sup>10)</sup> According to the traffic signs
- 11) Drivers who have had their driver's licence for less than two years must not drive faster than 70 km/h
- <sup>12)</sup> Trailer with no brakes whose maximum permissible gross weight is two times the unladen weight of the towing vehicle: 40 km/h

Date 03/2012 Source: ADAC

Specifications without guarantee

#### 17.4 Driving with low beam in European countries



▷ In many European countries, it is compulsory to drive with the vehicle's lights on even during the day. Regulations vary between countries. Motoring organisations or consulates can provide you with the relevant information.

## 17.5 Sleeping in the vehicle away from camping areas

Country	Sleep roads fields	ing on and	Sleeping on privately owned lands		Comments
	Yes	No	Yes	No	
Belgium		Х	Х		On highway rest areas max. 24 hours permitted
Bulgaria		Х		Х	
Denmark		Х	Х		
Germany	Х		Х		Staying overnight for one night to restore driving ability is permitted. There may be regional and local limitations
Finland		Х		Х	Possible with the permission of the land owner
France	(X)		X		Permission from the local authorities or the owner of the land is required. Parking and staying overnight on free areas is prohibited



Country	Sleepi roads fields		Sleeping on privately owned lands		Comments
	Yes	No	Yes	No	
Greece		Х		Х	One-off overnight stays in designated areas are permitted
Great Britain		Х	Х		Regulated by local rules
Ireland		Х	Х		Regulated by local rules
Italy	X		×		Staying overnight for one night at car parks and service stations is allowed. Observe the local regulations. Parking and staying overnight on free areas is pro- hibited
Croatia		Х		Х	
Luxembourg		Х		Х	
Macedonia		Х		Х	
Netherlands		Х		Х	Overnight stays on streets and squares is allowed in some boroughs
Norway	Х		Х		Officially prohibited on rest areas and cultivated grounds. Driving on dirt tracks prohibited; observe local regulations
Austria		X		X	Staying overnight for one night to restore driving ability is permitted, but not in nature reserves. Observe regional and local restrictions. Generally forbidden in Tyrol
Poland		Х	Х		Requires property owner's permission
Portugal		Х		Х	Staying overnight for one night on motorway service stations and car parks under 10 hours are tolerated
Romania		Х		Х	
Russia		Х		Х	
Sweden	Х		Х		Not on agriculture areas or in the vicinity of houses. Driving on rough terrain prohibited; ob- serve local regulations
Switzerland		Х	Х		One overnight stay at highway rest areas and in some cantons is tolerated
Serbia and Montenegro		Х		Х	
Slovakia		Х	Х		Overnight stays on private land are only allowed if a toilet is present
Slovenia		Х		Х	



Country	Sleepi roads fields	_	Sleeping on privately owned lands		Comments
	Yes	No	Yes	No	
Spain	Х		Х		Some regional prohibitions apply, especially on beaches
Czech Repub- lic		Х	Х		Overnight stays on private land are only allowed if a toilet is present
Turkey	Х		Х		
Ukraine	Х		Х		
Hungary		X	Х		Staying overnight on privately owned land is permitted only with police certification

Specifications without guarantee

#### 17.6 Gas supply in European countries



▷ In Europe, there are several different connection systems for gas bottles. It is not always possible to fill or exchange your gas bottles in a foreign country. Get information about the connection system in the country you are travelling to before embarking on your journey, e.g. at a motoring club or in the trade press.

#### **General tips**

Always observe the following instructions:

- Only go on vacation with completely filled gas bottles.
- Use all of the gas bottles' capacity.
- Take along adapter sets (available in camping supply stores) for filling gas bottles in foreign countries and for connecting the gas pressure regulator to foreign gas bottles.
- During the cold time of the year observe filling with propane gas component (butane does not gas below 0 °C).
- Use blue bottles from the firm Campingaz (distributed world-wide). Only use gas bottles with safety valves.
- When bottles from other countries are used, check the gas bottle compartments to see if the gas bottles fit into them. Gas bottles from other countries do not always display the same size as your own gas bottles.

#### 17.7 Toll regulations in European countries

Many European countries have introduced a mandatory toll system. The toll regulations and how they are collected vary greatly from country to country. Nevertheless, ignorance is no excuse. Penalties can be guite severe.

As is the case with traffic regulations, the vehicle driver is required to be familiar with the toll formalities before starting out on a trip.

Contact your automobile club or the Internet for further information.



#### 17.8 Tips on staying overnight safely during travel

Prudent behaviour is the most important protective measure for insuring a safe night in the caravan.

The risk of thievery is reduced to a minimum when the following basic rules are observed:

- Before commencing the journey, close and lock all windows, doors and skylights.
- During high season do not spend the night at highway rest stops or parking areas located along typical vacation routes.
- Several vehicles on one site at the same time do not necessarily decrease the chances of thievery occurring. Consult your own feelings about the parking site.
- Even if it is just for one night, go to a camping site.
- Only take with you those valuables which are absolutely necessary for the journey. If possible, store valuables in a small safe and not in the immediate vicinity of windows or doors.
- Always lock up the vehicle.

#### 17.9 Tips for winter campers

The following tips will help make your winter camping experience as agreeable as possible.

- Reserve your parking place in good time. Good winter camping sites are often booked up early.
- Do not start your trip without winter tyres.
- Choose your parking place with care. Observe the ground beneath you. Snow and ice may melt.
- Place boards of a sufficient size under the jockey wheel and the corner steadies to prevent then from sinking when the snow thaws.
- When the vehicle has been positioned, release the handbrake to prevent freezing.
- Protect the handbrake lever and the accumulator against frost with protective covers.
- No snow walls should be allowed to cover the built-in forced ventilation.
- Protect the gas bottle compartment against freezing with a protective cover.
- Do not leave waste water in the tank but drain it into a bucket.
- Keep the built-in forced ventilation free from snow and ice.
- Make sure the air circulation is good. Good air circulation prevents moisture from collecting and makes it easier to heat the living area.
- Follow the instructions in the section "Gas supply in European countries".
- Use a two-bottle system with automatic controller for the gas system, so that the supply does not run out during the night.
- Only operate the gas system using propane gas.
- Do not use the space behind the heater as a storage compartment.
- Never operate catalytic ovens or infra-red gas radiators in the interior of the vehicle, since they consume oxygen for burning.
- Lay the 230 V power cable in such a way that the cable cannot be frozen or be damaged (e.g. during snow removal).
- Use a winter awning.
- When it is snowing heavily, clear the roof of the vehicle of snow regularly.
   A few centimetres of powdery snow serves as insulation, but wet snow quickly becomes a heavy burden.
- Before embarking on the return journey, remove all the snow from the roof to avoid impeding vehicles behind you with a "snow flag".



#### 17.10 Travel checklists

The following checklists will help that nothing important is left at home although not everything on the checklists might be necessary.



Do not leave checking of documents (e.g. vehicle papers and information) as well as checking the condition of the vehicle until just before commencing the trip. Planning and checking documents well in advance will save unnecessary trouble.

#### Kitchen area

$\checkmark$	Object	✓	Object	$\checkmark$	Object
	Wiping cloth		Cleansing agent (detergent)		Salad servers
	Mug		Dishcloths		Chopping board
	Turnspit		Set of knifes and forks for grilling		Bowls
	Can opener		Coffeepot		Brush to wash the dishes
	Egg-cup		Corkscrew		Cloth to wash the dishes
	Ice cube tray		Kitchen paper		Matches
	Lighter		Spoons		Cups
	Bottle opener		Knifes		Plates
	Air-tight storage boxes		Garbage bags		Thermos jug
	Breakfast plate		Frying pans		Pots
	Forks		Stirring spoons		Glasses

# Bathroom/sanitary items

Towels	Toilet brush	Toothbrush glass
Sanitary items	Toilet paper	

#### Living area

Dustbin	Insect lamp	Rain clothes
Road atlas	Insect repellent	First aid kit
Bath towels	Deck of cards	Travel guides/park- ing guide
Bath shoes	Broom	Rucksack
Batteries	Candles	Sleeping bags
Bed sheets	Dust pan	Pencils and paper
Bed linen	Coat-hangers	Shoes
Laundry bag	Clothes brush	Shoe polish
Books	Pillow	Vacuum cleaner
Camping guide	Мар	Flash light
Spare bulbs	Medicine	Pocket knife
Water bottle	Music cassettes	Table cloth
Binoculars	Neck-supporting pillow	Clothes pins



✓	Object	✓	Object	<b>√</b>	Object
	Fire extinguisher		Sewing kit		Clothesline
	Gas bottle		Radio		

#### Vehicle/tools

Waste water container	Fabric tape	Screwdriver
Adapter socket	Watering can for drinking water	Current-measuring instrument
CEE adapter	Cable reel	Step
Wire	V-belt	Wheel chocks
Spare wheel	Glue	First-aid kit
Spare lamps	Universal pliers	Vehicle jack
Spare fuses	Compressor	Hazard warning tri- angle
Replacement wa- ter pump	Luster terminals	Warning sign
Hammer	Loops	Warning vest(s)
Flat wrench	Tube adapter	Flashing hazard warning light
Gas filling adapter	Hose clips	
Gas tube	Snow chains (winter)	

#### Outside

Stay rope	Camping table	Lock
Bellows	Luggage racks	String
Camping chairs	Grill	Tent pegs/tighten- ing ropes

#### **Documents**

List of addresses	Registration book	Identity card
Registration confirmation(s)	Driving licence	Passport
Allergy certificate	Green insurance card	Writ of protection
Instruction manuals	Vaccination certificate	Vignette/toll card
Instruction leaflets for medicines	Credit card	Visa





Pos.	Component	Activity	Interval
1	Jockey wheel	Lubricate, check wheel rims for damage, visu- al check of the tyres, check threaded spin- dle and crank	Annually
2	Corner steadies	Lubrication	Annually
3	Joints, hinges and levers on the chassis	Lubrication	Annually
4	Underbody	Visual check, repair underbody protection as necessary	Annually
5	Chassis	Lubrication	Annually
6	Wheel attachment	Tighten the wheel nuts, check tyre bearings	Annually
7	Tyres and wheel rims	Air pressure check (see section 13.7). Visual check for damage, tread depth at least 2 mm	Annually
8	Brakes	Check and adjust if necessary	Annually
9	Outside lighting	Function check	Annually
10	Refrigerator, heater, kitchenette, storage flap locks, water system, interior electrics	Function check	Annually
11	Upholstery, curtains, blinds	Visual check	Annually
12	Windows, skylights	Function check, water ingress test	Annually
13	Sealing strips, edges, rubber	Check for damage	Annually
14	Brake lining	Lining thickness min. 4 mm	Every two years
15	Brake drums	Visual check for wear and rust, check spring tension	Every two years
16	Axle bearing	Check the slack	Every two years
17	Slotted nut on the wheel	Check position and dummy fuse	Every two years
18	Overrun brake	Function check	Every two years
19	Brake cable assembly	Visual check	Every two years
20	Chassis underbody	Check bolts are firmly secured	Every two years
21	Gas fittings	Official gas inspection	Every two years

# Inspection plan



Delivery	Pos. 1-13		
Stamp of the	Bürstner dealer		
Date	Signature		
1st year	Pos. 1-13	2nd year	Pos. 1-21
Stamp of the	Bürstner dealer	Stamp of th	ne Bürstner dealer
Date	Signature	Date	Signature
3rd year	Pos. 1-13	4th year	Pos. 1-21
Stamp of the	Bürstner dealer	Stamp of th	ne Bürstner dealer
Date	Signature	Date	Signature
5th year	Pos. 1-13	6th year	Pos. 1-21
Stamp of the	Bürstner dealer	Stamp of th	ne Bürstner dealer
Date	Signature	Date	Signature
7th year	Pos. 1-13	8th year	Pos. 1-21
Stamp of the	Bürstner dealer	Stamp of th	ne Bürstner dealer
Date	Signature	Date	Signature



12 V fuses	02	Alloy wheel rims	197
For the refrigerator	03	Antenna alignment	
For Thetford toilet 1	03	Automatic	. 39
On the power supply unit	03	Semi-automatic	. 40
12 V indicator lamp	97	Antenna, lowering for driving	41
12 V main switch	97	Appliances	109
12 V power supply	91	Manuals	. 12
Switching on	97	Warranty cards	1
Troubleshooting		ATC (caravan control system)	. 20
230 V automatic circuit breaker 1		Automatic power selection (AES)	138
230 V connection	01	Axle load	. 28
External flap			
Troubleshooting		В	
230 V fuse		Basic equipment	24
230 V indicator lamp		Battery see living area battery	
230 V power supply		Battery voltage, displaying	
A STATE OF THE PARTY OF THE PAR		Bed widening, single beds	
A		Beds	
		Before the journey	
Accessories, fitting	-	Bench and central seating group, sleeping	.,
Additional agricument	0-1	conversion	. 78
Additional equipment	23	Bike rack	
Add-on parts see special equipment	12	Bicycles, loading	. 30
Air current, adjusting	20	Load	
Care		On the front	
LED1		On the rear wall	
Maintenance		Travelling with a loaded bike rack	
		Blind, cleaning	
Operating modes	19	Blind, Heki skylight	
_		Closing	67
Switching on		Opening	67
Air conditioning unit (Telair)	.10	Blind, window	
Care	71	Closing	63
Filter, cleaning		Opening	63
Operating modes		Boiler (Truma)	124
Switching off		230 V electrical operation	125
Switching on		Combined operation	125
Troubleshooting		Emptying	126
Ventilation grill, cleaning		Gas operation	124
Air conditioning unit (Truma)	<i>,</i> ,	Operating modes	124
Maintenance	71	Troubleshooting	206
Position		Water, filling with	125
Remote control		Brakes	. 35
Switching off		Check	
Switching on		Maintenance	179
Timer		Braking system, troubleshooting	201
Troubleshooting		Breakaway brake cable	. 18
Air outlet nozzles, adjustment		Breakdown services in Europe	219
-	16		





Bulbs, changing	Upholstery	68
Ceiling lamp	Washing1	66
Cooker lamp	Waste water tank1	
Exterior lighting180	Water system1	68
Front lights	Windows	
Garage light188	Winter lay-up	
Halogen spotlight 186, 187	Carpet, cleaning	
Interior lighting	Ceiling lamp183, 1	
Rear lights181	Changing wheels	
Recessed halogen light 184, 185	Tightening torque194, 1	
Types of external bulbs	With alloy wheel rims1	
Bunk bed	Chassis number1	
Butane gas	Chassis, troubleshooting	
, , , , , , , , , , , , , , , , , , , ,	Checklist	
С	Before the journey	
	For the journey2	
Cable reel	Initial start-up after temporary lay-up 1	
Camping gas bottles, use	Road safety	
Camping in winter	Temporary lay-up	
Cap for the drinking water filler neck	Winter lay-up	
Capacity of the battery	Children's beds 70, 71,	
Correct loading	Circuit diagram	. •
_	Exterior	08
Pitching	Interior	
Caravan control system (ATC)	Circulation fan	
Troubleshooting	Cleaning	
Caravan coupling	Water pipes	69
Caravan load	Water tank1	
Care	Cleaning see care	65
Air conditioning unit (Telair)	Condensation	.56
Blind	On the double acrylic glass pane	.57
Carpet	On the screwed connections in the	
Curtains	floor	56
External care	Condensation water see condensation	57
Extractor hood	Connecting	.18
Furniture surfaces	Connecting cable see 230 V power supply 1	01
Gas cooker	Connection diagram, thirteen-pin plug1	04
High-pressure cleaner, washing with 165	Connection to the towing vehicle1	04
In the winter	Connection diagram1	04
Insect screen	Conversion door43,	44
Interior care	Roman shade, closing	44
Lamps	Roman shade, opening	44
Leather covers	Conversion door, inside	
Net curtains	Locking	44
PVC-floor covering	Opening	44
Roman shade	Conversion door, outside	
Sink	Locking	
Synthetic parts, interior	Opening	43
Temporary lay-up		
Underbody		



Cooker	External gas connection
Troubleshooting	External mirrors
Cooker lamp	External shower
Corner steadies	Connection
Cranking down	Emptying84
Cranking up	External socket
Curtains, cleaning	Extractor hood
<b>3</b>	Care
D	Filter, cleaning
Danger of suffocation	
Detaching	F
Dimensions see table of linear measures 217	Fault current protection switch 101, 104
Displays, battery voltage96	Check
Disposal	Fire
Household waste 8	Behaviour in the event of
Sewage	Extinguishing11
Waste water 8	Fire prevention
Door lock	Fire risks, avoidance11
Doors	FI-switch see fault current protection
Conversion door	switch
Lock	Fixed bed71
Maintenance work	Closing
Troubleshooting	Opening
Driving in reverse	Fixed table69
Driving with the caravan	Table-top, moving69
DuoControl switching facility	Flap lock
During the journey	Closing
	Elliptical-shaped
E	Flap for toilet cassette47
Electric kit	Opening45, 46, 47, 48
Panel LT 408	Rectangular
Power supply unit	With recessed handle46
Scope	Flat screen with holder 53
Electrical system	Positioning
230 V connection, troubleshooting 203	Storing54, 55
Explanation of terms	Floor warming unit, electrical
Lighting, troubleshooting 203	Overload protection
Safety instructions	Switching off
Troubleshooting	Switching on
Entrance step	Forced ventilation
Environmental tips	Furniture flaps48
Exterior lighting	Closing
Bulbs, changing	Opening
Types of bulbs	Furniture flaps, troubleshooting
External care	Furniture surfaces, cleaning 168
External connection see 230 V	Fuses
connection	12 V fuses
External flaps	230 V fuse100, 104
Flap lock	





For the Thefford foilet	Switching off	111, 114
On the power supply unit	Switching on	111, 114
Fuses see 12 V fuses and 230 V fuse102	Troubleshooting	205
	Heater automatic ignition, changing	
G	the battery	112, 115
Garage light	Heating	
	Heating mode	
Gas bottle compartment	Heki skylight	64, 66
Changing87	Blind	
	Closing	
Safety instructions	Insect screen	•
Gas connection, external	Opening	· · · · · · · · · · · · · · · · · · ·
	Roman shade	
Cleaning	Ventilation position	
Switching off	Help on Europe's roads	
Switching on	·	
Troubleshooting	High rate of gas consumption	
Gas isolator taps	High-pressure cleaner, washing with Hinged window	105
Symbols	Blind	62
Gas odour14, 85, 204		
Gas oven130	Closing	<b>,</b>
Switching off	Continuous ventilation	,
Switching on	Insect screen	•
Troubleshooting	Opening	
Gas supply in European countries 225	Roman shade	
Gas system85	Hot air distribution	
Defect	Hot galvanized chassis	
General instructions	Hot water source	
Safety instructions14, 85	Emptying	
Switching automatics 89	Switching off	
Troubleshooting204	Switching on	127
Gas tube, check	Troubleshooting	
General instructions	Water, filling with	127
	Hot-air heater	
Н	Battery on the automatic ignition,	
	changing	,
Halogen spotlight	Circulation fan	
Hand crank, corner steadies	Switching off	*
Handbrake	Switching on	,
Applying	Troubleshooting	205
Releasing		
Handling of tyres193	I	
Heat exchanger, heater, replacement 109	Indicator lamp, 12 V power supply	97
Heater110	Indicator lamp, 230 V power supply .	
Air outlet nozzles, adjustment110	Indicator lamp, water pump	
Battery on the automatic ignition,	Information stickers	
changing112, 115	Inner door, troubleshooting	
Circulation fan113	Inner doors	
Heat exchanger, replacement109		
Hot air distribution		
Initial start-up110		



Insect screen door	Troubleshooting	204
Closing 45	Voltage, displaying	96
Opening	Load	
Insect screen, cleaning	Bike rack	
Insect screen, Heki skylight	Load see also payload	
Closing 65, 67	Lock	
Opening	Conversion door	43
Insect screen, windows	External flap45,	46, 47
Closing 62, 63	Furniture flap	49
Opening	Low beam	
Inspection plan		
Inspection work	M	
Inspections	Maintenance	177
Installation diagram	Maintenance work	
Thirteen pin socket		
Interior care	Air conditioning unit (Dometic)	
Interior lighting	Air conditioning unit (Telair)	
Bulbs, changing	Air conditioning unit (Truma)	
Troubleshooting 204	AKS 1300	
	AKS 3004	
K	Braking system	
Keys 17	Doors	
•	Manoeuvring system	179
1	Manoeuvring system	170
L Annua Annu	Maintenance work	
Lamps	Manoeuvring	
Cleaning	Operation	
Lay-up	Remote control	
Temporary         173           Winter lay-up         174	Troubleshooting	
•	Marker light	
Leakage water inside the vehicle	Mass in ready-to-drive condition	
Leather covers, cleaning	Maximum permissible gross weight	
Conversion to bed foundation 70	Maximum permissible speed	
Table-top, moving	Maximum speed, technically permissible	221
Light metal wheel rims see alloy wheel	Microwave oven	400
rims	Switching off	
Light switch	Switching on	
Living area	Troubleshooting	
Recessed light	Minimum nose weight	
Lighting	Mover see manoeuvring system	21
Front 181		
Lamps, cleaning	N	
Rear 181	Net curtains, cleaning	168
Troubleshooting	No gas	204
Living area battery	Nose weight18,	24, 28
Changing the battery 94		
Charging 94		
Discharging		
Instructions		



0	R
Operating modes	Rear axle load
Air conditioning unit (Dometic) 119	Recessed halogen light184
Air conditioning unit (Telair) 121	Refrigerator
Boiler (Truma)124	12 V operation, switching on/off 135, 137
Refrigerator	230 V operation, switching on/off 135, 137
Switching automatics, gas system 90	Change-over between energy sources 139
Oven see gas cooker or gas oven128, 130	Door lock
Overrun brake	Fuse
	Gas operation
Р	Gas operation, switching off 135, 137
-	Gas operation, switching on
Panel LT 408	
Panel see also displays96	Operating modes 134, 136, 138, 140
Payload23, 24	Operation
Calculation26	Refrigerating temperature control
Composition	Switching off
Example calculation	Switching on
Payload see also load	Troubleshooting
People in the caravan	Ventilation grill, removal
Permissible gross weight see maximum	Refrigerator door locking mechanism
permissible gross weight23	Closing
Permitted mass24	Locking in the ventilation position143, 144
Personal equipment	Opening
Power supply	Refrigerator ventilation grill, removal133
Power supply unit CSV 300	Registration
Functions	Remote control, air conditioning unit
Position92	(Truma)
Power supply unit CSV 409	Risk of frost damage 16, 145, 150
Battery selector switch 95	Road safety
Charging the battery95	Checklist
Functions	Notes for
Fuses	Roman shade, cleaning168
Position95	Roman shade, Heki skylight
Propane gas	Closing
Pull-down bed	Opening
Access ladder73, 75	Roman shade, window of conversion door
Closing	Closing
Opening	Opening
Retaining belts, tightening72	Roman shade, windows
Pull-down bed, electrically operated73	Closing
Closing74	Opening
Emergency operation	Round seating group, conversion
Making ready for operation74	Round seating group, sleeping
Opening	conversion
Overload protection74	
Retaining belts, tightening75	
Pull-down bed, manually operated 71	
PVC-floor covering, cleaning 168	



S	Spotlight
Safety cut-out	Removing
Safety instructions	Shifting
Changing wheels	Turning
Cooker	Stabiliser
Electrical system	AKS 1300
Fire prevention11	AKS 1300, maintenance work 178
Gas bottles	AKS 3004
Gas system	AKS 3004, maintenance work 178
Road safety	Stabiliser see also caravan coupling 19, 178
Towing	Stabilising lever
Water system 16	Start-up
Safety knob, hinged window 57, 59	After temporary lay-up
Safety net, pull-down bed	After winter lay-up
Safety net, pull-down bed, electrically	Staying overnight
operated	Away from camping areas
Sanitary fittings	During travel
SAT socket 106	Supports see corner steadies
Satellite unit	Suspension table
With automatic antenna alignment 39	Conversion to bed foundation
With semi-automatic antenna	Conversion to round seating group 69
alignment	Switching automatics, gas system
Seating groups, sleeping conversion 77	Swivel table
Shower 151	Conversion to bed foundation
Shower connection point, external shower 84	Conversion to round seating group 69
Side marker light	Symbols
Single beds, bed widening	For instructions
Sink, cleaning	Gas isolator taps
Skylights 64	cleaning168
Sleeping conversion	Geating100
Bench and central seating group 77, 78	т
Round seating group 79, 80, 81, 82, 83	-
Widening single beds	Table of linear measures
Sockets	Tables
External socket	Technical data
SAT socket	Dimensions
TV socket	Power supply
Spare parts	Television
Spare wheel	Thermal cut-out
Spare wheel support	Thetford cassette
Special equipment	Emptying
Description	Removing
Marking	Retaining clip
Safety instructions	Thetford toilet
Weight details	Emptying
Speed limits	Fuse
	Preparing
	Swiveling
	Troubleshooting





Using	154, 160	Tyres	191
Water tank, emptying	163	Excessive wear	
Water tank, filling		General instructions	191
With fixed seat	157	Handling	193
Thirteen-pin plug, connection diagram .	104	Identification	193
Tightening torque, wheels	194, 197	Load-carrying capacity	194
Tips	219	Tyre pressure	199
Toilet compartment	151	Tyre selection	192
Ventilation		·	
Toilet see also Thetford toilet	151	U	
Toll regulations in European countries .		Ultraheat additional electric heater .	116
Towing		Switching off	
Safety instructions	13	Switching on	
Traffic rules in foreign countries		Underbody, maintenance	
Travel checklists		Upholstery, cleaning	
Travel cots suitable for children		Opholstery, cleaning	100
Troubleshooting			
12 V power supply		V	
230 V connection		Vehicle identification plate	
Air conditioning unit		Vehicle jack	,
Air conditioning unit (Dometic)		Vehicle lighting see exterior lighting	
Air conditioning unit (Telair)		Vehicle, washing	166
Air conditioning unit (Truma)		Ventilation	
Body		Toilet compartment	151
Boiler (Truma)			
Braking system		W	
Caravan control system (ATC)		Warning stickers	190
Chassis		Warranty cards	
Cooker		Washing with a high-pressure cleane	
Electrical system		Waste gas vent on the right hand	
Extractor hood		side of the vehicle.	110, 124
Furniture flaps		Waste gas vent, cap	*
Gas cooker		Waste water tank	
		Care	
Gas over		Cleaning	
Gas system		Emptying	
Heater		Water pipes, cleaning	
Hot water source		Water pump	
Hot-air heater		Indicator lamp	
Inner door		Switch	
Lighting		Water supply	
Manoeuvring system		General	145
Microwave oven		Troubleshooting	
Refrigerator		Water system	
Thetford toilet		Care	168
Water supply		Cleaning	
TV socket		Disinfect	
Tyre change see changing wheels		Emptying	
Tyre specifications	193	1 7 0	





Filling	149
Safety instructions	
Water tank	146
Cleaning	168
Emptying	146, 147, 148
Filling	146, 147, 148
Water, removing	146, 147, 148
Water tank 16 I	146
Water tank 22 I	146
Water tank 40 I	147
Weight details for special equipment	215
Wheel chocks	37
Wheel rim size	194
Wheel rim type	191
Wheels	191
Window, conversion door	
Roman shade, closing	44
Roman shade, opening	44
Windows	56
Blind	61, 62
Insect screen	61, 62, 63
Roman shade	63
Windows, cleaning	166
Winter care	172
Winter operation	172



